

MaxiDiag_Daewoo _V2.10 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 ○ This function is not supported. ▲ This function is the new feature in this version.
 As for special function please refer to the special function table.

YEAR	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(8) 2008	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(9) 2009	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(A) 2010	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(B) 2011	(EP) Epica/Tosca	Engine	2.0L L6 DOHC	●	●	●
(7) 2007	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(8) 2008	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(9) 2009	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(A) 2010	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(B) 2011	(EP) Epica/Tosca	Engine	2.5L L6 DOHC	●	●	●
(7) 2007	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(8) 2008	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(9) 2009	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(A) 2010	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(B) 2011	(EP) Epica/Tosca	Chassis	ABS / ETC	●	●	●
(7) 2007	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(8) 2008	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(9) 2009	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(A) 2010	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(B) 2011	(EP) Epica/Tosca	Transmission	Automatic Transmission	●	●	●
(7) 2007	(EP) Epica/Tosca	Body	ISU (Intelligent Switching Unit)	●	●	●
(8) 2008	(EP) Epica/Tosca	Body	ISU (Intelligent Switching Unit)	●	●	●
(9) 2009	(EP) Epica/Tosca	Body	ISU (Intelligent Switching Unit)	●	●	●
(A) 2010	(EP) Epica/Tosca	Body	ISU (Intelligent Switching Unit)	●	●	●
(B) 2011	(EP) Epica/Tosca	Body	ISU (Intelligent Switching Unit)	●	●	●
(7) 2007	(EP) Epica/Tosca	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(8) 2008	(EP) Epica/Tosca	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(9) 2009	(EP) Epica/Tosca	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(A) 2010	(EP) Epica/Tosca	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(B) 2011	(EP) Epica/Tosca	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(3) 2003	(J) Lacetti/Optra/Excelle	Engine	1.8L L4 DOHC	●	●	●
(4) 2004	(J) Lacetti/Optra/Excelle	Engine	1.8L L4 DOHC	●	●	●
(3) 2003	(J) Lacetti/Optra/Excelle	Chassis	ABS	●	●	●

YEAR	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(4) 2004	(J) Lacetti/Optra/Excelle	Chassis	ABS	●	●	●
(3) 2003	(J) Lacetti/Optra/Excelle	Body	Immobiliser	●	●	●
(4) 2004	(J) Lacetti/Optra/Excelle	Body	Immobiliser	●	●	●
(3) 2003	(J) Lacetti/Optra/Excelle	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(4) 2004	(J) Lacetti/Optra/Excelle	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(3) 2003	(J) Lacetti/Optra/Excelle	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(4) 2004	(J) Lacetti/Optra/Excelle	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(1) 2001	(J) Nubira	Engine	1.6L L4 DOHC		●	●
(2) 2002	(J) Nubira	Engine	1.6L L4 DOHC		●	●
(3) 2003	(J) Nubira	Engine	1.6L L4 DOHC		●	●
(4) 2004	(J) Nubira	Engine	1.6L L4 DOHC		●	●
(X) 1999	(J) Nubira	Engine	1.6L L4 DOHC		●	●
(Y) 2000	(J) Nubira	Engine	1.6L L4 DOHC		●	●
(1) 2001	(J) Nubira	Engine	2.0L L4 DOHC		●	●
(2) 2002	(J) Nubira	Engine	2.0L L4 DOHC		●	●
(3) 2003	(J) Nubira	Engine	2.0L L4 DOHC		●	●
(4) 2004	(J) Nubira	Engine	2.0L L4 DOHC		●	●
(X) 1999	(J) Nubira	Engine	2.0L L4 DOHC		●	●
(Y) 2000	(J) Nubira	Engine	2.0L L4 DOHC		●	●
(1) 2001	(J) Nubira	Transmission	4T40-E Automatic Transaxle		●	●
(2) 2002	(J) Nubira	Transmission	4T40-E Automatic Transaxle		●	●
(3) 2003	(J) Nubira	Transmission	4T40-E Automatic Transaxle		●	●
(4) 2004	(J) Nubira	Transmission	4T40-E Automatic Transaxle		●	●
(X) 1999	(J) Nubira	Transmission	4T40-E Automatic Transaxle		●	●
(Y) 2000	(J) Nubira	Transmission	4T40-E Automatic Transaxle		●	●
(1) 2001	(J) Nubira	Chassis	ABS 5		●	●
(2) 2002	(J) Nubira	Chassis	ABS 5		●	●
(3) 2003	(J) Nubira	Chassis	ABS 5		●	●
(4) 2004	(J) Nubira	Chassis	ABS 5		●	●
(X) 1999	(J) Nubira	Chassis	ABS 5		●	●
(Y) 2000	(J) Nubira	Chassis	ABS 5		●	●
(1) 2001	(J) Nubira	Body	SDM (Airbag)	●	●	●
(2) 2002	(J) Nubira	Body	SDM (Airbag)	●	●	●
(3) 2003	(J) Nubira	Body	SDM (Airbag)	●	●	●
(4) 2004	(J) Nubira	Body	SDM (Airbag)	●	●	●
(X) 1999	(J) Nubira	Body	SDM (Airbag)	●	●	●
(Y) 2000	(J) Nubira	Body	SDM (Airbag)	●	●	●
(6) 2006	(J) Viva	Engine	1.8L L4 DOHC	●	●	●
(7) 2007	(J) Viva	Engine	1.8L L4 DOHC	●	●	●
(8) 2008	(J) Viva	Engine	1.8L L4 DOHC	●	●	●

YEAR	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(9) 2009	(J) Viva	Engine	1.8L L4 DOHC	●	●	●
(6) 2006	(J) Viva	Chassis	ABS	●	●	●
(7) 2007	(J) Viva	Chassis	ABS	●	●	●
(8) 2008	(J) Viva	Chassis	ABS	●	●	●
(9) 2009	(J) Viva	Chassis	ABS	●	●	●
(7) 2007	(J) Viva	Chassis	ABS (Bosch)	●	●	●
(8) 2008	(J) Viva	Chassis	ABS (Bosch)	●	●	●
(9) 2009	(J) Viva	Chassis	ABS (Bosch)	●	●	●
(6) 2006	(J) Viva	Body	Immobiliser	●	●	●
(7) 2007	(J) Viva	Body	Immobiliser	●	●	●
(8) 2008	(J) Viva	Body	Immobiliser	●	●	●
(9) 2009	(J) Viva	Body	Immobiliser	●	●	●
(6) 2006	(J) Viva	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(7) 2007	(J) Viva	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(8) 2008	(J) Viva	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(9) 2009	(J) Viva	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(6) 2006	(J) Viva	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(7) 2007	(J) Viva	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(8) 2008	(J) Viva	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(9) 2009	(J) Viva	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(1) 2001	(M) Matiz/Spark	Engine	0.8L L3 SOHC (12PIN ALDL)	●	●	●
(2) 2002	(M) Matiz/Spark	Engine	0.8L L3 SOHC (12PIN ALDL)	●	●	●
(3) 2003	(M) Matiz/Spark	Engine	0.8L L3 SOHC (12PIN ALDL)	●	●	●
(4) 2004	(M) Matiz/Spark	Engine	0.8L L3 SOHC (12PIN ALDL)	●	●	●
(X) 1999	(M) Matiz/Spark	Engine	0.8L L3 SOHC (12PIN ALDL)	●	●	●
(Y) 2000	(M) Matiz/Spark	Engine	0.8L L3 SOHC (12PIN ALDL)	●	●	●
(1) 2001	(M) Matiz/Spark	Body	Immobiliser	●	●	●
(2) 2002	(M) Matiz/Spark	Body	Immobiliser	●	●	●
(3) 2003	(M) Matiz/Spark	Body	Immobiliser	●	●	●
(4) 2004	(M) Matiz/Spark	Body	Immobiliser	●	●	●
(X) 1999	(M) Matiz/Spark	Body	Immobiliser	●	●	●
(Y) 2000	(M) Matiz/Spark	Body	Immobiliser	●	●	●
(1) 2001	(M) Matiz/Spark	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(2) 2002	(M) Matiz/Spark	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(3) 2003	(M) Matiz/Spark	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(4) 2004	(M) Matiz/Spark	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(X) 1999	(M) Matiz/Spark	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(Y) 2000	(M) Matiz/Spark	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(6) 2006	(T) Barina	Engine	1.6L L4 DOHC	●	●	●
(7) 2007	(T) Barina	Engine	1.6L L4 DOHC	●	●	●

YEAR	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(8) 2008	(T) Barina	Engine	1.6L L4 DOHC	●	●	●
(9) 2009	(T) Barina	Engine	1.6L L4 DOHC	●	●	●
(A) 2010	(T) Barina	Engine	1.6L L4 DOHC	●	●	●
(B) 2011	(T) Barina	Engine	1.6L L4 DOHC	●	●	●
(6) 2006	(T) Barina	Chassis	ABS	●	●	●
(7) 2007	(T) Barina	Chassis	ABS	●	●	●
(8) 2008	(T) Barina	Chassis	ABS	●	●	●
(9) 2009	(T) Barina	Chassis	ABS	●	●	●
(A) 2010	(T) Barina	Chassis	ABS	●	●	●
(B) 2011	(T) Barina	Chassis	ABS	●	●	●
(6) 2006	(T) Barina	Transmission	AISIN Automatic Transaxle	●	●	●
(7) 2007	(T) Barina	Transmission	AISIN Automatic Transaxle	●	●	●
(8) 2008	(T) Barina	Transmission	AISIN Automatic Transaxle	●	●	●
(9) 2009	(T) Barina	Transmission	AISIN Automatic Transaxle	●	●	●
(A) 2010	(T) Barina	Transmission	AISIN Automatic Transaxle	●	●	●
(B) 2011	(T) Barina	Transmission	AISIN Automatic Transaxle	●	●	●
(6) 2006	(T) Barina	Body	Immobiliser	●	●	●
(7) 2007	(T) Barina	Body	Immobiliser	●	●	●
(8) 2008	(T) Barina	Body	Immobiliser	●	●	●
(9) 2009	(T) Barina	Body	Immobiliser	●	●	●
(A) 2010	(T) Barina	Body	Immobiliser	●	●	●
(B) 2011	(T) Barina	Body	Immobiliser	●	●	●
(6) 2006	(T) Barina	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(7) 2007	(T) Barina	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(8) 2008	(T) Barina	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(9) 2009	(T) Barina	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(A) 2010	(T) Barina	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(B) 2011	(T) Barina	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(3) 2003	(T) Kalos/Aveo	Engine	1.5L L4 SOHC	●	●	●
(4) 2004	(T) Kalos/Aveo	Engine	1.5L L4 SOHC	●	●	●
(3) 2003	(T) Kalos/Aveo	Transmission	AISIN Automatic Transaxle	●	●	●
(4) 2004	(T) Kalos/Aveo	Transmission	AISIN Automatic Transaxle	●	●	●
(3) 2003	(T) Kalos/Aveo	Body	Immobiliser	●	●	●
(4) 2004	(T) Kalos/Aveo	Body	Immobiliser	●	●	●
(3) 2003	(T) Kalos/Aveo	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(4) 2004	(T) Kalos/Aveo	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(1) 2001	(T) Lanos	Engine	1.5L L4 SOHC		●	●
(2) 2002	(T) Lanos	Engine	1.5L L4 SOHC		●	●
(3) 2003	(T) Lanos	Engine	1.5L L4 SOHC		●	●
(V) 1997	(T) Lanos	Engine	1.5L L4 SOHC		●	●

YEAR	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(W) 1998	(T) Lanos	Engine	1.5L L4 SOHC		●	●
(X) 1999	(T) Lanos	Engine	1.5L L4 SOHC		●	●
(Y) 2000	(T) Lanos	Engine	1.5L L4 SOHC		●	●
(1) 2001	(T) Lanos	Engine	1.6L L4 DOHC		●	●
(2) 2002	(T) Lanos	Engine	1.6L L4 DOHC		●	●
(3) 2003	(T) Lanos	Engine	1.6L L4 DOHC		●	●
(V) 1997	(T) Lanos	Engine	1.6L L4 DOHC		●	●
(W) 1998	(T) Lanos	Engine	1.6L L4 DOHC		●	●
(X) 1999	(T) Lanos	Engine	1.6L L4 DOHC		●	●
(Y) 2000	(T) Lanos	Engine	1.6L L4 DOHC		●	●
(1) 2001	(T) Lanos	Transmission	4T40-E Automatic Transaxle		●	●
(2) 2002	(T) Lanos	Transmission	4T40-E Automatic Transaxle		●	●
(3) 2003	(T) Lanos	Transmission	4T40-E Automatic Transaxle		●	●
(V) 1997	(T) Lanos	Transmission	4T40-E Automatic Transaxle		●	●
(W) 1998	(T) Lanos	Transmission	4T40-E Automatic Transaxle		●	●
(X) 1999	(T) Lanos	Transmission	4T40-E Automatic Transaxle		●	●
(Y) 2000	(T) Lanos	Transmission	4T40-E Automatic Transaxle		●	●
(1) 2001	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(2) 2002	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(3) 2003	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(V) 1997	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(W) 1998	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(X) 1999	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(Y) 2000	(T) Lanos	Body	SDM (Sensing and Diagnostic Module)	●	●	●
(1) 2001	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC		●	●
(2) 2002	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC		●	●
(X) 1999	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC		●	●
(Y) 2000	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC		●	●
(3) 2003	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC (ITMS6F)		●	●
(1) 2001	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC (MR140)	●	●	●
(2) 2002	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC (MR140)	●	●	●
(X) 1999	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC (MR140)	●	●	●
(Y) 2000	(U) Tacuma/Rezzo	Engine	2.0L L4 DOHC (MR140)	●	●	●
(1) 2001	(U) Tacuma/Rezzo	Chassis	ABS/TC/ESP	●	●	●
(2) 2002	(U) Tacuma/Rezzo	Chassis	ABS/TC/ESP	●	●	●
(3) 2003	(U) Tacuma/Rezzo	Chassis	ABS/TC/ESP	●	●	●
(X) 1999	(U) Tacuma/Rezzo	Chassis	ABS/TC/ESP	●	●	●
(Y) 2000	(U) Tacuma/Rezzo	Chassis	ABS/TC/ESP	●	●	●
(1) 2001	(U) Tacuma/Rezzo	Body	Airbag	●	●	●
(2) 2002	(U) Tacuma/Rezzo	Body	Airbag	●	●	●

YEAR	Vehicle Type	System Type	System Name	Ecu Info.	Read Codes	Erase Codes
(3) 2003	(U) Tacuma/Rezzo	Body	Airbag	●	●	●
(X) 1999	(U) Tacuma/Rezzo	Body	Airbag	●	●	●
(Y) 2000	(U) Tacuma/Rezzo	Body	Airbag	●	●	●
(1) 2001	(U) Tacuma/Rezzo	Body	Immobiliser	●	●	●
(2) 2002	(U) Tacuma/Rezzo	Body	Immobiliser	●	●	●
(3) 2003	(U) Tacuma/Rezzo	Body	Immobiliser	●	●	●
(X) 1999	(U) Tacuma/Rezzo	Body	Immobiliser	●	●	●
(Y) 2000	(U) Tacuma/Rezzo	Body	Immobiliser	●	●	●
(1) 2001	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(2) 2002	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(3) 2003	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(X) 1999	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(Y) 2000	(U) Tacuma/Rezzo	Transmission	ZF 4HP16 Automatic Transaxle	●	●	●
(1) 2001	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(2) 2002	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(3) 2003	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(4) 2004	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(X) 1999	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(Y) 2000	(V) Leganza/Evanda	Engine	2.2L L4 DOHC	●	●	●
(1) 2001	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(2) 2002	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(3) 2003	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(4) 2004	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(X) 1999	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(Y) 2000	(V) Leganza/Evanda	Chassis	ABS 5		●	●
(1) 2001	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(2) 2002	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(3) 2003	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(4) 2004	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(X) 1999	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(Y) 2000	(V) Leganza/Evanda	Transmission	AISIN 50-40LE Automatic Transaxle		●	●
(1) 2001	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(2) 2002	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(3) 2003	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(4) 2004	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(X) 1999	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●
(Y) 2000	(V) Leganza/Evanda	Body	SDM (Airbag)	●	●	●