

Battery_BMW_V6. 10 Function List (Note:For reference only)

备注:

• This function is supported.

▲ This function is the new feature in this version.

\circ	This	function	is	not	supported.

Part	Components	Status
Body	Evaluate closed-circuit current monitoring	A
Body	Evaluate state of battery charge	A
Body	Power down command	A
Body	Register battery replacement	A