

DPF_FordEU_V6.02 Function List (Note:For reference only)

NOTES:

- This function is supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	PCM	●	●	●	○
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	PCM	●	●	●	○
AEROSTAR	3.0L	Other	1996 -	PCM	●	●	●	○
AEROSTAR	4.0L	Other	1996 -	PCM	●	●	●	○
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM	●	●	●	○
B-Max	1.25L	DURATEC 16V	2008	PCM	●	●	●	○
B-Max	1.4L	DURATEC 16V	2008 -	PCM	●	●	●	○
B-Max	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	0x0099 0x009A 0x00B4 0x00BC 0x00C1
B-Max	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	PCM	●	●	●	○
B-Max	1.6L	DURATEC VCT	2008 -	PCM	●	●	●	○
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x00AA 0x00B0 0x00B1
B-Max	1.6L	TDCi ECO II	2012	PCM	●	●	●	○
BT-50 / Ranger	2.2L	F2	2007	PCM	●	●	●	○
BT-50 / Ranger	2.5L	L5	2012	PCM	●	●	●	○
BT-50 / Ranger	2.5L	WL	2007	PCM	●	●	●	○
BT-50 / Ranger	2.5L	WL-CD	2007	PCM	●	●	●	○
BT-50 / Ranger	2.6L	G6	2007	PCM	●	●	●	○
BT-50 / Ranger	3.0L	WE-CD	2007	PCM	●	●	●	○
BT-50 / Ranger	4.0L	V6 SOHC	2007	PCM	●	●	●	○
Cougar	2.0L	Zetec	1998 -	PCM	●	●	●	○
Cougar	2.5L	Duratec-VE	1998 -	PCM	●	●	●	○
Cougar	3.8L	Other	1996 -	PCM	●	●	●	○
Cougar	4.6L	2V	1994 -	PCM	●	●	●	○
Crown Victoria	4.6L	2V	1995 -	PCM	●	●	●	○
Crown Victoria	4.6L	2V_NGV	1996 -	PCM	●	●	●	○
Crown Victoria	4.6L	Other	1995	PCM	●	●	●	○
E-Series	4.2L	Other	1997 -	PCM	●	●	●	○
E-Series	4.6L	2V	2003 -	PCM	●	●	●	○
E-Series	4.6L	Other	1997 -	PCM	●	●	●	○
E-Series	4.9L	GFP	1996	PCM	●	●	●	○
E-Series	4.9L	Other	1996	PCM	●	●	●	○
E-Series	5.0L	Other	1996	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
E-Series	5.4L	2V	2004 -	PCM	●	●	●	○
E-Series	5.4L	BIF	1999	PCM	●	●	●	○
E-Series	5.4L	NGV	1997 -	PCM	●	●	●	○
E-Series	5.4L	Other	1997 -	PCM	●	●	●	○
E-Series	5.8L	Other	1996	PCM	●	●	●	○
E-Series	6.0L	Direct Injection - Turbo	2004 -	PCM	●	●	●	○
E-Series	6.8L	2V	2004 -	PCM	●	●	●	○
E-Series	6.8L	Other	1997 -	PCM	●	●	●	○
E-Series	7.3L	Direct Injection - Turbo	1995 -	PCM	●	●	●	○
E-Series	7.5L	Other	1996	PCM	●	●	●	○
E-Series	Other	Other	2012	PCM	●	●	●	○
E-Series Shuttle Bus	6.8L	H2ICE	2006	PCM	●	●	●	○
EcoSport	1.0L	Zetec Rocam	2003	PCM	●	●	●	○
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	PCM	●	●	●	○
EcoSport	1.5L	TiVCT	2012	PCM	●	●	●	○
EcoSport	1.6L	FFV	2003 -	PCM	●	●	●	○
EcoSport	1.6L	Sigma	2012	PCM	●	●	●	○
EcoSport	1.6L	Zetec Rocam	2003 -	PCM	●	●	●	○
EcoSport	2.0L	DURATEC-HE / I4	2003 -	PCM	●	●	●	○
EcoSport	2.0L	FFV	2009 -	PCM	●	●	●	○
EcoSport	2.0L	Zetec Rocam	2009	PCM	●	●	●	○
Escort	1.3L	Endura-E	1995 -	PCM	●	●	●	○
Escort	1.4L	1.4 PT-E SFI	1994 -	PCM	●	●	●	○
Escort	1.6L	PT-E	Other	PCM	●	●	●	○
Escort	1.6L	Zetec	1993 -	PCM	●	●	●	○
Escort	1.6L	Zetec Rocam	2000	PCM	●	●	●	○
Escort	1.8L	Endura-DE	1996 - Other	PCM	●	●	●	○
Escort	1.8L	Other	1996	PCM	●	●	●	○
Escort	1.8L	Zetec	1992 -	PCM	●	●	●	○
Escort	1.9L	Other	1996	PCM	●	●	●	○
Escort	2.0L	DOHC Cosworth	1994 -	PCM	●	●	●	○
Escort	2.0L	SPI	1997 -	PCM	●	●	●	○
Escort	2.0L	Zetec	1998 -	PCM	●	●	●	○
Excursion	5.4L	2V	2004 -	PCM	●	●	●	○
Excursion	5.4L	Other	2000 -	PCM	●	●	●	○
Excursion	6.0L	Direct Injection - Turbo	2003 -	PCM	●	●	●	○
Excursion	6.8L	2V	2004 -	PCM	●	●	●	○
Excursion	6.8L	Other	2000 -	PCM	●	●	●	○
Excursion	7.3L	Direct Injection - Turbo	2000 -	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
Expedition	4. 6L	2V	2003 -	PCM	●	●	●	○
Expedition	4. 6L	Other	1997 -	PCM	●	●	●	○
Expedition	5. 4L	2V	2003 -	PCM	●	●	●	○
Expedition	5. 4L	3V	2005 -	PCM	●	●	●	○
Expedition	5. 4L	Other	1997 -	PCM	●	●	●	○
Expedition	Other	Other	2013	PCM	●	●	●	○
Explorer	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2011 -	PCM	●	●	●	0x0095
Explorer	3. 5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●	○
Explorer	3. 5L	TiVCT	2011 -	PCM	●	●	●	0x0095
Explorer	3. 7L	TiVCT	2013	PCM	●	●	●	○
Explorer	4. 0L	2V	2006 -	PCM	●	●	●	○
Explorer	4. 0L	Other	1996 -	PCM	●	●	●	○
Explorer	4. 0L	V6 OHV	1996 -	PCM	●	●	●	○
Explorer	4. 0L	V6 SOHC	1997 -	PCM	●	●	●	○
Explorer	4. 6L	2V	2002 -	PCM	●	●	●	○
Explorer	4. 6L	3V	2006 -	PCM	●	●	●	○
Explorer	5. 0L	Other	1996 -	PCM	●	●	●	○
Explorer Sport	4. 0L	V6 SOHC	2000 -	PCM	●	●	●	○
Explorer SportTrac	4. 0L	2V	2007 -	PCM	●	●	●	○
Explorer SportTrac	4. 0L	V6 SOHC	2000 -	PCM	●	●	●	○
Explorer SportTrac	4. 6L	3V	2007 -	PCM	●	●	●	○
F-250 Light Duty	4. 2L	Other	1999	PCM	●	●	●	○
F-250 Light Duty	4. 6L	Other	1997 -	PCM	●	●	●	○
F-250 Light Duty	5. 4L	BIF	1998 -	PCM	●	●	●	○
F-250 Light Duty	5. 4L	NGV	1997 -	PCM	●	●	●	○
F-250 Light Duty	5. 4L	Other	1997 -	PCM	●	●	●	○
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003	PCM	●	●	●	○
F-Series Super Duty	4. 2L	Other	2001	PCM	●	●	●	○
F-Series Super Duty	5. 4L	2V	2004 -	PCM	●	●	●	○
F-Series Super Duty	5. 4L	3V	2005 -	PCM	●	●	●	○
F-Series Super Duty	5. 4L	BIF	1999	PCM	●	●	●	○
F-Series Super Duty	5. 4L	Other	1999 -	PCM	●	●	●	○
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 -	PCM	●	●	●	○
F-Series Super Duty	6. 2L	2V	2011 -	PCM	●	●	●	0x0095
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	PCM	●	●	●	0x0047 0x0048 0x0058 0x00A2 0x00A3
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2013	PCM	●	●	●	0x0058 0x0091 0x0093 0x0095 0x009B 0x009C 0x009D 0x009E 0x009F 0x00A0
F-Series Super Duty	6. 8L	2V	2004 -	PCM	●	●	●	○
F-Series Super Duty	6. 8L	3V	2005 -	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
F-Series Super Duty	6.8L	Other	1999 -	PCM	●	●	●	○
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 -	PCM	●	●	●	○
FORD GT	5.4L	4V	2005 -	PCM	●	●	●	○
Fiesta	1.0L	GTDI FGEC	2013	PCM	●	●	●	○
Fiesta	1.25L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fiesta	1.3L	BZ	2008	PCM	●	●	●	○
Fiesta	1.3L	DURATEC 8V	2002 -	PCM	●	●	●	○
Fiesta	1.4L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 -	PCM	●	●	●	○
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	0x0092 0x0098 0x0099 0x009A
Fiesta	1.5L	BZ	2008	PCM	●	●	●	○
Fiesta	1.5L	DURATEC 16V	2013	PCM	●	●	●	○
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	○
Fiesta	1.5L	TiVCT	2008 -	PCM	●	●	●	○
Fiesta	1.6L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fiesta	1.6L	DURATEC VCT	2008 -	PCM	●	●	●	0x00BC
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	●	●	●	0x0092 0x0096 0x0097 0x0099 0x009A 0x00AD 0x00AE 0x0090 0x0098 0x00AA 0x00B0 0x00B1
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x009A 0x00AF 0x00B0 0x00B1 0x00B2 0x00B8 0x00B9 0x00BD
Fiesta	1.6L	Sigma	2011 -	PCM	●	●	●	0x0096 0x0097
Fiesta	1.6L	TDCi ECO II	2008	PCM	●	●	●	○
Fiesta	1.6L	TiVCT	2008 -	PCM	●	●	●	○
Fiesta / Ikon	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	○
Fiesta / Ikon	1.4L	DURATEC 16V	2006	PCM	●	●	●	○
Fiesta / Ikon	1.6L	DURATEC 16V	2006	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1996 -	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.0L	Zetec Rocam	1999	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.25L	Zetec-SE	1996 -	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1996 -	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996 -	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Other	2001	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000	PCM	●	●	●	○
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996 - Other	PCM	○	○	●	○
Fiesta 3-Door	1.25L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fiesta 3-Door	1.3L	DURATEC 8V	2002 -	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
Fiesta 3-Door	1.4L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 -	PCM	●	●	●	○
Fiesta 3-Door	1.6L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●	0x0092 0x0096 0x0097 0x0099 0x009A 0x00AD 0x00AE
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 -	PCM	●	●	●	○
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	0x00C3 0x0114
Focus	1.4L	DURATEC 16V	2003 -	PCM	●	●	●	○
Focus	1.4L	Zetec-SE	1999 -	PCM	●	●	●	○
Focus	1.6L	BZ	2005	PCM	●	●	●	○
Focus	1.6L	DURATEC 16V	2003 -	PCM	●	●	●	○
Focus	1.6L	DURATEC VCT	2003 -	PCM	●	●	●	○
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 -	FACM	●	●	●	0x006B 0x0094 0x00A1
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PCM	●	●	●	0x0090 0x0092 0x0096 0x0097 0x0098 0x0099 0x009A
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	○
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	○
Focus	1.6L	FFV	2007 -	PCM	●	●	●	0x0096 0x0097 0x009A 0x00AB
Focus	1.6L	OHC	2009	PCM	●	●	●	○
Focus	1.6L	Sigma	2010	PCM	●	●	●	○
Focus	1.6L	TDCi ECO III	2011	PCM	●	●	●	○
Focus	1.6L	Zetec	1999 -	PCM	●	●	●	○
Focus	1.6L	Zetec Rocam	2002	PCM	●	●	●	○
Focus	1.6L	Zetec-SE	1999 -	PCM	●	●	●	○
Focus	1.8L	DURATEC-HE / I4	2003 -	PCM	●	●	●	○
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001 -	PCM	●	●	●	0x00B4
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	●	●	●	0x006B
Focus	1.8L	Endura DI	1999 -	PCM	●	●	●	○
Focus	1.8L	Zetec	1999 -	PCM	●	●	●	○
Focus	2.0L	DURATEC 16V	2005	PCM	●	●	●	○
Focus	2.0L	DURATEC-HE / I4	2003 -	PCM	●	●	●	○
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 -	FACM	●	●	●	0x006B 0x0094 0x00A1
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 -	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 -	PCM	●	●	●	○
Focus	2.0L	FFV	2010	PCM	●	●	●	0x0096 0x0097 0x009A 0x00AB
Focus	2.0L	Gasoline Direct injection	2011	PCM	●	●	●	○
Focus	2.0L	Gasoline_Direct_injection	2011	PCM	●	●	●	○
Focus	2.0L	SPI	2000 -	PCM	●	●	●	○
Focus	2.0L	ZETEC ST	2002 -	PCM	●	●	●	○
Focus	2.0L	Zetec	1999 -	PCM	●	●	●	○
Focus	2.3L	DURATEC-HE / I4	2003 -	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
Focus	2. 5L	Duratec RS	2008	PCM	●	●	●	○
Focus	2. 5L	I5	2003 -	PCM	●	●	●	○
Focus	23kWh	Battery_Electric_Vehicle	2012	PCM	●	●	●	○
Focus C-MAX	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	○
Focus C-MAX	1. 4L	DURATEC 16V	2002 -	PCM	●	●	●	○
Focus C-MAX	1. 6L	DURATEC 16V	2002 -	PCM	●	●	●	○
Focus C-MAX	1. 6L	DURATEC VCT	2002 -	PCM	●	●	●	○
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 -	FACM	●	●	●	0x006B 0x0094 0x00A1
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	●	●	●	0x0090 0x0092 0x0096 0x0097 0x0098 0x0099 0x009A
Focus C-MAX	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	0x009A 0x00BC 0x00C3 0x0114
Focus C-MAX	1. 8L	DURATEC-HE / I4	2002 -	PCM	●	●	●	○
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002 -	PCM	●	●	●	0x00B4
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	●	●	●	0x006B
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002 -	PCM	●	●	●	○
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002 -	FACM	●	●	●	0x006B 0x0094 0x00A1
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x00AB
Fusion	1. 25L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fusion	1. 4L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 -	PCM	●	●	●	○
Fusion	1. 5L	EcoBoost - Gas Turbocharged Direct Injection	2014	PCM	●	●	●	○
Fusion	1. 6L	DURATEC 16V	2002 -	PCM	●	●	●	○
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●	0x0092 0x0096 0x0097 0x0099 0x009A 0x00AD 0x00AE
Fusion	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●	○
Fusion	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 -	PCM	●	●	●	○
Fusion	2. 0L	HEV / ATKINSON 4V	2013	PCM	●	●	●	○
Fusion	2. 0L	PHEV	2013	PCM	●	●	●	○
Fusion	2. 3L	DURATEC-HE / I4	2006 -	PCM	●	●	●	○
Fusion	2. 5L	DURATEC-HE / I4	2010 -	PCM	●	●	●	○
Fusion	2. 5L	HEV / ATKINSON 4V	2010 -	PCM	●	●	●	○
Fusion	2. 5L	IVCT	2013 -	PCM	●	●	●	○
Fusion	3. 0L	4V	2006 -	PCM	●	●	●	○
Fusion	3. 5L	4V	2010 -	PCM	●	●	●	○
GALAXY\S-Max	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	●	●	●	○
GALAXY\S-Max	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	●	●	●	0x00C3 0x0114
GALAXY\S-Max	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x009A 0x00AB 0x00AC 0x00B4 0x00C1
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006 -	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x009A 0x00AB 0x00AC 0x00B4 0x00C1
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	●	●	●	○
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 -	PCM	●	●	●	○
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	●	●	●	○
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006 -	PCM	●	●	●	○
GALAXY\S-Max	2.5L	I5	2006	PCM	●	●	●	○
Galaxy	1.9L	EDC 1.9	2001 - Other	PCM	●	●	●	○
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 -	PCM	●	●	●	○
Galaxy	2.3L	DOHC SFI (16V)	1997 -	PCM	●	●	●	○
Galaxy	2.8L	2.8 CD-V6	2001 - Other	PCM	●	●	●	○
KA	1.0L	HCS	1997 -	PCM	●	●	●	○
KA	1.0L	Zetec Rocam	1999	PCM	●	●	●	○
KA	1.2L	DURATEC 8V	2009	PCM	●	●	●	○
KA	1.3L	DURATEC 8V	2000	PCM	●	●	●	○
KA	1.3L	Duratorq-Turbo Diesel Common Rail Injection	2009	PCM	●	●	●	○
KA	1.3L	Endura-E	1997 -	PCM	●	●	●	○
KA	1.6L	DURATEC 8V	2000	PCM	●	●	●	○
KA	1.6L	Zetec Rocam	2001	PCM	●	●	●	○
KA	Other	Other	2009	PCM	●	●	●	○
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●	○
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x00AB 0x00AC 0x00B4 0x00C1
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●	○
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●	○
Kuga	2.5L	I5	2008	PCM	●	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 -	PCM	●	●	●	○
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●	○
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●	0x00C3 0x0114
MONDEO	1.6L	Zetec	1997 -	PCM	●	●	●	○
MONDEO	1.8L	DURATEC-HE / I4	2001	PCM	●	●	●	○
MONDEO	1.8L	DURATEC-SCi	2001	PCM	●	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x009A 0x00AB 0x00AC 0x00B4 0x00C1
MONDEO	1.8L	Endura-DE	1997	PCM	○	○	●	○
MONDEO	1.8L	Zetec	1997 -	PCM	●	●	●	○
MONDEO	2.0L	DURATEC-HE / I4	2001 -	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
MONDEO	2. 0L	DURATORQ_DI	2001	PCM	●	●	●	○
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	PCM	●	●	●	0x0090 0x0092 0x0098 0x0099 0x009A 0x00AB 0x00AC 0x00B4 0x00C1
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2007 -	PCM	●	●	●	○
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2007 -	PCM	●	●	●	○
MONDEO	2. 0L	Ecoboost GTDI Chinese market only	2007 -	PCM	●	●	●	○
MONDEO	2. 0L	Zetec	1997 -	PCM	●	●	●	○
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 -	PCM	●	●	●	0x0092
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●	○
MONDEO	2. 3L	DURATEC-HE / I4	2007 -	PCM	●	●	●	○
MONDEO	2. 5L	Duratec-VE	1997 -	PCM	●	●	●	○
MONDEO	2. 5L	I5	2007	PCM	●	●	●	○
MONDEO	3. 0L	Duratec SE	2001	PCM	●	●	●	○
MONDEO	3. 0L	Duratec-ST	2001	PCM	●	●	●	○
Puma	1. 4L	Zetec-SE	1998 -	PCM	●	●	●	○
Puma	1. 6L	Zetec-SE	2001	PCM	●	●	●	○
Puma	1. 7L	Zetec-SE	1997 -	PCM	●	●	●	○
Ranger	2. 3L	DURATEC-HE / I4	2006 -	PCM	●	●	●	○
Ranger	3. 0L	I4 DSL Electronic	2005	PCM	●	●	●	○
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●	0x0090 0x0092 0x0098 0x00B0 0x00B3 0x00B9 0x00C1 0x00E7
Ranger / Mazda B-Series / Courier	2. 3L	DURATEC-HE / I4	2004 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	2. 3L	OHC	1995 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	2. 3L	Other	1996 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	2. 5L	DURATEC-HE / I4	2011	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	2. 5L	Other	1998 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	2. 8L	Other	2001	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	3. 0L	FFV	1999 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	3. 0L	Other	1995 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	4. 0L	Other	1995 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	4. 0L	V6 SOHC	2003 -	PCM	●	●	●	○
Ranger / Mazda B-Series / Courier	Other	Other	2004	PCM	●	●	●	○
S. A. Fiesta	1. 0L	FFV	2006 -	PCM	●	●	●	○
S. A. Fiesta	1. 0L	Zetec Rocam	2002	PCM	●	●	●	○
S. A. Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 -	PCM	●	●	●	○
S. A. Fiesta	1. 6L	FFV	2002 -	PCM	●	●	●	○
S. A. Fiesta	1. 6L	Zetec Rocam	2002 -	PCM	●	●	●	○
Street Ka	1. 6L	DURATEC 8V	2003	PCM	●	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Specil Function
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	PCM	●	●	●	○
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection	2014	PCM	●	●	●	○
Transit Connect	1.6L	TDCi ECO III	2014	PCM	●	●	●	○
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 -	PCM	●	●	●	○
Transit Connect	2.0L	DURATEC-HE / I4	2010 -	PCM	●	●	●	○
Transit Connect	2.0L	DURATORQ_DI	2001	PCM	●	●	●	○
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PCM	●	●	●	0x0092
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V	2006	PCM	●	●	●	○
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PCM	●	●	●	○
Transit Connect	2.3L	DOHC SFI (16V)	2001	PCM	●	●	●	○
Transit Connect	2.3L	DURATEC-HE / I4	2006	PCM	●	●	●	○
Transit Connect	2.4L	DURATORQ_DI	2000	PCM	●	●	●	○
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 -	PCM	●	●	●	0x0092
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	PCM	●	●	●	○
Transit Connect	2.5L	IVCT	2014	PCM	●	●	●	○
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●	0x0090 0x0092 0x0098 0x00A6 0x00A7 0x00A8 0x00A9 0x00B0 0x00B1 0x00B5 0x00B6 0x00C0 0x00C1 0x00C2 0x00C4
Transit Connect	3.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PCM	●	●	●	○
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2009	PCM	●	●	●	0x0092 0x0092 0x0090 0x0098 0x0099 0x00AB 0x00AC 0x00B4 0x00C1
Transit Connect / Tourneo Connect	1.8L	Endura DI	2002	PCM	●	●	●	○
Transit Connect / Tourneo Connect	1.8L	Zetec	2002	PCM	●	●	●	○
Windstar	3.0L	V6 OHV	1995 -	PCM	●	●	●	○
Windstar	3.8L	V6 OHV	1995 -	PCM	●	●	●	○