

## OilReset\_Honda\_V6.10 Function List (Note:For reference only)

YEAR	Vehicle Type	Reset
1996~2012	ALL	reset with tool
1996	Accord	reset without tool
1997	Accord	reset without tool
1998	Accord	reset without tool
1999	Accord	reset without tool
2000	Accord	reset without tool
2001	Accord	reset without tool
2002	Accord	reset without tool
2003	Accord	reset without tool
2004	Accord	reset without tool
2005	Accord	reset without tool
2006	Accord	reset without tool
2007	Accord	reset without tool
2008	Accord	reset without tool
2009	Accord	reset without tool
2010	Accord	reset without tool
2011	Accord	reset without tool
2012	Accord	reset without tool
2010	Accord Crosstour	reset without tool
2011	Accord Crosstour	reset without tool
1996	Civic	reset without tool

YEAR	Vehicle Type	Reset
1997	Civic	reset without tool
1998	Civic	reset without tool
1999	Civic	reset without tool
2000	Civic	reset without tool
2001	Civic	reset without tool
2002	Civic	reset without tool
2003	Civic	reset without tool
2004	Civic	reset without tool
2005	Civic	reset without tool
2006	Civic	reset without tool
2007	Civic	reset without tool
2008	Civic	reset without tool
2009	Civic	reset without tool
2010	Civic	reset without tool
2011	Civic	reset without tool
2012	Civic	reset without tool
2012	Civic	reset without tool
2012	Civic	reset without tool
1996	Civic del Sol	reset without tool
1997	Civic del Sol	reset without tool
1998	CR-V	reset without tool
1999	CR-V	reset without tool
2000	CR-V	reset without tool
2001	CR-V	reset without tool

YEAR	Vehicle Type	Reset
2002	CR-V	reset without tool
2003	CR-V	reset without tool
2004	CR-V	reset without tool
2005	CR-V	reset without tool
2006	CR-V	reset without tool
2007	CR-V	reset without tool
2008	CR-V	reset without tool
2009	CR-V	reset without tool
2010	CR-V	reset without tool
2011	CR-V	reset without tool
2012	CR-V	reset without tool
2012	CR-Z	reset without tool
2006	Element	reset without tool
2007	Element	reset without tool
2008	Element	reset without tool
2009	Element	reset without tool
2010	Element	reset without tool
2011	Element	reset without tool
2007	Fit	reset without tool
2008	Fit	reset without tool
2009	Fit	reset without tool
2010	Fit	reset without tool
2011	Fit	reset without tool
2012	Fit	reset without tool

YEAR	Vehicle Type	Reset
2000	Insight	reset without tool
2001	Insight	reset without tool
2002	Insight	reset without tool
2003	Insight	reset without tool
2004	Insight	reset without tool
2005	Insight	reset without tool
2006	Insight	reset without tool
2010	Insight	reset without tool
2011	Insight	reset without tool
2012	Insight	reset without tool
1996	Odyssey	reset without tool
1997	Odyssey	reset without tool
1998	Odyssey	reset without tool
1999	Odyssey	reset without tool
2000	Odyssey	reset without tool
2001	Odyssey	reset without tool
2002	Odyssey	reset without tool
2006	Odyssey	reset without tool
2007	Odyssey	reset without tool
2007	Odyssey	reset without tool
2007	Odyssey	reset without tool
2008	Odyssey	reset without tool
2008	Odyssey	reset without tool
2008	Odyssey	reset without tool

YEAR	Vehicle Type	Reset
2008	Odyssey	reset without tool
2009	Odyssey	reset without tool
2010	Odyssey	reset without tool
2011	Odyssey	reset without tool
2012	Odyssey	reset without tool
2006	Pilot	reset without tool
2007	Pilot	reset without tool
2008	Pilot	reset without tool
2009	Pilot	reset without tool
2010	Pilot	reset without tool
2011	Pilot	reset without tool
2012	Pilot	reset without tool
1996	Prelude	reset without tool
1997	Prelude	reset without tool
1998	Prelude	reset without tool
1999	Prelude	reset without tool
2000	Prelude	reset without tool
2001	Prelude	reset without tool
2006	Ridgeline	reset without tool
2007	Ridgeline	reset without tool
2008	Ridgeline	reset without tool
2009	Ridgeline	reset without tool
2010	Ridgeline	reset without tool
2011	Ridgeline	reset without tool

YEAR	Vehicle Type	Reset
2012	Ridgeline	reset without tool
2000	S2000	reset without tool
2001	S2000	reset without tool
2002	S2000	reset without tool
2003	S2000	reset without tool
2004	S2000	reset without tool
2005	S2000	reset without tool
2006	S2000	reset without tool
2007	S2000	reset without tool
2008	S2000	reset without tool
2009	S2000	reset without tool