

# MaxiSys\_FordEU\_V6.61 Function List (Note:For reference only)

**NOTES:**

- This function is supported.                      ※ This function may be supported, which depends on the actual condition of the vehicle.
  - This function is not supported.                ▲ This function is the new feature in this version.
- As for special function please refer to the special function table.

| Vehicle                                    | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|--|----------|--|-------------|--------|------------|-------------|-----------|-------------|---|
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4                              | 2005        | 4X4    | ●          | ●           | ●         | ●           | ○   |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4                              | 2005        | ABS    | ●          | ●           | ●         | ●           | 0x0008  |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4                              | 2005        | GEM    | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4                              | 2005        | IC     | ●          | ●           | ●         | ●           | ○   |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4                              | 2005        | PAM    | ●          | ●           | ●         | ●           | ○   |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4                              | 2005        | PCM    | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0024 0x0025<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 0x00C5               |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4                              | 2005        | RCM    | ●          | ●           | ●         | ●           | 0x000C  |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V   | 2005        | 4X4    | ●          | ●           | ●         | ●           | ○   |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V   | 2005        | ABS    | ●          | ●           | ●         | ●           | 0x0008  |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V   | 2005        | GEM    | ●          | ●           | ●         | ●           | 0x000A 0x000F 0xF042 0xF04E<br>0xF04F 0xF050 0xF051 0xF056<br>0xF057 0xF058 0xF059 0xF090 |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V   | 2005        | IC     | ●          | ●           | ●         | ●           | 0x0005 0xF040 0xF043 0xF04D<br>0xF052 0xF053 0xF054 0xF055                                |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V   | 2005        | PAM    | ●          | ●           | ●         | ●           | ○   |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V   | 2005        | PCM    | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0024 0x0025<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 0x00C5               |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V   | 2005        | RCM    | ●          | ●           | ●         | ●           | 0x000C 0x006D   |
| AEROSTAR                                   | 3.0L     | Other  | 1996 - 1997 | PCM    | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| AEROSTAR                                   | 4.0L     | Other  | 1996 - 1997 | PCM    | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119                                       |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | ACM    | ●          | ●           | ●         | ○           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | APIM   | ●          | ●           | ●         | ●           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | BCMii  | ●          | ●           | ●         | ●           | 0x00FE 0x0101 0x0118 0x0207   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | DDM    | ●          | ●           | ●         | ○           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | FCDIM  | ●          | ●           | ●         | ●           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | FDSM   | ●          | ●           | ●         | ○           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | GPSM   | ●          | ●           | ●         | ○           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | GWM    | ●          | ●           | ●         | ○           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| B-Max                                      | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | IPC    | ●          | ●           | ●         | ●           | 0x0009  |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| B-Max   | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x009A 0x00BC 0x00C3 0x0114 |
| B-Max   | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | PDM    | ●          | ●           | ●         | ○           | ○  |
| B-Max   | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | PSCM   | ●          | ●           | ●         | ○           | 0x00D7 0x00DC  |
| B-Max   | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | RCM    | ●          | ●           | ●         | ○           | 0x00EF   |
| B-Max   | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012        | RFA    | ●          | ●           | ●         | ○           | 0x000A   |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | ABS    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | ACM    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | HVAC   | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | IPC    | ●          | ●           | ●         | ●           | 0x0009   |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                                |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | PSCM   | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | RCM    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | RFA    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.25L    | DURATEC 16V                                  | 2008        | SRM    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008        | SRM    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008        | TCM    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | ABS    | ●          | ●           | ●         | ●           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119        |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | ACM    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | BCMii  | ●          | ●           | ●         | ●           | 0x00FE 0x0101 0x0118 0x0207                                |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | HVAC   | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | IPC    | ●          | ●           | ●         | ●           | 0x0009   |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00BC                      |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | PSCM   | ●          | ●           | ●         | ●           | 0x00D7 0x00DC  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | RCM    | ●          | ●           | ●         | ●           | 0x00EF   |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2008 - 2012 | RFA    | ●          | ●           | ●         | ●           | 0x000A   |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2012        | APIM   | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2012        | DDM    | ●          | ●           | ●         | ○           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2012        | FDSM   | ●          | ●           | ●         | ○           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2012        | GPSM   | ●          | ●           | ●         | ○           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2012        | GWM    | ●          | ●           | ●         | ○           | ○  |
| B-Max   | 1.4L     | DURATEC 16V                                  | 2012        | PDM    | ●          | ●           | ●         | ○           | ○  |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2008        | ABS    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2008        | ACM    | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2008        | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2008        | HVAC   | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | IPC    | ●          | ●           | ●         | ●           | 0x0009  |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083   |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | PSCM   | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | RCM    | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | RFA    | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | SRM    | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D7<br>0x00D9 0x00DB 0x00E8 0x0119  |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | ACM    | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | APIM   | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | BCMii  | ●          | ●           | ●         | ●           | 0x00FE 0x0101 0x0118 0x0207   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | DDM    | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | FCDIM  | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | FDSM   | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | GPSP   | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | GWM    | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | IPC    | ●          | ●           | ●         | ●           | 0x0009  |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00AF 0x00B0 0x00B1<br>0x00B2 0x00B8 0x00BD |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | PDM    | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | PSCM   | ●          | ●           | ●         | ○           | 0x00DC  |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | RCM    | ●          | ●           | ●         | ○           | 0x00EF  |
| B-Max   | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2012        | RFA    | ●          | ●           | ●         | ○           | 0x000A  |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008        | SRM    | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | ABS    | ●          | ●           | ●         | ●           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | ACM    | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | BCMii  | ●          | ●           | ●         | ●           | 0x00FE 0x0101 0x0118 0x0207   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | FCDIM  | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | IPC    | ●          | ●           | ●         | ●           | 0x0009  |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00BC   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | PSCM   | ●          | ●           | ●         | ●           | 0x00D7 0x00DC   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | RCM    | ●          | ●           | ●         | ●           | 0x00EF  |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2008 - 2012 | RFA    | ●          | ●           | ●         | ●           | 0x000A  |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2012        | APIM   | ●          | ●           | ●         | ●           | ○   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2012        | DDM    | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2012        | FDSM   | ●          | ●           | ●         | ○           | ○   |
| B-Max   | 1.6L     | DURATEC VCT                                 | 2012        | GPSP   | ●          | ●           | ●         | ○           | ○   |

| Vehicle        | Capacity | EngineType                                  | Year | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|----------------|----------|---|------|---------|------------|-------------|-----------|-------------|---|
| B-Max          | 1. 6L    | DURATEC VCT                                 | 2012 | GWM     | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | DURATEC VCT                                 | 2012 | PDM     | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | DURATEC VCT                                 | 2012 | TCM     | ●          | ●           | ●         | ●           | 0x0117  |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | ABS     | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | ACM     | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | BCMii   | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | HVAC    | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | IPC     | ●          | ●           | ●         | ●           | 0x0009  |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | PSCM    | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | RCM     | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | RFA     | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008 | SRM     | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D7<br>0x00D9 0x00DB 0x00E8 0x0119  |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | ACM     | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | APIM    | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | BCMii   | ●          | ●           | ●         | ●           | 0x00FE 0x0101 0x0118 0x0207   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | DDM     | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | FDSM    | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | GPSM    | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | GWM     | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | HVAC    | ●          | ●           | ●         | ●           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | IPC     | ●          | ●           | ●         | ●           | 0x0009  |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00AF 0x00B0 0x00B1<br>0x00B2 0x00B8 0x00BD |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | PDM     | ●          | ●           | ●         | ○           | ○   |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | PSCM    | ●          | ●           | ●         | ○           | 0x00DC  |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | RCM     | ●          | ●           | ●         | ○           | 0x00EF  |
| B-Max          | 1. 6L    | TDCi ECO II                                 | 2012 | RFA     | ●          | ●           | ●         | ○           | 0x000A  |
| BT-50 / Ranger | 2. 2L    | F2  | 2007 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| BT-50 / Ranger | 2. 2L    | F2  | 2007 | PCM     | ●          | ●           | ●         | ●           | ○   |
| BT-50 / Ranger | 2. 2L    | F2  | 2007 | RCM     | ●          | ●           | ●         | ●           | ○   |
| BT-50 / Ranger | 2. 5L    | L5  | 2012 | PCM     | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083   |
| BT-50 / Ranger | 2. 5L    | WL  | 2007 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| BT-50 / Ranger | 2. 5L    | WL  | 2007 | PCM     | ●          | ●           | ●         | ●           | ○   |
| BT-50 / Ranger | 2. 5L    | WL  | 2007 | RCM     | ●          | ●           | ●         | ●           | ○   |
| BT-50 / Ranger | 2. 5L    | WL-CD                                       | 2007 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |

| Vehicle        | Capacity | EngineType                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                  |
|----------------|----------|------------------------------|-------------|---------|------------|-------------|-----------|-------------|--|
| BT-50 / Ranger | 2.5L     | WL-CD                        | 2007        | PCM     | ●          | ●           | ●         | ●           | 0x0055 0x0080 0x0081 0x0082 0x0083               |
| BT-50 / Ranger | 2.5L     | WL-CD                        | 2007        | RCM     | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 2.5L     | WL-CD                        | 2007        | TCM     | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 2.6L     | G6                           | 2007        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 2.6L     | G6                           | 2007        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                      |
| BT-50 / Ranger | 2.6L     | G6                           | 2007        | RCM     | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 3.0L     | WE-CD                        | 2007        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 3.0L     | WE-CD                        | 2007        | PCM     | ●          | ●           | ●         | ●           | 0x0055 0x0080 0x0081 0x0082 0x0083               |
| BT-50 / Ranger | 3.0L     | WE-CD                        | 2007        | RCM     | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 3.0L     | WE-CD                        | 2007        | TCM     | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 4.0L     | V6 SOHC                      | 2007        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| BT-50 / Ranger | 4.0L     | V6 SOHC                      | 2007        | ESOF    | ●          | ●           | ●         | ●           | ○  |
| BT-50 / Ranger | 4.0L     | V6 SOHC                      | 2007        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0024 0x0080 0x0081 0x0082 0x0083 0x0084 |
| BT-50 / Ranger | 4.0L     | V6 SOHC                      | 2007        | RCM     | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | ABS     | ●          | ●           | ●         | ●           | 0x0012 0x0074 0x010A                             |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | ACM     | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | APIM    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | BECM    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | DDM     | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | GWM     | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | HVAC    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | IPC     | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | PAM     | ●          | ●           | ○         | ○           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | PSCM    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2013 - 2014 | RFA     | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2014        | FCIM    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2014        | GPSM    | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | Full Hybrid Electric Vehicle | 2014        | RGTM    | ●          | ●           | ●         | ○           | 0x013D   |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | ABS     | ●          | ●           | ●         | ●           | 0x0012 0x0074 0x010A                             |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | ACM     | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | APIM    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | BECM    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | DDM     | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | GFM     | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | GWM     | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | HVAC    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | IPC     | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | PAM     | ●          | ●           | ○         | ○           | ○  |
| C-MAX          | 2.0L     | PHEV                         | 2013 - 2014 | PSCM    | ●          | ●           | ●         | ●           | ○  |

| Vehicle        | Capacity | EngineType | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------------|----------|------------|-------------|---------|------------|-------------|-----------|-------------|--|
| C-MAX          | 2.0L     | PHEV       | 2013 - 2014 | RFA     | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | PHEV       | 2013 - 2014 | SOBDM   | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | PHEV       | 2013 - 2014 | TCU#1   | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | PHEV       | 2014        | FCIM    | ●          | ●           | ●         | ●           | ○  |
| C-MAX          | 2.0L     | PHEV       | 2014        | GPSM    | ●          | ●           | ●         | ○           | ○  |
| C-MAX          | 2.0L     | PHEV       | 2014        | RGTM    | ●          | ●           | ●         | ○           | 0x013D   |
| Cougar         | 2.0L     | Zetec      | 1998 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Cougar         | 2.0L     | Zetec      | 1998 - 2002 | CSM     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.0L     | Zetec      | 1998 - 2002 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.0L     | Zetec      | 1998 - 2002 | IAB     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.0L     | Zetec      | 1998 - 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 0x0084   |
| Cougar         | 2.5L     | Duratec-VE | 1998 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Cougar         | 2.5L     | Duratec-VE | 1998 - 2002 | CSM     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.5L     | Duratec-VE | 1998 - 2002 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.5L     | Duratec-VE | 1998 - 2002 | IAB     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.5L     | Duratec-VE | 1998 - 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x0009   |
| Cougar         | 2.5L     | Duratec-VE | 2001        | ABS     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.5L     | Duratec-VE | 2001        | IC      | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.5L     | Duratec-VE | 2001        | MC      | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 2.5L     | Duratec-VE | 2001        | REM     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 3.8L     | Other      | 1996 - 1997 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 3.8L     | Other      | 1996 - 1997 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 3.8L     | Other      | 1996 - 1997 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083   |
| Cougar         | 4.6L     | 2V         | 1994 - 1997 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 4.6L     | 2V         | 1994 - 1997 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Cougar         | 4.6L     | 2V         | 1994 - 1997 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083   |
| Crown Victoria | 4.6L     | 2V         | 1995 - 1997 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Crown Victoria | 4.6L     | 2V         | 1995 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Crown Victoria | 4.6L     | 2V         | 1995 - 2007 | EATC    | ●          | ●           | ●         | ●           | ○  |
| Crown Victoria | 4.6L     | 2V         | 1995 - 2011 | DDM     | ●          | ●           | ●         | ●           | 0x000F 0x000A 0x0042 0x0005<br>0xF044 0xF04C 0xF06A  |
| Crown Victoria | 4.6L     | 2V         | 1995 - 2011 | LCM     | ●          | ●           | ●         | ●           | 0xF042 0xF043  |
| Crown Victoria | 4.6L     | 2V         | 1995 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 0x0009<br>0x0024 0x00C5 |
| Crown Victoria | 4.6L     | 2V         | 1996 - 1997 | IAB     | ●          | ●           | ●         | ●           | ○  |
| Crown Victoria | 4.6L     | 2V         | 1998 - 2000 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Crown Victoria | 4.6L     | 2V         | 1998 - 2002 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| Crown Victoria | 4.6L     | 2V         | 2000 - 2011 | RCM     | ●          | ●           | ●         | ●           | 0x000C   |

| Vehicle        | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|----------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| Crown Victoria | 4. 6L    | 2V   | 2003 – 2006 | RASM    | ●          | ●           | ●         | ●           | 0x0013  |
| Crown Victoria | 4. 6L    | 2V   | 2003 – 2006 | VAPS    | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V   | 2004 – 2010 | MC      | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V   | 2005 – 2011 | ABS     | ●          | ●           | ●         | ●           | 0x0008  |
| Crown Victoria | 4. 6L    | 2V   | 2005 – 2011 | FSSM    | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V   | 2006 – 2011 | IC      | ●          | ●           | ●         | ●           | 0x0005  |
| Crown Victoria | 4. 6L    | 2V   | 2007 – 2011 | VDM     | ●          | ●           | ●         | ●           | 0x0005 0x0013 0x0014  |
| Crown Victoria | 4. 6L    | 2V   | 2008 – 2011 | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1996 – 1997 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1996 – 1997 | IAB     | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1996 – 2000 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1996 – 2000 | DDM     | ●          | ●           | ●         | ●           | 0x000F 0x000A   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1996 – 2000 | FIM     | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1996 – 2000 | LCM     | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1996 – 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082<br>0x0083 0x0010 0x0028 0x0031<br>0x0033 0x0084 |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1998 – 2000 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1998 – 2000 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 1998 – 2000 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Crown Victoria | 4. 6L    | 2V_NGV                                       | 2000        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Crown Victoria | 4. 6L    | Other  | 1995        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Crown Victoria | 4. 6L    | Other  | 1995        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083                                |
| EcoSport       | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2013        | ABS     | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2013        | ACM     | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2013        | DDM     | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2013        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2013        | PSCM    | ●          | ●           | ●         | ○           | 0x00CB 0x00CC   |
| EcoSport       | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2013        | RCM     | ●          | ●           | ●         | ○           | ○   |
| EcoSport       | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2013 – 2014 | APIM    | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | Zetec Rocam                                  | 2003        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x000B   |
| EcoSport       | 1. 0L    | Zetec Rocam                                  | 2003        | GEM     | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | Zetec Rocam                                  | 2003        | IC      | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | Zetec Rocam                                  | 2003        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084                         |
| EcoSport       | 1. 0L    | Zetec Rocam                                  | 2003        | RCM     | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 0L    | Zetec Rocam                                  | 2003        | RKE     | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 4L    | Duratorq Turbo Diesel Common Rail Injection  | 2003        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x000B   |
| EcoSport       | 1. 4L    | Duratorq Turbo Diesel Common Rail Injection  | 2003        | GEM     | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 4L    | Duratorq Turbo Diesel Common Rail Injection  | 2003        | IC      | ●          | ●           | ●         | ●           | ○   |
| EcoSport       | 1. 4L    | Duratorq Turbo Diesel Common Rail Injection  | 2003        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083                                       |

| Vehicle  | Capacity | EngineType  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| EcoSport | 1.4L     | Duratorq Turbo Diesel Common Rail Injection       | 2003        | RCM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.4L     | Duratorq Turbo Diesel Common Rail Injection       | 2003        | RKE     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | DURATEC VCT                                       | 2014        | APIM    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | ABS     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | ACM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | APIM    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | PSCM    | ●          | ●           | ●         | ○           | 0x00CB 0x00CC  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | RCM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2012        | TBM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq Turbo Diesel Common Rail Injection       | 2014        | APIM    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | Duratorq-Turbo Diesel Common Rail Injection       | 2014        | ABS     | ●          | ●           | ●         | ●           | 0x00E8   |
| EcoSport | 1.5L     | Duratorq-Turbo Diesel Common Rail Injection StgVI | 2014        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0083 0x0090<br>0x0092 0x0098 0x0099 0x009A<br>0x00AF 0x00B0 0x00B1 0x00B2<br>0x00B8 0x00BD |
| EcoSport | 1.5L     | Duratorq-Turbo Diesel Common Rail Injection       | 2014        | PSCM    | ●          | ●           | ●         | ●           | 0x00D7 0x00DC  |
| EcoSport | 1.5L     | Duratorq-Turbo Diesel Common Rail Injection       | 2014        | RCM     | ●          | ●           | ●         | ●           | 0x00EF 0x021B  |
| EcoSport | 1.5L     | TiVCT   | 2012        | ABS     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | ACM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | APIM    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | BCM#1   | ●          | ●           | ●         | ●           | 0x000A   |
| EcoSport | 1.5L     | TiVCT   | 2012        | DDM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | IPC     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0084   |
| EcoSport | 1.5L     | TiVCT   | 2012        | PSCM    | ●          | ●           | ●         | ○           | 0x00CB 0x00CC  |
| EcoSport | 1.5L     | TiVCT   | 2012        | RCM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 1.5L     | TiVCT   | 2012        | TCM     | ●          | ●           | ●         | ●           | 0x0117 0x0158  |
| EcoSport | 1.6L     | FFV   | 2003 - 2006 | GEM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.6L     | FFV   | 2003 - 2011 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x000B  |
| EcoSport | 1.6L     | FFV   | 2003 - 2011 | IC      | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.6L     | FFV   | 2003 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x012E  |
| EcoSport | 1.6L     | FFV   | 2003 - 2011 | RCM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.6L     | FFV   | 2003 - 2011 | RKE     | ●          | ●           | ●         | ●           | 0x000A   |
| EcoSport | 1.6L     | FFV   | 2011        | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3   |
| EcoSport | 1.6L     | Sigma   | 2012        | ABS     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.6L     | Sigma   | 2012        | ACM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1.6L     | Sigma   | 2012        | APIM    | ●          | ●           | ●         | ●           | ○  |



| Vehicle  | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|--|
| EcoSport | 1. 6L    | Sigma           | 2012        | BCM#1   | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1. 6L    | Sigma           | 2012        | DDM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 1. 6L    | Sigma           | 2012        | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1. 6L    | Sigma           | 2012        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1. 6L    | Sigma           | 2012        | IPC     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1. 6L    | Sigma           | 2012        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083 0x0084                             |
| EcoSport | 1. 6L    | Sigma           | 2012        | PSCM    | ●          | ●           | ●         | ○           | 0x00CB 0x00CC  |
| EcoSport | 1. 6L    | Sigma           | 2012        | RCM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 1. 6L    | Sigma           | 2012        | RFA     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 1. 6L    | Sigma           | 2012        | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3   |
| EcoSport | 1. 6L    | Zetec Rocam     | 2003        | GEM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1. 6L    | Zetec Rocam     | 2003 – 2009 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x000B  |
| EcoSport | 1. 6L    | Zetec Rocam     | 2003 – 2009 | IC      | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1. 6L    | Zetec Rocam     | 2003 – 2009 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081 0x0082 0x0083 0x0084               |
| EcoSport | 1. 6L    | Zetec Rocam     | 2003 – 2009 | RCM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 1. 6L    | Zetec Rocam     | 2003 – 2009 | RKE     | ●          | ●           | ●         | ●           | 0x000A   |
| EcoSport | 2. 0L    | DURATEC         | 2013        | ABS     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC         | 2013        | ACM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC         | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC         | 2013        | DDM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC         | 2013        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC         | 2013        | PSCM    | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 2. 0L    | DURATEC         | 2013        | RCM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 2. 0L    | DURATEC         | 2013        | TBM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2003 – 2006 | GEM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2003 – 2007 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x000B  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2003 – 2007 | IC      | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2003 – 2007 | RKE     | ●          | ●           | ●         | ●           | 0x000A   |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2003 – 2012 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081 0x0082 0x0083 0x0023 0x0067 0x0084 |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2003 – 2012 | RCM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | ABS     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | ACM     | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | APIM    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | BCM#1   | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | DDM     | ●          | ●           | ●         | ○           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| EcoSport | 2. 0L    | DURATEC-HE / I4 | 2012        | IPC     | ●          | ●           | ●         | ●           | ○  |

| Vehicle  | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|----------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|---|
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2012        | PSCM    | ●          | ●           | ●         | ○           | 0x00CB 0x00CC                                       |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2012        | RFA     | ●          | ●           | ●         | ○           | ○   |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2012        | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3                                |
| EcoSport | 2.0L     | FFV             | 2009 - 2011 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x000B                                       |
| EcoSport | 2.0L     | FFV             | 2009 - 2011 | IC      | ●          | ●           | ●         | ●           | ○   |
| EcoSport | 2.0L     | FFV             | 2009 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x00C5 |
| EcoSport | 2.0L     | FFV             | 2009 - 2011 | RCM     | ●          | ●           | ●         | ●           | ○   |
| EcoSport | 2.0L     | FFV             | 2009 - 2011 | RKE     | ●          | ●           | ●         | ●           | 0x000A  |
| EcoSport | 2.0L     | FFV             | 2011        | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3                                |
| EcoSport | 2.0L     | Zetec Rocam     | 2009        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| EcoSport | 2.0L     | Zetec Rocam     | 2009        | IC      | ●          | ●           | ●         | ●           | ○   |
| EcoSport | 2.0L     | Zetec Rocam     | 2009        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083        |
| EcoSport | 2.0L     | Zetec Rocam     | 2009        | RCM     | ●          | ●           | ●         | ●           | ○   |
| EcoSport | 2.0L     | Zetec Rocam     | 2009        | RKE     | ●          | ●           | ●         | ●           | 0x000A  |
| EcoSport | Other    | Other           | 2012        | ABS     | ●          | ●           | ●         | ●           | ○   |
| EcoSport | Other    | Other           | 2012        | ACM     | ●          | ●           | ●         | ○           | ○   |
| EcoSport | Other    | Other           | 2012        | APIM    | ●          | ●           | ●         | ●           | ○   |
| EcoSport | Other    | Other           | 2012        | BCM#1   | ●          | ●           | ●         | ●           | 0x000A  |
| EcoSport | Other    | Other           | 2012        | DDM     | ●          | ●           | ●         | ○           | ○   |
| EcoSport | Other    | Other           | 2012        | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| EcoSport | Other    | Other           | 2012        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| EcoSport | Other    | Other           | 2012        | IPC     | ●          | ●           | ●         | ●           | ○   |
| EcoSport | Other    | Other           | 2012        | PSCM    | ●          | ●           | ●         | ○           | ○   |
| EcoSport | Other    | Other           | 2012        | RCM     | ●          | ●           | ●         | ○           | ○   |
| Escort   | 1.3L     | Endura-E        | 1995 - 1998 | ABS     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.3L     | Endura-E        | 1995 - 1998 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.3L     | Endura-E        | 1995 - 1998 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.3L     | Endura-E        | 1995 - 1998 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.3L     | Endura-E        | 1995 - 1998 | PATS    | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.3L     | Endura-E        | 1995 - 1998 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083        |
| Escort   | 1.4L     | 1.4 PT-E SFI    | 1994 - 1998 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.4L     | 1.4 PT-E SFI    | 1994 - 1998 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.4L     | 1.4 PT-E SFI    | 1994 - 1998 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.4L     | 1.4 PT-E SFI    | 1994 - 1998 | PATS    | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.4L     | 1.4 PT-E SFI    | 1994 - 1998 | PCM     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.4L     | 1.4 PT-E SFI    | 1995 - 1998 | ABS     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.6L     | PT-E            | Other       | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.6L     | PT-E            | Other       | CSM     | ●          | ●           | ●         | ●           | ○   |
| Escort   | 1.6L     | PT-E            | Other       | HEC     | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType    | Year         | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                  |
|---------|----------|---------------|--------------|---------|------------|-------------|-----------|-------------|--|
| Escort  | 1. 6L    | PT-E          | Other        | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | PT-E          | Other        | PCM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec         | 1993 - 1997  | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082 0x0083               |
| Escort  | 1. 6L    | Zetec         | 1993 - 1998  | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec         | 1993 - 1998  | CSM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec         | 1993 - 1998  | HEC     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec         | 1993 - 1998  | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec         | 1995 - 1998  | ABS     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec Rocam   | 2000         | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec Rocam   | 2000         | CSM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec Rocam   | 2000         | HEC     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec Rocam   | 2000         | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 6L    | Zetec Rocam   | 2000         | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083 0x0084 |
| Escort  | 1. 8L    | Endura-DE     | 1996 - Other | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Endura-DE     | 1996 - Other | CSM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Endura-DE     | 1996 - Other | HEC     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Endura-DE     | 1996 - Other | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Endura-DE     | 1996 - Other | PCM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Endura-DE     | 1997         | ABS     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Other         | 1996         | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Other         | 1996         | CSM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Other         | 1996         | HEC     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Other         | 1996         | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Other         | 1996         | PCM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Zetec         | 1992 - 1996  | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082 0x0083               |
| Escort  | 1. 8L    | Zetec         | 1992 - 1998  | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Zetec         | 1992 - 1998  | CSM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Zetec         | 1992 - 1998  | HEC     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Zetec         | 1992 - 1998  | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 8L    | Zetec         | 1995 - 1998  | ABS     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 9L    | Other         | 1996         | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 9L    | Other         | 1996         | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 1. 9L    | Other         | 1996         | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083        |
| Escort  | 2. 0L    | DOHC Cosworth | 1994 - 1995  | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Escort  | 2. 0L    | DOHC Cosworth | 1994 - 1995  | PATS    | ●          | ●           | ●         | ●           | ○  |
| Escort  | 2. 0L    | DOHC Cosworth | 1994 - 1995  | PCM     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 2. 0L    | DOHC Cosworth | 1995         | ABS     | ●          | ●           | ●         | ●           | ○  |
| Escort  | 2. 0L    | SPI           | 1997 - 2002  | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Escort  | 2. 0L    | SPI           | 1997 - 2002  | PATS    | ●          | ●           | ●         | ●           | ○  |

| Vehicle  | Capacity | EngineType | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------|----------|------------|-------------|-----------|------------|-------------|-----------|-------------|--|
| Escort   | 2.0L     | SPI        | 1997 - 2002 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084  |
| Escort   | 2.0L     | SPI        | 1997 - 2002 | RAP       | ●          | ●           | ●         | ●           | 0x000A   |
| Escort   | 2.0L     | SPI        | 1998 - 1999 | ABS       | ●          | ●           | ●         | ●           | 0x0008   |
| Escort   | 2.0L     | SPI        | 1998 - 2002 | ECS       | ●          | ●           | ●         | ●           | ○  |
| Escort   | 2.0L     | Zetec      | 1998 - 1999 | ABS       | ●          | ●           | ●         | ●           | 0x0008   |
| Escort   | 2.0L     | Zetec      | 1998 - 2003 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008   |
| Escort   | 2.0L     | Zetec      | 1998 - 2003 | ECS       | ●          | ●           | ●         | ●           | ○  |
| Escort   | 2.0L     | Zetec      | 1998 - 2003 | PATS      | ●          | ●           | ●         | ●           | ○  |
| Escort   | 2.0L     | Zetec      | 1998 - 2003 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084  |
| Escort   | 2.0L     | Zetec      | 1998 - 2003 | RAP       | ●          | ●           | ●         | ●           | 0x000A   |
| E-Series | 4.2L     | Other      | 1997 - 2003 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 4.2L     | Other      | 1997 - 2003 | ECS       | ●          | ●           | ●         | ●           | ○  |
| E-Series | 4.2L     | Other      | 1997 - 2003 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084                         |
| E-Series | 4.6L     | 2V         | 2003        | ECS       | ●          | ●           | ●         | ●           | ○  |
| E-Series | 4.6L     | 2V         | 2003 - 2007 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008 0x001B  |
| E-Series | 4.6L     | 2V         | 2003 - 2014 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x0024<br>0x0009 0x0067 |
| E-Series | 4.6L     | 2V         | 2004 - 2006 | RAP       | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| E-Series | 4.6L     | 2V         | 2004 - 2008 | IC        | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF066 0xF067<br>0x0009  |
| E-Series | 4.6L     | 2V         | 2004 - 2014 | RCM       | ●          | ●           | ●         | ●           | ○  |
| E-Series | 4.6L     | 2V         | 2006 - 2014 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| E-Series | 4.6L     | 2V         | 2007 - 2008 | VSM       | ●          | ●           | ●         | ●           | 0x000A 0x0042  |
| E-Series | 4.6L     | 2V         | 2007 - 2014 | PAM       | ●          | ●           | ●         | ●           | ○  |
| E-Series | 4.6L     | 2V         | 2009 - 2014 | ACM       | ●          | ●           | ●         | ●           | 0x0017 0x0018  |
| E-Series | 4.6L     | 2V         | 2009 - 2014 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x0042 0xF03C 0xF042<br>0xF049 0xF04B 0xF04C 0xF068<br>0xF069 0xF06A                                |
| E-Series | 4.6L     | 2V         | 2009 - 2014 | IPC       | ●          | ●           | ●         | ●           | 0x0009   |
| E-Series | 4.6L     | 2V         | 2009 - 2014 | TBC       | ●          | ●           | ●         | ●           | ○  |
| E-Series | 4.6L     | 2V         | 2010 - 2013 | SDARS     | ●          | ●           | ●         | ●           | ○  |
| E-Series | 4.6L     | 2V         | 2010 - 2014 | APIM      | ●          | ●           | ●         | ●           | 0x0019   |
| E-Series | 4.6L     | 2V         | 2010 - 2014 | GPSM      | ●          | ●           | ●         | ○           | ○  |
| E-Series | 4.6L     | Other      | 1997 - 2002 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 4.6L     | Other      | 1997 - 2002 | ECS       | ●          | ●           | ●         | ●           | ○  |
| E-Series | 4.6L     | Other      | 1997 - 2002 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084                         |

| Vehicle  | Capacity | EngineType | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------|----------|------------|-------------|---------|------------|-------------|-----------|-------------|--|
| E-Series | 4. 9L    | GFP        | 1996        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 4. 9L    | GFP        | 1996        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082 0x0083   |
| E-Series | 4. 9L    | Other      | 1996        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 4. 9L    | Other      | 1996        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083  |
| E-Series | 5. 0L    | Other      | 1996        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 5. 0L    | Other      | 1996        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083  |
| E-Series | 5. 4L    | 2V         | 2004        | AFCM    | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | 2V         | 2004 - 2006 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| E-Series | 5. 4L    | 2V         | 2004 - 2007 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x001B  |
| E-Series | 5. 4L    | 2V         | 2004 - 2008 | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF066 0xF067 0x0009 0xF027   |
| E-Series | 5. 4L    | 2V         | 2004 - 2014 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025 0x0028 0x0031 0x0033 0x0080 0x0081 0x0082 0x0083 0x0084 0x00C5 0x0009 0x0067 |
| E-Series | 5. 4L    | 2V         | 2004 - 2014 | RCM     | ●          | ●           | ●         | ●           | 0x0005 0xF022  |
| E-Series | 5. 4L    | 2V         | 2006 - 2014 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| E-Series | 5. 4L    | 2V         | 2007 - 2008 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0xF044 0x0042   |
| E-Series | 5. 4L    | 2V         | 2007 - 2014 | PAM     | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | 2V         | 2009 - 2014 | ACM     | ●          | ●           | ●         | ●           | 0x0017 0x0018  |
| E-Series | 5. 4L    | 2V         | 2009 - 2014 | GEM /   | ●          | ●           | ●         | ●           | 0x000A 0x0042  |
| E-Series | 5. 4L    | 2V         | 2009 - 2014 | IPC     | ●          | ●           | ●         | ●           | 0x0009   |
| E-Series | 5. 4L    | 2V         | 2009 - 2014 | TBC     | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | 2V         | 2010 - 2013 | SDARS   | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | 2V         | 2010 - 2014 | APIM    | ●          | ●           | ●         | ●           | 0x0019   |
| E-Series | 5. 4L    | 2V         | 2010 - 2014 | GPSM    | ●          | ●           | ●         | ○           | ○  |
| E-Series | 5. 4L    | BIF        | 1999        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 5. 4L    | BIF        | 1999        | AFCM    | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | BIF        | 1999        | ECS     | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | BIF        | 1999        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082 0x0083   |
| E-Series | 5. 4L    | NGV        | 1997 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 5. 4L    | NGV        | 1997 - 2000 | ECS     | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | NGV        | 1997 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083 0x0010 0x0028 0x0031 0x0033 0x0084                             |
| E-Series | 5. 4L    | NGV        | 1998 - 2000 | FIM     | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | Other      | 1997 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series | 5. 4L    | Other      | 1997 - 2003 | ECS     | ●          | ●           | ●         | ●           | ○  |
| E-Series | 5. 4L    | Other      | 1997 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083 0x0010 0x0028 0x0031 0x0033 0x0084                             |

| Vehicle  | Capacity | EngineType               | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|----------|----------|--------------------------|-------------|-----------|------------|-------------|-----------|-------------|---|
| E-Series | 5. 8L    | Other                    | 1996        | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008  |
| E-Series | 5. 8L    | Other                    | 1996        | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2004 - 2006 | RAP       | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2004 - 2007 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008 0x001B   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2004 - 2008 | IC        | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF066 0xF067<br>0x0009   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2004 - 2010 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x00C5<br>0x0009               |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2004 - 2010 | RCM       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2004 - 2010 | TCM       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2006 - 2010 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012 0x0005  |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2007 - 2008 | VSM       | ●          | ●           | ●         | ●           | 0x000A 0x0042   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2007 - 2010 | PAM       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2009 - 2010 | ACM       | ●          | ●           | ●         | ●           | 0x0017 0x0018   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2009 - 2010 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x0042 0xF03C 0xF042<br>0xF049 0xF04B 0xF04C 0xF068<br>0xF069 0xF06A                                       |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2009 - 2010 | IPC       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2009 - 2010 | TBC       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2010        | APIM      | ●          | ●           | ●         | ●           | 0x0019  |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2010        | GPSM      | ●          | ●           | ●         | ○           | ○   |
| E-Series | 6. 0L    | Direct Injection - Turbo | 2010        | SDARS     | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 8L    | 2V                       | 2004 - 2006 | RAP       | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| E-Series | 6. 8L    | 2V                       | 2004 - 2007 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008 0x001B   |
| E-Series | 6. 8L    | 2V                       | 2004 - 2008 | IC        | ●          | ●           | ●         | ●           | 0x0009  |
| E-Series | 6. 8L    | 2V                       | 2004 - 2014 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x00C5 0x0067 0x0009 |
| E-Series | 6. 8L    | 2V                       | 2004 - 2014 | RCM       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 8L    | 2V                       | 2006 - 2014 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012 0x0005  |
| E-Series | 6. 8L    | 2V                       | 2007 - 2008 | VSM       | ●          | ●           | ●         | ●           | 0x000A 0x0042   |
| E-Series | 6. 8L    | 2V                       | 2007 - 2014 | PAM       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 8L    | 2V                       | 2009 - 2014 | ACM       | ●          | ●           | ●         | ●           | 0x0017 0x0018   |
| E-Series | 6. 8L    | 2V                       | 2009 - 2014 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x0042 0xF03C 0xF042<br>0xF049 0xF04B 0xF04C 0xF068<br>0xF069 0xF06A                                       |
| E-Series | 6. 8L    | 2V                       | 2009 - 2014 | IPC       | ●          | ●           | ●         | ●           | 0x0009  |
| E-Series | 6. 8L    | 2V                       | 2009 - 2014 | TBC       | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 8L    | 2V                       | 2010 - 2013 | SDARS     | ●          | ●           | ●         | ●           | ○   |
| E-Series | 6. 8L    | 2V                       | 2010 - 2014 | APIM      | ●          | ●           | ●         | ●           | 0x0019  |

| Vehicle              | Capacity | EngineType               | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------------------|----------|--------------------------|-------------|---------|------------|-------------|-----------|-------------|--|
| E-Series             | 6. 8L    | 2V                       | 2010 - 2014 | GPSM    | ●          | ●           | ●         | ○           | ○  |
| E-Series             | 6. 8L    | Other                    | 1997 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series             | 6. 8L    | Other                    | 1997 - 2003 | ECS     | ●          | ●           | ●         | ●           | ○  |
| E-Series             | 6. 8L    | Other                    | 1997 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 |
| E-Series             | 7. 3L    | Direct Injection - Turbo | 1995 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series             | 7. 3L    | Direct Injection - Turbo | 1995 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0083 0x0010 0x0028<br>0x0031 0x0033        |
| E-Series             | 7. 3L    | Direct Injection - Turbo | 1997 - 2003 | ECS     | ●          | ●           | ●         | ●           | ○  |
| E-Series             | 7. 5L    | Other                    | 1996        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| E-Series             | 7. 5L    | Other                    | 1996        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083                                       |
| E-Series             | Other    | Other                    | 2012        | ABS     | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | ACM     | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | APIM    | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | GEM /   | ●          | ●           | ●         | ●           | 0x0042   |
| E-Series             | Other    | Other                    | 2012        | GPSM    | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | IPC     | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | PAM     | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| E-Series             | Other    | Other                    | 2012        | RCM     | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | SDARS   | ●          | ●           | ●         | ●           | ○  |
| E-Series             | Other    | Other                    | 2012        | TBC     | ●          | ●           | ●         | ●           | ○  |
| E-Series Shuttle Bus | 6. 8L    | H2ICE                    | 2006        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| E-Series Shuttle Bus | 6. 8L    | H2ICE                    | 2006        | AFCM    | ●          | ●           | ●         | ●           | ○  |
| E-Series Shuttle Bus | 6. 8L    | H2ICE                    | 2006        | EMM     | ●          | ●           | ●         | ●           | ○  |
| E-Series Shuttle Bus | 6. 8L    | H2ICE                    | 2006        | IC      | ●          | ●           | ●         | ●           | ○  |
| E-Series Shuttle Bus | 6. 8L    | H2ICE                    | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082<br>0x0083  |
| E-Series Shuttle Bus | 6. 8L    | H2ICE                    | 2006        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004        | ECS     | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x001B  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | EATC    | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | OTC     | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Excursion            | 5. 4L    | 2V                       | 2004 - 2005 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |

| Vehicle   | Capacity | EngineType               | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-----------|----------|--------------------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Excursion | 5.4L     | 2V                       | 2004 - 2005 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084        |
| Excursion | 5.4L     | 2V                       | 2004 - 2005 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Excursion | 5.4L     | 2V                       | 2005        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2000        | MC      | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2000 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Excursion | 5.4L     | Other                    | 2000 - 2003 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2000 - 2003 | GEM     | ●          | ●           | ●         | ●           | 0x000F  |
| Excursion | 5.4L     | Other                    | 2000 - 2003 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2000 - 2003 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Excursion | 5.4L     | Other                    | 2000 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084        |
| Excursion | 5.4L     | Other                    | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Excursion | 5.4L     | Other                    | 2002 - 2003 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2002 - 2003 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2002 - 2003 | OTC     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2003        | FOH     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 5.4L     | Other                    | 2003        | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003        | FOH     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2004 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x001B   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | OTC     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x00C5 0x0084 |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | TCM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2003 - 2005 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Excursion | 6.0L     | Direct Injection - Turbo | 2005        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.8L     | 2V                       | 2004        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.8L     | 2V                       | 2004 - 2005 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x001B   |
| Excursion | 6.8L     | 2V                       | 2004 - 2005 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.8L     | 2V                       | 2004 - 2005 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.8L     | 2V                       | 2004 - 2005 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Excursion | 6.8L     | 2V                       | 2004 - 2005 | HEC     | ●          | ●           | ●         | ●           | ○   |



| Vehicle    | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|--|
| Excursion  | 6.8L     | 2V   | 2004 - 2005 | OTC     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | 2V   | 2004 - 2005 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | 2V   | 2004 - 2005 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| Excursion  | 6.8L     | 2V   | 2004 - 2005 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084 |
| Excursion  | 6.8L     | 2V   | 2004 - 2005 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Excursion  | 6.8L     | 2V   | 2005        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2000        | MC      | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2000 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Excursion  | 6.8L     | Other  | 2000 - 2003 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2000 - 2003 | GEM     | ●          | ●           | ●         | ●           | 0x000F   |
| Excursion  | 6.8L     | Other  | 2000 - 2003 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2000 - 2003 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| Excursion  | 6.8L     | Other  | 2000 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084 |
| Excursion  | 6.8L     | Other  | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Excursion  | 6.8L     | Other  | 2002 - 2003 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2002 - 2003 | EATC    | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2002 - 2003 | OTC     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2003        | FOH     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 6.8L     | Other  | 2003        | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2000        | MC      | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2000 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2000 - 2003 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2000 - 2003 | GEM     | ●          | ●           | ●         | ●           | 0x000F   |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2000 - 2003 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2000 - 2003 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2000 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0025 0x0028 0x0031<br>0x0033 0x0080 0x0081 0x0082<br>0x0083               |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2002 - 2003 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2002 - 2003 | EATC    | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2002 - 2003 | OTC     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2003        | FOH     | ●          | ●           | ●         | ●           | ○  |
| Excursion  | 7.3L     | Direct Injection - Turbo                     | 2003        | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Expedition | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2016        | 4WAS    | ●          | ●           | ●         | ●           | 0x000E   |
| Expedition | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2016        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Expedition | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2016        | BCM#1   | ●          | ●           | ●         | ●           | 0x0009 0x00D4 0x0112   |

| Vehicle    | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| Expedition | 3. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2016        | BCM#27  | ●          | ●           | ●         | ●           | 0x00D5  |
| Expedition | 3. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2016        | CSM     | ●          | ●           | ●         | ●           | 0x000F  |
| Expedition | 3. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2016        | GEM /   | ●          | ●           | ●         | ●           | 0xF060  |
| Expedition | 3. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2016        | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0028<br>0x0031 0x0033 0x0067 0x0080<br>0x0081 0x0083 0x0084 0x0095<br>0x00AC |
| Expedition | 3. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2016        | RFA     | ●          | ●           | ●         | ●           | 0x0064  |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | DCSM    | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x0024           |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | PCSM    | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | RCM     | ●          | ●           | ●         | ●           | 0x000C  |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | TPM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | VDM     | ●          | ●           | ●         | ●           | 0x000E 0x0013 0x0014  |
| Expedition | 4. 6L    | 2V   | 2003 - 2004 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Expedition | 4. 6L    | Other  | 1997 - 1998 | IAB     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | Other  | 1997 - 1998 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Expedition | 4. 6L    | Other  | 1997 - 2000 | 4WAS    | ●          | ●           | ●         | ●           | 0x000E  |
| Expedition | 4. 6L    | Other  | 1997 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Expedition | 4. 6L    | Other  | 1997 - 2000 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | Other  | 1997 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084                  |
| Expedition | 4. 6L    | Other  | 1997 - 2000 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Expedition | 4. 6L    | Other  | 1998        | RCC     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | Other  | 1999 - 2000 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | Other  | 1999 - 2000 | HEC     | ●          | ●           | ●         | ●           | 0x0009  |
| Expedition | 4. 6L    | Other  | 1999 - 2000 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | Other  | 2000        | DSM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 4. 6L    | Other  | 2000        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 5. 4L    | 2V   | 2003 - 2004 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 5. 4L    | 2V   | 2003 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Expedition | 5. 4L    | 2V   | 2003 - 2004 | DCSM    | ●          | ●           | ●         | ●           | ○   |
| Expedition | 5. 4L    | 2V   | 2003 - 2004 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Expedition | 5. 4L    | 2V   | 2003 - 2004 | EATC    | ●          | ●           | ●         | ●           | ○   |

| Vehicle    | Capacity | EngineType | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|------------|----------|------------|-------------|--------|------------|-------------|-----------|-------------|--|
| Expedition | 5.4L     | 2V         | 2003 - 2004 | HEC    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 2V         | 2003 - 2004 | PAM    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 2V         | 2003 - 2004 | PCM    | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x0024                                |
| Expedition | 5.4L     | 2V         | 2003 - 2004 | PCSM   | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 2V         | 2003 - 2004 | RCM    | ●          | ●           | ●         | ●           | 0x000C   |
| Expedition | 5.4L     | 2V         | 2003 - 2004 | TPM    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 2V         | 2003 - 2004 | VDM    | ●          | ●           | ●         | ●           | 0x000E 0x0013 0x0014   |
| Expedition | 5.4L     | 2V         | 2003 - 2004 | VSM    | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Expedition | 5.4L     | 3V         | 2005 - 2006 | VSM    | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Expedition | 5.4L     | 3V         | 2005 - 2007 | EATC   | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2005 - 2010 | 4X4    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2005 - 2012 | PAM    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2005 - 2014 | ABS    | ●          | ●           | ●         | ●           | 0x0012 0x0008  |
| Expedition | 5.4L     | 3V         | 2005 - 2014 | DCSM   | ●          | ●           | ●         | ●           | 0xF070   |
| Expedition | 5.4L     | 3V         | 2005 - 2014 | DSM    | ●          | ●           | ●         | ●           | 0xF041 0xF06C 0xF06D 0xF06F  |
| Expedition | 5.4L     | 3V         | 2005 - 2014 | IC     | ●          | ●           | ●         | ●           | 0xF041 0xF044 0xF04A 0xF04D<br>0xF06B 0xF06E 0x0009  |
| Expedition | 5.4L     | 3V         | 2005 - 2014 | PCM    | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082<br>0x0083 0x0083 0x0084 0x0009<br>0x0010 0x0024 0x0025 0x0028<br>0x0031 0x0033 0x00C5 0x0067 |
| Expedition | 5.4L     | 3V         | 2005 - 2014 | RCM    | ●          | ●           | ●         | ●           | 0xF022 0xF05D 0x000C   |
| Expedition | 5.4L     | 3V         | 2005 - 2014 | VDM    | ●          | ●           | ●         | ●           | 0x000E 0x0013 0x0014   |
| Expedition | 5.4L     | 3V         | 2007        | GEM    | ●          | ●           | ●         | ●           | 0xF03C 0xF042 0xF049 0xF05C<br>0xF060 0xF068 0xF069 0xF06A   |
| Expedition | 5.4L     | 3V         | 2007 - 2011 | TCM    | ●          | ●           | ●         | ●           | 0x00CE   |
| Expedition | 5.4L     | 3V         | 2007 - 2012 | RETM   | ●          | ●           | ●         | ●           | 0xF04D 0xF05A  |
| Expedition | 5.4L     | 3V         | 2007 - 2014 | ACM    | ●          | ●           | ●         | ●           | 0x0016 0x0017 0x0018   |
| Expedition | 5.4L     | 3V         | 2007 - 2014 | DSP    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2007 - 2014 | LTM    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2007 - 2014 | RCU    | ●          | ●           | ●         | ●           | 0xF05A   |
| Expedition | 5.4L     | 3V         | 2007 - 2014 | SDARS  | ●          | ●           | ●         | ●           | 0x0019   |
| Expedition | 5.4L     | 3V         | 2008 - 2014 | GEM /  | ●          | ●           | ●         | ●           | 0x000F 0x0042 0x000A   |
| Expedition | 5.4L     | 3V         | 2008 - 2014 | HVAC   | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2008 - 2014 | PRB    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2009 - 2014 | APIM   | ●          | ●           | ●         | ●           | 0x0019 0x001C  |
| Expedition | 5.4L     | 3V         | 2010 - 2012 | GPSM   | ●          | ●           | ●         | ○           | ○  |
| Expedition | 5.4L     | 3V         | 2010 - 2014 | TCCM   | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | 3V         | 2013 - 2014 | TBC    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | Other      | 1997 - 1998 | IAB    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | Other      | 1997 - 1998 | PATS   | ●          | ●           | ●         | ●           | 0x0009   |

| Vehicle    | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|--|
| Expedition | 5.4L     | Other  | 1997 - 2000 | 4WAS    | ●          | ●           | ●         | ●           | 0x000E   |
| Expedition | 5.4L     | Other  | 1997 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Expedition | 5.4L     | Other  | 1997 - 2000 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | Other  | 1997 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 |
| Expedition | 5.4L     | Other  | 1997 - 2000 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Expedition | 5.4L     | Other  | 1998        | RCC     | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | Other  | 1999 - 2000 | EATC    | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | Other  | 1999 - 2000 | HEC     | ●          | ●           | ●         | ●           | 0x0009   |
| Expedition | 5.4L     | Other  | 1999 - 2000 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | Other  | 2000        | DSM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | 5.4L     | Other  | 2000        | PAM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | ABS     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | DCSM    | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | DSM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | DSP     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | GEM /   | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | IC      | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | LTM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | PCM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | PRB     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | RCU     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | SDARS   | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | TBC     | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | TCCM    | ●          | ●           | ●         | ●           | ○  |
| Expedition | Other    | Other  | 2013        | VDM     | ●          | ●           | ●         | ●           | ○  |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2012 | TPM     | ●          | ●           | ●         | ●           | ○  |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | ACM     | ●          | ●           | ●         | ○           | ○  |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | BCM#1   | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0x00D5<br>0x00FE 0x0009 0x00D4                                |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | C-CM    | ●          | ●           | ●         | ○           | 0x0046   |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | IPC     | ●          | ●           | ●         | ●           | 0x00D0   |
| Explorer   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | OCSM    | ●          | ●           | ●         | ●           | 0x000C   |

| Vehicle  | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|----------|----------|--|-------------|--------|------------|-------------|-----------|-------------|---|
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | PCM    | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0067 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0095 0x0024 0x0038 |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | SCCM   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | TCM    | ●          | ●           | ●         | ●           | 0x0038 0x0010 0x0028 0x0031<br>0x0033   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | APIM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | ATCM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | CLM#1  | ●          | ●           | ●         | ○           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | DCSM   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | DSM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | DSP    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | FLM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | GPSM   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | HSMW   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | HUD    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | LTM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | PAM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | PSCM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | RCM    | ●          | ●           | ●         | ○           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | RFA    | ●          | ●           | ●         | ●           | 0x0064  |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | RLCM-A | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | IPM-A  | ●          | ●           | ●         | ○           | 0x013E  |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | GFM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RTM    | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | ACM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | BCM#1  | ●          | ●           | ●         | ○           | 0x0009 0x000F 0x0042 0x00D4<br>0x00D5 0x00FE  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | C-CM   | ●          | ●           | ●         | ○           | 0x0046  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | FCDIM  | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | IPC    | ●          | ●           | ●         | ●           | 0x00D0  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | IPM-A  | ●          | ●           | ●         | ○           | 0x013E  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | OCSM   | ●          | ●           | ●         | ●           | 0x000C  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PCM    | ●          | ●           | ●         | ●           | 0x0010 0x0024 0x0028 0x0031<br>0x0033 0x0038 0x0067 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0095 0x0108        |

| Vehicle  | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCCM   | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | APIM   | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | ATCM   | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | CLM#1  | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DCSM   | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DSM    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DSP    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | FLM    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | GFM    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | GPSM   | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | HSWM   | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | HUD    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | LTM    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | PAM    | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | PSCM   | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RCM    | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RFA    | ●          | ●           | ●         | ●           | 0x0064   |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RLCM-A | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RTM    | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SOD-L  | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SOD-R  | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2012 | TPM    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | ACM    | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | BCM#1  | ●          | ●           | ●         | ●           | 0x0009 0x000F 0x0042 0x00D4<br>0x00D5 0x00FE 0x000A  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | C-CM   | ●          | ●           | ●         | ○           | 0x0046   |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | HVAC   | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | IPC    | ●          | ●           | ●         | ●           | 0x00D0   |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | OCSM   | ●          | ●           | ●         | ●           | 0x000C   |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | PCM    | ●          | ●           | ●         | ●           | 0x0024 0x0038 0x0067 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0095 0x0010 0x0023 0x0025<br>0x0028 0x0031 0x0033 0x0108 |
| Explorer | 3.5L     | TiVCT  | 2011 - 2013 | SCCM   | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2014 | APIM   | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2014 | ATCM   | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2014 | CLM#1  | ●          | ●           | ●         | ○           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2014 | DCSM   | ●          | ●           | ●         | ●           | ○  |
| Explorer | 3.5L     | TiVCT  | 2011 - 2014 | DSM    | ●          | ●           | ●         | ●           | ○  |

| Vehicle  | Capacity | EngineType | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|----------|----------|------------|-------------|--------|------------|-------------|-----------|-------------|---|
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | DSP    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | FLM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | GPSM   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | HSWM   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | HUD    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | LTM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | PAM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | PSCM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | RCM    | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | RFA    | ●          | ●           | ●         | ●           | 0x0064  |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | RLCM-A | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2011 - 2014 | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2013        | IPM-A  | ●          | ●           | ●         | ○           | 0x013E  |
| Explorer | 3.5L     | TiVCT      | 2013 - 2014 | GFM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.5L     | TiVCT      | 2013 - 2014 | RTM    | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013        | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Explorer | 3.7L     | TiVCT      | 2013        | ACM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013        | BCM#1  | ●          | ●           | ●         | ○           | 0x0009 0x000F 0x0042 0x00D4<br>0x00D5 0x00FE  |
| Explorer | 3.7L     | TiVCT      | 2013        | C-CM   | ●          | ●           | ●         | ○           | 0x0046  |
| Explorer | 3.7L     | TiVCT      | 2013        | FCDIM  | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013        | IPC    | ●          | ●           | ●         | ●           | 0x00D0  |
| Explorer | 3.7L     | TiVCT      | 2013        | IPM-A  | ●          | ●           | ●         | ○           | 0x013E  |
| Explorer | 3.7L     | TiVCT      | 2013        | OCSM   | ●          | ●           | ●         | ●           | 0x000C  |
| Explorer | 3.7L     | TiVCT      | 2013        | PCM    | ●          | ●           | ●         | ●           | 0x0010 0x0024 0x0028 0x0031<br>0x0033 0x0038 0x0067 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0095 |
| Explorer | 3.7L     | TiVCT      | 2013        | SCCM   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | APIM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | ATCM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | CLM#1  | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | DCSM   | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | DSM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | DSP    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | FLM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | GFM    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3.7L     | TiVCT      | 2013 - 2014 | GPSM   | ●          | ●           | ●         | ○           | ○   |

| Vehicle  | Capacity | EngineType | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|----------|----------|------------|-------------|-----------|------------|-------------|-----------|-------------|---|
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | HSWM      | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | HUD       | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | LTM       | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | PAM       | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | PSCM      | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | RCM       | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | RFA       | ●          | ●           | ●         | ●           | 0x0064  |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | RLCM-A    | ●          | ●           | ●         | ●           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | RTM       | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | SOD-L     | ●          | ●           | ●         | ○           | ○   |
| Explorer | 3. 7L    | TiVCT      | 2013 - 2014 | SOD-R     | ●          | ●           | ●         | ●           | ○   |
| Explorer | 4. 0L    | 2V         | 2006 - 2007 | EATC      | ●          | ●           | ●         | ●           | ○   |
| Explorer | 4. 0L    | 2V         | 2006 - 2007 | GEM       | ●          | ●           | ●         | ●           | 0x0005 0x000A 0x000F 0xF042 0xF044 0xF04C   |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | 4X4       | ●          | ●           | ●         | ●           | ○   |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | ABS       | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0012  |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | ACM       | ●          | ●           | ●         | ●           | 0x0005 0x0016 0x0017 0x0018 0xF05A 0xF073   |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | DSM       | ●          | ●           | ●         | ●           | 0xF041 0xF074 0xF075 0x0005   |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | IC        | ●          | ●           | ●         | ●           | 0x0009 0xF027 0xF040 0xF044 0xF04D 0xF054 0xF06B 0x0005   |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | OCSM      | ●          | ●           | ●         | ○           | 0x000C 0x0015 0x006D  |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | PAM       | ●          | ●           | ●         | ●           | ○   |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025 0x0028 0x0031 0x0033 0x0080 0x0081 0x0082 0x0083 0x0084 0x00C5 0x00C6 |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | PRB       | ●          | ●           | ●         | ●           | ○   |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022 0xF05D  |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | RETM      | ●          | ●           | ●         | ●           | 0xF04D 0xF05A 0xF076  |
| Explorer | 4. 0L    | 2V         | 2006 - 2010 | SDARS     | ●          | ●           | ●         | ●           | 0x0005 0x0019   |
| Explorer | 4. 0L    | 2V         | 2008 - 2010 | APIM      | ●          | ●           | ●         | ●           | 0x0019 0x001C   |
| Explorer | 4. 0L    | 2V         | 2008 - 2010 | GEM / SJB | ●          | ●           | ●         | ●           | 0x0005 0x000A 0x000F 0x0042 0xF042 0xF044 0xF04C  |
| Explorer | 4. 0L    | 2V         | 2008 - 2010 | HVAC      | ●          | ●           | ●         | ●           | 0x0005  |
| Explorer | 4. 0L    | 2V         | 2010        | GPSM      | ●          | ●           | ●         | ○           | ○   |
| Explorer | 4. 0L    | Other      | 1996 - 1998 | IAB       | ●          | ●           | ●         | ●           | ○   |
| Explorer | 4. 0L    | Other      | 1996 - 2000 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008  |
| Explorer | 4. 0L    | Other      | 1996 - 2000 | ARC       | ●          | ●           | ●         | ●           | 0x000E  |
| Explorer | 4. 0L    | Other      | 1996 - 2000 | EATC      | ●          | ●           | ●         | ●           | ○   |
| Explorer | 4. 0L    | Other      | 1996 - 2000 | GEM       | ●          | ●           | ●         | ●           | 0x0203 0x0204   |
| Explorer | 4. 0L    | Other      | 1996 - 2000 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083 0x0084  |
| Explorer | 4. 0L    | Other      | 1996 - 2000 | RAP       | ●          | ●           | ●         | ●           | 0x000F 0x000A   |



| Vehicle  | Capacity | EngineType | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------|----------|------------|-------------|---------|------------|-------------|-----------|-------------|--|
| Explorer | 4.0L     | Other      | 1998 - 2000 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | Other      | 1998 - 2000 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | Other      | 1998 - 2000 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| Explorer | 4.0L     | Other      | 1999 - 2000 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 OHV     | 1996 - 1998 | IAB     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 OHV     | 1996 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Explorer | 4.0L     | V6 OHV     | 1996 - 1999 | ARC     | ●          | ●           | ●         | ●           | 0x000E   |
| Explorer | 4.0L     | V6 OHV     | 1996 - 1999 | EATC    | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 OHV     | 1996 - 1999 | GEM     | ●          | ●           | ●         | ●           | 0x0203   |
| Explorer | 4.0L     | V6 OHV     | 1996 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083   |
| Explorer | 4.0L     | V6 OHV     | 1996 - 1999 | RAP     | ●          | ●           | ●         | ●           | 0x000F 0x000A  |
| Explorer | 4.0L     | V6 OHV     | 1998 - 1999 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 OHV     | 1998 - 1999 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 OHV     | 1998 - 1999 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| Explorer | 4.0L     | V6 OHV     | 1999        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 SOHC    | 1997 - 1998 | IAB     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 SOHC    | 1997 - 2000 | ARC     | ●          | ●           | ●         | ●           | 0x000E   |
| Explorer | 4.0L     | V6 SOHC    | 1997 - 2000 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Explorer | 4.0L     | V6 SOHC    | 1997 - 2002 | GEM     | ●          | ●           | ●         | ●           | 0x0203 0x0204  |
| Explorer | 4.0L     | V6 SOHC    | 1997 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Explorer | 4.0L     | V6 SOHC    | 1997 - 2005 | EATC    | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4.0L     | V6 SOHC    | 1997 - 2005 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 0x0009<br>0x00C6 0x0024 |
| Explorer | 4.0L     | V6 SOHC    | 1998 - 2000 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| Explorer | 4.0L     | V6 SOHC    | 1998 - 2005 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 SOHC    | 1998 - 2005 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 SOHC    | 1999        | MC      | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 SOHC    | 1999 - 2005 | RCM     | ●          | ●           | ●         | ●           | 0x000C 0x006D  |
| Explorer | 4.0L     | V6 SOHC    | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000F   |
| Explorer | 4.0L     | V6 SOHC    | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4.0L     | V6 SOHC    | 2002 - 2005 | 4X4     | ●          | ●           | ●         | ●           | 0x0111   |
| Explorer | 4.0L     | V6 SOHC    | 2002 - 2005 | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF044 0xF04D<br>0xF054 0xF071 0xF072  |
| Explorer | 4.0L     | V6 SOHC    | 2002 - 2005 | TPM     | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4.0L     | V6 SOHC    | 2003 - 2005 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Explorer | 4.0L     | V6 SOHC    | 2004 - 2005 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0012 0x0005   |
| Explorer | 4.6L     | 2V         | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000F   |
| Explorer | 4.6L     | 2V         | 2002        | GEM     | ●          | ●           | ●         | ●           | 0x0203 0x0204  |
| Explorer | 4.6L     | 2V         | 2002 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Explorer | 4.6L     | 2V         | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○  |

| Vehicle  | Capacity | EngineType | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|----------|----------|------------|-------------|-----------|------------|-------------|-----------|-------------|--|
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | DSM       | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | EATC      | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | IC        | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | PAM       | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | PCM       | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x00C6 0x0024 |
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | RCM       | ●          | ●           | ●         | ●           | 0x000C   |
| Explorer | 4. 6L    | 2V         | 2002 - 2005 | TPM       | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4. 6L    | 2V         | 2003 - 2005 | VSM       | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Explorer | 4. 6L    | 2V         | 2004 - 2005 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Explorer | 4. 6L    | 3V         | 2006 - 2007 | EATC      | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4. 6L    | 3V         | 2006 - 2007 | GEM       | ●          | ●           | ●         | ●           | 0x0005 0x000A 0x000F 0xF042<br>0xF044 0xF04C   |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | ABS       | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0012   |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | ACM       | ●          | ●           | ●         | ●           | 0x0005 0x0016 0x0017 0x0018<br>0xF04D 0xF05A 0xF073  |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | DSM       | ●          | ●           | ●         | ●           | 0x0005 0xF041 0xF074 0xF075  |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | IC        | ●          | ●           | ●         | ●           | 0x0009 0xF044 0x0005 0xF027<br>0xF04D 0xF054   |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | OCSM      | ●          | ●           | ●         | ○           | 0x000C 0x0015 0x006D   |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | PAM       | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x00C5 0x00C6 |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | PRB       | ●          | ●           | ●         | ●           | ○  |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022 0xF05D   |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | RETM      | ●          | ●           | ●         | ●           | 0x0005 0xF04D 0xF05A 0xF076  |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | SDARS     | ●          | ●           | ●         | ●           | 0x0005 0x0019  |
| Explorer | 4. 6L    | 3V         | 2006 - 2010 | TCM       | ●          | ●           | ●         | ●           | 0x00CE   |
| Explorer | 4. 6L    | 3V         | 2008 - 2010 | APIM      | ●          | ●           | ●         | ●           | 0x0019 0x001C  |
| Explorer | 4. 6L    | 3V         | 2008 - 2010 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0x0005<br>0xF042 0xF044 0xF04C  |
| Explorer | 4. 6L    | 3V         | 2008 - 2010 | HVAC      | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer | 4. 6L    | 3V         | 2010        | GPSM      | ●          | ●           | ●         | ○           | ○  |
| Explorer | 5. 0L    | Other      | 1996 - 1998 | IAB       | ●          | ●           | ●         | ●           | ○  |
| Explorer | 5. 0L    | Other      | 1996 - 2000 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008 0x0005  |
| Explorer | 5. 0L    | Other      | 1996 - 2000 | EATC      | ●          | ●           | ●         | ●           | ○  |
| Explorer | 5. 0L    | Other      | 1996 - 2000 | GEM       | ●          | ●           | ●         | ●           | 0x0203 0x0005 0x0204   |

| Vehicle            | Capacity | EngineType | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|--------------------|----------|------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Explorer           | 5.0L     | Other      | 1996 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084        |
| Explorer           | 5.0L     | Other      | 1996 - 2000 | RAP     | ●          | ●           | ●         | ●           | 0x000F 0x000A 0x0005 0xF044   |
| Explorer           | 5.0L     | Other      | 1997 - 2000 | ARC     | ●          | ●           | ●         | ●           | 0x000E  |
| Explorer           | 5.0L     | Other      | 1998 - 2000 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | 5.0L     | Other      | 1998 - 2000 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | 5.0L     | Other      | 1998 - 2000 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Explorer           | 5.0L     | Other      | 1999 - 2000 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | APIM    | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | ATCM    | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | CLM#1   | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | DCSM    | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | DSM     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | DSP     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | FCIM    | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | FLM     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | GFM     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | GPSM    | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | HSWM    | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | HUD     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | LTM     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | PSCM    | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | RCM     | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | RFA     | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | RLCM-A  | ●          | ●           | ●         | ●           | ○   |
| Explorer           | Other    | Other      | 2014        | RTM     | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | SOD-L   | ●          | ●           | ●         | ○           | ○   |
| Explorer           | Other    | Other      | 2014        | SOD-R   | ●          | ●           | ●         | ●           | ○   |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000        | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000 - 2003 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000 - 2003 | GEM     | ●          | ●           | ●         | ●           | 0x0203 0x0204   |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084 |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000 - 2003 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000 - 2003 | RCM     | ●          | ●           | ●         | ●           | 0x000C  |
| Explorer SportTrac | 4.0L     | 2V         | 2007        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Explorer SportTrac | 4.0L     | 2V         | 2007        | GEM     | ●          | ●           | ●         | ●           | 0x0005 0x000A 0x000F 0xF042<br>0xF044 0xF04C  |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | 4X4     | ●          | ●           | ●         | ●           | ○   |

| Vehicle            | Capacity | EngineType | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--------------------|----------|------------|-------------|-----------|------------|-------------|-----------|-------------|--|
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | ACM       | ●          | ●           | ●         | ●           | 0x0016 0x0017 0x0018   |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | IC        | ●          | ●           | ●         | ●           | 0x0009 0xF027 0xF040 0xF044<br>0xF04D 0xF054 0xF06B 0x0005   |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | OCSM      | ●          | ●           | ●         | ○           | 0x000C 0x0015 0x006D   |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | PAM       | ●          | ●           | ●         | ●           | ○  |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x00C5 0x00C6 |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022 0xF05D   |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | RETM      | ●          | ●           | ●         | ●           | 0xF04D 0xF05A  |
| Explorer SportTrac | 4.0L     | 2V         | 2007 - 2010 | SDARS     | ●          | ●           | ●         | ●           | 0x0005 0x0019  |
| Explorer SportTrac | 4.0L     | 2V         | 2008 - 2010 | APIM      | ●          | ●           | ●         | ●           | 0x0019 0x001C  |
| Explorer SportTrac | 4.0L     | 2V         | 2008 - 2010 | GEM / SJB | ●          | ●           | ●         | ●           | 0x0005 0x000A 0x000F 0x0042<br>0xF042 0xF044 0xF04C  |
| Explorer SportTrac | 4.0L     | 2V         | 2008 - 2010 | HVAC      | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer SportTrac | 4.0L     | 2V         | 2010        | GPSM      | ●          | ●           | ●         | ○           | ○  |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000 - 2003 | GEM       | ●          | ●           | ●         | ●           | 0x0203 0x0204  |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000 - 2005 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000 - 2005 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008   |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000 - 2005 | PCM       | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0024        |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000 - 2005 | RAP       | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000 - 2005 | RCM       | ●          | ●           | ●         | ●           | 0x000C   |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2004 - 2005 | HEC       | ●          | ●           | ●         | ●           | ○  |
| Explorer SportTrac | 4.6L     | 3V         | 2007        | EATC      | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer SportTrac | 4.6L     | 3V         | 2007        | GEM       | ●          | ●           | ●         | ●           | 0x0005 0x000A 0x000F 0xF042<br>0xF044 0xF04C   |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | ACM       | ●          | ●           | ●         | ●           | 0x0016 0x0017 0x0018 0x0005  |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | IC        | ●          | ●           | ●         | ●           | 0x0009 0xF044 0x0005 0xF027<br>0xF04D 0xF054   |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | OCSM      | ●          | ●           | ●         | ○           | 0x000C 0x0015 0x006D   |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | PAM       | ●          | ●           | ●         | ●           | 0x0005   |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x00C5 0x00C6 |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022 0xF05D   |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | RETM      | ●          | ●           | ●         | ●           | 0x0005 0xF04D 0xF05A   |
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | SDARS     | ●          | ●           | ●         | ●           | 0x0005 0x0019  |

| Vehicle            | Capacity | EngineType | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|--------------------|----------|------------|-------------|-----------|------------|-------------|-----------|-------------|---|
| Explorer SportTrac | 4.6L     | 3V         | 2007 - 2010 | TCM       | ●          | ●           | ●         | ●           | 0x00CE  |
| Explorer SportTrac | 4.6L     | 3V         | 2008 - 2010 | APIM      | ●          | ●           | ●         | ●           | 0x0019 0x001C                                       |
| Explorer SportTrac | 4.6L     | 3V         | 2008 - 2010 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0x0005<br>0xF042 0xF044 0xF04C |
| Explorer SportTrac | 4.6L     | 3V         | 2008 - 2010 | HVAC      | ●          | ●           | ●         | ●           | 0x0005  |
| Explorer SportTrac | 4.6L     | 3V         | 2010        | GPSM      | ●          | ●           | ●         | ○           | ○   |
| F-250 Light Duty   | 4.2L     | Other      | 1999        | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008  |
| F-250 Light Duty   | 4.2L     | Other      | 1999        | GEM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 4.2L     | Other      | 1999        | IC        | ●          | ●           | ●         | ●           | 0x0009  |
| F-250 Light Duty   | 4.2L     | Other      | 1999        | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083        |
| F-250 Light Duty   | 4.2L     | Other      | 1999        | RAP       | ●          | ●           | ●         | ●           | 0x000A 0x000F                                       |
| F-250 Light Duty   | 4.2L     | Other      | 1999        | RCM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 4.6L     | Other      | 1997 - 1998 | IAB       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 4.6L     | Other      | 1997 - 2000 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008  |
| F-250 Light Duty   | 4.6L     | Other      | 1997 - 2000 | GEM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 4.6L     | Other      | 1997 - 2000 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084 |
| F-250 Light Duty   | 4.6L     | Other      | 1997 - 2000 | RAP       | ●          | ●           | ●         | ●           | 0x000A  |
| F-250 Light Duty   | 4.6L     | Other      | 1999 - 2000 | IC        | ●          | ●           | ●         | ●           | 0x0009  |
| F-250 Light Duty   | 4.6L     | Other      | 1999 - 2000 | RCM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | BIF        | 1998        | IAB       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | BIF        | 1998 - 1999 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008  |
| F-250 Light Duty   | 5.4L     | BIF        | 1998 - 1999 | AFCM      | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | BIF        | 1998 - 1999 | GEM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | BIF        | 1998 - 1999 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082<br>0x0083               |
| F-250 Light Duty   | 5.4L     | BIF        | 1998 - 1999 | RAP       | ●          | ●           | ●         | ●           | 0x000A 0x000F                                       |
| F-250 Light Duty   | 5.4L     | BIF        | 1999        | IC        | ●          | ●           | ●         | ●           | 0x0009  |
| F-250 Light Duty   | 5.4L     | BIF        | 1999        | RCM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | NGV        | 1997 - 1998 | IAB       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | NGV        | 1997 - 2000 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008  |
| F-250 Light Duty   | 5.4L     | NGV        | 1997 - 2000 | FIM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | NGV        | 1997 - 2000 | GEM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | NGV        | 1997 - 2000 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082<br>0x0083 0x0084        |
| F-250 Light Duty   | 5.4L     | NGV        | 1997 - 2000 | RAP       | ●          | ●           | ●         | ●           | 0x000A 0x000F                                       |
| F-250 Light Duty   | 5.4L     | NGV        | 1999 - 2000 | IC        | ●          | ●           | ●         | ●           | 0x0009  |
| F-250 Light Duty   | 5.4L     | NGV        | 1999 - 2000 | RCM       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | Other      | 1997 - 1998 | IAB       | ●          | ●           | ●         | ●           | ○   |
| F-250 Light Duty   | 5.4L     | Other      | 1997 - 2000 | ABS/TCS   | ●          | ●           | ●         | ●           | 0x0008  |
| F-250 Light Duty   | 5.4L     | Other      | 1997 - 2000 | GEM       | ●          | ●           | ●         | ●           | ○   |

| Vehicle          | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|------------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| F-250 Light Duty | 5.4L     | Other  | 1997 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084 |
| F-250 Light Duty | 5.4L     | Other  | 1997 - 2000 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F                                       |
| F-250 Light Duty | 5.4L     | Other  | 1999 - 2000 | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| F-250 Light Duty | 5.4L     | Other  | 1999 - 2000 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | APIM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | DDM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | FCIM    | ●          | ●           | ●         | ○           | ○   |
| Fiesta           | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | GPSM    | ●          | ●           | ●         | ○           | ○   |
| Fiesta           | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | RCM     | ●          | ●           | ●         | ○           | ○   |
| Fiesta           | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | RFA     | ●          | ●           | ●         | ○           | ○   |
| Fiesta           | 1.0L     | Gasoline_Direct_injection                    | 2013        | APIM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.0L     | GTDI FGEC                                    | 2013        | APIM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.0L     | GTDI FGEC                                    | 2013        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00BC 0x0115        |
| Fiesta           | 1.0L     | GTDI FGEC                                    | 2013        | TCM     | ●          | ●           | ●         | ●           | 0x0117  |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                       |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF02D 0xF030 0xF0A2<br>0xF0B3               |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF020                                       |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2002 - 2008 | RCM     | ●          | ●           | ●         | ●           | 0x00F0 0x0102                                       |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2002 - 2013 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x00BC |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2006 - 2008 | ACM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2006 - 2008 | SRM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2008        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119 |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2008        | BCMii   | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2008        | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9  |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2008        | IPC     | ●          | ●           | ●         | ●           | 0x0009 0xF020                                       |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC                         |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2008        | RFA     | ●          | ●           | ●         | ○           | 0x000A  |
| Fiesta           | 1.25L    | DURATEC 16V                                  | 2013        | APIM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.3L     | BZ   | 2008        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119 |
| Fiesta           | 1.3L     | BZ   | 2008        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.3L     | BZ   | 2008        | BCMii   | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.3L     | BZ   | 2008        | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9  |
| Fiesta           | 1.3L     | BZ   | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Fiesta           | 1.3L     | BZ   | 2008        | IPC     | ●          | ●           | ●         | ●           | 0x0009  |

| Vehicle | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                  |
|---------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Fiesta  | 1.3L     | BZ  | 2008        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                      |
| Fiesta  | 1.3L     | BZ  | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC                      |
| Fiesta  | 1.3L     | BZ  | 2008        | RCM     | ●          | ●           | ●         | ○           | 0x00F0 0x0102                                    |
| Fiesta  | 1.3L     | BZ  | 2008        | RFA     | ●          | ●           | ●         | ○           | 0x000A   |
| Fiesta  | 1.3L     | BZ  | 2008        | SRM     | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2002 – 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                    |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2002 – 2006 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2002 – 2006 | IC      | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2002 – 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081 0x0082 0x0083        |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2002 – 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.3L     | DURATEC 8V                                  | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2002 – 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                    |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2002 – 2006 | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF02D 0xF030 0xF0A2 0xF0B3 0xF0B6        |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2002 – 2006 | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF020 0xF063 0xF0B5 0xF0B7               |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2002 – 2006 | TCM     | ●          | ●           | ●         | ●           | 0x003F   |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2002 – 2008 | RCM     | ●          | ●           | ●         | ●           | 0x00F0 0x0102                                    |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2002 – 2013 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081 0x0082 0x0083 0x00BC |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2006 – 2008 | ACM     | ●          | ●           | ●         | ●           | 0x0005   |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2006 – 2008 | SRM     | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039                             |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2008        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9 0x00DB 0x00E8 0x0119 |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2008        | BCMii   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2008        | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9   |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2008        | IPC     | ●          | ●           | ●         | ●           | 0x0009 0xF020                                    |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC                      |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2008        | RFA     | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.4L     | DURATEC 16V                                 | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 – 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                    |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 – 2006 | GEM     | ●          | ●           | ●         | ●           | 0xF02D 0xF030 0xF0A2 0xF0B3 0xF0B6 0xF0B7        |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 – 2006 | IC      | ●          | ●           | ●         | ●           | 0xF020 0xF063 0xF0B5 0xF0B7                      |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 – 2006 | TCM     | ●          | ●           | ●         | ●           | 0x003F   |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 – 2008 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082 0x0083               |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 – 2008 | RCM     | ●          | ●           | ●         | ●           | 0x00F0 0x0102                                    |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType                                       | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|---|
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2008 | ACM    | ●          | ●           | ●         | ●           | 0x0005  |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2008 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039                                |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119 |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | FCDIM  | ●          | ●           | ●         | ●           | 0x00E9  |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | IPC    | ●          | ●           | ●         | ●           | 0x0009 0xF020                                       |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | PSCM   | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC                         |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RFA    | ●          | ●           | ●         | ○           | 0x000A  |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2008        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8        |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | ACM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | FCDIM  | ●          | ●           | ●         | ●           | 0x00E9  |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | IPC    | ●          | ●           | ●         | ●           | 0x0009  |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083                         |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | PSCM   | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA                                |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RCM    | ●          | ●           | ●         | ○           | 0x00F0  |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RFA    | ●          | ●           | ●         | ○           | ○   |
| Fiesta  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | SRM    | ●          | ●           | ●         | ○           | ○   |
| Fiesta  | 1.5L     | BZ   | 2008        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119 |
| Fiesta  | 1.5L     | BZ   | 2008        | ACM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.5L     | BZ   | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.5L     | BZ   | 2008        | FCDIM  | ●          | ●           | ●         | ●           | 0x00E9  |
| Fiesta  | 1.5L     | BZ   | 2008        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.5L     | BZ   | 2008        | IPC    | ●          | ●           | ●         | ●           | 0x0009 0xF020                                       |
| Fiesta  | 1.5L     | BZ   | 2008        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                         |
| Fiesta  | 1.5L     | BZ   | 2008        | PSCM   | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC                         |
| Fiesta  | 1.5L     | BZ   | 2008        | RCM    | ●          | ●           | ●         | ○           | 0x00F0 0x0102                                       |
| Fiesta  | 1.5L     | BZ   | 2008        | RFA    | ●          | ●           | ●         | ○           | 0x000A  |
| Fiesta  | 1.5L     | BZ   | 2008        | SRM    | ●          | ●           | ●         | ○           | ○   |
| Fiesta  | 1.5L     | DURATEC 16V                                      | 2013        | APIM   | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.5L     | DURATEC 16V                                      | 2013        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                         |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119 |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | ACM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | FCDIM  | ●          | ●           | ●         | ●           | 0x00E9  |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | IPC    | ●          | ●           | ●         | ●           | 0x0009  |



| Vehicle | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | PCM     | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083<br>0x0092 0x0099 0x009A 0x00B4<br>0x00BC |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC  |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | RCM     | ●          | ●           | ●         | ○           | 0x00F0 0x0102  |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | RFA     | ●          | ●           | ●         | ○           | 0x000A   |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | SRM     | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.5L     | Duratorq Turbo Diesel Common Rail Injection | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119                  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | BCMii   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9   |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | IPC     | ●          | ●           | ●         | ●           | 0x0009   |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | RCM     | ●          | ●           | ●         | ○           | 0x00F0 0x0102  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | RFA     | ●          | ●           | ●         | ○           | 0x000A   |
| Fiesta  | 1.5L     | TiVCT                                       | 2008        | SRM     | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008 – 2013 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| Fiesta  | 1.5L     | TiVCT                                       | 2008 – 2013 | TCM     | ●          | ●           | ●         | ●           | 0x0117 0x0158  |
| Fiesta  | 1.5L     | TiVCT                                       | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.5L     | Zetec-SE                                    | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2002        | TCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2002 – 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2002 – 2006 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2002 – 2006 | IC      | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2002 – 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083                         |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2002 – 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC 16V                                 | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119                  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | BCMii   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9   |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | IPC     | ●          | ●           | ●         | ●           | 0x0009 0xF020  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | RCM     | ●          | ●           | ●         | ○           | 0x00F0 0x0102  |
| Fiesta  | 1.6L     | DURATEC VCT                                 | 2008        | RFA     | ●          | ●           | ●         | ○           | 0x000A   |

| Vehicle | Capacity | EngineType                                       | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|--|
| Fiesta  | 1.6L     | DURATEC VCT                                      | 2008        | SRM     | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | DURATEC VCT                                      | 2008 - 2013 | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x00BC   |
| Fiesta  | 1.6L     | DURATEC VCT                                      | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2002 - 2006 | EPS     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2002 - 2008 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083 0x0092 0x0096 0x0097<br>0x0099 0x009A 0x00AD 0x00AE<br>0x0090 0x0098 0x00AA 0x00B0<br>0x00B1 |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2002 - 2008 | RCM     | ●          | ●           | ●         | ●           | 0x00F0 0x0102  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2008 | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2008 | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | BCMii   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9   |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | IPC     | ●          | ●           | ●         | ●           | 0x0009 0xF020  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RFA     | ●          | ●           | ●         | ○           | 0x000A   |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2008        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | BCMii   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9   |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | IPC     | ●          | ●           | ●         | ●           | 0x0009 0xF020  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2008        | PCM     | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00AF 0x00B0 0x00B1<br>0x00B2 0x00B8 0x00B9 0x00BD           |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | PSCM    | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RCM     | ●          | ●           | ●         | ○           | 0x00F0   |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RFA     | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | SRM     | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013 - 2014 | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection     | 2014        | DDM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection     | 2014        | FCIM    | ●          | ●           | ●         | ○           | ○  |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| Fiesta  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | GPSM   | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | HVAC   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | RCM    | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | RFA    | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | ACM    | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | APIM   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | BCM#1  | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | GPSM   | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | IPC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | OCSM   | ●          | ●           | ●         | ○           | 0x000C   |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | PCM    | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0096 0x0097<br>0x009A 0x012B 0x020A 0x0211                                |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | PSCM   | ●          | ●           | ●         | ○           | 0x00CB 0x00CC 0x011E   |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | RCM    | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | RFA    | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | TBM    | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3   |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | TCM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | Sigma  | 2011 - 2012 | VSM    | ●          | ●           | ●         | ●           | 0x0042   |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0054 0x00D9<br>0x00DB 0x00E8 0x0119  |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | ACM    | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | FCDIM  | ●          | ●           | ●         | ●           | 0x00E9   |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | HVAC   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | IPC    | ●          | ●           | ●         | ●           | 0x0009   |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00AF 0x00B0 0x00B1<br>0x00B2 0x00B8 0x00BD 0x00C3 |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | PSCM   | ●          | ●           | ●         | ○           | 0x00D7 0x00D8 0x00DA 0x00DC  |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | RCM    | ●          | ●           | ●         | ○           | 0x00F0 0x0102  |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | RFA    | ●          | ●           | ●         | ○           | 0x000A   |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2008        | SRM    | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | TDCi ECO II                                  | 2013        | APIM   | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | TiVCT  | 2008        | BCMii  | ●          | ●           | ●         | ●           | ○  |
| Fiesta  | 1.6L     | TiVCT  | 2008        | SRM    | ●          | ●           | ●         | ○           | ○  |
| Fiesta  | 1.6L     | TiVCT  | 2008 - 2012 | PSCM   | ●          | ●           | ●         | ○           | 0x00CB 0x00CC 0x011E 0x00D7<br>0x00D8 0x00DA 0x00DC  |
| Fiesta  | 1.6L     | TiVCT  | 2008 - 2013 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0012 0x002B 0x002C<br>0x0054 0x00D9 0x00DB 0x00E8<br>0x0119   |

| Vehicle                     | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|-----------------------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|---|
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2013 | ACM     | ●          | ●           | ●         | ○           | ○   |
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2013 | FCDIM   | ●          | ●           | ●         | ●           | 0x00E9  |
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2013 | IPC     | ●          | ●           | ●         | ●           | 0x0009  |
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2013 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083 0x0084 0x0023 |
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2013 | TCM     | ●          | ●           | ●         | ●           | 0x0117  |
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2014 | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2014 | RCM     | ●          | ●           | ●         | ○           | 0x00F0 0x0102                                       |
| Fiesta                      | 1.6L     | TiVCT                                       | 2008 – 2014 | RFA     | ●          | ●           | ●         | ○           | 0x000A  |
| Fiesta                      | 1.6L     | TiVCT                                       | 2011 – 2013 | BCM#1   | ●          | ●           | ●         | ●           | ○   |
| Fiesta                      | 1.6L     | TiVCT                                       | 2011 – 2013 | OCSM    | ●          | ●           | ●         | ○           | 0x000C  |
| Fiesta                      | 1.6L     | TiVCT                                       | 2011 – 2013 | VSM     | ●          | ●           | ●         | ●           | 0x0042  |
| Fiesta                      | 1.6L     | TiVCT                                       | 2011 – 2014 | APIM    | ●          | ●           | ●         | ●           | ○   |
| Fiesta                      | 1.6L     | TiVCT                                       | 2011 – 2014 | GPSM    | ●          | ●           | ●         | ○           | ○   |
| Fiesta                      | 1.6L     | TiVCT                                       | 2014        | DDM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta                      | 1.6L     | TiVCT                                       | 2014        | FCIM    | ●          | ●           | ●         | ○           | ○   |
| Fiesta / Ikon               | 1 4 DV4  | Duratorq Turbo Diesel Common Rail Injection | 2006        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Fiesta / Ikon               | 1 4 DV4  | Duratorq Turbo Diesel Common Rail Injection | 2006        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1 4 DV4  | Duratorq Turbo Diesel Common Rail Injection | 2006        | IC      | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1 4 DV4  | Duratorq Turbo Diesel Common Rail Injection | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083               |
| Fiesta / Ikon               | 1 4 DV4  | Duratorq Turbo Diesel Common Rail Injection | 2006        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1.4L     | DURATEC 16V                                 | 2006        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Fiesta / Ikon               | 1.4L     | DURATEC 16V                                 | 2006        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1.4L     | DURATEC 16V                                 | 2006        | IC      | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1.4L     | DURATEC 16V                                 | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083        |
| Fiesta / Ikon               | 1.4L     | DURATEC 16V                                 | 2006        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1.6L     | DURATEC 16V                                 | 2006        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Fiesta / Ikon               | 1.6L     | DURATEC 16V                                 | 2006        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1.6L     | DURATEC 16V                                 | 2006        | IC      | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Ikon               | 1.6L     | DURATEC 16V                                 | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083               |
| Fiesta / Ikon               | 1.6L     | DURATEC 16V                                 | 2006        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | HCS   | 1996 – 1999 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | HCS   | 1996 – 1999 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | HCS   | 1996 – 1999 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | HCS   | 1996 – 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0023        |
| Fiesta / Mazda 121 / Bantam | 1.0L     | HCS   | 1999        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | Zetec Rocam                                 | 1999        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | Zetec Rocam                                 | 1999        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | Zetec Rocam                                 | 1999        | ECS     | ●          | ●           | ●         | ●           | ○   |

| Vehicle                     | Capacity | EngineType   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|-----------------------------|----------|--------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Fiesta / Mazda 121 / Bantam | 1.0L     | Zetec Rocam  | 1999        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | Zetec Rocam  | 1999        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.0L     | Zetec Rocam  | 1999        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083        |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE     | 1996 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE     | 1996 - 2000 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE     | 1996 - 2000 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE     | 1996 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE     | 1999 - 2000 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE     | 1999 - 2000 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE     | 2000        | PATS    | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.3L     | Endura-E     | 1996 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.3L     | Endura-E     | 1996 - 1999 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.3L     | Endura-E     | 1996 - 1999 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.3L     | Endura-E     | 1996 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 |
| Fiesta / Mazda 121 / Bantam | 1.3L     | Endura-E     | 1999        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.3L     | Endura-E     | 1999        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | 1.4 PT-E SFI | 1994 - 1996 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | 1.4 PT-E SFI | 1994 - 1996 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | 1.4 PT-E SFI | 1994 - 1996 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | PT-E         | 2000        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | PT-E         | 2000        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | PT-E         | 2000        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | PT-E         | 2000        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | PT-E         | 2000        | PCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | Zetec-SE     | 1996 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | Zetec-SE     | 1996 - 1999 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | Zetec-SE     | 1996 - 1999 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | Zetec-SE     | 1996 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 |
| Fiesta / Mazda 121 / Bantam | 1.4L     | Zetec-SE     | 1999        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.4L     | Zetec-SE     | 1999        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Other        | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Other        | 2001        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Other        | 2001        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Other        | 2001        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Other        | 2001        | PATS    | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Other        | 2001        | PCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec Rocam  | 1999        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec Rocam  | 1999        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec Rocam  | 1999        | ECS     | ●          | ●           | ●         | ●           | ○   |

| Vehicle                     | Capacity | EngineType  | Year         | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-----------------------------|----------|-------------|--------------|---------|------------|-------------|-----------|-------------|--|
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec Rocam | 1999         | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec Rocam | 1999         | HEC     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec Rocam | 1999         | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083               |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec-SE    | 2000         | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec-SE    | 2000         | CSM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec-SE    | 2000         | ECS     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec-SE    | 2000         | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec-SE    | 2000         | HEC     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec-SE    | 2000         | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084 |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | CSM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | ECS     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | FIP     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | HEC     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | PATS    | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI   | 2000         | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083                      |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura-DE   | 1996 - Other | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura-DE   | 1996 - Other | CSM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura-DE   | 1996 - Other | ECS     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura-DE   | 1996 - Other | HEC     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura-DE   | 1996 - Other | PATS    | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura-DE   | 1996 - Other | PCM     | ○          | ○           | ●         | ○           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Zetec       | 1992 - 1994  | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Zetec       | 1992 - 1994  | CSM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Zetec       | 1992 - 1994  | HEC     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2002 - 2006  | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2002 - 2006  | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF02D 0xF030 0xF0A2<br>0xF0B3                      |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2002 - 2006  | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF020  |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2002 - 2006  | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083               |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2002 - 2006  | RCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2006         | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2006         | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door               | 1.25L    | DURATEC 16V | 2006         | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door               | 1.3L     | DURATEC 8V  | 2002 - 2006  | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fiesta 3-Door               | 1.3L     | DURATEC 8V  | 2002 - 2006  | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door               | 1.3L     | DURATEC 8V  | 2002 - 2006  | IC      | ●          | ●           | ●         | ●           | ○  |

| Vehicle       | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                              |
|---------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Fiesta 3-Door | 1.3L     | DURATEC 8V                                  | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 |
| Fiesta 3-Door | 1.3L     | DURATEC 8V                                  | 2002 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.3L     | DURATEC 8V                                  | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.3L     | DURATEC 8V                                  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.3L     | DURATEC 8V                                  | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF02D 0xF030 0xF0A2<br>0xF0B3 0xF0B6 |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF020 0xF063 0xF0B5<br>0xF0B7        |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2002 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2002 - 2006 | TCM     | ●          | ●           | ●         | ●           | 0x003F                                       |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2006        | ACM     | ●          | ●           | ●         | ●           | 0x0005                                       |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.4L     | DURATEC 16V                                 | 2006        | SRM     | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039                         |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0xF02D 0xF030 0xF0A2 0xF0B3<br>0xF0B6 0xF0B7 |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | 0xF020 0xF063 0xF0B5 0xF0B7                  |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083        |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | TCM     | ●          | ●           | ●         | ●           | 0x003F                                       |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | ACM     | ●          | ●           | ●         | ●           | 0x0005                                       |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | SRM     | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039                         |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2002        | TCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2002 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | DURATEC 16V                                 | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012                                |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | EPS     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | ○  |

| Vehicle       | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083 0x0092 0x0096 0x0097<br>0x0099 0x009A 0x00AD 0x00AE |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2002 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2006        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2006        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Fiesta 3-Door | 2.0L     | DURATEC-HE / I4                              | 2006        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0119                                       |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | AHCM    | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | APIM    | ●          | ●           | ●         | ●           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | CCMii   | ●          | ●           | ●         | ●           | 0x00F9  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | DDM     | ●          | ●           | ●         | ○           | 0x0140  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | DSP     | ●          | ●           | ●         | ○           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FCIM    | ●          | ●           | ●         | ●           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FDSM    | ●          | ●           | ●         | ○           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | HCM     | ●          | ●           | ●         | ○           | 0x0032  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | HVAC    | ●          | ●           | ●         | ○           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPC     | ●          | ●           | ●         | ●           | 0xF020  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-B   | ●          | ●           | ●         | ○           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x009A 0x00BC 0x00C3 0x0114                                |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PDM     | ●          | ●           | ●         | ○           | 0x0141  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PSCM    | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RCM     | ●          | ●           | ●         | ●           | 0x0102  |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RFA     | ●          | ●           | ●         | ○           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SASM    | ●          | ●           | ●         | ○           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-L   | ●          | ●           | ●         | ●           | ○   |
| Focus         | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-R   | ●          | ●           | ●         | ●           | ○   |



| Vehicle | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|--|
| Focus   | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | TRM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003        | RL_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003        | RR_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2007 | GDM     | ●          | ●           | ●         | ●           | 0x0100   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2007 | NAV     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x00DD 0x00DE 0x00E8<br>0x002B 0x00EB 0x00EC |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | ACM     | ●          | ●           | ●         | ●           | 0x011A   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | CDP     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | D_DCU   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | EATC    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | FFH     | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | GEM     | ●          | ●           | ●         | ●           | 0x00ED   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | HCM     | ●          | ●           | ●         | ●           | 0x0156 0x0155  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | IC      | ●          | ●           | ●         | ●           | 0x0009   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | P_DCU   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | PAM     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0025  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | RCM     | ●          | ●           | ●         | ●           | 0x00EA   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | RETM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | RKE     | ●          | ●           | ●         | ●           | 0x000A   |
| Focus   | 1.4L     | DURATEC 16V                                  | 2003 - 2008 | SRM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2008        | CMR     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | DURATEC 16V                                  | 2008        | EPS     | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 1999        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 1999        | CTM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 1999 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1 0x0008 0x0012   |
| Focus   | 1.4L     | Zetec-SE                                     | 1999 - 2002 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 1999 - 2002 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 1999 - 2002 | MC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 1999 - 2002 | PATS    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 1999 - 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x000A<br>0x0084               |
| Focus   | 1.4L     | Zetec-SE                                     | 2002        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 2002        | GEM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.4L     | Zetec-SE                                     | 2002        | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| Focus   | 1.4L     | Zetec-SE                                     | 2002        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | BZ   | 2005        | ABS     | ●          | ●           | ●         | ●           | 0x0012 0x0029 0x002A 0x002C<br>0x0054  |

| Vehicle | Capacity | EngineType  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|-------------|-------------|--------|------------|-------------|-----------|-------------|---|
| Focus   | 1. 6L    | BZ          | 2005        | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | BZ          | 2005        | EATC   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | BZ          | 2005        | GEM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | BZ          | 2005        | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156   |
| Focus   | 1. 6L    | BZ          | 2005        | IC     | ●          | ●           | ●         | ●           | 0x0009  |
| Focus   | 1. 6L    | BZ          | 2005        | P_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | BZ          | 2005        | PAM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | BZ          | 2005        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00C5 0x00C6  |
| Focus   | 1. 6L    | BZ          | 2005        | RCM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | BZ          | 2005        | RL_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | BZ          | 2005        | RR_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | DURATEC 16V | 2003        | RL_DCU | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 1. 6L    | DURATEC 16V | 2003        | RR_DCU | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100 0x0005   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2007 | RETM   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x00DD 0x00DE 0x00E8<br>0x0005 0x002B 0x00EB 0x00EC                         |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | ACM    | ●          | ●           | ●         | ●           | 0x011A 0x0005   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | D_DCU  | ●          | ●           | ●         | ●           | 0xF026  |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF026 0xF02D<br>0xF02E 0xF02F 0xF030 0xF032<br>0xF035 0xF03A 0xF03B 0xF03C<br>0xF03D 0xF033 0xF034 |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | HCM    | ●          | ●           | ●         | ●           | 0x0156 0x0005 0x0155  |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0xF01E 0xF020 0xF028<br>0xF032 0xF03E  |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | P_DCU  | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | PAM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0025   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | RCM    | ●          | ●           | ●         | ●           | 0xF027 0xF031   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | RKE    | ●          | ●           | ●         | ●           | 0x0005 0x000A   |
| Focus   | 1. 6L    | DURATEC 16V | 2003 – 2008 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039  |
| Focus   | 1. 6L    | DURATEC 16V | 2006 – 2008 | FTCM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | DURATEC 16V | 2007        | TCM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | DURATEC 16V | 2008        | EPS    | ●          | ●           | ●         | ○           | 0x0005  |
| Focus   | 1. 6L    | DURATEC VCT | 2003        | RL_DCU | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|-------------|-------------|--------|------------|-------------|-----------|-------------|--|
| Focus   | 1. 6L    | DURATEC VCT | 2003        | RR_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2007 | NAV    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | GEM    | ●          | ●           | ●         | ●           | 0x00ED 0x0005 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF033<br>0xF034 0xF035 0xF03A 0xF03B<br>0xF03C 0xF03D               |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF020<br>0xF028 0xF032 0xF036 0xF03E   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2008 | RKE    | ●          | ●           | ●         | ●           | 0x000A 0x0005  |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2011 | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0119 0x0008<br>0x0029 0x002A 0x0030 0x00DD<br>0x00DE 0x00EB 0x0005 0x00EC |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2011 | ACM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032 0x0155 0x0156   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2011 | PAM    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00BC 0x0116 0x0117 0x0025   |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2011 | RCM    | ●          | ●           | ●         | ●           | 0x0102 0x00EA 0xF027 0xF031  |
| Focus   | 1. 6L    | DURATEC VCT | 2003 – 2011 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039   |
| Focus   | 1. 6L    | DURATEC VCT | 2008        | CMR    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2008        | EPS    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | APIM   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101   |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | DDM    | ●          | ●           | ●         | ○           | 0x00FB 0x0140  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | DSP    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | FCIM   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | FDSM   | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | HVAC   | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | IPC    | ●          | ●           | ●         | ●           | 0xF020   |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1. 6L    | DURATEC VCT | 2011        | PDM    | ●          | ●           | ●         | ○           | 0x00FC 0x0141  |

| Vehicle | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| Focus   | 1.6L     | DURATEC VCT                                 | 2011        | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1   |
| Focus   | 1.6L     | DURATEC VCT                                 | 2011        | RFA    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | DURATEC VCT                                 | 2011        | SASM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | DURATEC VCT                                 | 2011        | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | DURATEC VCT                                 | 2011        | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | DURATEC VCT                                 | 2011        | TCM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | DURATEC VCT                                 | 2011        | TRM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003        | RL_DCU | ●          | ●           | ●         | ●           | 0xF026  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003        | RR_DCU | ●          | ●           | ●         | ●           | 0xF026  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0005 0x0100   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | D_DCU  | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | EPS    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | FACM   | ●          | ●           | ●         | ●           | 0x0005 0x006B 0x0094 0x00A1   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x00ED 0xF026 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF035<br>0xF03A 0xF03B 0xF03C 0xF03D   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0xF01E 0xF020 0xF028<br>0xF032 0xF03E  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x0005 0x000A   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | ABS    | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0029 0x002A<br>0x002B 0x002C 0x0030 0x00E8<br>0x00DD 0x00DE 0x00EB 0x00EC<br>0x0053 0x00D9 0x00DB 0x0119                                |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | ACM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | HCM    | ●          | ●           | ●         | ●           | 0x0005 0x0155 0x0156 0x0032   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | PAM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0096 0x0097<br>0x0098 0x0099 0x009A 0x020A<br>0x00B1 0x00B3 0x00B7 0x00B9<br>0x00BC 0x00BD 0x00C1 0x00C3 |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | RCM    | ●          | ●           | ●         | ●           | 0xF027 0xF031 0x00EA 0x0102   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | APIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |

| Vehicle | Capacity | EngineType                                       | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|------|--------|------------|-------------|-----------|-------------|--|
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | DDM    | ●          | ●           | ●         | ○           | 0x0140   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | DSP    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | FCIM   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | FDSM   | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | HVAC   | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | IPC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | PDM    | ●          | ●           | ●         | ○           | 0x0141   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1                                    |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | RFA    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | SASM   | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | SOD-L  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | SOD-R  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2011 | TRM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0029 0x002A 0x002C 0x0030 0x00DD 0x00DE 0x00E8 |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | ACM    | ●          | ●           | ●         | ●           | 0x0005 0x011A  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | CMR    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | EPS    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | GEM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | HCM    | ●          | ●           | ●         | ○           | 0x0155 0x0156  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | PAM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                                    |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | RCM    | ●          | ●           | ●         | ●           | 0x00EA   |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | RETM   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | RKE    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | SRM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 | TCM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection     | 2011 | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9 0x00DB 0x00E8 0x0119               |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection     | 2011 | ACM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection     | 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection     | 2011 | APIM   | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101  |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | CCMii   | ●          | ●           | ●         | ●           | 0x00F9  |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | DDM     | ●          | ●           | ●         | ○           | 0x00FB 0x0140   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | DSP     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FCIM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FDSM    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | HCM     | ●          | ●           | ●         | ○           | 0x0032  |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | HVAC    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5  |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-B   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PCM     | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083<br>0x009A 0x00BC 0x00C3 0x0114                                |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PDM     | ●          | ●           | ●         | ○           | 0x00FC 0x0141   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PSCM    | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RCM     | ●          | ●           | ●         | ●           | 0x0102  |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RFA     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SASM    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-L   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-R   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2007 - 2009 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0012 0x0008   |
| Focus   | 1.6L     | FFV  | 2007 - 2010 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2007 - 2010 | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| Focus   | 1.6L     | FFV  | 2007 - 2010 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0096<br>0x0097 0x009A 0x00AB 0x020A |
| Focus   | 1.6L     | FFV  | 2007 - 2010 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2009        | MC      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2009 - 2010 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2009 - 2010 | HCM     | ●          | ●           | ●         | ●           | 0x0032 0x0155   |
| Focus   | 1.6L     | FFV  | 2010        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x0053 0x00DD 0x00DE<br>0x00EB 0x00EC               |
| Focus   | 1.6L     | FFV  | 2010        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2010        | D_DCU   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2010        | EPS     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1.6L     | FFV  | 2010        | P_DCU   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2010        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1.6L     | FFV  | 2010        | RKE     | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType   | Year | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--------------|------|---------|------------|-------------|-----------|-------------|---|
| Focus   | 1. 6L    | FFV          | 2010 | SRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | FFV          | 2010 | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3  |
| Focus   | 1. 6L    | FFV          | 2010 | TCM     | ●          | ●           | ●         | ●           | 0x0070 0x00C5   |
| Focus   | 1. 6L    | OHC          | 2009 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0012  |
| Focus   | 1. 6L    | OHC          | 2009 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | OHC          | 2009 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | OHC          | 2009 | HCM     | ●          | ●           | ●         | ●           | 0x0032  |
| Focus   | 1. 6L    | OHC          | 2009 | IC      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | OHC          | 2009 | MC      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | OHC          | 2009 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0025 0x0080<br>0x0081 0x0082 0x0083                         |
| Focus   | 1. 6L    | OHC          | 2009 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x0053 0x00DD 0x00DE<br>0x00EB 0x00EC |
| Focus   | 1. 6L    | Sigma        | 2010 | ACM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | D_DCU   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | EATC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | EPS     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | HCM     | ●          | ●           | ●         | ○           | 0x0155  |
| Focus   | 1. 6L    | Sigma        | 2010 | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| Focus   | 1. 6L    | Sigma        | 2010 | P_DCU   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0096 0x0097 0x009A 0x00AB<br>0x020A        |
| Focus   | 1. 6L    | Sigma        | 2010 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | RKE     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | SRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Sigma        | 2010 | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3  |
| Focus   | 1. 6L    | Sigma        | 2010 | TCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0119                         |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | ACM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | AHCM    | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | APIM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101  |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | CCMii   | ●          | ●           | ●         | ●           | 0x00F9  |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | DDM     | ●          | ●           | ●         | ○           | 0x0140  |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | DSP     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011 | FCIM    | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Focus   | 1. 6L    | TDCi ECO III | 2011        | FDSM    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | HCM     | ●          | ●           | ●         | ○           | 0x0032  |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | HVAC    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5  |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | IPM-B   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0098 0x00AF 0x00B0<br>0x00B2 0x00B8 0x00BD 0x00C3 |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | PDM     | ●          | ●           | ●         | ○           | 0x0141  |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | PSCM    | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | RCM     | ●          | ●           | ●         | ●           | 0x0102  |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | RFA     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | SASM    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | SOD-L   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | SOD-R   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | TDCi ECO III | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 1999        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 1999        | CTM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 1999        | PATS    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | Zetec        | 1999 – 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1 0x0008 0x0012  |
| Focus   | 1. 6L    | Zetec        | 1999 – 2002 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 1999 – 2002 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 1999 – 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0023 0x0025<br>0x0080 0x0081 0x0082 0x0083<br>0x0084                      |
| Focus   | 1. 6L    | Zetec        | 2002        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 2002        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 2002        | HCM     | ●          | ●           | ●         | ●           | 0x0032  |
| Focus   | 1. 6L    | Zetec        | 2002        | MC      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec        | 2002        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | HCM     | ●          | ●           | ●         | ●           | 0x0032  |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | MC      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec Rocam  | 2002        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0023 0x0025<br>0x0080 0x0081 0x0082 0x0083<br>0x0084                      |



| Vehicle | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Focus   | 1. 6L    | Zetec Rocam     | 2002        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 1999        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 1999        | CTM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 1999 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1 0x0008 0x0012  |
| Focus   | 1. 6L    | Zetec-SE        | 1999 - 2002 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 1999 - 2002 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 1999 - 2002 | MC      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 1999 - 2002 | PATS    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 1999 - 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 0x000A<br>0x0084  |
| Focus   | 1. 6L    | Zetec-SE        | 2002        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 2002        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 6L    | Zetec-SE        | 2002        | HCM     | ●          | ●           | ●         | ●           | 0x0032  |
| Focus   | 1. 6L    | Zetec-SE        | 2002        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2005 | RL_DCU  | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2005 | RR_DCU  | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2007 | GDM     | ●          | ●           | ●         | ●           | 0x0100  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2007 | NAV     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2007 | TCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002B<br>0x002C 0x0030 0x00E8 0x0005<br>0x0012 0x0054 0x00DD 0x00DE<br>0x00EB 0x00EC                                |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | ACM     | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | CDP     | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | D_DCU   | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | EATC    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | EPS     | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | FFH     | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | GEM     | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF025 0xF026<br>0xF02B 0xF02C 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF035<br>0xF03A 0xF033 0xF034 0xF03B<br>0xF03C 0xF03D |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | HCM     | ●          | ●           | ●         | ●           | 0x0155 0x0156 0x0005  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | IC      | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF020<br>0xF028 0xF029 0xF032 0xF03E<br>0xF03F 0xF040 0xF036  |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | P_DCU   | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083   |
| Focus   | 1. 8L    | DURATEC-HE / I4 | 2003 - 2008 | RCM     | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF031 0x00EA   |

| Vehicle | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Focus   | 1.8L     | DURATEC-HE / I4                             | 2003 - 2008 | RETM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.8L     | DURATEC-HE / I4                             | 2003 - 2008 | RKE     | ●          | ●           | ●         | ●           | 0x000A   |
| Focus   | 1.8L     | DURATEC-HE / I4                             | 2003 - 2008 | SRM     | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039   |
| Focus   | 1.8L     | DURATEC-HE / I4                             | 2008        | CMR     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | CTM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2002 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2002 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2002 | ICU     | ○          | ○           | ●         | ○           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2002 | MC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2008 | FFH     | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2008 | PCM     | ●          | ●           | ●         | ●           | 0x006F 0x0080 0x0081 0x0082<br>0x0083 0x00B4   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | EATC    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | GEM     | ●          | ●           | ●         | ●           | 0x00ED 0x0005 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF033<br>0xF034 0xF035 0xF03A 0xF03B<br>0xF03C 0xF03D |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | HCM     | ●          | ●           | ●         | ●           | 0x0155 0x0156  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RCM     | ●          | ●           | ●         | ●           | 0x00EA 0xF027 0xF031   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003        | RL_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003        | RR_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2007 | GDM     | ●          | ●           | ●         | ●           | 0x0100   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2007 | NAV     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002B<br>0x002C 0x0030 0x00E8 0x00DD<br>0x00DE 0x00EB 0x00EC 0x0005                  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | ACM     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | CDP     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | D_DCU   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | EPS     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | IC      | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF020<br>0xF028 0xF032 0xF036 0xF03E   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | P_DCU   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | PAM     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | RETM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | RKE     | ●          | ●           | ●         | ●           | 0x000A 0x0005  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | SRM     | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039   |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | CMR     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | FACM    | ●          | ●           | ●         | ●           | 0x0005 0x006B  |
| Focus   | 1.8L     | Endura DI                                   | 1999        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1.8L     | Endura DI                                   | 1999        | CTM     | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|--|
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1 0x0008 0x0012                                       |
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | FFH     | ●          | ●           | ●         | ●           | 0x00CF   |
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | FIP     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | MC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | PATS    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1. 8L    | Endura DI       | 1999 - 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0080 0x0081<br>0x0082 0x0083               |
| Focus   | 1. 8L    | Endura DI       | 2002        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Endura DI       | 2002        | GEM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Endura DI       | 2002        | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| Focus   | 1. 8L    | Endura DI       | 2002        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 1999        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 1999        | CTM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 1999        | PATS    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 1. 8L    | Zetec           | 1999 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1   |
| Focus   | 1. 8L    | Zetec           | 1999 - 2002 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 1999 - 2002 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 1999 - 2002 | MC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 1999 - 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0084 0x0009 0x0023 0x0025 |
| Focus   | 1. 8L    | Zetec           | 2002        | AFCM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 2002        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 2002        | GEM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 2002        | HCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 1. 8L    | Zetec           | 2002        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | GEM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | IC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | MC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0023 0x0025<br>0x0080 0x0081 0x0082 0x0083 |
| Focus   | 2. 0L    | DURATEC 16V     | 2005        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC-HE / I4 | 2003        | RL_DCU  | ●          | ●           | ●         | ●           | 0x0005 0xF026  |
| Focus   | 2. 0L    | DURATEC-HE / I4 | 2003        | RR_DCU  | ●          | ●           | ●         | ●           | 0x0005 0xF026  |
| Focus   | 2. 0L    | DURATEC-HE / I4 | 2003 - 2007 | GDM     | ●          | ●           | ●         | ●           | 0x0100   |
| Focus   | 2. 0L    | DURATEC-HE / I4 | 2003 - 2007 | NAV     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC-HE / I4 | 2003 - 2007 | RETM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2. 0L    | DURATEC-HE / I4 | 2003 - 2008 | CDP     | ●          | ●           | ●         | ●           | 0x0005   |

| Vehicle | Capacity | EngineType                                  | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|---|-------------|-----------|------------|-------------|-----------|-------------|---|
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | D_DCU     | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | EATC      | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | EPS       | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | FFH       | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | GEM       | ●          | ●           | ●         | ●           | 0x000A 0x0005 0x00ED 0xF025<br>0xF026 0xF02A 0xF02B 0xF02C<br>0xF02D 0xF02E 0xF02F 0xF030<br>0xF032 0xF035 0xF03A 0xF031<br>0xF034 0xF03B 0xF03C 0xF03D |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | HCM       | ●          | ●           | ●         | ●           | 0x0005 0x0155 0x0156  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | P_DCU     | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | PAM       | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | RKE       | ●          | ●           | ●         | ●           | 0x000A 0x0005   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2008 | SRM       | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2011 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012 0x0029 0x002A<br>0x002B 0x002C 0x0030 0x00DD<br>0x00DE 0x00E8 0x00EB 0x00EC<br>0x0005   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2011 | ACM       | ●          | ●           | ●         | ●           | 0x0005 0x0017 0x0018 0xF021<br>0xF05A 0xF078 0xF079 0xF07A<br>0xF07B 0xF07C 0xF07D  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2011 | IC        | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF027 0xF020   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2011 | PCM       | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0024 0x0025<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 0x00C5   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003 - 2011 | RCM       | ●          | ●           | ●         | ●           | 0x000C 0x0005 0xF027 0xF031<br>0xF022 0xF05D  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2006 - 2008 | FTCM      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2008        | SDARS     | ●          | ●           | ●         | ●           | 0xF062  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2008 - 2011 | APIM      | ●          | ●           | ●         | ○           | 0x0019 0x001C   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2008 - 2011 | FCIM      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2008 - 2011 | FDIM      | ●          | ●           | ●         | ●           | 0x0005 0xF05A 0xF078  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2008 - 2011 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0xF042<br>0xF04B 0xF04C  |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2008 - 2011 | HVAC      | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2008 - 2011 | OCSM      | ●          | ●           | ●         | ○           | 0x000C 0x006D   |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2010 - 2011 | GPSM      | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2005 | RL_DCU    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2005 | RR_DCU    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2007 | GDM       | ●          | ●           | ●         | ●           | 0x0005 0x0100   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2007 | NAV       | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2007 | RETM      | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | CDP       | ●          | ●           | ●         | ●           | 0x0005  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | D_DCU     | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---|-------------|--------|------------|-------------|-----------|-------------|--|
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | EPS    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | FACM   | ●          | ●           | ●         | ●           | 0x0005 0x006B 0x0094 0x00A1  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF026 0xF02D<br>0xF02E 0xF02F 0xF030 0xF032<br>0xF035 0xF03A 0xF03B 0xF03C<br>0xF03D  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x0005 0x000A  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0119 0x0005<br>0x0008 0x0029 0x002A 0x0030<br>0x00DD 0x00DE 0x00EB 0x00EC<br>0x0012 0x0054  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | ACM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032 0x0155 0x0156   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | PAM    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00A4 0x00B0 0x00B1<br>0x00B3 0x00B7 0x00B8 0x00B9<br>0x00BC 0x00BF 0x00C1 0x00E7<br>0x0115 0x0116 0x013B 0x00AB |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | RCM    | ●          | ●           | ●         | ●           | 0x0102 0xF027 0xF031   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2003 - 2011 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF039 0xF03F   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2008 | FTCM   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | APIM   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | DDM    | ●          | ●           | ●         | ○           | 0x0140   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | DSP    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | FCIM   | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | FDSM   | ●          | ●           | ●         | ○           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | HVAC   | ●          | ●           | ●         | ○           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | PDM    | ●          | ●           | ●         | ○           | 0x0141   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1  |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | RFA    | ●          | ●           | ●         | ○           | ○  |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|---|
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection  | 2011        | SASM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection  | 2011        | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection  | 2011        | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection  | 2011        | TCM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Duratorq Turbo Diesel Common Rail Injection  | 2011        | TRM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FDSM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SRM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | TRM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | ACM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | FCDIM  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | IPC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | IPM-B  | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | PCM    | ●          | ●           | ●         | ●           | 0x0024 0x0067 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x0095                  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | PSCM   | ●          | ●           | ●         | ○           | 0x00CB 0x00CC 0x00DC 0x00DF<br>0x00E0 0x00E1                                |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | ABS    | ●          | ●           | ●         | ○           | 0x0012 0x002B 0x002C 0x0053<br>0x00D9 0x00DB 0x00E8 0x0119                  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | APIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | DDM    | ●          | ●           | ●         | ●           | 0x0140  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | DSP    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | FCIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | ICM#1  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | PAM    | ●          | ●           | ○         | ○           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | PDM    | ●          | ●           | ●         | ●           | 0x0141  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | RCM    | ●          | ●           | ●         | ○           | 0x0102  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | RFA    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2014 | SASM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | BCM#1  | ●          | ●           | ●         | ●           | 0x00D5 0x0101   |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | OCSM   | ●          | ●           | ●         | ●           | 0x000C  |
| Focus   | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | GPSM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | FFV  | 2010        | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x0053 0x00DD 0x00DE<br>0x00EB 0x00EC |
| Focus   | 2.0L     | FFV  | 2010        | ACM    | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType                | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|---------------------------|------|--------|------------|-------------|-----------|-------------|---|
| Focus   | 2.0L     | FFV                       | 2010 | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | EATC   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | EPS    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | GEM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | HCM    | ●          | ●           | ●         | ○           | 0x0155  |
| Focus   | 2.0L     | FFV                       | 2010 | IC     | ●          | ●           | ●         | ●           | 0x0009  |
| Focus   | 2.0L     | FFV                       | 2010 | P_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | PAM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | PCM    | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0096 0x0097 0x009A<br>0x00AB 0x020A |
| Focus   | 2.0L     | FFV                       | 2010 | RCM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | RKE    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | SRM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | FFV                       | 2010 | TBM    | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3  |
| Focus   | 2.0L     | FFV                       | 2010 | TCM    | ●          | ●           | ●         | ●           | 0x0070 0x00C5   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0119                         |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | APIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | CCMi   | ●          | ●           | ●         | ●           | 0x00F9  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | DDM    | ●          | ●           | ●         | ○           | 0x0140  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | DSP    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | FCDIM  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | FCIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | FDSM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | HVAC   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | IPM-B  | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | PAM    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | PDM    | ●          | ●           | ●         | ○           | 0x0141  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | RCM    | ●          | ●           | ●         | ●           | 0x0102  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | RFA    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | SASM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | SRM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | TCM    | ●          | ●           | ●         | ●           | 0x0117  |
| Focus   | 2.0L     | Gasoline Direct injection | 2011 | TRM    | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType                | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|---------------------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | AHCM    | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x00D5 0x0101  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | CCMii   | ●          | ●           | ●         | ●           | 0x00F9  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | FDSM    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | HCM     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | PCM     | ●          | ●           | ●         | ●           | 0x0067 0x0080 0x0081 0x0082<br>0x0083 0x0115 0x0116                         |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | SOD-L   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | SOD-R   | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2012 | IPC     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2012 | IPM-B   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2012 | PSCM    | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2012 | TCM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | ABS     | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0119 0x0012                  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | APIM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | DDM     | ●          | ●           | ●         | ○           | 0x0140  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | DSP     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | FCIM    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | HVAC    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | PAM     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | PDM     | ●          | ●           | ●         | ○           | 0x0141  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | RCM     | ●          | ●           | ●         | ●           | 0x0102  |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | RFA     | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2011 - 2014 | SASM    | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | Gasoline_Direct_injection | 2012 - 2014 | GPSPM   | ●          | ●           | ●         | ○           | ○   |
| Focus   | 2.0L     | SPI                       | 2000        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | SPI                       | 2000        | CTM     | ●          | ●           | ●         | ●           | 0x000A  |
| Focus   | 2.0L     | SPI                       | 2000 - 2002 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | SPI                       | 2000 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Focus   | 2.0L     | SPI                       | 2000 - 2004 | HEC     | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | SPI                       | 2000 - 2004 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x000A 0x0024 |
| Focus   | 2.0L     | SPI                       | 2002        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Focus   | 2.0L     | SPI                       | 2002        | HCM     | ●          | ●           | ●         | ●           | 0x0032  |
| Focus   | 2.0L     | SPI                       | 2002        | MC      | ●          | ●           | ●         | ●           | ○   |



| Vehicle | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|--|
| Focus   | 2.0L     | SPI             | 2002 - 2004 | GEM     | ●          | ●           | ●         | ●           | 0x000A   |
| Focus   | 2.0L     | SPI             | 2002 - 2004 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Zetec           | 1999        | PATS    | ●          | ●           | ●         | ○           | ○  |
| Focus   | 2.0L     | Zetec           | 1999 - 2000 | CSM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Zetec           | 1999 - 2000 | CTM     | ●          | ●           | ●         | ●           | 0x000A   |
| Focus   | 2.0L     | Zetec           | 1999 - 2002 | ECS     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Zetec           | 1999 - 2002 | MC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Zetec           | 1999 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1 0x0008 0x0012   |
| Focus   | 2.0L     | Zetec           | 1999 - 2004 | HEC     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.0L     | Zetec           | 1999 - 2004 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0024 |
| Focus   | 2.0L     | Zetec           | 2002        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Zetec           | 2002        | HCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | Zetec           | 2002 - 2004 | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF02D 0xF02F 0xF030<br>0xF03A 0xF09E 0xF0A1 0xF0A4<br>0x000A |
| Focus   | 2.0L     | Zetec           | 2002 - 2004 | RCM     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.0L     | ZETEC ST        | 2002        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | ZETEC ST        | 2002        | ECS     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | ZETEC ST        | 2002        | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| Focus   | 2.0L     | ZETEC ST        | 2002        | MC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | ZETEC ST        | 2002 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Focus   | 2.0L     | ZETEC ST        | 2002 - 2004 | GEM     | ●          | ●           | ●         | ●           | 0x000A   |
| Focus   | 2.0L     | ZETEC ST        | 2002 - 2004 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.0L     | ZETEC ST        | 2002 - 2004 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0024 |
| Focus   | 2.0L     | ZETEC ST        | 2002 - 2004 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003 - 2007 | GEM     | ●          | ●           | ●         | ●           | 0x000A   |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003 - 2007 | IC      | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003 - 2007 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0024 |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003 - 2007 | RCM     | ●          | ●           | ●         | ●           | 0x000C   |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2004        | HEC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2005 - 2007 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Focus   | 2.5L     | Duratec RS      | 2008        | ABS     | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0029 0x002A<br>0x00EB 0x00EC                         |
| Focus   | 2.5L     | Duratec RS      | 2008        | ACM     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | Duratec RS      | 2008        | CDP     | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | Duratec RS      | 2008        | CMR     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | Duratec RS      | 2008        | D_DCU   | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|------------|-------------|--------|------------|-------------|-----------|-------------|--|
| Focus   | 2.5L     | Duratec RS | 2008        | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | Duratec RS | 2008        | EPS    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus   | 2.5L     | Duratec RS | 2008        | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus   | 2.5L     | Duratec RS | 2008        | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF033<br>0xF034 0xF035 0xF03A 0xF03B<br>0xF03C 0xF03D |
| Focus   | 2.5L     | Duratec RS | 2008        | HCM    | ●          | ●           | ●         | ○           | 0x0155 0x0156  |
| Focus   | 2.5L     | Duratec RS | 2008        | IC     | ●          | ●           | ●         | ●           | 0x0005 0x0009 0x0113 0xF01E<br>0xF020 0xF028 0xF032 0xF036<br>0xF03E                                       |
| Focus   | 2.5L     | Duratec RS | 2008        | MC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | Duratec RS | 2008        | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | Duratec RS | 2008        | PAM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | Duratec RS | 2008        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| Focus   | 2.5L     | Duratec RS | 2008        | RCM    | ●          | ●           | ●         | ●           | 0x00EA 0xF027 0xF031   |
| Focus   | 2.5L     | Duratec RS | 2008        | RETM   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | Duratec RS | 2008        | RKE    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | Duratec RS | 2008        | SRM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003        | RL_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003        | RR_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003 – 2007 | GDM    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003 – 2007 | NAV    | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x00DD 0x00DE 0x00E8<br>0x00EB 0x00EC                                |
| Focus   | 2.5L     | I5         | 2003 – 2008 | ACM    | ●          | ●           | ●         | ●           | 0x011A 0x0005  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | I5         | 2003 – 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | I5         | 2003 – 2008 | EPS    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus   | 2.5L     | I5         | 2003 – 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | HCM    | ●          | ●           | ●         | ○           | 0x0156 0x0155  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009   |
| Focus   | 2.5L     | I5         | 2003 – 2008 | MC     | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | PAM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | I5         | 2003 – 2008 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | RCM    | ●          | ●           | ●         | ●           | 0x0005 0x00EA  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus   | 2.5L     | I5         | 2003 – 2008 | RKE    | ●          | ●           | ●         | ●           | 0x0005 0x000A  |
| Focus   | 2.5L     | I5         | 2003 – 2008 | SRM    | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType               | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function             |
|---------|----------|--------------------------|-------------|--------|------------|-------------|-----------|-------------|-----------------------------|
| Focus   | 2.5L     | I5                       | 2008        | CMR    | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012        | ACCM#2 | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012        | BCCM   | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012        | BCM#1  | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012        | IPM-B  | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012        | OCSM   | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012        | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083 |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012        | PSCM   | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2013 | ACM    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2013 | FCDIM  | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2013 | IPC    | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2013 | TCM    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | ABS    | ●          | ●           | ●         | ○           | 0x0012 0x0074 0x010A        |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | APIM   | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | BECM   | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | DCDC   | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | DDM    | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | DSP    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | GFM    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | GPSM   | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | GWM    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | HCM    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | HVAC   | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | PAM    | ●          | ●           | ○         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | PDM    | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | RCM    | ●          | ●           | ●         | ○           | 0x00EF                      |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | RFA    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | SASM   | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | SOBDM  | ●          | ●           | ●         | ●           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2012 - 2014 | TCU#1  | ●          | ●           | ●         | ○           | ○                           |
| Focus   | 23kWh    | Battery_Electric_Vehicle | 2013        | BCM i  | ●          | ●           | ●         | ●           | 0x0101                      |
| Focus   | Other    | Other                    | 2013        | ABS    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | Other    | Other                    | 2013        | ACM    | ●          | ●           | ●         | ●           | ○                           |
| Focus   | Other    | Other                    | 2013        | APIM   | ●          | ●           | ●         | ●           | ○                           |
| Focus   | Other    | Other                    | 2013        | BCM#1  | ●          | ●           | ●         | ●           | 0x00D5 0x0101               |
| Focus   | Other    | Other                    | 2013        | DDM    | ●          | ●           | ●         | ●           | ○                           |
| Focus   | Other    | Other                    | 2013        | DSP    | ●          | ●           | ●         | ○           | ○                           |
| Focus   | Other    | Other                    | 2013        | FCDIM  | ●          | ●           | ●         | ●           | ○                           |
| Focus   | Other    | Other                    | 2013        | FCIM   | ●          | ●           | ●         | ●           | ○                           |
| Focus   | Other    | Other                    | 2013        | GPSM   | ●          | ●           | ●         | ○           | ○                           |

| Vehicle     | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-------------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| Focus       | Other    | Other  | 2013        | HVAC   | ●          | ●           | ●         | ●           | ○  |
| Focus       | Other    | Other  | 2013        | IPC    | ●          | ●           | ●         | ●           | ○  |
| Focus       | Other    | Other  | 2013        | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus       | Other    | Other  | 2013        | OCSM   | ●          | ●           | ●         | ●           | ○  |
| Focus       | Other    | Other  | 2013        | PAM    | ●          | ●           | ○         | ○           | ○  |
| Focus       | Other    | Other  | 2013        | PDM    | ●          | ●           | ●         | ●           | ○  |
| Focus       | Other    | Other  | 2013        | PSCM   | ●          | ●           | ●         | ○           | 0x00CB 0x00CC  |
| Focus       | Other    | Other  | 2013        | RCM    | ●          | ●           | ●         | ○           | ○  |
| Focus       | Other    | Other  | 2013        | RFA    | ●          | ●           | ●         | ○           | ○  |
| Focus       | Other    | Other  | 2013        | SASM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8                         |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | DDM    | ●          | ●           | ●         | ○           | 0x00FB 0x0140  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | FDSM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | HCM    | ●          | ●           | ●         | ○           | 0x0032   |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | HVAC   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPC    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PAM    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PDM    | ●          | ●           | ●         | ○           | 0x00FC 0x0141  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RCM    | ●          | ●           | ●         | ●           | 0x0102   |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RFA    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SASM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SRM    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | TRM    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002        | RL_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002        | RR_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002 - 2007 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x00DD 0x00DE 0x00E8<br>0x002B |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002 - 2007 | ACM    | ●          | ●           | ●         | ●           | 0x011A   |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002 - 2007 | CDP    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002 - 2007 | D_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002 - 2007 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 1.4L     | DURATEC 16V                                  | 2002 - 2007 | EPB    | ●          | ●           | ●         | ●           | 0x001F   |

| Vehicle     | Capacity | EngineType  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-------------|----------|-------------|-------------|--------|------------|-------------|-----------|-------------|---|
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100  |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | GEM    | ●          | ●           | ●         | ●           | 0x00ED  |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156   |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | IC     | ●          | ●           | ●         | ●           | 0x0009  |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | P_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | PAM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0025   |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | RCM    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | RETM   | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | RKE    | ●          | ●           | ●         | ●           | 0x000A  |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2002 - 2007 | SRM    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002        | RL_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002        | RR_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2007 | EPB    | ●          | ●           | ●         | ●           | 0x001F  |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100 0x0005   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002C<br>0x0030 0x00DD 0x00DE 0x00E8<br>0x0005 0x002B 0x00EB 0x00EC                         |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | ACM    | ●          | ●           | ●         | ●           | 0x011A 0x0005   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF026 0xF02D<br>0xF02E 0xF02F 0xF030 0xF032<br>0xF035 0xF03A 0xF03B 0xF03C<br>0xF03D 0xF033 0xF034 |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF020<br>0xF028 0xF032 0xF03E   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | PAM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0025   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | RCM    | ●          | ●           | ●         | ●           | 0xF027 0xF031 0x00EA  |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x0005 0x000A   |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002 - 2008 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039  |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |

| Vehicle     | Capacity | EngineType  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-------------|----------|-------------|-------------|--------|------------|-------------|-----------|-------------|--|
| Focus C-MAX | 1. 6L    | DURATEC 16V | 2008        | EPS    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002        | RL_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002        | RR_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2007 | EPB    | ●          | ●           | ●         | ●           | 0x001F   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2007 | NAV    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | GEM    | ●          | ●           | ●         | ●           | 0x00ED 0x0005 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF033<br>0xF034 0xF035 0xF03A 0xF03B<br>0xF03C 0xF03D |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF020<br>0xF028 0xF032 0xF036 0xF03E   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2008 | RKE    | ●          | ●           | ●         | ●           | 0x000A 0x0005  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2011 | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0008 0x0029<br>0x002A 0x0030 0x00DD 0x00DE<br>0x00EB        |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2011 | ACM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032 0x0155 0x0156   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2011 | PAM    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00BC 0x0116 0x0117 0x0025   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2011 | RCM    | ●          | ●           | ●         | ●           | 0x0102 0x00EA 0xF027 0xF031  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2002 – 2011 | SRM    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2008        | CMR    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2008        | EPS    | ●          | ●           | ●         | ○           | 0x0005   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | BCM i  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | DDM    | ●          | ●           | ●         | ○           | 0x00FB 0x0140  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | FDSM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | HVAC   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | IPC    | ●          | ●           | ●         | ●           | 0xF020   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | PDM    | ●          | ●           | ●         | ○           | 0x00FC 0x0141  |
| Focus C-MAX | 1. 6L    | DURATEC VCT | 2011        | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1  |

| Vehicle     | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-------------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| Focus C-MAX | 1. 6L    | DURATEC VCT                                 | 2011        | RFA    | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX | 1. 6L    | DURATEC VCT                                 | 2011        | RGTM   | ●          | ●           | ●         | ●           | 0x00FD 0x013D   |
| Focus C-MAX | 1. 6L    | DURATEC VCT                                 | 2011        | SASM   | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX | 1. 6L    | DURATEC VCT                                 | 2011        | SOD-L  | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX | 1. 6L    | DURATEC VCT                                 | 2011        | SOD-R  | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX | 1. 6L    | DURATEC VCT                                 | 2011        | TRM    | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002        | RL_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002        | RR_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | EPB    | ●          | ●           | ●         | ●           | 0x001F  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0005 0x0100   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | TCM    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | EATC   | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | EPS    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | FACM   | ●          | ●           | ●         | ●           | 0x0005 0x006B 0x0094 0x00A1   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x00ED 0xF026 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF035<br>0xF03A 0xF03B 0xF03C 0xF03D   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x0005 0x000A   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | ABS    | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0029 0x002A<br>0x002B 0x002C 0x0030 0x00E8<br>0x00DD 0x00DE 0x00EB 0x00EC<br>0x0053 0x00D9 0x00DB                                       |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | ACM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156 0x0032  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | PAM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0096 0x0097<br>0x0098 0x0099 0x009A 0x020A<br>0x00B1 0x00B3 0x00B9 0x00BC<br>0x00BD 0x00C1 0x00C3 0x00E7 |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | RCM    | ●          | ●           | ●         | ●           | 0xF027 0xF031 0x00EA 0x0102   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | BCMii  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | DDM    | ●          | ●           | ●         | ○           | 0x00FB 0x0140   |

| Vehicle     | Capacity | EngineType                                   | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-------------|----------|--|------|--------|------------|-------------|-----------|-------------|--|
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | FDSM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | HVAC   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | IPC    | ●          | ●           | ●         | ●           | 0xF020   |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | PDM    | ●          | ●           | ●         | ○           | 0x00FC 0x0141  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1                                |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | RFA    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | RGTM   | ●          | ●           | ●         | ●           | 0x00FD 0x013D  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | SASM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | SOD-L  | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | SOD-R  | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | TRM    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8               |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | ACM    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | BCMii  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | DDM    | ●          | ●           | ●         | ○           | 0x00FB 0x0140  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | FDSM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032   |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | HVAC   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | IPC    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | IPM-B  | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PAM    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083<br>0x009A 0x00BC 0x00C3 0x0114 |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PDM    | ●          | ●           | ●         | ○           | 0x00FC 0x0141  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PSCM   | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1                                |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | RCM    | ●          | ●           | ●         | ●           | 0x0102   |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | RFA    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | RGTM   | ●          | ●           | ●         | ●           | 0x00FD 0x013D  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SASM   | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SRM    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | TRM    | ●          | ●           | ●         | ○           | ○  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                              | 2002 | RL_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                              | 2002 | RR_DCU | ●          | ●           | ●         | ●           | ○  |



| Vehicle     | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-------------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2007 | EPB    | ●          | ●           | ●         | ●           | 0x001F  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2007 | TCM    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002B<br>0x002C 0x0030 0x00E8 0x00DD<br>0x00DE 0x00EB   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | ACM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | EPS    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF025 0xF026<br>0xF02B 0xF02C 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF035<br>0xF03A 0xF033 0xF034 0xF03B<br>0xF03C 0xF03D |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF020<br>0xF028 0xF032 0xF036 0xF03E  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | PAM    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | PCM    | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | RCM    | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF031 0x00EA   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x000A  |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2002 - 2008 | SRM    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                             | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002        | RL_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002        | RR_DCU | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | EPB    | ●          | ●           | ●         | ●           | 0x001F  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002B<br>0x002C 0x0030 0x00E8 0x00DD<br>0x00DE 0x00EB 0x00EC 0x0005   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | ACM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | EPS    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |

| Vehicle     | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-------------|----------|---|-------------|--------|------------|-------------|-----------|-------------|--|
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x00ED 0x0005 0xF02D 0xF02E<br>0xF02F 0xF030 0xF032 0xF034<br>0xF035 0xF03A 0xF03B 0xF03C<br>0xF03D  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF020<br>0xF028 0xF032 0xF03E  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | PAM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | PCM    | ●          | ●           | ●         | ●           | 0x006F 0x0080 0x0081 0x0082<br>0x0083 0x00B4   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RCM    | ●          | ●           | ●         | ●           | 0x00EA 0xF027 0xF031   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x000A 0x0005  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | SRM    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | CMR    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | FACM   | ●          | ●           | ●         | ●           | 0x0005 0x006B  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002        | RL_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002        | RR_DCU | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2007 | EPB    | ●          | ●           | ●         | ●           | 0x001F   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0100   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002B<br>0x002C 0x0030 0x00DD 0x00DE<br>0x00E8 0x00EB 0x00EC 0x0005  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | ACM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | EPS    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF025 0xF026<br>0xF02A 0xF02B 0xF02C 0xF02D<br>0xF02E 0xF02F 0xF030 0xF032<br>0xF035 0xF03A 0xF031 0xF034<br>0xF03B 0xF03C 0xF03D |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF01E 0xF028<br>0xF032 0xF03E   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | PAM    | ●          | ●           | ●         | ●           | 0x0005   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | PCM    | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | RCM    | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF031 0x00EA  |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005   |

| Vehicle     | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-------------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x000A 0x0005   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2002 - 2008 | SRM    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                             | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002        | RL_DCU | ●          | ●           | ●         | ●           | 0xF026  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002        | RR_DCU | ●          | ●           | ●         | ●           | 0xF026  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | EPB    | ●          | ●           | ●         | ●           | 0x0005 0x001F 0xF0B8  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | GDM    | ●          | ●           | ●         | ●           | 0x0005 0x0100   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | NAV    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | D_DCU  | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | EPS    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | FACM   | ●          | ●           | ●         | ●           | 0x0005 0x006B 0x0094 0x00A1   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF026 0xF02D<br>0xF02E 0xF02F 0xF030 0xF032<br>0xF035 0xF03A 0xF03B 0xF03C<br>0xF03D   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | IC     | ●          | ●           | ●         | ●           | 0x0009 0xF01E 0xF020 0xF028<br>0xF032 0xF03E  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | P_DCU  | ●          | ●           | ●         | ●           | 0x0005 0xF026   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2008 | RKE    | ●          | ●           | ●         | ●           | 0x0005 0x000A   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | ABS    | ●          | ●           | ●         | ○           | 0x002B 0x002C 0x0053 0x00D9<br>0x00DB 0x00E8 0x0005 0x0008<br>0x0029 0x002A 0x0030 0x00DD<br>0x00DE 0x00EB 0x00EC   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | ACM    | ●          | ●           | ●         | ●           | 0x0005  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032 0x0155 0x0156  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | PAM    | ●          | ●           | ●         | ○           | 0x0005  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00A4 0x00B0 0x00B1<br>0x00B3 0x00B7 0x00B8 0x00B9<br>0x00BC 0x00BF 0x00C1 0x00E7<br>0x0116 0x013B 0x00AB |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | RCM    | ●          | ●           | ●         | ●           | 0x0102 0xF027 0xF031 0x00EA   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2011 | SRM    | ●          | ●           | ●         | ●           | 0xF037 0xF039 0xF03F  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2008 - 2011 | TCM    | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | BCMii  | ●          | ●           | ●         | ●           | ○   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | DDM    | ●          | ●           | ●         | ○           | 0x00FB 0x0140   |
| Focus C-MAX | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | FCDIM  | ●          | ●           | ●         | ●           | ○   |

| Vehicle             | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|---------------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|---|
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | FDSM    | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | HVAC    | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPC     | ●          | ●           | ●         | ●           | 0xF020  |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5  |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPM-B   | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | PDM     | ●          | ●           | ●         | ○           | 0x00FC 0x0141                                       |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | PSCM    | ●          | ●           | ●         | ○           | 0x00DC 0x00DF 0x00E0 0x00E1                         |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | RFA     | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | RGTM    | ●          | ●           | ●         | ●           | 0x00FD 0x013D                                       |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | SASM    | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | SOD-L   | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | SOD-R   | ●          | ●           | ●         | ○           | ○   |
| Focus C-MAX         | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | TRM     | ●          | ●           | ●         | ○           | ○   |
| FORD GT             | 5.4L     | 4V  | 2005 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| FORD GT             | 5.4L     | 4V  | 2005 - 2006 | AFCM    | ●          | ●           | ●         | ●           | ○   |
| FORD GT             | 5.4L     | 4V  | 2005 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0x000A  |
| FORD GT             | 5.4L     | 4V  | 2005 - 2006 | IC      | ●          | ●           | ●         | ●           | ○   |
| FORD GT             | 5.4L     | 4V  | 2005 - 2006 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| FORD GT             | 5.4L     | 4V  | 2005 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0024 0x0025 0x0080<br>0x0081 0x0082 0x0083 |
| FORD GT             | 5.4L     | 4V  | 2005 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | FOH     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | GEM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | HEC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | OTC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | PAM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                         |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | RCM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Direct Injection - Turbo                    | 2003        | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F                                       |
| F-Series Super Duty | 4.2L     | Other                                       | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| F-Series Super Duty | 4.2L     | Other                                       | 2001        | ECS     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Other                                       | 2001        | GEM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Other                                       | 2001        | OTC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Other                                       | 2001        | PAM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 4.2L     | Other                                       | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084 |
| F-Series Super Duty | 4.2L     | Other                                       | 2001        | RCM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | 2V  | 2004        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x001B                                       |
| F-Series Super Duty | 5.4L     | 2V  | 2004        | HEC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | 2V  | 2004        | OTC     | ●          | ●           | ●         | ●           | ○   |

| Vehicle             | Capacity | EngineType | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------------------|----------|------------|-------------|-----------|------------|-------------|-----------|-------------|--|
| F-Series Super Duty | 5.4L     | 2V         | 2004        | PATS      | ●          | ●           | ●         | ●           | 0x0009   |
| F-Series Super Duty | 5.4L     | 2V         | 2004 - 2006 | GEM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2004 - 2006 | VSM       | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| F-Series Super Duty | 5.4L     | 2V         | 2004 - 2008 | PAM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2004 - 2008 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084                         |
| F-Series Super Duty | 5.4L     | 2V         | 2004 - 2008 | RCM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2005 - 2006 | EATC      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2005 - 2008 | ABS       | ●          | ●           | ●         | ●           | 0x0008   |
| F-Series Super Duty | 5.4L     | 2V         | 2005 - 2008 | IC        | ●          | ●           | ●         | ●           | 0x0009   |
| F-Series Super Duty | 5.4L     | 2V         | 2005 - 2008 | TBC       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2008        | 4X4       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2008        | ACM       | ●          | ●           | ●         | ●           | 0x0016 0x0017 0x0018   |
| F-Series Super Duty | 5.4L     | 2V         | 2008        | DSM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2008        | GEM /     | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042   |
| F-Series Super Duty | 5.4L     | 2V         | 2008        | HVAC      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2008        | RETM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 2V         | 2008        | SDARS     | ●          | ●           | ●         | ●           | 0x0019   |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2007 | EATC      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2007 | GEM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2007 | VSM       | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2010 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0005  |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2010 | IC        | ●          | ●           | ●         | ●           | 0x0009 0x0005 0xF027 0xF04D<br>0xF07E  |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2010 | PAM       | ●          | ●           | ●         | ●           | 0x0005   |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2010 | PCM       | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x00C5        |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2010 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022  |
| F-Series Super Duty | 5.4L     | 3V         | 2005 - 2010 | TBC       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 3V         | 2008 - 2010 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 3V         | 2008 - 2010 | ACM       | ●          | ●           | ●         | ●           | 0x0016 0x0017 0x0018   |
| F-Series Super Duty | 5.4L     | 3V         | 2008 - 2010 | DSM       | ●          | ●           | ●         | ●           | 0x0005 0xF041  |
| F-Series Super Duty | 5.4L     | 3V         | 2008 - 2010 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0xF042<br>0xF048 0xF049 0xF04B 0xF04C<br>0xF05C 0xF065 0xF06A 0xF080<br>0xF081 0xF0B0 |
| F-Series Super Duty | 5.4L     | 3V         | 2008 - 2010 | HVAC      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 5.4L     | 3V         | 2008 - 2010 | RETM      | ●          | ●           | ●         | ●           | 0x0005 0xF04D 0xF05A   |
| F-Series Super Duty | 5.4L     | 3V         | 2008 - 2010 | SDARS     | ●          | ●           | ●         | ●           | 0x0019 0x0005 0xF07F   |
| F-Series Super Duty | 5.4L     | 3V         | 2009 - 2010 | APIM      | ●          | ●           | ●         | ●           | 0x001C 0x0019  |

| Vehicle             | Capacity | EngineType               | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------------------|----------|--------------------------|-------------|---------|------------|-------------|-----------|-------------|---|
| F-Series Super Duty | 5.4L     | 3V                       | 2010        | GPSM    | ●          | ●           | ●         | ○           | ○   |
| F-Series Super Duty | 5.4L     | BIF                      | 1999        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| F-Series Super Duty | 5.4L     | BIF                      | 1999        | AFCM    | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | BIF                      | 1999        | ECS     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | BIF                      | 1999        | GEM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | BIF                      | 1999        | OTC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | BIF                      | 1999        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082 0x0083  |
| F-Series Super Duty | 5.4L     | Other                    | 1999 - 2001 | ECS     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | Other                    | 1999 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| F-Series Super Duty | 5.4L     | Other                    | 1999 - 2003 | GEM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | Other                    | 1999 - 2003 | OTC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | Other                    | 1999 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083 0x0010 0x0028 0x0031 0x0033 0x0084        |
| F-Series Super Duty | 5.4L     | Other                    | 2000 - 2003 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| F-Series Super Duty | 5.4L     | Other                    | 2001 - 2003 | PAM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | Other                    | 2001 - 2003 | RCM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | Other                    | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| F-Series Super Duty | 5.4L     | Other                    | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | Other                    | 2003        | FOH     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 5.4L     | Other                    | 2003        | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2004 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x001B   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2004 | FOH     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2004 | HEC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2004 | OTC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2004 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2007 | GEM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2007 | PAM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2007 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028 0x0031 0x0033 0x0080 0x0081 0x0082 0x0083 0x0084 0x00C5 |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2007 | RCM     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2007 | TCM     | ●          | ●           | ●         | ●           | 0x0010 0x0028 0x0031 0x0033 0x00C5  |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2003 - 2007 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2005 - 2007 | ABS     | ●          | ●           | ●         | ●           | 0x0008  |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2005 - 2007 | EATC    | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2005 - 2007 | IC      | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.0L     | Direct Injection - Turbo | 2005 - 2007 | TBC     | ●          | ●           | ●         | ●           | ○   |
| F-Series Super Duty | 6.2L     | 2V                       | 2011 - 2012 | ABS     | ●          | ●           | ●         | ●           | 0x0008  |
| F-Series Super Duty | 6.2L     | 2V                       | 2011 - 2012 | ACM     | ●          | ●           | ●         | ○           | 0x0017 0x0018   |
| F-Series Super Duty | 6.2L     | 2V                       | 2011 - 2012 | HVAC    | ●          | ●           | ●         | ●           | ○   |

| Vehicle             | Capacity | EngineType                                   | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------------------|----------|--|-------------|-----------|------------|-------------|-----------|-------------|--|
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2012 | IPC       | ●          | ●           | ●         | ●           | 0x00D0   |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2012 | PAM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2012 | PCM       | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0024<br>0x0025 0x0028 0x0031 0x0033<br>0x0038 0x0067 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x0095 |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2012 | SDARS     | ●          | ●           | ●         | ●           | 0x0019   |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2012 | TPM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | APIM      | ●          | ●           | ●         | ●           | 0x0019   |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | BCM#1     | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0x00D4<br>0x00FE 0x0112   |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | DCSM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | DSM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | GPSM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | RCM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | SCCM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | TBC       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2011 - 2014 | TCCM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2013 - 2014 | FCIM      | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.2L     | 2V   | 2013 - 2014 | RTM       | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | ABS       | ●          | ●           | ●         | ●           | 0x0005 0xF046 0xF084   |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | ACM       | ●          | ●           | ●         | ●           | 0x0005 0x0017 0x0018 0xF05A<br>0xF07A 0xF07F   |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | AHCM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | CDIM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | DSM       | ●          | ●           | ●         | ●           | 0x0005   |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | GEM / SJB | ●          | ●           | ●         | ●           | 0x0042 0xF042 0xF048 0xF049<br>0xF04B 0xF05C 0xF06A 0xF080<br>0xF081   |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | HVAC      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | IC        | ●          | ●           | ●         | ●           | 0xF027 0xF04D 0xF07E 0xF082<br>0xF083  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | PAM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0047 0x0048<br>0x0058 0x0080 0x0081 0x0082<br>0x0083 0x0084 0x00A2 0x00A3                                |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | RETM      | ●          | ●           | ●         | ●           | 0x0005 0xF04D 0xF05A   |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | SDARS     | ●          | ●           | ●         | ●           | 0x0005 0xF07F  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | TBC       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 - 2010 | TCM       | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 - 2010 | APIM      | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010        | GPSM      | ●          | ●           | ●         | ○           | ○  |

| Vehicle             | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|--|
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011        | NOx#1   | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2012 | ABS     | ●          | ●           | ●         | ●           | 0x0008   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2012 | ACM     | ●          | ●           | ●         | ○           | 0x0017 0x0018 0x0005   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2012 | HVAC    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2012 | IPC     | ●          | ●           | ●         | ●           | 0x00D0   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2012 | PAM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2012 | SDARS   | ●          | ●           | ●         | ●           | 0x0005   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2012 | TPM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2013 | GPCM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2013 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0058 0x0059 0x0080<br>0x0081 0x0082 0x0083 0x0091<br>0x0093 0x0095 0x009B 0x009C<br>0x009D 0x009E 0x009F 0x00A0<br>0x00CE 0x000F 0x0010 0x0028<br>0x0031 0x0033 |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2013 | TCM     | ●          | ●           | ●         | ●           | 0x0038 0x00CE  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | AHCM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | APIM    | ●          | ●           | ●         | ●           | 0x0019   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | BCM#1   | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0x00D4<br>0x00FE 0x0112   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | CDIM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | DCSM    | ●          | ●           | ●         | ●           | 0x0005   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | DSM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | GPSM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | RCM     | ●          | ●           | ●         | ●           | 0x0005   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | SCCM    | ●          | ●           | ●         | ●           | 0x0005   |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | TBC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 - 2014 | TCCM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2013 - 2014 | FCIM    | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2013 - 2014 | RTM     | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.8L     | 2V   | 2004        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x001B  |
| F-Series Super Duty | 6.8L     | 2V   | 2004        | HEC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V   | 2004        | OTC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V   | 2004        | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| F-Series Super Duty | 6.8L     | 2V   | 2004 - 2007 | GEM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V   | 2004 - 2007 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| F-Series Super Duty | 6.8L     | 2V   | 2004 - 2008 | PAM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V   | 2004 - 2008 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084   |
| F-Series Super Duty | 6.8L     | 2V   | 2004 - 2008 | RCM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V   | 2005 - 2007 | EATC    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V   | 2005 - 2008 | ABS     | ●          | ●           | ●         | ●           | 0x0008   |



| Vehicle             | Capacity | EngineType | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------------------|----------|------------|-------------|---------|------------|-------------|-----------|-------------|--|
| F-Series Super Duty | 6.8L     | 2V         | 2005 - 2008 | IC      | ●          | ●           | ●         | ●           | 0x0009   |
| F-Series Super Duty | 6.8L     | 2V         | 2005 - 2008 | TBC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V         | 2008        | 4X4     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V         | 2008        | ACM     | ●          | ●           | ●         | ●           | 0x0016 0x0017 0x0018   |
| F-Series Super Duty | 6.8L     | 2V         | 2008        | DSM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V         | 2008        | GEM /   | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042   |
| F-Series Super Duty | 6.8L     | 2V         | 2008        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V         | 2008        | RETM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 2V         | 2008        | SDARS   | ●          | ●           | ●         | ●           | 0x0019   |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2007 | EATC    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2007 | GEM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2007 | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2010 | IC      | ●          | ●           | ●         | ●           | 0x0009   |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2012 | ABS     | ●          | ●           | ●         | ●           | 0x0008   |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2012 | PAM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2012 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x00C5 0x0009 0x0067 0x0095 |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2014 | RCM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2005 - 2014 | TBC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2008 - 2010 | 4X4     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2008 - 2010 | GEM /   | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042   |
| F-Series Super Duty | 6.8L     | 3V         | 2008 - 2010 | RETM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2008 - 2011 | SDARS   | ●          | ●           | ●         | ●           | 0x0019   |
| F-Series Super Duty | 6.8L     | 3V         | 2008 - 2012 | ACM     | ●          | ●           | ●         | ●           | 0x0016 0x0017 0x0018   |
| F-Series Super Duty | 6.8L     | 3V         | 2008 - 2012 | HVAC    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2008 - 2014 | DSM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2009 - 2014 | APIM    | ●          | ●           | ●         | ●           | 0x0019 0x001C  |
| F-Series Super Duty | 6.8L     | 3V         | 2010 - 2014 | GPSM    | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2011 - 2012 | IPC     | ●          | ●           | ●         | ●           | 0x00D0   |
| F-Series Super Duty | 6.8L     | 3V         | 2011 - 2012 | TPM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2011 - 2014 | BCM#1   | ●          | ●           | ●         | ●           | 0x000F 0x0042 0x00D4 0x00FE<br>0x0112  |
| F-Series Super Duty | 6.8L     | 3V         | 2011 - 2014 | DCSM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2011 - 2014 | SCCM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2011 - 2014 | TCCM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2013 - 2014 | FCIM    | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.8L     | 3V         | 2013 - 2014 | RTM     | ●          | ●           | ●         | ○           | ○  |
| F-Series Super Duty | 6.8L     | Other      | 1999 - 2001 | ECS     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | Other      | 1999 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| F-Series Super Duty | 6.8L     | Other      | 1999 - 2003 | GEM     | ●          | ●           | ●         | ●           | ○  |

| Vehicle             | Capacity | EngineType               | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------------------|----------|--------------------------|-------------|---------|------------|-------------|-----------|-------------|--|
| F-Series Super Duty | 6.8L     | Other                    | 1999 - 2003 | OTC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | Other                    | 1999 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 |
| F-Series Super Duty | 6.8L     | Other                    | 2000 - 2001 | AFCM    | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | Other                    | 2000 - 2003 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| F-Series Super Duty | 6.8L     | Other                    | 2001 - 2003 | PAM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | Other                    | 2001 - 2003 | RCM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | Other                    | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| F-Series Super Duty | 6.8L     | Other                    | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | Other                    | 2003        | FOH     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 6.8L     | Other                    | 2003        | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 1999 - 2001 | ECS     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 1999 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 1999 - 2003 | GEM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 1999 - 2003 | OTC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 1999 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0010 0x0028 0x0031<br>0x0033               |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 2000 - 2003 | PATS    | ●          | ●           | ●         | ●           | 0x0009   |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 2001 - 2003 | PAM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 2001 - 2003 | RCM     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 2002        | CSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 2002 - 2003 | HEC     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 2003        | FOH     | ●          | ●           | ●         | ●           | ○  |
| F-Series Super Duty | 7.3L     | Direct Injection - Turbo | 2003        | VSM     | ●          | ●           | ●         | ●           | 0x000A 0x000F  |
| Fusion              | 1.25L    | DURATEC 16V              | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fusion              | 1.25L    | DURATEC 16V              | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF02D 0xF030 0xF0A2<br>0xF0B3  |
| Fusion              | 1.25L    | DURATEC 16V              | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF020  |
| Fusion              | 1.25L    | DURATEC 16V              | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083                                       |
| Fusion              | 1.25L    | DURATEC 16V              | 2002 - 2006 | RCM     | ●          | ●           | ○         | ○           | ○  |
| Fusion              | 1.25L    | DURATEC 16V              | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fusion              | 1.25L    | DURATEC 16V              | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fusion              | 1.25L    | DURATEC 16V              | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fusion              | 1.4L     | DURATEC 16V              | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fusion              | 1.4L     | DURATEC 16V              | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF02D 0xF030 0xF0A2<br>0xF0B3  |
| Fusion              | 1.4L     | DURATEC 16V              | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | 0x0005 0xF020  |
| Fusion              | 1.4L     | DURATEC 16V              | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083                                       |
| Fusion              | 1.4L     | DURATEC 16V              | 2002 - 2006 | RCM     | ●          | ●           | ○         | ○           | ○  |
| Fusion              | 1.4L     | DURATEC 16V              | 2002 - 2006 | TCM     | ●          | ●           | ●         | ●           | 0x003F   |

| Vehicle | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|--|
| Fusion  | 1.4L     | DURATEC 16V                                  | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.4L     | DURATEC 16V                                  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.4L     | DURATEC 16V                                  | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0xF02D 0xF030 0xF0A2 0xF0B3<br>0xF0B6 0xF0B7   |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | 0xF020 0xF063 0xF0B5 0xF0B7  |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083  |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | RCM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | TCM     | ●          | ●           | ●         | ●           | 0x003F   |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | ACM     | ●          | ●           | ●         | ●           | 0x0005   |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | SRM     | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039   |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | DACM-C  | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | DSM     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | DSP     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | FCIM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | HUD     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0038<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 0x0108 |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | RACM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | RCM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | RTM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | SCCM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | SCM-E   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | SOD-L   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014        | SOD-R   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x020C 0x0012 0x010A  |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | BCM#1   | ●          | ●           | ●         | ●           | 0x0112   |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | OCSM    | ●          | ●           | ●         | ●           | 0x000C   |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | PBM     | ●          | ●           | ●         | ●           | 0x00F5   |
| Fusion  | 1.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0083<br>0x00AC 0x0095   |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2002        | TCM     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | 0xF02D 0xF030 0xF0A2 0xF0B3<br>0xF0B6 0xF0B7   |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | 0xF020 0xF063 0xF0B5   |

| Vehicle | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| Fusion  | 1.6L     | DURATEC 16V                                  | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2002 - 2006 | RCM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2006        | ACM     | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | DURATEC 16V                                  | 2006        | SRM     | ●          | ●           | ●         | ●           | 0xF037 0xF038 0xF039  |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | EPS     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | IC      | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083 0x0092 0x0096 0x0097<br>0x0099 0x009A 0x00AD 0x00AE |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2006 | RCM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | EATC    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | ABS     | ●          | ●           | ●         | ○           | 0x0008 0x0012 0x00F5 0x010A<br>0x020C   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | ACM     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | BCM#1   | ●          | ●           | ●         | ●           | 0x000F 0x00D4 0x00D5 0x00FE<br>0x0112   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | C-CM    | ●          | ●           | ●         | ○           | 0x0046  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | DDM     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GFM     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GPSM    | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GWM     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HCM     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HSWM    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | IPM-A   | ●          | ●           | ●         | ○           | 0x013E  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | OCSM    | ●          | ●           | ●         | ○           | 0x000C  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PAM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0024 0x0025 0x0067<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 0x0108               |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PDM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PSCM    | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | RGTM    | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCM-G   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCM-H   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | VDM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | APIM    | ●          | ●           | ●         | ○           | ○   |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                    |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|------------------------------------|
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DACM-C | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DSM    | ●          | ●           | ●         | ●           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DSP    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | FCDIM  | ●          | ●           | ●         | ●           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | HUD    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RACM   | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RCM    | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RTM    | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SCCM   | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SCM-E  | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SOD-L  | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SOD-R  | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x0012 0x00F5 0x010A 0x020C |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | ACM    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | BCM#1  | ●          | ●           | ●         | ●           | 0x000F 0x00D4 0x00D5 0x00FE 0x0112 |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | C-CM   | ●          | ●           | ●         | ○           | 0x0046                             |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | DDM    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GFM    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GPSM   | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GWM    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HCM    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HSWM   | ●          | ●           | ●         | ●           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | IPC    | ●          | ●           | ●         | ●           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | IPM-A  | ●          | ●           | ●         | ○           | 0x013E                             |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | OCSM   | ●          | ●           | ●         | ○           | 0x000C                             |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PAM    | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PDM    | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | PSCM   | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | RGTM   | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCM-G  | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCM-H  | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | VDM    | ●          | ●           | ○         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | APIM   | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DACM-C | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DSM    | ●          | ●           | ●         | ●           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | DSP    | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | FCDIM  | ●          | ●           | ●         | ●           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○                                  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | HUD    | ●          | ●           | ●         | ○           | ○                                  |

| Vehicle | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0024 0x0028 0x0031<br>0x0033 0x0067 0x0080 0x0081<br>0x0082 0x0083 0x0084 0x0108<br>0x0023 0x0025 0x0038 |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RACM    | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RCM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | RTM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SCCM    | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SCM-E   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SOD-L   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 - 2014 | SOD-R   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x020C 0x0012 0x010A   |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | BCM#1   | ●          | ●           | ●         | ●           | 0x0112  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | OCSM    | ●          | ●           | ●         | ●           | 0x000C  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | PBM     | ●          | ●           | ●         | ●           | 0x00F5  |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0083<br>0x0095 0x00AC  |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013        | C-CM    | ●          | ●           | ●         | ○           | 0x0046  |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013        | GWM     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | ACCM#2  | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | APIM    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | DACM-C  | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | DSM     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | DSP     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | HUD     | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | RACM    | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | RCM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | SCCM    | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | SCM-E   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | SOD-L   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2013 - 2014 | SOD-R   | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2014        | FCIM    | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2014        | RTM     | ●          | ●           | ○         | ○           | ○   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2017        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x020C 0x0012 0x0074<br>0x010A   |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2017        | BCM#1   | ●          | ●           | ●         | ●           | 0x0112  |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2017        | OCSM    | ●          | ●           | ●         | ●           | 0x000C  |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2017        | PBM     | ●          | ●           | ●         | ●           | 0x00F5  |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2017        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0083<br>0x0095 0x00AC  |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2017        | SOBDM-C | ●          | ●           | ●         | ●           | 0x013C  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V                            | 2013        | ABS     | ●          | ●           | ●         | ○           | 0x0074  |

| Vehicle | Capacity | EngineType        | Year | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                              |
|---------|----------|-------------------|------|---------|------------|-------------|-----------|-------------|--|
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | ACCM#2  | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | ACM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | APIM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | BCM#1   | ●          | ●           | ●         | ●           | 0x000F 0x00D4 0x00D5 0x00FE                  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | BECM    | ●          | ●           | ●         | ○           | 0x006E                                       |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | C-CM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | DACM-C  | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | DCDC    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | DDM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | DSP     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | FCIM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | GFM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | GPSM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | GWM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | HCM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | HSWM    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | HUD     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | IPC     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | IPM-A   | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | OCSM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | PAM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0108 |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | PDM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | PSCM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | RACM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | RCM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | RGTM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | RTM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | SCCM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | SCM-E   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | SCM-G   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | SCM-H   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | SOBDM-C | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | SOD-L   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | SOD-R   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | HEV / ATKINSON 4V | 2013 | VDM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV              | 2013 | ABS     | ●          | ●           | ●         | ○           | 0x0074 0x00F5 0x010A 0x020C                  |
| Fusion  | 2.0L     | PHEV              | 2013 | ACM     | ●          | ●           | ●         | ○           | ○  |

| Vehicle | Capacity | EngineType                      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---------------------------------|-------------|---------|------------|-------------|-----------|-------------|--|
| Fusion  | 2.0L     | PHEV                            | 2013        | BCM#1   | ●          | ●           | ●         | ●           | 0x000F 0x00D4 0x00D5 0x00FE 0x0112   |
| Fusion  | 2.0L     | PHEV                            | 2013        | C-CM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | DDM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | GPSM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | GWM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | HCM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | HSWM    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | IPC     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | IPM-A   | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | OCSM    | ●          | ●           | ●         | ○           | 0x000C   |
| Fusion  | 2.0L     | PHEV                            | 2013        | PAM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028 0x0031 0x0033 0x0080 0x0081 0x0082 0x0083 0x0108 |
| Fusion  | 2.0L     | PHEV                            | 2013        | PDM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | PSCM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | RGTM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | SCM-G   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | SCM-H   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | SOBDM-C | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013        | VDM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | ACCM#2  | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | APIM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | BECM    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | DACM-C  | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | DSM     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | DSP     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | FCDIM   | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | FCIM    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | GFM     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | HUD     | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | RACM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | RCM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | RTM     | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | SCCM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | SCM-E   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | SOBDM   | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | SOD-L   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | PHEV                            | 2013 - 2014 | SOD-R   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.0L     | Plug-in Hybrid Electric Vehicle | 2017        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x020C 0x0012 0x0074 0x010A   |



| Vehicle | Capacity | EngineType                      | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---------------------------------|-------------|-----------|------------|-------------|-----------|-------------|--|
| Fusion  | 2.0L     | Plug-in Hybrid Electric Vehicle | 2017        | BCM#1     | ●          | ●           | ●         | ●           | 0x0112   |
| Fusion  | 2.0L     | Plug-in Hybrid Electric Vehicle | 2017        | OCSM      | ●          | ●           | ●         | ●           | 0x000C   |
| Fusion  | 2.0L     | Plug-in Hybrid Electric Vehicle | 2017        | PBM       | ●          | ●           | ●         | ●           | 0x00F5   |
| Fusion  | 2.0L     | Plug-in Hybrid Electric Vehicle | 2017        | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0083<br>0x00AC 0x0095   |
| Fusion  | 2.0L     | Plug-in Hybrid Electric Vehicle | 2017        | SOBDM-C   | ●          | ●           | ●         | ●           | 0x013C   |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2007 | EATC      | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2007 | GEM       | ●          | ●           | ●         | ●           | 0xF044 0xF048 0xF04C 0xF057<br>0xF085  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | ABS       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | ACM       | ●          | ●           | ●         | ●           | 0xF05A 0xF062 0xF07A   |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | IC        | ●          | ●           | ●         | ●           | 0x0009 0xF027  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | OCSM      | ●          | ●           | ●         | ○           | 0x006D   |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082<br>0x0083 0x0084   |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022 0xF05D   |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | TBM       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2006 - 2009 | TCM       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2007 - 2009 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2007 - 2009 | SDARS     | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2008 - 2009 | APIM      | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2008 - 2009 | GEM / SJB | ●          | ●           | ●         | ●           | 0x0042 0xF044 0xF048 0xF04C<br>0xF057 0xF085 0xF086  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2008 - 2009 | HVAC      | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.3L     | DURATEC-HE / I4                 | 2008 - 2009 | PAM       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | 4X4       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | ACM       | ●          | ●           | ●         | ●           | 0x0017 0x0018  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | APIM      | ●          | ●           | ●         | ●           | 0x0019 0x001C  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | DSP       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | FCIM      | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | FDIM      | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | GEM /     | ●          | ●           | ●         | ●           | 0x000F 0x0042  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | GPSP      | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | HVAC      | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | IPC       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | OCSM      | ●          | ●           | ●         | ●           | 0x000C 0x0015 0x006D   |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | PAM       | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | PCM       | ●          | ●           | ●         | ●           | 0x0009 0x0024 0x0038 0x0067<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 0x0010 0x0023 0x0028<br>0x0031 0x0033 |
| Fusion  | 2.5L     | DURATEC-HE / I4                 | 2010 - 2012 | PSCM      | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType        | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|-------------------|-------------|--------|------------|-------------|-----------|-------------|---|
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 - 2012 | RCM    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 - 2012 | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 - 2012 | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 - 2012 | TBM    | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | 4X4    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | ABS    | ●          | ●           | ●         | ●           | 0x0074  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | ACCM#2 | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | ACM    | ●          | ●           | ●         | ●           | 0x0005 0x0017 0x0018  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | APIM   | ●          | ●           | ●         | ●           | 0x0019 0x001C   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | BECM   | ●          | ●           | ●         | ●           | 0x006E  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | DCDC   | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | DSP    | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | FCIM   | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | FDIM   | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | GEM /  | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | GPSM   | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | IPC    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | OCSM   | ●          | ●           | ●         | ●           | 0x000C 0x0015   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | PAM    | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | PCM    | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0024<br>0x0025 0x0028 0x0031 0x0033<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | PSCM   | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | RCM    | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | SOD-L  | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | SOD-R  | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | TBM    | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3  |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 - 2012 | TCM    | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x0012 0x00F5 0x010A<br>0x020C   |
| Fusion  | 2.5L     | IVCT              | 2013        | ACM    | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | BCM#1  | ●          | ●           | ●         | ●           | 0x00D4 0x00D5 0x0112  |
| Fusion  | 2.5L     | IVCT              | 2013        | C-CM   | ●          | ●           | ●         | ○           | 0x0046  |
| Fusion  | 2.5L     | IVCT              | 2013        | DDM    | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | GFM    | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | GPSM   | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | GWM    | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | HCM    | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | HSWM   | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 2.5L     | IVCT              | 2013        | IPC    | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| Fusion  | 2.5L     | IVCT   | 2013        | IPM-A  | ●          | ●           | ●         | ○           | 0x013E   |
| Fusion  | 2.5L     | IVCT   | 2013        | OCSM   | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013        | PAM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013        | PDM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013        | PSCM   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013        | RGTM   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013        | SCM-G  | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013        | SCM-H  | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013        | VDM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | APIM   | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | DACM-C | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | DSM    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | DSP    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | FCDIM  | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | FCIM   | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | HUD    | ●          | ●           | ●         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | PCM    | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0024 0x0025<br>0x0028 0x0031 0x0033 0x0067<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 0x0108 |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | RACM   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | RCM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | RTM    | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | SCCM   | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | SCM-E  | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | SOD-L  | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2013 - 2014 | SOD-R  | ●          | ●           | ○         | ○           | ○  |
| Fusion  | 2.5L     | IVCT   | 2017        | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x020C 0x0012 0x010A  |
| Fusion  | 2.5L     | IVCT   | 2017        | BCM#1  | ●          | ●           | ●         | ●           | 0x0112   |
| Fusion  | 2.5L     | IVCT   | 2017        | OCSM   | ●          | ●           | ●         | ●           | 0x000C   |
| Fusion  | 2.5L     | IVCT   | 2017        | PBM    | ●          | ●           | ●         | ●           | 0x00F5   |
| Fusion  | 2.5L     | IVCT   | 2017        | PCM    | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0083<br>0x00AC 0x0095   |
| Fusion  | 2.7L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x020C 0x0012 0x010A  |
| Fusion  | 2.7L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | BCM#1  | ●          | ●           | ●         | ●           | 0x0112   |
| Fusion  | 2.7L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | OCSM   | ●          | ●           | ●         | ●           | 0x000C   |
| Fusion  | 2.7L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | PBM    | ●          | ●           | ●         | ●           | 0x00F5   |
| Fusion  | 2.7L     | EcoBoost - Gas Turbocharged Direct Injection | 2017        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0083 0x00AC<br>0x0095  |
| Fusion  | 3.0L     | 4V   | 2006 - 2007 | EATC   | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 3.0L     | 4V   | 2006 - 2007 | GEM    | ●          | ●           | ●         | ●           | ○  |
| Fusion  | 3.0L     | 4V   | 2006 - 2009 | IC     | ●          | ●           | ●         | ●           | 0x0005 0xF027  |
| Fusion  | 3.0L     | 4V   | 2006 - 2009 | TCM    | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType | Year        | Module    | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|------------|-------------|-----------|------------|-------------|-----------|-------------|---|
| Fusion  | 3.0L     | 4V         | 2006 - 2012 | ABS       | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Fusion  | 3.0L     | 4V         | 2006 - 2012 | ACM       | ●          | ●           | ●         | ●           | 0x0017 0x0018   |
| Fusion  | 3.0L     | 4V         | 2006 - 2012 | OCSM      | ●          | ●           | ●         | ○           | 0x000C 0x0015   |
| Fusion  | 3.0L     | 4V         | 2006 - 2012 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0080 0x0081 0x0082<br>0x0083 0x0084 0x0009 0x0024<br>0x0038 0x0067 |
| Fusion  | 3.0L     | 4V         | 2006 - 2012 | RCM       | ●          | ●           | ●         | ●           | 0x0005 0xF022 0xF05D  |
| Fusion  | 3.0L     | 4V         | 2006 - 2012 | TBM       | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3  |
| Fusion  | 3.0L     | 4V         | 2007 - 2009 | SDARS     | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 3.0L     | 4V         | 2007 - 2012 | 4X4       | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2008 - 2012 | APIM      | ●          | ●           | ●         | ●           | 0x0019 0x001C   |
| Fusion  | 3.0L     | 4V         | 2008 - 2012 | GEM / SJB | ●          | ●           | ●         | ●           | 0x0005 0xF044 0xF048 0xF04C<br>0xF057 0xF085 0xF086 0xF08A<br>0x000F 0x0042 |
| Fusion  | 3.0L     | 4V         | 2008 - 2012 | HVAC      | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2008 - 2012 | PAM       | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | DSP       | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | FCIM      | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | FDIM      | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | GPSM      | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | IPC       | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | PSCM      | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | SOD-L     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.0L     | 4V         | 2010 - 2012 | SOD-R     | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | 4X4       | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | ABS       | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0012  |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | ACM       | ●          | ●           | ●         | ●           | 0x0018 0x0017   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | APIM      | ●          | ●           | ●         | ●           | 0x0019 0x001C   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | DSP       | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | FCIM      | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | FDIM      | ●          | ●           | ●         | ●           | 0x0005 0xF062   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | GEM / SJB | ●          | ●           | ●         | ●           | 0x000A 0x000F 0x0042 0xF042<br>0xF048 0xF049 0xF04B 0xF04C<br>0xF08A        |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | GPSM      | ●          | ●           | ●         | ○           | ○   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | HVAC      | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | IPC       | ●          | ●           | ●         | ●           | ○   |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | OCSM      | ●          | ●           | ●         | ●           | 0x000C 0x0015 0x006D  |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | PAM       | ●          | ●           | ●         | ●           | 0x0005  |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | PCM       | ●          | ●           | ●         | ●           | 0x0023 0x0024 0x0025 0x0037<br>0x0080 0x0081 0x0082 0x0083<br>0x0084        |
| Fusion  | 3.5L     | 4V         | 2010 - 2012 | PSCM      | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType        | Year         | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function      |
|---------|----------|-------------------|--------------|--------|------------|-------------|-----------|-------------|----------------------|
| Fusion  | 3.5L     | 4V                | 2010 - 2012  | RCM    | ●          | ●           | ●         | ●           | 0x0005               |
| Fusion  | 3.5L     | 4V                | 2010 - 2012  | SOD-L  | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | 3.5L     | 4V                | 2010 - 2012  | SOD-R  | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | 3.5L     | 4V                | 2010 - 2012  | TBM    | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3 |
| Fusion  | 3.5L     | 4V                | 2010 - 2012  | TCM    | ●          | ●           | ●         | ○           | 0x0038               |
| Fusion  | Other    | Other             | 2012         | 4X4    | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | ABS    | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | ACM    | ●          | ●           | ●         | ○           | ○                    |
| Fusion  | Other    | Other             | 2012         | APIM   | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | DSP    | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | FCIM   | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | FDIM   | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | GEM /  | ●          | ●           | ●         | ●           | 0x0042               |
| Fusion  | Other    | Other             | 2012         | GPSM   | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | HVAC   | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | IPC    | ●          | ●           | ●         | ●           | 0x0009               |
| Fusion  | Other    | Other             | 2012         | OCSM   | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | PAM    | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | PSCM   | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | RCM    | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | SOD-L  | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | SOD-R  | ●          | ●           | ●         | ●           | ○                    |
| Fusion  | Other    | Other             | 2012         | TBM    | ●          | ●           | ●         | ○           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | FFH    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | LHID   | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | MFSW   | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | PAM    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | RADIO  | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | RCC    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | RHID   | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001         | RNS    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | ABS    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | CCM    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | CJB    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | IC     | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | PATS   | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | PCM    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | RCM    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 1.9L     | EDC 1.9           | 2001 - Other | TCM    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | ABS    | ●          | ●           | ●         | ●           | ○                    |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | CCM    | ●          | ●           | ●         | ●           | ○                    |

| Vehicle | Capacity | EngineType        | Year         | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                           |
|---------|----------|-------------------|--------------|--------|------------|-------------|-----------|-------------|---|
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | CJB    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | IC     | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | PATS   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | PCM    | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082 0x0083 0x0009 |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | RCM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 1995 - 2000  | TCM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 2000         | LHID   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 2000         | MFSW   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 2000         | PAM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 2000         | RADIO  | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 2000         | RCC    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 2000         | RHID   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.0L     | 2.0 DOHC SFI (8V) | 2000         | RNS    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | ABS    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | CCM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | CJB    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | IC     | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | PATS   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | PCM    | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082 0x0083 0x0009 |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | RCM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 1997 - 2000  | TCM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 2000         | LHID   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 2000         | MFSW   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 2000         | PAM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 2000         | RADIO  | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 2000         | RCC    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 2000         | RHID   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.3L     | DOHC SFI (16V)    | 2000         | RNS    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001         | LHID   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001         | MFSW   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001         | PAM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001         | RADIO  | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001         | RCC    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001         | RHID   | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001         | RNS    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001 - Other | ABS    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001 - Other | CCM    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001 - Other | CJB    | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001 - Other | IC     | ●          | ●           | ●         | ●           | ○   |
| Galaxy  | 2.8L     | 2.8 CD-V6         | 2001 - Other | PATS   | ●          | ●           | ●         | ●           | ○   |

| Vehicle      | Capacity | EngineType                                   | Year         | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--------------|----------|--|--------------|--------|------------|-------------|-----------|-------------|--|
| Galaxy       | 2.8L     | 2.8 CD-V6                                    | 2001 - Other | PCM    | ●          | ●           | ●         | ●           | ○  |
| Galaxy       | 2.8L     | 2.8 CD-V6                                    | 2001 - Other | RCM    | ●          | ●           | ●         | ●           | ○  |
| Galaxy       | 2.8L     | 2.8 CD-V6                                    | 2001 - Other | TCM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | ACM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | AHCM   | ●          | ●           | ●         | ●           | 0x00CF   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | CDP    | ●          | ●           | ●         | ●           | 0x0005   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | CMR    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | DABM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | DDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | HCM    | ●          | ●           | ●         | ●           | 0x0032   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | HVAC   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | IPC    | ●          | ●           | ●         | ●           | 0xF020   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | NAV    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | PAM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | PBM    | ●          | ●           | ●         | ○           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00B1 0x00B3 0x00B7<br>0x00B9 0x00BC 0x00BD 0x00C1<br>0x00C3 |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | PDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | PSCM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | RCM    | ●          | ●           | ●         | ○           | 0x00EF 0x0102  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | RFA    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | RGTM   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | RHVAC  | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | SASM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | SRM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | TRM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2010         | VDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010         | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010         | ACM    | ●          | ●           | ●         | ●           | ○  |

| Vehicle      | Capacity | EngineType                                   | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|--------------|----------|--|------|--------|------------|-------------|-----------|-------------|---|
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | AHCM   | ●          | ●           | ●         | ●           | 0x00CF  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132 0x0153                      |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | CMR    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | DABM   | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | DDM    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | DSM    | ●          | ●           | ●         | ○           | 0x00F2  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | HVAC   | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | IPC    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | NAV    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | PAM    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | PBM    | ●          | ●           | ●         | ○           | 0x00EE 0x00F3 0x00F4 0x00F5 0x00F6 0x00F7 0x00F8        |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083 0x009A 0x00BC 0x00C3 0x0114 |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | PDM    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | PSCM   | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | RCM    | ●          | ●           | ●         | ○           | 0x00EF 0x0102   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | RFA    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | RGTM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | RHVAC  | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | SASM   | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | SOD-L  | ●          | ●           | ●         | ○           | 0xF026  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | SOD-R  | ●          | ●           | ●         | ○           | 0xF026  |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | SRM    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | TRM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | VDM    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x002B 0x0053 0x0054 0x00D9 0x00E2 0x00E8 0x0129 |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | ACM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132 0x0153                      |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | CDP    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | DDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | GDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 | HVAC   | ●          | ●           | ●         | ●           | ○   |



| Vehicle      | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|--------------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | IPC    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | NAV    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | PAM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | PCM    | ●          | ●           | ●         | ●           | 0x006F 0x0080 0x0081 0x0082<br>0x0083 0x0090 0x0092 0x0098<br>0x0099 0x009A 0x00AB 0x00AC<br>0x00B4 0x00C1 0x020A |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | PDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | PSCM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | RCM    | ●          | ●           | ●         | ○           | 0x0102  |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | RFA    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | RGTM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | RHVAC  | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | SASM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | SRM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | TRM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | VDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006        | GDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | ACM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | DDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | IPC    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | NAV    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | PAM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00AC   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | PDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | PSCM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | RCM    | ●          | ●           | ●         | ○           | 0x0102 0x00EF   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | RFA    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | RGTM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | RHVAC  | ●          | ●           | ●         | ●           | ○   |

| Vehicle      | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|--------------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | SASM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | SRM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | TRM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2006 - 2010 | VDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2010        | CMR    | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2010        | DABM   | ●          | ●           | ●         | ○           | ○   |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2010        | DSM    | ●          | ●           | ●         | ○           | 0x00F2  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2010        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2010        | SOD-L  | ●          | ●           | ●         | ○           | 0xF026  |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4                             | 2010        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | GDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | PAM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | ACM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | CDP    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | DDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | IPC    | ●          | ●           | ●         | ●           | 0xF020  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | NAV    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | PCM    | ●          | ●           | ●         | ●           | 0x006F 0x0080 0x0081 0x0082<br>0x0083 0x0090 0x0092 0x0098<br>0x0099 0x009A 0x00AB 0x00AC<br>0x00B4 0x00C1 0x020A |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | PDM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | PSCM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | RCM    | ●          | ●           | ●         | ○           | 0x0102 0x00EF   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | RFA    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | RGTM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | RHVAC  | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | SASM   | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | SRM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | TCM    | ●          | ●           | ●         | ○           | 0x0121 0x0122 0x0123 0x0124<br>0x0125   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | TRM    | ●          | ●           | ●         | ●           | ○   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2006 - 2010 | VDM    | ●          | ●           | ●         | ●           | ○   |

| Vehicle      | Capacity | EngineType                                       | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--------------|----------|--|------|--------|------------|-------------|-----------|-------------|--|
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | CMR    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | DABM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2010 | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8        |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | ACM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | AHCM   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C                                       |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | CDP    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | CMR    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | DABM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | DDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | HCM    | ●          | ●           | ●         | ●           | 0x0032   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | HVAC   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | IPC    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | NAV    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | PAM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2010 | PBM    | ●          | ●           | ●         | ○           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8        |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                                |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | PDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | PSCM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | RCM    | ●          | ●           | ●         | ○           | 0x00EF   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | RFA    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | RGTM   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | RHVAC  | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | SASM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | SRM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | TCM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | TRM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2010 | VDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2010 | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129 |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2010 | ACM    | ●          | ●           | ●         | ●           | ○  |

| Vehicle      | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--------------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | AHCM   | ●          | ●           | ●         | ●           | 0x00CF   |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | BCMii  | ●          | ●           | ●         | ●           | 0x011B 0x011C 0x0132 0x0153                                |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | CDP    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | CMR    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | DABM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | DDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | HCM    | ●          | ●           | ●         | ●           | 0x0032   |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | HVAC   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | IPC    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | NAV    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | PBM    | ●          | ●           | ●         | ○           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8        |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083                                |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | PDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | PSCM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | RCM    | ●          | ●           | ●         | ○           | 0x00EF 0x0102  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | RGTM   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | RHVAC  | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | SASM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | SRM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | TCM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | TRM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2010        | VDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | GDM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | PAM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006        | RFA    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129 |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | ACM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011C 0x0132 0x0153<br>0x011B                      |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | CDP    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | DDM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | HCM    | ●          | ●           | ●         | ●           | 0x0032   |
| GALAXY\S-Max | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2006 - 2010 | HVAC   | ●          | ●           | ●         | ●           | ○  |

| Vehicle      | Capacity | EngineType                                       | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--------------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | IPC    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | NAV    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00A5 0x00AA 0x00AF<br>0x00B0 0x00B1 0x00B2 0x00B8<br>0x00B9 0x00BB 0x00C1 |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | PDM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | PSCM   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | RCM    | ●          | ●           | ●         | ○           | 0x00EF 0x0102  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | RGTM   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | RHVAC  | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | SASM   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | SRM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | TRM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2006 - 2010 | VDM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | CMR    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | DABM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection StgV | 2010        | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | ACM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | AHCM   | ●          | ●           | ●         | ●           | 0x00CF   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | BCMii  | ●          | ●           | ●         | ●           | 0x011B 0x011C 0x0132 0x0153  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | CDP    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | CMR    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | DABM   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | DDM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | HCM    | ●          | ●           | ●         | ●           | 0x0032   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | HVAC   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | IPC    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | NAV    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection StgV | 2010        | PBM    | ●          | ●           | ●         | ○           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2010        | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083  |

| Vehicle      | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | PDM     | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | PSCM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | RCM     | ●          | ●           | ●         | ○           | 0x00EF 0x0102  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | RGTM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | RHVAC   | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | SASM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | SOD-L   | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | SOD-R   | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | SRM     | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | TCM     | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | TRM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2010        | VDM     | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006        | GDM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006        | PAM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129 |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | ACM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | AHCM    | ●          | ●           | ●         | ○           | 0x00CF   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | BCM i i | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153                      |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | CCM i i | ●          | ●           | ●         | ●           | 0x00F9   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | CDP     | ●          | ●           | ●         | ●           | 0x0005   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | DDM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | HVAC    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | IPC     | ●          | ●           | ●         | ●           | 0xF020   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | NAV     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | PBM     | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8        |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                                |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | PDM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | PSCM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | RCM     | ●          | ●           | ●         | ○           | 0x00EF 0x0102  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | RFA     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | RGTM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | RHVAC   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | SASM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | SRM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | TCM     | ●          | ●           | ●         | ●           | 0x0121 0x0123 0x0122 0x0124<br>0x0125                      |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | TRM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2010 | VDM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4                             | 2010        | CMR     | ●          | ●           | ●         | ○           | ○  |

| Vehicle      | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--------------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|--|
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4 | 2010        | DABM    | ●          | ●           | ●         | ○           | ○  |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4 | 2010        | DSM     | ●          | ●           | ●         | ○           | 0x00F2   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4 | 2010        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4 | 2010        | SOD-L   | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2. 3L    | DURATEC-HE / I4 | 2010        | SOD-R   | ●          | ●           | ●         | ○           | 0xF026   |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 0x0129 |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | AHCM    | ●          | ●           | ●         | ○           | 0x00CF   |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | BCM i i | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153                      |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | CCM i i | ●          | ●           | ●         | ●           | 0x00F9   |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | CDP     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | DDM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | GDM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | IPC     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | NAV     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | PAM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | PBM     | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8        |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                                |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | PDM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | PSCM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | RCM     | ●          | ●           | ●         | ○           | 0x0102   |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | RFA     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | RGTM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | RHVAC   | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | SASM    | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | TRM     | ●          | ●           | ●         | ●           | ○  |
| GALAXY\S-Max | 2. 5L    | I5              | 2006        | VDM     | ●          | ●           | ●         | ●           | ○  |
| KA           | 1. 0L    | HCS             | 1997        | PATS    | ●          | ●           | ●         | ●           | ○  |
| KA           | 1. 0L    | HCS             | 1997 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| KA           | 1. 0L    | HCS             | 1997 - 1999 | CSM     | ●          | ●           | ●         | ●           | ○  |
| KA           | 1. 0L    | HCS             | 1997 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0009               |
| KA           | 1. 0L    | HCS             | 1999        | ECS     | ●          | ●           | ●         | ●           | ○  |
| KA           | 1. 0L    | Zetec Rocam     | 1999        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| KA           | 1. 0L    | Zetec Rocam     | 1999        | CSM     | ●          | ●           | ●         | ●           | ○  |
| KA           | 1. 0L    | Zetec Rocam     | 1999        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083        |

| Vehicle | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|---|-------------|---------|------------|-------------|-----------|-------------|---|
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | ABS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | BCMii   | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | EATC    | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | EPS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | IPC     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | PAM     | ●          | ●           | ●         | ○           | ○   |
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                             |
| KA      | 1. 2L    | DURATEC 8V                                  | 2009        | RCM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | DURATEC 8V                                  | 2000        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | DURATEC 8V                                  | 2000        | CSM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | DURATEC 8V                                  | 2000        | ECS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | DURATEC 8V                                  | 2000        | GEM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | DURATEC 8V                                  | 2000        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081 0x0082 0x0083               |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | ABS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | BCMii   | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | EATC    | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | EPS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | IPC     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | PAM     | ●          | ●           | ●         | ○           | ○   |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                             |
| KA      | 1. 3L    | Duratorq-Turbo Diesel Common Rail Injection | 2009        | RCM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Endura-E                                    | 1997 - 1998 | PATS    | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Endura-E                                    | 1997 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Endura-E                                    | 1997 - 2000 | CSM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Endura-E                                    | 1997 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080 0x0081 0x0082 0x0083 0x0084 |
| KA      | 1. 3L    | Endura-E                                    | 1999 - 2000 | ECS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 3L    | Endura-E                                    | 2000        | GEM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | DURATEC 8V                                  | 2000        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | DURATEC 8V                                  | 2000        | CSM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | DURATEC 8V                                  | 2000        | ECS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | DURATEC 8V                                  | 2000        | GEM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | DURATEC 8V                                  | 2000        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082 0x0083                      |
| KA      | 1. 6L    | Zetec Rocam                                 | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | Zetec Rocam                                 | 2001        | CSM     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | Zetec Rocam                                 | 2001        | ECS     | ●          | ●           | ●         | ●           | ○   |
| KA      | 1. 6L    | Zetec Rocam                                 | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081 0x0082 0x0083 0x0084        |
| KA      | Other    | Other                                       | 2009        | ABS     | ●          | ●           | ●         | ●           | ○   |
| KA      | Other    | Other                                       | 2009        | BCMii   | ●          | ●           | ●         | ●           | ○   |
| KA      | Other    | Other                                       | 2009        | EATC    | ●          | ●           | ●         | ●           | ○   |



| Vehicle | Capacity | EngineType                                   | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|------|--------|------------|-------------|-----------|-------------|--|
| KA      | Other    | Other  | 2009 | EPS    | ●          | ●           | ●         | ●           | ○  |
| KA      | Other    | Other  | 2009 | IPC    | ●          | ●           | ●         | ●           | ○  |
| KA      | Other    | Other  | 2009 | PAM    | ●          | ●           | ●         | ○           | ○  |
| KA      | Other    | Other  | 2009 | PCM    | ●          | ●           | ●         | ●           | ○  |
| KA      | Other    | Other  | 2009 | RCM    | ●          | ●           | ●         | ●           | ○  |
| Kuga    | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2013 | ABS    | ●          | ●           | ●         | ●           | 0x0012 0x00E8  |
| Kuga    | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2013 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Kuga    | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2013 | APIM   | ●          | ●           | ●         | ●           | 0x0019   |
| Kuga    | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2013 | HCM    | ●          | ●           | ●         | ○           | ○  |
| Kuga    | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2013 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x009A 0x00BC 0x00C3 0x0114   |
| Kuga    | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2013 | PDM    | ●          | ●           | ●         | ○           | 0x0141   |
| Kuga    | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2013 | SOD-L  | ●          | ●           | ●         | ○           | ○  |
| Kuga    | 1. 6L    | GTDI FGEC                                    | 2013 | ABS    | ●          | ●           | ●         | ●           | 0x0012 0x00E8  |
| Kuga    | 1. 6L    | GTDI FGEC                                    | 2013 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| Kuga    | 1. 6L    | GTDI FGEC                                    | 2013 | APIM   | ●          | ●           | ●         | ●           | 0x0019   |
| Kuga    | 1. 6L    | GTDI FGEC                                    | 2013 | HCM    | ●          | ●           | ●         | ○           | ○  |
| Kuga    | 1. 6L    | GTDI FGEC                                    | 2013 | PDM    | ●          | ●           | ●         | ○           | 0x0141   |
| Kuga    | 1. 6L    | GTDI FGEC                                    | 2013 | SOD-L  | ●          | ●           | ●         | ○           | ○  |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | ABS    | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0029 0x002A<br>0x002B 0x002C 0x0030 0x00DD<br>0x00DE 0x00E8                                |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | ACM    | ●          | ●           | ●         | ●           | 0x011A   |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | AWD    | ●          | ●           | ●         | ●           | 0x0005   |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | CMR    | ●          | ●           | ●         | ●           | ○  |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | D_DCU  | ●          | ●           | ●         | ●           | ○  |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | EATC   | ●          | ●           | ●         | ●           | 0x0005   |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | EPS    | ●          | ●           | ●         | ○           | 0x0005   |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | FFH    | ●          | ●           | ●         | ●           | 0x002F   |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF025 0xF026<br>0xF02B 0xF02D 0xF02E 0xF02F<br>0xF030 0xF032 0xF034 0xF035<br>0xF03A 0xF03D |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156  |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | IC     | ●          | ●           | ●         | ●           | 0x0005 0xF01E 0xF020 0xF028<br>0xF032 0xF036 0xF03E  |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | PAM    | ●          | ●           | ●         | ●           | 0x0005   |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | PCM    | ●          | ●           | ●         | ●           | 0x006F 0x0080 0x0081 0x0082<br>0x0083 0x0090 0x0092 0x0098<br>0x0099 0x00AB 0x00AC 0x00B4<br>0x00C1        |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | RCM    | ●          | ●           | ●         | ●           | 0x00EA 0xF027 0xF031   |
| Kuga    | 2. 0L    | Duratorq Turbo Diesel Common Rail Injection  | 2008 | RETM   | ●          | ●           | ●         | ●           | 0x0005   |

| Vehicle | Capacity | EngineType                                       | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|---|
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RKE    | ●          | ●           | ●         | ●           | 0x0005  |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | SRM    | ●          | ●           | ●         | ●           | 0x011D  |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | ACM    | ●          | ●           | ●         | ●           | 0x0005 0x011A   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | AWD    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | EATC   | ●          | ●           | ●         | ●           | 0x0005  |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | EPS    | ●          | ●           | ●         | ○           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | FFH    | ●          | ●           | ●         | ●           | 0x002D 0x002F   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | GEM    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | IC     | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | P_DCU  | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | PAM    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RCM    | ●          | ●           | ●         | ●           | 0x00EA  |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RETM   | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | RKE    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | SRM    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008        | TCM    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2008 - 2013 | ABS    | ●          | ●           | ●         | ●           | 0x0008 0x0029 0x002A 0x002B<br>0x002C 0x0030 0x00DD 0x00DE<br>0x00E8 0x0012 |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2008 - 2013 | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156   |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2013        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2013        | APIM   | ●          | ●           | ●         | ●           | 0x0019  |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2013        | PDM    | ●          | ●           | ●         | ○           | 0x0141  |
| Kuga    | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2013        | SOD-L  | ●          | ●           | ●         | ○           | ○   |
| Kuga    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013        | ABS    | ●          | ●           | ●         | ●           | 0x0005 0x0012 0x00E8  |
| Kuga    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013        | AHCM   | ●          | ●           | ●         | ○           | 0x0005 0x00CF   |
| Kuga    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013        | APIM   | ●          | ●           | ●         | ●           | 0x0019  |
| Kuga    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013        | HCM    | ●          | ●           | ●         | ○           | 0x0005  |
| Kuga    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013        | PCM    | ●          | ●           | ●         | ●           | 0x0067 0x0080 0x0081 0x0082<br>0x0083 0x0108                                |
| Kuga    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013        | PDM    | ●          | ●           | ●         | ○           | 0x0005 0x0141   |
| Kuga    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2013        | SOD-L  | ●          | ●           | ●         | ○           | 0x0005  |
| Kuga    | 2.5L     | I5   | 2008        | ABS    | ●          | ●           | ●         | ●           | 0x0005 0x0008 0x0029 0x002A<br>0x002B 0x002C 0x0030 0x00DD<br>0x00DE 0x00E8 |
| Kuga    | 2.5L     | I5   | 2008        | ACM    | ●          | ●           | ●         | ●           | 0x0005 0x011A   |
| Kuga    | 2.5L     | I5   | 2008        | AWD    | ●          | ●           | ●         | ●           | 0x0005  |
| Kuga    | 2.5L     | I5   | 2008        | CMR    | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.5L     | I5   | 2008        | D_DCU  | ●          | ●           | ●         | ●           | ○   |
| Kuga    | 2.5L     | I5   | 2008        | EATC   | ●          | ●           | ●         | ●           | 0x0005  |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| Kuga    | 2. 5L    | I5   | 2008        | EPS    | ●          | ●           | ●         | ○           | 0x0005   |
| Kuga    | 2. 5L    | I5   | 2008        | FFH    | ●          | ●           | ●         | ●           | 0x002F   |
| Kuga    | 2. 5L    | I5   | 2008        | GEM    | ●          | ●           | ●         | ●           | 0x0005 0x00ED 0xF025 0xF026<br>0xF02B 0xF02D 0xF02E 0xF02F<br>0xF030 0xF032 0xF034 0xF035<br>0xF03A 0xF03D |
| Kuga    | 2. 5L    | I5   | 2008        | HCM    | ●          | ●           | ●         | ●           | 0x0155 0x0156  |
| Kuga    | 2. 5L    | I5   | 2008        | IC     | ●          | ●           | ●         | ●           | 0x0005 0xF01E 0xF020 0xF028<br>0xF031 0xF032 0xF036 0xF03E   |
| Kuga    | 2. 5L    | I5   | 2008        | P_DCU  | ●          | ●           | ●         | ●           | ○  |
| Kuga    | 2. 5L    | I5   | 2008        | PAM    | ●          | ●           | ●         | ●           | 0x0005   |
| Kuga    | 2. 5L    | I5   | 2008        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0126 0x0127   |
| Kuga    | 2. 5L    | I5   | 2008        | RCM    | ●          | ●           | ●         | ●           | 0x0005 0x00EA 0xF027   |
| Kuga    | 2. 5L    | I5   | 2008        | RETM   | ●          | ●           | ●         | ●           | 0x0005   |
| Kuga    | 2. 5L    | I5   | 2008        | RKE    | ●          | ●           | ●         | ●           | 0x0005   |
| Kuga    | 2. 5L    | I5   | 2008        | SRM    | ●          | ●           | ●         | ●           | 0x011D   |
| Kuga    | 2. 5L    | I5   | 2008        | TCM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | APIM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | C-CM   | ●          | ●           | ●         | ○           | 0x0046   |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | DSP    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | FCIM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GPSM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GWM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HCM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HUD    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | RACM   | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | RCM    | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | RTM    | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCCM   | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCM-E  | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 1. 5L    | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SOD-L  | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8  |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | ACM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | BCMii  | ●          | ●           | ●         | ●           | 0x011B 0x011C 0x0132 0x0153<br>0x0009  |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | CDP    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | CMR    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | DDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                  | 2007 - 2011 | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |

| Vehicle | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---|-------------|--------|------------|-------------|-----------|-------------|--|
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032   |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | HVAC   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | IPC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | PAM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | PBM    | ●          | ●           | ●         | ●           | 0x00F3 0x00F4 0x00F5 0x00F6<br>0x00F7 0x00EE 0x00F8  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083<br>0x0025 0x00BC   |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | PDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | PSCM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | RFA    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | SASM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | SRM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | TRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2007 - 2011 | VDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2011        | DABM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2011        | RGTM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2011        | RHVAC  | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2011        | SOD-L  | ●          | ●           | ●         | ○           | 0x00BC 0xF026  |
| MONDEO  | 1. 6L    | DURATEC VCT                                 | 2011        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | ACM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | BCMii  | ●          | ●           | ●         | ●           | 0x011C 0x0132 0x0153   |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | CDP    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | CMR    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | DABM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | DDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | HCM    | ●          | ●           | ●         | ○           | 0x0032   |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | HVAC   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | PAM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | PBM    | ●          | ●           | ●         | ●           | 0x00F3 0x00F4 0x00F5 0x00F6  |
| MONDEO  | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x0099<br>0x009A 0x00B1 0x00B7 0x00B9<br>0x00BC 0x00BD 0x00C1 0x00C3 |

| Vehicle | Capacity | EngineType                                   | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|--|------|--------|------------|-------------|-----------|-------------|--|
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | PDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | PSCM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | RFA    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | RGTM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | RHVAC  | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | SASM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | SRM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | TRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1.6L     | Duratorq Turbo Diesel Common Rail Injection  | 2011 | VDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8        |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | ACM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | BCMii  | ●          | ●           | ●         | ●           | 0x011B 0x011C 0x0132 0x0153                                |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | CDP    | ●          | ●           | ●         | ○           | 0x0005   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | CMR    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | DABM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | DDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | DSM    | ●          | ●           | ●         | ○           | 0x00F2   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | HCM    | ●          | ●           | ●         | ○           | 0x0032   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | HVAC   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | IPC    | ●          | ●           | ●         | ●           | 0xF020   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PAM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PBM    | ●          | ●           | ●         | ●           | 0x00F3 0x00F4 0x00F5 0x00F6<br>0x00F7                      |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083<br>0x009A 0x00BC 0x00C3 0x0114 |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | PSCM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | RFA    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | RGTM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | RHVAC  | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SASM   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SOD-L  | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SOD-R  | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | SRM    | ●          | ●           | ●         | ○           | ○  |

| Vehicle | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| MONDEO  | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 6L    | EcoBoost - Gas Turbocharged Direct Injection | 2011        | VDM     | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 1. 6L    | Zetec  | 1993 - 1999 | ABS     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 6L    | Zetec  | 1993 - 1999 | CSM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 6L    | Zetec  | 1993 - 1999 | PATS    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 6L    | Zetec  | 1997 - 1999 | FFH     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 6L    | Zetec  | 1997 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| MONDEO  | 1. 6L    | Zetec  | 1998 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x00F1   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x00F1   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | ACM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | CDP     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | CSM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | EATC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | GDM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF02D 0xF02F<br>0xF030 0xF03A 0xF09D 0xF09E<br>0xF09F 0xF0A0 0xF0A1 0xF0A2<br>0xF0A3 0xF0A4 0xF0A5 |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | HEC     | ●          | ●           | ●         | ●           | 0x0005  |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | LHID    | ●          | ●           | ●         | ●           | 0x0005 0x0032   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | NAV     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | PATS    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | RCM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | RETM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | RHID    | ●          | ●           | ●         | ●           | 0x0005  |
| MONDEO  | 1. 8L    | DURATEC-HE / I4                              | 2001        | SRM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | ABS     | ●          | ●           | ●         | ●           | 0x00F1  |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x00F1   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | ACM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | CDP     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | CSM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | EATC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | GDM     | ●          | ●           | ●         | ●           | 0x0100  |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | GEM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | HEC     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | LHID    | ●          | ●           | ●         | ●           | 0x0032  |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | NAV     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                  | 2001        | PATS    | ●          | ●           | ●         | ●           | ○   |

| Vehicle | Capacity | EngineType                                  | Year         | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---|--------------|--------|------------|-------------|-----------|-------------|--|
| MONDEO  | 1. 8L    | DURATEC-SCi                                 | 2001         | PCM    | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083   |
| MONDEO  | 1. 8L    | DURATEC-SCi                                 | 2001         | RCM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | DURATEC-SCi                                 | 2001         | RETM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | DURATEC-SCi                                 | 2001         | RHID   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | DURATEC-SCi                                 | 2001         | SRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | ACM    | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | CDP    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | CMR    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | DDM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | DSM    | ●          | ●           | ●         | ●           | 0x00F2   |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | HCM    | ●          | ●           | ●         | ●           | 0x0032   |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | HVAC   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | IPC    | ●          | ●           | ●         | ●           | 0xF020   |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | PAM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | PCM    | ●          | ●           | ●         | ●           | 0x006F 0x0080 0x0081 0x0082<br>0x0083 0x0090 0x0092 0x0098<br>0x0099 0x009A 0x00AB 0x00AC<br>0x00B4 0x00C1 |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | PDM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | PSCM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | RFA    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | SASM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | SRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | TRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Duratorq Turbo Diesel Common Rail Injection | 2007         | VDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 1. 8L    | Endura-DE                                   | 1997         | FFH    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Endura-DE                                   | 1997         | PCM    | ○          | ○           | ●         | ○           | ○  |
| MONDEO  | 1. 8L    | Endura-DE                                   | 1997 - Other | ABS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Endura-DE                                   | 1997 - Other | CSM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Endura-DE                                   | 1997 - Other | PATS   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Zetec                                       | 1993 - 2000  | ABS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Zetec                                       | 1993 - 2000  | CSM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 1. 8L    | Zetec                                       | 1993 - 2000  | PATS   | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|---------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|---|
| MONDEO  | 1. 8L    | Zetec           | 1997 - 1999 | FFH     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | Zetec           | 1997 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 0x0084  |
| MONDEO  | 1. 8L    | Zetec           | 1998 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 1. 8L    | Zetec           | 2000        | AFCM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x00F1   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | CSM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | EATC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | GDM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | GEM     | ●          | ●           | ●         | ●           | 0x0005 0xF027 0xF02D 0xF02F<br>0xF030 0xF03A 0xF09D 0xF09E<br>0xF09F 0xF0A0 0xF0A1 0xF0A2<br>0xF0A3 0xF0A4 0xF0A5 |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | HEC     | ●          | ●           | ●         | ●           | 0x0005  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | LHID    | ●          | ●           | ●         | ●           | 0x0005 0x0032   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | NAV     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | PATS    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | RETM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001        | RHID    | ●          | ●           | ●         | ●           | 0x0005  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001 - 2007 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x00F1 0x002B 0x0053<br>0x0054 0x00D9 0x00E2 0x00E8  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001 - 2007 | ACM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001 - 2007 | CDP     | ●          | ●           | ●         | ●           | 0x0005  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001 - 2007 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x00AC   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001 - 2007 | RCM     | ●          | ●           | ●         | ●           | 0x00EF 0x0102   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2001 - 2007 | SRM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | AHCM    | ●          | ●           | ●         | ○           | 0x00CF  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | BCM i   | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | CCM i   | ●          | ●           | ●         | ●           | 0x00F9  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | CMR     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | DDM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | DSM     | ●          | ●           | ●         | ●           | 0x00F2  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | HCM     | ●          | ●           | ●         | ●           | 0x0032  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | IPC     | ●          | ●           | ●         | ●           | 0xF020  |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | PAM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | PBM     | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | PDM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | PSCM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | RFA     | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 0L    | DURATEC-HE / I4 | 2007        | SASM    | ●          | ●           | ●         | ●           | ○   |



| Vehicle | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| MONDEO  | 2.0L     | DURATEC-HE / I4                             | 2007        | TRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATEC-HE / I4                             | 2007        | VDM     | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | CSM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | EATC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | FFH     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | GDM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | GEM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | HEC     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | ICU     | ○          | ○           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | LHID    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | NAV     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | PATS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | RETM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | RHID    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | ABS     | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | ACM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | CDP     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x006F 0x0080 0x0081 0x0082<br>0x0083 0x0090 0x0092 0x0098<br>0x0099 0x009A 0x00AB 0x00AC<br>0x00B4 0x00C1 |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | RCM     | ●          | ●           | ●         | ●           | 0x00EF 0x0102  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | SRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | TCM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007        | PAM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | AHCM    | ●          | ●           | ●         | ○           | 0x00CF   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | CCMii   | ●          | ●           | ●         | ●           | 0x00F9   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | CMR     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | DDM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | DSM     | ●          | ●           | ●         | ●           | 0x00F2   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | HVAC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | IPC     | ●          | ●           | ●         | ●           | 0xF020   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | PBM     | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | PDM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | PSCM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | RFA     | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2011 | SASM    | ●          | ●           | ●         | ●           | ○  |

| Vehicle | Capacity | EngineType                                       | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|---------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | TRM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | VDM     | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | DABM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | RGTM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | RHVAC   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | SOD-L   | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | SOD-R   | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007        | PAM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007        | RFA     | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2007 - 2011 | ABS     | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | ACM     | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | AHCM    | ●          | ●           | ●         | ○           | 0x00CF  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x011C 0x0132 0x0153                         |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | CCMii   | ●          | ●           | ●         | ●           | 0x00F9  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | CDP     | ●          | ●           | ●         | ●           | 0x0005  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | CMR     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | DDM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | DSM     | ●          | ●           | ●         | ●           | 0x00F2  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | HCM     | ●          | ●           | ●         | ●           | 0x0032  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | HVAC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | IPC     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection StgV | 2007 - 2011 | PBM     | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8 |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                         |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | PDM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | PSCM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | RCM     | ●          | ●           | ●         | ●           | 0x00EF 0x0102                                       |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | SASM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | SRM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | TCM     | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | TRM     | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | VDM     | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | DABM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | RGTM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | RHVAC   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | SOD-L   | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2.0L     | Duratorq Turbo Diesel Common Rail Injection      | 2011        | SOD-R   | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2.0L     | DURATORQ_DI                                      | 2001        | ABS     | ●          | ●           | ●         | ○           | 0x0008 0x00F1                                       |
| MONDEO  | 2.0L     | DURATORQ_DI                                      | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1  |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                  |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|--|
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | ACM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | CDP    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | CSM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | EATC   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | FFH    | ●          | ●           | ●         | ●           | 0x00CF   |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | FIP    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | GDM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | GEM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | HEC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | LHID   | ●          | ●           | ●         | ●           | 0x0032   |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | NAV    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | PATS   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | PCM    | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082 0x0083               |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | RCM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | RETM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | RHID   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | DURATORQ_DI                                  | 2001        | SRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007        | PAM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007        | RFA    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007        | TCM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054 0x00D9 0x00E2 0x00E8 |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | ACM    | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011C 0x0132 0x0153                      |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | CDP    | ●          | ●           | ●         | ●           | 0x0005   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | CMR    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | DDM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | DSM    | ●          | ●           | ●         | ●           | 0x00F2   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | HVAC   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | IPC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5 0x00F6 0x00F7 0x00F8 |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | PDM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | PSCM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | SASM   | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | SRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | TRM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2011 | VDM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2013 | HCM    | ●          | ●           | ●         | ●           | 0x0032   |

| Vehicle | Capacity | EngineType                                   | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|---|
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2013 | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083<br>0x0095 0x0108        |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2007 - 2013 | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102                                       |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | DABM   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RGTM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | RHVAC  | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 - 2013 | SOD-L  | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | APIM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | C-CM   | ●          | ●           | ●         | ○           | 0x0046  |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | DSP    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | FCIM   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GPSM   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | GWM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | HUD    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | RACM   | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | RTM    | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCCM   | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013        | SCM-E  | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007        | PAM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007        | RFA    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007        | TCM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | ACM    | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x0132 0x0153                                |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | CDP    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | CMR    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | DDM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | DSM    | ●          | ●           | ●         | ●           | 0x00F2  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | IPC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8 |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083                         |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | PDM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | PSCM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only            | 2007 - 2011 | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102                                       |

| Vehicle | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2007 - 2011 | SASM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2007 - 2011 | SRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2007 - 2011 | TRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2007 - 2011 | VDM     | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2011        | DABM    | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2011        | IPM-A   | ●          | ●           | ●         | ○           | 0x00E5   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2011        | RGTM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2011        | RHVAC   | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2011        | SOD-L   | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 2.0L     | Ecoboost GTDI Chinese market only           | 2011        | SOD-R   | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 2.0L     | Zetec                                       | 1993 - 2000 | ABS     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Zetec                                       | 1993 - 2000 | CSM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Zetec                                       | 1993 - 2000 | PATS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Zetec                                       | 1997 - 1999 | FFH     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.0L     | Zetec                                       | 1997 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 0x0084   |
| MONDEO  | 2.0L     | Zetec                                       | 1998 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x00F1   |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | CSM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | EATC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | FFH     | ●          | ●           | ●         | ●           | 0x00CF   |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | GDM     | ●          | ●           | ●         | ●           | 0x0100   |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | GEM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | HEC     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | ICU     | ○          | ○           | ●         | ○           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | LHID    | ●          | ●           | ●         | ●           | 0x0032   |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | NAV     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | PATS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | RETM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | RHID    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2007 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083 0x0092 0x0090 0x0098<br>0x0099 0x009A 0x00A5 0x00AA<br>0x00AF 0x00B0 0x00B1 0x00B2<br>0x00B8 0x00B9 0x00C1 |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | ABS     | ●          | ●           | ●         | ○           | 0x0008 0x00F1 0x002B 0x0053<br>0x0054 0x00D9 0x00E2 0x00E8   |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | ACM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | CDP     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | RCM     | ●          | ●           | ●         | ●           | 0x00EF 0x0102  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2001 - 2011 | SRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2007        | PAM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2.2L     | Duratorq Turbo Diesel Common Rail Injection | 2007        | RFA     | ●          | ●           | ●         | ○           | ○  |

| Vehicle | Capacity | EngineType                                       | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|---------|----------|--|-------------|--------|------------|-------------|-----------|-------------|---|
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011C 0x0132 0x0153                         |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | CMR    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | DDM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | DSM    | ●          | ●           | ●         | ●           | 0x00F2  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | IPC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6 0x00F7 0x00F8 |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | PDM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | PSCM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | SASM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | TRM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2007 - 2011 | VDM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | DABM   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | RGTM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | RHVAC  | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | SOD-L  | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection StgV | 2011        | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | ACM    | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection StgV | 2011        | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153               |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | CDP    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | CMR    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | DABM   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | DDM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | DSM    | ●          | ●           | ●         | ○           | 0x00F2  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | HCM    | ●          | ●           | ●         | ○           | 0x0032  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | HVAC   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | IPC    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | PBM    | ●          | ●           | ●         | ●           | 0x00F3 0x00F4 0x00F5 0x00F7                         |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | PCM    | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083                         |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | PDM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection      | 2011        | PSCM   | ●          | ●           | ●         | ○           | ○   |

| Vehicle | Capacity | EngineType                                  | Year        | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|---------|----------|---|-------------|--------|------------|-------------|-----------|-------------|---|
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102                                       |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | RGTM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | RHVAC  | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | SASM   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | SOD-L  | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | SOD-R  | ●          | ●           | ●         | ○           | 0xF026  |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | SRM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | TCM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | TRM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | VDM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007        | PAM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | ABS    | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8 |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | ACM    | ●          | ●           | ○         | ○           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | BCMii  | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153               |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | CCMii  | ●          | ●           | ●         | ●           | 0x00F9  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | CDP    | ●          | ●           | ●         | ●           | 0x0005  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | CMR    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | DDM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | DSM    | ●          | ●           | ●         | ●           | 0x00F2  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | HCM    | ●          | ●           | ●         | ●           | 0x0032  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | HVAC   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | IPC    | ●          | ●           | ●         | ●           | 0xF020  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | PBM    | ●          | ●           | ●         | ●           | 0x00EE 0x00F3 0x00F4 0x00F5<br>0x00F6               |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x00AC               |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | PDM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | PSCM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | RCM    | ●          | ●           | ●         | ●           | 0x00EF 0x0102                                       |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | RFA    | ●          | ●           | ●         | ○           | 0x000A  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | SASM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | SRM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | TCM    | ●          | ●           | ●         | ●           | 0x0121 0x0122 0x0123 0x0124<br>0x0125               |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | TRM    | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | VDM    | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2011        | DABM   | ●          | ●           | ●         | ○           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2011        | IPM-A  | ●          | ●           | ●         | ○           | 0x00E5  |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2011        | RGTM   | ●          | ●           | ●         | ●           | ○   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4                             | 2011        | RHVAC  | ●          | ●           | ●         | ○           | ○   |

| Vehicle | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|---------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|--|
| MONDEO  | 2. 3L    | DURATEC-HE / I4 | 2011        | SOD-L   | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 2. 3L    | DURATEC-HE / I4 | 2011        | SOD-R   | ●          | ●           | ●         | ○           | 0xF026   |
| MONDEO  | 2. 5L    | Duratec-VE      | 1994 - 2001 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x00F1  |
| MONDEO  | 2. 5L    | Duratec-VE      | 1994 - 2001 | CSM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 1994 - 2001 | PATS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 1997 - 1999 | FFH     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 1997 - 2001 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0083 0x0009<br>0x0084 |
| MONDEO  | 2. 5L    | Duratec-VE      | 1998 - 2001 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x00F1  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | ACM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | CDP     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | EATC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | GDM     | ●          | ●           | ●         | ●           | 0x0100   |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | GEM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | HEC     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | LHID    | ●          | ●           | ●         | ●           | 0x0032   |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | NAV     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | RCM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | RETM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | RHID    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | Duratec-VE      | 2001        | SRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | ABS     | ●          | ●           | ●         | ○           | 0x0008 0x002B 0x0053 0x0054<br>0x00D9 0x00E2 0x00E8                  |
| MONDEO  | 2. 5L    | I5              | 2007        | ACM     | ●          | ●           | ○         | ○           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | AHCM    | ●          | ●           | ●         | ○           | 0x00CF   |
| MONDEO  | 2. 5L    | I5              | 2007        | BCM i i | ●          | ●           | ●         | ●           | 0x0009 0x011B 0x011C 0x0132<br>0x0153                                |
| MONDEO  | 2. 5L    | I5              | 2007        | CCM i i | ●          | ●           | ●         | ●           | 0x00F9   |
| MONDEO  | 2. 5L    | I5              | 2007        | CDP     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | CMR     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | DDM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | DSM     | ●          | ●           | ●         | ●           | 0x00F2   |
| MONDEO  | 2. 5L    | I5              | 2007        | HCM     | ●          | ●           | ●         | ●           | 0x0032   |
| MONDEO  | 2. 5L    | I5              | 2007        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | IPC     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | PAM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | PBM     | ●          | ●           | ●         | ●           | 0x00F3 0x00F4 0x00F5 0x00F6<br>0x00F7                                |
| MONDEO  | 2. 5L    | I5              | 2007        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| MONDEO  | 2. 5L    | I5              | 2007        | PDM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | PSCM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5              | 2007        | RCM     | ●          | ●           | ●         | ●           | 0x00EF 0x0102  |



| Vehicle | Capacity | EngineType | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                              |
|---------|----------|------------|-------------|---------|------------|-------------|-----------|-------------|--|
| MONDEO  | 2. 5L    | I5         | 2007        | RFA     | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 2. 5L    | I5         | 2007        | SASM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5         | 2007        | SRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5         | 2007        | TRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 2. 5L    | I5         | 2007        | VDM     | ●          | ●           | ●         | ○           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x00F1                                |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x00F1                                |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | ACM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | CDP     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | CSM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | EATC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | GDM     | ●          | ●           | ●         | ●           | 0x0100                                       |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | GEM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | HEC     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | LHID    | ●          | ●           | ●         | ●           | 0x0032                                       |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | NAV     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | PATS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | RCM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | RETM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | RHID    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec SE | 2001        | SRM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x00F1                                |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x00F1                                |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | ACM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | CDP     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | CSM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | EATC    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | GDM     | ●          | ●           | ●         | ●           | 0x0100                                       |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | GEM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | HEC     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | LHID    | ●          | ●           | ●         | ●           | 0x0032                                       |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | NAV     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | PATS    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | RCM     | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | RETM    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | RHID    | ●          | ●           | ●         | ●           | ○  |
| MONDEO  | 3. 0L    | Duratec-ST | 2001        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Puma    | 1. 4L    | Zetec-SE   | 1998 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |

| Vehicle                                  | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|--|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Puma                                     | 1. 4L    | Zetec-SE                                    | 1998 - 1999 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 4L    | Zetec-SE                                    | 1998 - 1999 | PATS    | ○          | ○           | ●         | ○           | ○  |
| Puma                                     | 1. 4L    | Zetec-SE                                    | 1998 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083                         |
| Puma                                     | 1. 4L    | Zetec-SE                                    | 1999        | GEM     | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 6L    | Zetec-SE                                    | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 6L    | Zetec-SE                                    | 2001        | GEM     | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 6L    | Zetec-SE                                    | 2001        | HEC     | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 6L    | Zetec-SE                                    | 2001        | PATS    | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 6L    | Zetec-SE                                    | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084           |
| Puma                                     | 1. 7L    | Zetec-SE                                    | 1997 - 2001 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 7L    | Zetec-SE                                    | 1997 - 2001 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 7L    | Zetec-SE                                    | 1997 - 2001 | PATS    | ●          | ●           | ●         | ●           | ○  |
| Puma                                     | 1. 7L    | Zetec-SE                                    | 1997 - 2001 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0084                  |
| Puma                                     | 1. 7L    | Zetec-SE                                    | 1999 - 2001 | GEM     | ●          | ●           | ●         | ●           | ○  |
| Ranger                                   | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2009 | 4X4     | ●          | ●           | ●         | ●           | ○  |
| Ranger                                   | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2009 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Ranger                                   | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2009 | GEM     | ●          | ●           | ●         | ●           | 0x000A 0x0063  |
| Ranger                                   | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2009 | IC      | ●          | ●           | ●         | ●           | 0x0009   |
| Ranger                                   | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2009 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0024 0x0025<br>0x0080 0x0081 0x0082 0x0083<br>0x0084 |
| Ranger                                   | 2. 3L    | DURATEC-HE / I4                             | 2006 - 2009 | RCM     | ●          | ●           | ●         | ●           | 0x000C   |
| Ranger                                   | 2. 3L    | DURATEC-HE / I4                             | 2009        | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3   |
| Ranger                                   | 3. 0L    | I4 DSL Electronic                           | 2005        | 4X4     | ●          | ●           | ●         | ●           | ○  |
| Ranger                                   | 3. 0L    | I4 DSL Electronic                           | 2005        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Ranger                                   | 3. 0L    | I4 DSL Electronic                           | 2005        | GEM     | ●          | ●           | ●         | ●           | 0x0063   |
| Ranger                                   | 3. 0L    | I4 DSL Electronic                           | 2005        | IC      | ●          | ●           | ●         | ●           | ○  |
| Ranger                                   | 3. 0L    | I4 DSL Electronic                           | 2005        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083                                |
| Ranger                                   | 3. 0L    | I4 DSL Electronic                           | 2005        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Ranger                                   | 3. 0L    | I4 DSL Electronic                           | 2005        | TBM     | ●          | ●           | ●         | ●           | 0x00D1 0x00D2 0x00D3   |
| Ranger / Courier / Mazda B Series /Bravo | 4. 0L    | V6 SOHC                                     | 2003        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Ranger / Courier / Mazda B Series /Bravo | 4. 0L    | V6 SOHC                                     | 2003        | ESOF    | ●          | ●           | ●         | ●           | ○  |
| Ranger / Courier / Mazda B Series /Bravo | 4. 0L    | V6 SOHC                                     | 2003        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084           |
| Ranger / Mazda B-Series / Courier        | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x001E 0x00CA   |
| Ranger / Mazda B-Series / Courier        | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | ACM     | ●          | ●           | ●         | ○           | ○  |
| Ranger / Mazda B-Series / Courier        | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | BCMii   | ●          | ●           | ●         | ●           | 0x00D5   |
| Ranger / Mazda B-Series / Courier        | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | DDM     | ●          | ●           | ●         | ●           | ○  |
| Ranger / Mazda B-Series / Courier        | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | FCDIM   | ●          | ●           | ●         | ●           | ○  |

| Vehicle                           | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-----------------------------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|---|
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083 0x0090 0x0092 0x0098<br>0x0099 0x009A 0x00B0 0x00B1<br>0x00B3 0x00B9 0x00BC 0x00BD<br>0x00C1 0x00E7 |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | PDM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | RCM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | SRM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | TBM     | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3  |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | TCM     | ●          | ●           | ●         | ●           | 0x0038  |
| Ranger / Mazda B-Series / Courier | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2004 - 2007 | GEM     | ●          | ●           | ●         | ●           | 0x000A 0x0203   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2004 - 2009 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2004 - 2011 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2004 - 2011 | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2004 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0023 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0010 0x0024 0x0028 0x0031<br>0x0033                                       |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2004 - 2011 | RCM     | ●          | ●           | ●         | ●           | 0x000C  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2005        | TPM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | OCSM    | ●          | ●           | ●         | ○           | 0x000C  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2007 - 2011 | SDARS   | ●          | ●           | ●         | ●           | 0x0019  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2008 - 2011 | GEM /   | ●          | ●           | ●         | ●           | 0x000A 0x0042   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | DURATEC-HE / I4                             | 2010 - 2011 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | OHC   | 1995 - 1997 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | OHC   | 1995 - 1997 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | OHC   | 1995 - 1997 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | OHC   | 1995 - 1997 | RAP     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | OHC   | 1996 - 1997 | IAB     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | Other                                       | 1996 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | Other                                       | 1996 - 2003 | GEM     | ●          | ●           | ●         | ●           | 0x0203  |
| Ranger / Mazda B-Series / Courier | 2. 3L    | Other                                       | 1996 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0009 0x0010<br>0x0028 0x0031 0x0033 0x0084   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | Other                                       | 2001        | PATS    | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | Other                                       | 2001 - 2003 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | Other                                       | 2001 - 2003 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Ranger / Mazda B-Series / Courier | 2. 3L    | Other                                       | 2001 - 2003 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2. 5L    | DURATEC-HE / I4                             | 2011        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x001E 0x00CA  |

| Vehicle                           | Capacity | EngineType      | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-----------------------------------|----------|-----------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | ACM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | BCMii   | ●          | ●           | ●         | ●           | 0x00D5  |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | DDM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | PDM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | RCM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | SRM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | TBM     | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3  |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | TCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998        | IAB     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 - 2001 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 - 2001 | GEM     | ●          | ●           | ●         | ●           | 0x0203  |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 - 2001 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 0x0009 |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 - 2001 | RAP     | ●          | ●           | ●         | ●           | 0x000A  |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1999 - 2001 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1999 - 2001 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2001        | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001        | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001        | GEM     | ●          | ●           | ●         | ●           | 0x0203  |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001        | PATS    | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083   |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001        | RAP     | ●          | ●           | ●         | ●           | 0x000A  |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 - 2000 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 - 2000 | GEM     | ●          | ●           | ●         | ●           | 0x0203  |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 - 2000 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 - 2000 | PCM     | ●          | ●           | ●         | ●           | 0x0010 0x0023 0x0025 0x0028<br>0x0031 0x0033 0x0080 0x0081<br>0x0082 0x0083 0x0084        |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 - 2000 | RAP     | ●          | ●           | ●         | ●           | 0x000A  |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 - 2000 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other           | 1995 - 2003 | RAP     | ●          | ●           | ●         | ●           | 0x000A  |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other           | 1995 - 2007 | GEM     | ●          | ●           | ●         | ●           | 0x0203 0x000A   |

| Vehicle                           | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-----------------------------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|---|
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 1995 - 2008 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 1995 - 2008 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 0x0009<br>0x0024 |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 1996 - 1998 | IAB     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 1999 - 2008 | RCM     | ●          | ●           | ●         | ●           | 0x000C  |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 2000 - 2001 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 2001 - 2008 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 2004 - 2008 | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 2005        | TPM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 2007 - 2008 | OCSM    | ●          | ●           | ●         | ○           | 0x000C  |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 2007 - 2008 | SDARS   | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other                                       | 2008        | GEM /   | ●          | ●           | ●         | ●           | 0x000A 0x0042   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | ABS     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | ACM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | BCMii   | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | DDM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | PCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | PDM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | RCM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | SRM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | TBM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | TCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq Turbo Diesel Common Rail Injection | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 1995 - 2002 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 1995 - 2002 | GEM     | ●          | ●           | ●         | ●           | 0x0203  |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 1995 - 2002 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 0x0009           |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 1995 - 2002 | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 1996 - 1998 | IAB     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 1999 - 2001 | PATS    | ●          | ●           | ●         | ●           | 0x0009  |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 1999 - 2002 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other                                       | 2001 - 2002 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC                                     | 2003        | RAP     | ●          | ●           | ●         | ●           | 0x000A 0x000F   |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC                                     | 2003 - 2007 | GEM     | ●          | ●           | ●         | ●           | 0x0203 0x000A   |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC                                     | 2003 - 2009 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |

| Vehicle                           | Capacity | EngineType  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-----------------------------------|----------|-------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2003 - 2011 | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2003 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0010 0x0023 0x0025<br>0x0028 0x0031 0x0033 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0024 |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2003 - 2011 | RCM     | ●          | ●           | ●         | ●           | 0x000C  |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2004 - 2011 | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2005        | TPM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2007 - 2011 | OCSM    | ●          | ●           | ●         | ○           | 0x000C  |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2007 - 2011 | SDARS   | ●          | ●           | ●         | ●           | 0x0019  |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2008 - 2011 | GEM /   | ●          | ●           | ●         | ●           | 0x000A 0x0042   |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2010 - 2011 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0012   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004        | 4X4     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004        | IC      | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004        | PCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004 - 2011 | RCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | ABS     | ●          | ●           | ●         | ●           | 0x00CA  |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | ACM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | BCMii   | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | DDM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | FCDIM   | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | HVAC    | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | PDM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | SRM     | ●          | ●           | ●         | ○           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | TBM     | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3  |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | TCM     | ●          | ●           | ●         | ●           | ○   |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011        | TRM     | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006 - 2010 | ABS/TCS | ●          | ●           | ●         | ●           | 0x000B 0x0008   |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006 - 2010 | IC      | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006 - 2010 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x012E   |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006 - 2010 | RCM     | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006 - 2010 | RKE     | ●          | ●           | ●         | ●           | 0x000A  |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010        | TBM     | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3  |
| S. A. Fiesta                      | 1.0L     | Zetec Rocam | 2002        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta                      | 1.0L     | Zetec Rocam | 2002        | IC      | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta                      | 1.0L     | Zetec Rocam | 2002        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083  |
| S. A. Fiesta                      | 1.0L     | Zetec Rocam | 2002        | RCM     | ●          | ●           | ●         | ●           | ○   |

| Vehicle      | Capacity | EngineType                                   | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|--------------|----------|--|-------------|---------|------------|-------------|-----------|-------------|---|
| S. A. Fiesta | 1.0L     | Zetec Rocam                                  | 2002        | RKE     | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2011 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| S. A. Fiesta | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2011 | IC      | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083 0x0025        |
| S. A. Fiesta | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2011 | RCM     | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.4L     | Duratorq Turbo Diesel Common Rail Injection  | 2002 - 2011 | RKE     | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.6L     | FFV  | 2002 - 2011 | ABS/TCS | ●          | ●           | ●         | ●           | 0x000B 0x0008                                       |
| S. A. Fiesta | 1.6L     | FFV  | 2002 - 2011 | IC      | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.6L     | FFV  | 2002 - 2011 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x012E |
| S. A. Fiesta | 1.6L     | FFV  | 2002 - 2011 | RCM     | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.6L     | FFV  | 2002 - 2011 | RKE     | ●          | ●           | ●         | ●           | 0x000A  |
| S. A. Fiesta | 1.6L     | FFV  | 2011        | TBM     | ●          | ●           | ●         | ○           | 0x00D1 0x00D2 0x00D3                                |
| S. A. Fiesta | 1.6L     | Zetec Rocam                                  | 2002 - 2009 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| S. A. Fiesta | 1.6L     | Zetec Rocam                                  | 2002 - 2009 | IC      | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.6L     | Zetec Rocam                                  | 2002 - 2009 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083        |
| S. A. Fiesta | 1.6L     | Zetec Rocam                                  | 2002 - 2009 | RCM     | ●          | ●           | ●         | ●           | ○   |
| S. A. Fiesta | 1.6L     | Zetec Rocam                                  | 2002 - 2009 | RKE     | ●          | ●           | ●         | ●           | 0x000A  |
| Street Ka    | 1.6L     | DURATEC 8V                                   | 2003        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Street Ka    | 1.6L     | DURATEC 8V                                   | 2003        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Street Ka    | 1.6L     | DURATEC 8V                                   | 2003        | ECS     | ●          | ●           | ○         | ○           | ○   |
| Street Ka    | 1.6L     | DURATEC 8V                                   | 2003        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Street Ka    | 1.6L     | DURATEC 8V                                   | 2003        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081<br>0x0082 0x0083        |
| Transit      | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection  | 2016        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0083 0x00AC                         |
| Transit      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2016 MY     | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0083 0x00AC                         |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | APIM    | ●          | ●           | ●         | ●           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | AWD#1   | ●          | ●           | ●         | ●           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | CCMii   | ●          | ●           | ●         | ●           | 0x00F9  |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | FCIM    | ●          | ●           | ●         | ●           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | HCM     | ●          | ●           | ●         | ○           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | SASM    | ●          | ●           | ●         | ○           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | TRM     | ●          | ●           | ●         | ●           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | APIM    | ●          | ●           | ●         | ●           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | AWD#1   | ●          | ●           | ●         | ●           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | CCMii   | ●          | ●           | ●         | ●           | 0x00F9  |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | FCIM    | ●          | ●           | ●         | ●           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | HCM     | ●          | ●           | ●         | ○           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | PAM     | ●          | ●           | ●         | ○           | ○   |
| Transit      | 2.2L     | Duratorq Turbo Diesel Common Rail Injection  | 2014        | SASM    | ●          | ●           | ●         | ○           | ○   |

| Vehicle         | Capacity | EngineType                                   | Year | Module | Read Codes | Erase Codes | Live Data | Active Test | Specil Function                                     |
|-----------------|----------|--|------|--------|------------|-------------|-----------|-------------|---|
| Transit         | 2. 2L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | TRM    | ●          | ●           | ●         | ●           | ○   |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | APIM   | ●          | ●           | ●         | ●           | ○   |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | AWD#1  | ●          | ●           | ●         | ●           | ○   |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | CCMi i | ●          | ●           | ●         | ●           | 0x00F9  |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | FCIM   | ●          | ●           | ●         | ●           | ○   |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | HCM    | ●          | ●           | ●         | ○           | ○   |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | PAM    | ●          | ●           | ●         | ○           | ○   |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | SASM   | ●          | ●           | ●         | ○           | ○   |
| Transit         | 2. 2L    | TDCi_StgVI                                   | 2014 | TRM    | ●          | ●           | ●         | ●           | ○   |
| Transit         | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | TCM    | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | APIM   | ●          | ●           | ●         | ●           | 0x0019  |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | BCMii  | ●          | ●           | ●         | ●           | 0x00D5 0x0101                                       |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | DDM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | GPSM   | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | HCM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | HVAC   | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x009A 0x00BC 0x0114 |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | PDM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 0L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | TRM    | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | APIM   | ●          | ●           | ●         | ●           | 0x0019  |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | BCMii  | ●          | ●           | ●         | ●           | 0x00D5 0x0101                                       |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | DDM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | GPSM   | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | HCM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | HVAC   | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | PCM    | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083                         |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | PDM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | Duratorq Turbo Diesel Common Rail Injection  | 2014 | TRM    | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | APIM   | ●          | ●           | ●         | ●           | 0x0019  |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | BCMii  | ●          | ●           | ●         | ●           | 0x00D5 0x0101                                       |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | DDM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | GPSM   | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | HCM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | HVAC   | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | PDM    | ●          | ●           | ●         | ○           | ○   |
| Transit Connect | 1. 6L    | EcoBoost – Gas Turbocharged Direct Injection | 2014 | TRM    | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 1. 6L    | TDCi ECO III                                 | 2014 | AHCM   | ●          | ●           | ●         | ○           | 0x00CF  |
| Transit Connect | 1. 6L    | TDCi ECO III                                 | 2014 | APIM   | ●          | ●           | ●         | ●           | 0x0019  |



| Vehicle         | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-----------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | BCMii   | ●          | ●           | ●         | ●           | 0x00D5 0x0101  |
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | DDM     | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | GPSM    | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | HCM     | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | HVAC    | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | PCM     | ●          | ●           | ●         | ○           | 0x0080 0x0081 0x0082 0x0083  |
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | PDM     | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 1.6L     | TDCi ECO III                                | 2014        | TRM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | 2.0 DOHC SFI (8V)                           | 1995 - 1997 | PATS    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | 2.0 DOHC SFI (8V)                           | 1995 - 1999 | ABS     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | 2.0 DOHC SFI (8V)                           | 1995 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | 2.0 DOHC SFI (8V)                           | 1995 - 1999 | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | 2.0 DOHC SFI (8V)                           | 1995 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0083                  |
| Transit Connect | 2.0L     | 2.0 DOHC SFI (8V)                           | 1999        | AFCM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | ABS     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | GEM /   | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | IC      | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | OCSM    | ●          | ●           | ●         | ●           | 0x000C 0x006D  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0024 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084<br>0x0023 |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | SRM     | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010 - 2012 | VSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | FFH     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | FIP     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | HEC     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | ICU     | ○          | ○           | ●         | ○           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0092                                |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | RASM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | Duratorq Turbo Diesel Common Rail Injection | 2001        | TCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                 | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Transit Connect | 2.0L     | DURATORQ_DI                                 | 2001        | CSM     | ●          | ●           | ●         | ●           | ○  |

| Vehicle         | Capacity | EngineType                                    | Year | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-----------------|----------|---|------|---------|------------|-------------|-----------|-------------|--|
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | EPB     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | FFH     | ●          | ●           | ●         | ●           | 0x00CF   |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | FIP     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | HEC     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | PATS    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082 0x0083   |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | RASM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.0L     | DURATORQ_DI                                   | 2001 | TCM     | ●          | ●           | ●         | ●           | 0x003F   |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0053 0x00DD 0x00E3 0x00E4 0x00E8 0x011F 0x0135  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x011C  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | FFH     | ●          | ●           | ●         | ●           | 0x00CF   |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | IPC     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083 0x0090 0x0092 0x0098 0x00A6 0x00A7 0x00A8 0x00A9 0x00B0 0x00B1 0x00B5 0x00B6 0x00C0 0x00C1 0x00C2 0x00C4 |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq Turbo Diesel Common Rail Injection   | 2006 | SRM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | ABS     | ●          | ●           | ●         | ●           | 0x0053 0x00DD 0x00E3 0x00E4 0x00E8 0x011F 0x0135   |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | BCMii   | ●          | ●           | ●         | ●           | 0x011C   |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | FFH     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | IPC     | ●          | ●           | ●         | ●           | 0xF020   |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Inj_Stage_V | 2006 | SRM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Injection   | 2006 | ABS     | ●          | ●           | ●         | ●           | 0x0053 0x00DD 0x00E3 0x00E4 0x00E8 0x011F 0x0135   |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Injection   | 2006 | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.2L     | Duratorq_Turbo_Diesel_Common_Rail_Injection   | 2006 | ACM     | ●          | ●           | ●         | ●           | ○  |

| Vehicle         | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-----------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|---|
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | BCMii   | ●          | ●           | ●         | ●           | 0x011C  |
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | FFH     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083   |
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | PATS    | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0025 0x0080 0x0081 0x0082 0x0083   |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | RASM    | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DOHC SFI (16V)                              | 2001        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0053 0x00DD 0x00E3 0x00E4 0x00E8 0x011F 0x0135   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | ACM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x011C   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | FFH     | ●          | ●           | ●         | ●           | 0x00CF  |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | IPC     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082 0x0083 0x00AC   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 3L    | DURATEC-HE / I4                             | 2006        | SRM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000        | ICU     | ○          | ○           | ●         | ○           | ○   |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000 - 2006 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000 - 2006 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000 - 2006 | FFH     | ●          | ●           | ●         | ●           | 0x00CF  |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000 - 2006 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000 - 2006 | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082 0x0083 0x0092 0x0090 0x0098 0x00A6 0x00A7 0x00A8 0x00A9 0x00B0 0x00B1 0x00B5 0x00B6 0x00C0 0x00C1 0x00C2 0x00C4 |
| Transit Connect | 2. 4L    | Duratorq Turbo Diesel Common Rail Injection | 2000 - 2006 | RCM     | ●          | ●           | ●         | ●           | ○   |

| Vehicle         | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-----------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Transit Connect | 2.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0053 0x00DD 0x00E3<br>0x00E4 0x00E8 0x011F 0x0135 |
| Transit Connect | 2.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x011C  |
| Transit Connect | 2.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | IPC     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | Duratorq Turbo Diesel Common Rail Injection | 2006        | TBM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008   |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | EPB     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | FFH     | ●          | ●           | ●         | ●           | 0x00CF   |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | FIP     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | HEC     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | PATS    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x0080 0x0081 0x0082<br>0x0083                      |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | RASM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.4L     | DURATORQ_DI                                 | 2000        | TCM     | ●          | ●           | ●         | ●           | 0x003F   |
| Transit Connect | 2.5L     | 2.5 turbo diesel engines with EPIC          | Other       | ABS     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | 2.5 turbo diesel engines with EPIC          | Other       | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | 2.5 turbo diesel engines with EPIC          | Other       | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | 2.5 turbo diesel engines with EPIC          | Other       | PCM     | ●          | ●           | ●         | ●           | 0x0025 0x0080 0x0081 0x0082<br>0x0083 0x0083               |
| Transit Connect | 2.5L     | IVCT  | 2014        | DDM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | FCIM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | GPSM    | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | HCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | HVAC    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | OCSM    | ●          | ●           | ●         | ●           | 0x000C   |
| Transit Connect | 2.5L     | IVCT  | 2014        | PAM     | ●          | ●           | ○         | ○           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0024 0x0025 0x0080<br>0x0081 0x0082 0x0083 0x0084 |
| Transit Connect | 2.5L     | IVCT  | 2014        | PDM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | PSCM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 2.5L     | IVCT  | 2014        | TRM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011        | SRM     | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | ABS     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | ACCM#2  | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | GEM /   | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | IC      | ●          | ●           | ●         | ●           | ○  |

| Vehicle         | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function  |
|-----------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|--|
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | OCSM    | ●          | ●           | ●         | ●           | 0x000C   |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | PSCM    | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | RCM     | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2011 - 2013 | VSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 28kWh    | Battery_Electric_Vehicle                    | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | ABS     | ●          | ●           | ●         | ●           | 0x0008 0x0053 0x00DD 0x00E3<br>0x00E4 0x00E8 0x011F 0x0135   |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | BCMii   | ●          | ●           | ●         | ●           | 0x0009 0x011C  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | FFH     | ●          | ●           | ●         | ●           | 0x00CF   |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | IPC     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0090 0x0092 0x0098 0x00A6<br>0x00A7 0x00A8 0x00A9 0x00B0<br>0x00B1 0x00B5 0x00B6 0x00C0<br>0x00C1 0x00C2 0x00C4 |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq Turbo Diesel Common Rail Injection | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | ABS     | ●          | ●           | ●         | ●           | 0x0053 0x00DD 0x00E3 0x00E4<br>0x00E8 0x011F 0x0135  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | ABS/TCS | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | BCMii   | ●          | ●           | ●         | ●           | 0x011C   |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | CSM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | FFH     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | IPC     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | RCM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | 3. 2L    | Duratorq_Turbo_Diesel_Common_Rail_Injection | 2006        | SRM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | ABS     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | ACM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | APIM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | GEM /   | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | IC      | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | OCSM    | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | PAM     | ●          | ●           | ●         | ●           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | RCM     | ●          | ●           | ●         | ○           | ○  |
| Transit Connect | Other    | Other                                       | 2013        | VSM     | ●          | ●           | ●         | ●           | ○  |

| Vehicle                           | Capacity | EngineType                                  | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|-----------------------------------|----------|---|-------------|---------|------------|-------------|-----------|-------------|---|
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002        | ICU     | ○          | ○           | ●         | ○           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | CSM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2007 | ECS     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2009 | FFH     | ●          | ●           | ●         | ●           | 0x00CF  |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2009 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2002 - 2009 | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0009 0x0092 0x0092 0x006F<br>0x0090 0x0098 0x0099 0x00AB<br>0x00AC 0x00B4 0x00C1 |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2009 | ABS     | ●          | ●           | ●         | ●           | 0x002B 0x0054 0x00D7 0x00DD<br>0x00E2 0x00E8  |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2009 | ACM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2009 | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2007 - 2009 | SRM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2009        | GEM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq Turbo Diesel Common Rail Injection | 2009        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | FFH     | ●          | ●           | ●         | ●           | 0x00CF  |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | FIP     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                   | 2002        | PCM     | ●          | ●           | ●         | ●           | 0x0009 0x000A 0x0080 0x0081<br>0x0082 0x0083  |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | ABS/TCS | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | AFCM    | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | CSM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | ECS     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | FFH     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | HEC     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec                                       | 2002        | PCM     | ●          | ●           | ●         | ●           | 0x0080 0x0081 0x0082 0x0083<br>0x0084   |
| Windstar                          | 3.0L     | V6 OHV                                      | 1995 - 1998 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Windstar                          | 3.0L     | V6 OHV                                      | 1995 - 1999 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008  |
| Windstar                          | 3.0L     | V6 OHV                                      | 1995 - 1999 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033                                       |
| Windstar                          | 3.0L     | V6 OHV                                      | 1996 - 1998 | IAB     | ●          | ●           | ●         | ●           | ○   |
| Windstar                          | 3.0L     | V6 OHV                                      | 1996 - 1998 | PATS    | ●          | ●           | ●         | ●           | ○   |

| Vehicle  | Capacity | EngineType | Year        | Module  | Read Codes | Erase Codes | Live Data | Active Test | Specil Function   |
|----------|----------|------------|-------------|---------|------------|-------------|-----------|-------------|---|
| Windstar | 3.0L     | V6 OHV     | 1998        | RAP     | ●          | ●           | ●         | ●           | 0x000A  |
| Windstar | 3.0L     | V6 OHV     | 1999        | DDM     | ●          | ●           | ●         | ●           | 0x000A  |
| Windstar | 3.0L     | V6 OHV     | 1999        | FEM     | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.0L     | V6 OHV     | 1999        | IC      | ●          | ●           | ●         | ●           | 0x0009  |
| Windstar | 3.0L     | V6 OHV     | 1999        | MC      | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.0L     | V6 OHV     | 1999        | NGSC    | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.0L     | V6 OHV     | 1999        | PAM     | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.0L     | V6 OHV     | 1999        | RCM     | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.0L     | V6 OHV     | 1999        | REM     | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1995 - 1998 | GEM     | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1995 - 2003 | ABS/TCS | ●          | ●           | ●         | ●           | 0x0008 0x0005 0x0012  |
| Windstar | 3.8L     | V6 OHV     | 1995 - 2003 | PCM     | ●          | ●           | ●         | ●           | 0x0023 0x0025 0x0080 0x0081<br>0x0082 0x0083 0x0010 0x0028<br>0x0031 0x0033 0x0084 0x0009 |
| Windstar | 3.8L     | V6 OHV     | 1996 - 1998 | IAB     | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1996 - 1998 | PATS    | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1998        | RAP     | ●          | ●           | ●         | ●           | 0x000A  |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | DDM     | ●          | ●           | ●         | ●           | 0x000A 0x0005 0xF045  |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | FEM     | ●          | ●           | ●         | ●           | 0x0005 0xF042 0xF045 0xF08D<br>0xF090 0xF091 0xF092 0xF0B4                                |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | IC      | ●          | ●           | ●         | ●           | 0x0009 0xF027 0xF08E 0xF08F   |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | LPSDM   | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | MC      | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | NGSC    | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | PAM     | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | RCM     | ●          | ●           | ●         | ●           | 0x000C  |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | REM     | ●          | ●           | ●         | ●           | 0x000F  |
| Windstar | 3.8L     | V6 OHV     | 1999 - 2003 | RPSDM   | ●          | ●           | ●         | ●           | ○   |
| Windstar | 3.8L     | V6 OHV     | 2000 - 2003 | DSM     | ●          | ●           | ●         | ●           | ○   |

# Special Function

| Index | Specil Function Name                       | Index | Specil Function Name   |
|-------|--|-------|--|
| 0005  | Programmable Module Installation           | 0006  | Module Reprogramming   |
| 0007  | Programmable Parameters                    | 0008  | ABS Service Bleed  |
| 0009  | PATS Functions                             | 000A  | Remote Keyless Entry   |
| 000B  | G Sensor Calibration                       | 000C  | Passenger System Reset   |
| 000D  | Neutral Position Setting                   | 000E  | Ride Height Calibration  |
| 000F  | Factory Keyless Entry Code                 | 0010  | Stop Use of Transmission Adaptive  |
| 0011  | Power Seat Calibration                     | 0012  | IVD Initialization Sequence  |
| 0013  | Pneumatic Test                             | 0014  | Accurate Trim Test   |
| 0015  | Passenger Zero Seat Weight Test            | 0016  | Microphone Test  |
| 0017  | Audio Speaker Walkaround Test              | 0018  | Infotainment Display Test  |
| 0019  | Tones Test                                 | 001A  | TPMS Functions   |
| 001B  | Zero Speed Test                            | 001C  | Rear Tones Test  |
| 001D  | Monotones Test                             | 001E  | Sensor Initialization  |
| 001F  | EPB calibration.                           | 0020  | EATC Operation Check   |
| 0021  | Rain Sensor Reset                          | 0022  | LPSDM and RPSDM Service Function   |
| 0023  | Power Balance                              | 0024  | EVAP Test  |
| 0025  | Reset PCM KAM                              | 0026  | OBDII Modes  |
| 0027  | Clear Transmission Adaptive Learning       | 0028  | Clear Transmission Adaptive Tables                                       |
| 0029  | Configure All Three Sensors Together.      | 002A  | Configure Both the Yaw Rate Sensor and the Lateral Acceleration Sensors. |
| 002B  | Configure the lateral acceleration sensor. | 002C  | Configure the pressure sensor.   |
| 002D  | FFH SelfTest and Prefill Utility           | 002E  | FFH Start Heater Utility   |
| 002F  | FFH Unlock Utility                         | 0030  | Auxiliary vehicle ID reset   |
| 0031  | Halt Transmission Adaptive Learning        | 0032  | Headlamp Alignment   |
| 0033  | Resume Transmission Adaptive Learning      | 0034  | Resume Transmission Adaptive Tables                                      |
| 0035  | Keyfob Training                            | 0036  | Transmission   |
| 0037  | Transmission Learning                      | 0038  | Transmission Solenoid Body IDN   |
| 0039  | VSM Service Functions                      | 003A  | A/C Test   |
| 003B  | ACM  | 003C  | ACM Security Bypass Test   |
| 003D  | Air/Fuel Learning                          | 003E  | AM Antenna Reception Sensitivity Test                                    |
| 003F  | ASM Service Functions                      | 0040  | audio configuration  |
| 0041  | Auto Leveling Sensor Re-zero Procedure     | 0042  | Tire Pressure Monitoring System  |
| 0043  | BSM Radar Test                             | 0044  | Button Test  |
| 0045  | CAN Bus Fault Test                         | 0046  | CCM Calibration  |
| 0047  | Clear EGR Adaptive Tables                  | 0048  | Clear Fuel Injector&HP Pump Adaptive Table                               |
| 0050  | Clearing of Learning Value                 | 0051  | Component/Parameter Reset  |
| 0053  | Configure the steering angle sensor        | 0054  | Configure the yaw rate sensor  |
| 0055  | DATA Reset                                 | 0056  | DPF  |
| 0057  | DPF Component Parameter                    | 0058  | DPF Manual Regeneration  |
| 0059  | DPF Parameter Reset                        | 005A  | Electronic Throttle Control  |
| 005B  | EPS Steering Angle Calibration             | 005C  | ETB/EGR Initialization   |
| 005D  | FACM                                       | 005E  | FFH Operation Check  |
| 005F  | Gauge Test                                 | 0060  | ICCM Aiming Adjustment   |
| 0061  | Illumination Test                          | 0062  | Input and Data Test  |
| 0063  | Interior Scan Test                         | 0064  | Keyless Entry Keypad Code Reset  |
| 0065  | Learning                                   | 0066  | Misfire Check  |
| 0067  | Misfire Monitor Neutral Profile Correction | 0068  | Module Identification  |
| 0069  | Multifunction Output Test                  | 006A  | Network Test   |
| 006B  | New FACM                                   | 006C  | Parking Aid Switch Test  |
| 006D  | Passenger Seat Weight Sensor ReZero        | 006E  | Rebalance  |
| 006F  | Reset the Knock Sensor Learned Values      | 0070  | Reset Transmission Tables  |
| 0071  | Resetting adaptive values                  | 0072  | RVM Aiming   |
| 0074  | Service Routine                            | 0075  | Specil Ignition ON   |
| 0076  | Steering angle sensor calibration          | 0077  | Supplemental Heater test   |



| Index | Specil Function Name  | Index | Specil Function Name  |
|-------|---|-------|---|
| 0080  | Mode 1 Powertrain Data  | 0081  | Mode 6 On-Board Test Results  |
| 0082  | Mode 8 - On-Board device control  | 0083  | Mode 9 - Vehicle Information  |
| 0084  | OBD Drive Cycle   | 0085  | Service Functions   |
| 0090  | Diesel Particulate Filter Static Regeneration                                   | 0091  | DPF Regeneration Suspension   |
| 0092  | Fuel Injector Correction Factors  | 0093  | IQA   |
| 0094  | Refill the FAT.   | 0095  | Relearn Vehicle Data  |
| 0096  | Reset Charge Air Cooler Bypass Valve Position                                   | 0097  | Reset the Cooling Fan Motor Learned Values                          |
| 0098  | Reset the Diesel Particulate Filter Learned                                     | 0099  | Reset the Exhaust Gas Recirculation Valve Learned                   |
| 009A  | Reset the Intake Air Throttle Valve Learned                                     | 009B  | Reset / Clear Specified Function                                    |
| 009C  | SCR Dosing Measurement Test   | 009D  | SCR Parameter Reset   |
| 009E  | SCR System Emptying   | 009F  | SCR System Refill Activation  |
| 00A0  | SCR Visual Leak Check   | 00A1  | System Prime  |
| 00A2  | WIF Reset   | 00A3  | DPF Reset   |
| 00A4  | Enter the Fuel Injector Default Count Value                                     | 00A5  | Clutch Switch Learn   |
| 00A6  | Engine Oil Quality History  | 00A7  | Fuel Injection Pump Learn   |
| 00A8  | Fuel Injector Pilot Correction Learn  | 00A9  | Fuel System Leak Test   |
| 00AA  | Initialize the Exhaust Gas Related Component.                                   | 00AB  | Reset Differential Pressure Sensor Learned Values                   |
| 00AC  | Reset KAM   | 00AD  | Reset MAF Sensor Drift.   |
| 00AE  | Reset MAF Sensor Offset.  | 00AF  | Reset the air conditioning compressor learned values.               |
| 00B0  | Reset the Diesel Particulate Filter Differential Pressure Sensor Learned Values | 00B1  | Reset the Exhaust Gas Temperature Value                             |
| 00B2  | Reset the Fuel Injection Pump Learned Values                                    | 00B3  | Reset the Fuel Injector Learned Values                              |
| 00B4  | Reset the Fuel Metering Valve Learned Values                                    | 00B5  | Reset the Fuel Pressure Relief Valve Open Count Learned Value       |
| 00B6  | Reset the Fuel Pressure Relief Valve Open Duration Learned Value                | 00B7  | Reset the Fuel Rail Pressure Sensor Learned Values                  |
| 00B8  | Reset the Heated Exhaust Gas Oxygen Sensor Learned Values                       | 00B9  | Reset the Mass Air Flow Sensor Learned Values                       |
| 00BA  | Reset the Neutral Gear Position Learned Value                                   | 00BB  | Reset the oil change indicator.                                     |
| 00BC  | Reset the Powertrain Control Module Learned                                     | 00BD  | Reset the Turbocharger Learned Values.                              |
| 00BE  | Reset the Turbocharger Variable Vane Actuator Learned Values                    | 00BF  | Reset the Turbocharger Variable Vane Position Sensor Learned Values |
| 00C0  | Reset the Vehicle Speed Limit   | 00C1  | Reset the water in fuel Warning Indicator.                          |
| 00C2  | rpm Controller  | 00C3  | Stop-Start Activation   |
| 00C4  | Speed Limiting  | 00C5  | TR sensor   |
| 00C6  | Transmission Fluid Level Test   | 00C7  | Automatic Transmission PRNDL Display Test                           |
| 00CA  | ABS reset and configuration.  | 00CB  | PDC Reset   |
| 00CC  | Steering Wheel Position Sensor Calibration                                      | 00CD  | Preliminary Checks  |
| 00CE  | Reset TCM KAM   | 00CF  | Fuel System Prime   |
| 00D0  | Remote Start  | 00D1  | TBM SIM RAV_ID  |
| 00D2  | Reset TBM Password  | 00D3  | TBM Transit Mode  |
| 00D4  | CEI Lock Configuration  | 00D5  | BMS Reset   |
| 00D6  | Navigation  | 00D7  | Calibrate Steering Angle Sensor                                     |
| 00D8  | Configure the steering column assembly.   | 00D9  | Configure the longitudinal acceleration sensor.                     |
| 00DA  | Configure the intermediate shaft.   | 00DB  | Module Initialization   |
| 00DC  | Pull Drift Compensation   | 00DD  | Calibrate Longitudinal Acceleration Sensor                          |
| 00DE  | Inhibit longitudinal accelerometer monitoring                                   | 00DF  | Pull Drift Compensation enable/disable                              |
| 00E0  | Straight Ahead Adaption Angle Reset   | 00E1  | Steering Rack Limiter Configuration                                 |
| 00E2  | Pressure Sensor Calibration   | 00E3  | Reset Pressure Sensor Offset  |
| 00E4  | Enable/Disable hill launch assist .   | 00E5  | Camera Alignment  |
| 00E6  | Shift fork system learn.  | 00E7  | Reset the High Pressure Fuel System Learned Values                  |
| 00E8  | BleedMASTER   | 00E9  | FCDIM Keycode Reset   |
| 00EA  | Beltminder Enable/Disable   | 00EB  | TPMS reset.   |
| 00EC  | TPMS reset after ABS module replacement   | 00ED  | Show GEM configuration  |
| 00EE  | EPB   | 00EF  | Clear crash data memory.  |
| 00F0  | Passenger Airbag Deactivation Switch  | 00F1  | Component checks  |
| 00F2  | Driver's Seat Module  | 00F3  | Assembly Check  |
| 00F4  | Inclination Sensor Calibration  | 00F5  | Maintenance mode  |
| 00F6  | Static Apply  | 00F7  | Clear stored clutch engagement point                                |

| Index | Specil Function Name   | Index | Specil Function Name  |
|-------|--|-------|---|
| 00F8  | Module Configuration   | 00F9  | CCMii Sensor Alignment  |
| 00FA  | Track Key Configuration  | 00FB  | Driver Window Motor Test.   |
| 00FC  | Passenger Window Motor Test                                      | 00FD  | Clear Self-learning Data  |
| 00FE  | RVC Configuration  | 00FF  | Special Function  |
| 0100  | Disable GDM VIN  | 0101  | WMM Calibration   |
| 0102  | RCM  | 0103  | Cooling Fan Test  |
| 0104  | IAC System Test  | 0105  | VCT System Test   |
| 0106  | A/C Test   | 0107  | MAF Sensor / TP Sensor Dynamic Test   |
| 0108  | ATC Barcode Entry  | 0109  | ISM Configuration   |
| 010A  | Valve Calibration  | 010B  | TP Sweep Test   |
| 010C  | ICP Sensor Test  | 010D  | Oil Aeration Test   |
| 010E  | Exhaust System Test  | 010F  | MAF Sensor Contamination Test   |
| 0110  | EGR System Flow Test   | 0111  | Neutral Tow Function  |
| 0112  | LIN New Module Initialization                                    | 0113  | Tachometer  |
| 0114  | Camshaft Position Reference Adaption Learn                       | 0115  | Powertrain Control Module Central Car Configuration                             |
| 0116  | Powertrain Control Module (PCM) One Touch Start Configuration    | 0117  | TCM Adaptive Learning   |
| 0118  | On-demand lock test routine                                      | 0119  | Rear Brake Adjustment   |
| 011A  | ACM Configuration  | 011B  | BCMii   |
| 011C  | Car Mod  | 011D  | SPRM Configuration  |
| 011E  | EPAS Configuration   | 011F  | Learn the vehicle variant and VIN data  |
| 0120  | Burglar Service Functions  | 0121  | The removal and installation of the selector lever or the selector lever cable. |
| 0122  | Transmission fluid drain and refill.                             | 0123  | The installation of a new TCM.  |
| 0124  | The installation of a new automatic transmission with a new TCM. | 0125  | The installation of a new automatic transmission with the original TCM.         |
| 0126  | Reset the Transmission Control Module Learned                    | 0127  | Reset the Transmission Oil learned Values                                       |
| 0128  | Transmission Range Sensor Learn                                  | 0129  | Read the ECU serial number.   |
| 012A  | RCM Calibration  | 012B  | Reset maintenance lamp  |
| 012C  | Special Ignition ON  | 012D  | IC Service Functions  |
| 012E  | A/F (Fuel Ratio)   | 012F  | Reset Expansion ID  |
| 0130  | Reset security ID  | 0131  | Lockout Mode Reset  |
| 0132  | Sensor Learn Routine   | 0133  | Ambient Air Temp Sensor Configuration   |
| 0134  | Touchscreen  | 0135  | Variant and VIN Data Learning Procedure   |
| 0136  | Neutral Position Learning  | 0137  | Clear Grade Sensor Learning Value   |
| 0138  | Clear Oil Pressure Sensor Learning Value                         | 0139  | Grade Sensor Learning   |
| 013A  | Oil Pressure Sensor Learning                                     | 013B  | Fuel System Vaporizer Prime   |
| 013C  | Reset SOBDM-C KAM  | 013D  | Power Liftgate Initialization   |
| 013E  | LDWS Camera Alignment  | 013F  | SWS calibration   |
| 0140  | Driver side  | 0141  | Passenger side  |
| 0142  | Auto Leveling Sensor   | 0143  | Automatic 4 wheel drive   |
| 0144  | Clear Learning Value   | 0145  | CVT Learning Value Setting  |
| 0146  | Headlight Zero-set   | 0147  | Height Sensor Initial Setting   |
| 0148  | Maintenance Information  | 0149  | Reset Supply Pump Learned Values  |
| 014A  | Slope sensor initialization                                      | 014B  | Starter Driving Counter   |
| 014C  | FFH Fuel Priming   | 014D  | Urea Injector Test  |
| 014E  | Urea Pump Test   | 0150  | PCM Service Functions   |
| 0151  | ABD Initialization   | 0152  | Tire Size Configuration   |
| 0153  | Workshop test  | 0154  | PROXI Alignment   |
| 0155  | AFS  | 0156  | HID HEADLAMPS   |
| 0157  | Air Bleed for Electric Oil Pump                                  | 0158  | Clutch System Test  |
| 0159  | CVT Slope Sensor Calibration                                     | 015B  | High Voltage (HV) De-energise Tool  |
| 015C  | Injector ID code   | 0201  | Mazda Vehicle Check-up  |
| 0202  | Spark Duration PIDs  | 0203  | Windshield Wiper Test   |
| 0204  | Rear Window Wiper Test   | 0205  | Cooling System Degas  |
| 0206  | PAD Switch   | 0207  | Enable Heated Screens   |
| 0208  | Reader Aiming  | 0209  | System Initialize   |
| 020A  | Diesel Particulate Filter Dynamic Regeneration                   | 020B  | Coupling Calibration Data Writing   |

| Index | Specil Function Name                    | Index | Specil Function Name                        |
|-------|---|-------|---|
| 020C  | Apply and Release Test                  | 020D  | RF KeyPad Learn Process                     |
| 020E  | FSC Aiming                              | 020F  | TPMS Sensor Training Mode                   |
| 0210  | Police Vehicle Top Speed Limit          | 0211  | Maintenance revision status                 |
| 0212  | Hydraulic control test                  | 0213  | ABS   |
| 0214  | SASM Module Reset                       | 0215  | Steering Motor Angle Trim                   |
| 0216  | Steering Toe Adjustment                 | 0217  | Steering Wheel Angle Trim                   |
| 0218  | Police Idle                             | 0219  | 360 Camera Calibration                      |
| 021A  | BCM#1 Crash Status Reset                | 021B  | Emergency Assist Activation                 |
| 021C  | ESN                                     | 021D  | Remote Keyless Entry                        |
| F001  | Audio                                   | F002  | Battery saver                               |
| F003  | Body Type                               | F004  | Courtesy Lamp                               |
| F005  | Door Trigger Disable Mode               | F006  | Body and Fuel Type                          |
| F007  | Hazard Warning                          | F008  | Horn Warning                                |
| F009  | Master Door Trigger Disable Mode        | F00A  | Panic Alarm                                 |
| F00B  | Police Mode                             | F00C  | Traction control system                     |
| F00D  | Autolamp Off Setting                    | F00E  | Autolamp On Setting                         |
| F00F  | Police Speedometer Offset               | F010  | Cabin Temperature Sensor Calibration Factor |
| F011  | Taxi Mode                               | F012  | Low Coolant Warning                         |
| F013  | Parking Brake Warning                   | F014  | Headlamp Delay Door Open                    |
| F015  | Headlamp Delay Ignition Off             | F016  | Headlamp Delay Remote Lock Pressed          |
| F017  | Dynamic Stability Control               | F018  | Hill Descent Control LED                    |
| F019  | Brake System Configuration              | F01A  | BPM fitted                                  |
| F01B  | Camera fitted                           | F01C  | Audio Interface Module                      |
| F01D  | Sonar fitted                            | F01E  | Navigation System                           |
| F01F  | Parking Aid Module                      | F020  | Odometer Write                              |
| F021  | Subwoofer                               | F022  | Driver Beltminder Status                    |
| F023  | Alarm                                   | F024  | Audio Configure                             |
| F025  | Autolocking While The Vehicle Is Moving | F026  | Module Reset                                |
| F027  | BeltMinder                              | F028  | Electrical Auxiliary Heater Chimes          |
| F029  | Power Steering Status                   | F02A  | Repeat flasher                              |
| F02B  | Autolock/Relock Configuration Status    | F02C  | Autolocking Customer setting                |
| F02D  | Double Locking With REMOTE              | F02E  | Power Lock Configuration                    |
| F02F  | Single Door Unlocking Using The REMOTE  | F030  | Tailgate Release REMOTE Button              |
| F031  | PAD Switch                              | F032  | Speed Control                               |
| F033  | Ambient Temperature Sensor Conformation | F034  | Heated Screen(s) active during warm up      |
| F035  | Power Sunroof Or Taxi Meter Fitted      | F036  | Deflation Detection System                  |
| F037  | Baseplate                               | F038  | Select seat trim type.                      |
| F039  | Select Vehicle Type                     | F03A  | Repeat flasher                              |
| F03B  | Internal Remote Receiver                | F03C  | Lock confirmation flash                     |
| F03D  | Alarm system                            | F03E  | Wash Fluid Sensor                           |
| F03F  | Select Engine Type                      | F040  | Reverse Warning Chime                       |
| F041  | Easy Entry / Exit                       | F042  | Daytime Running Lamps                       |
| F043  | Turn Signal Warning Chime               | F044  | Autolock                                    |
| F045  | Horn Chirp                              | F046  | Tire Size (rev / mile)                      |
| F047  | TBM Transit Mode                        | F048  | Perimeter Lighting                          |
| F049  | Stop and taillamp outage configuration  | F04A  | Overspeed Warning Indicator                 |
| F04B  | Autolock Configuration Status           | F04C  | Auto unlock                                 |
| F04D  | Language                                | F04E  | Headlight Battery Saver Timeout             |
| F04F  | Heated Backlight                        | F050  | Front Foglamps                              |
| F051  | Headlamp Type                           | F052  | Button Press Chime                          |
| F053  | Not in Park Chime                       | F054  | Oil Life                                    |
| F055  | Parking Brake Chime                     | F056  | Central Unlock via Key Cylinder             |
| F057  | Two Stage Unlocking                     | F058  | Power Door Lock Inhibit                     |
| F059  | Perimeter Alarm                         | F05A  | Satellite Digital Audio Receiver System     |
| F05B  | Autolamp                                | F05C  | Fog Lamp                                    |
| F05D  | Passenger Beltminder Status             | F05E  | Keypad Configure                            |
| F05F  | Remote Panic                            | F060  | Remote Keyless Entry                        |

| Index | Specil Function Name                             | Index | Specil Function Name                           |
|-------|--|-------|--|
| F061  | Remote open/close signal                         | F062  | Cellular Phone Module                          |
| F063  | Radio Clock                                      | F064  | Divider Bar\$I                                 |
| F065  | Welcome illumination                             | F066  | Battery saver function                         |
| F067  | Speedometer Accuracy Bias                        | F068  | Dark car                                       |
| F069  | Horn Chirp Configuration Status                  | F06A  | Smart Unlock                                   |
| F06B  | Fuel Economy Display Mode                        | F06C  | Power Adjustable Pedals                        |
| F06D  | Power Seat Recline                               | F06E  | Fuel Gallon Configuration                      |
| F06F  | Power Mirrors                                    | F070  | High cool blower voltage                       |
| F071  | Outside Air Temperature                          | F072  | Oil Life Status and Warning                    |
| F073  | Telephone  | F074  | Driver Seat Recline Memory Function            |
| F075  | Pedal Memory Function                            | F076  | Screen Display-Brand                           |
| F077  | Flex Fuel  | F078  | APIM   |
| F079  | Steering wheel control                           | F07A  | Auxiliary Jack                                 |
| F07B  | SWC POD type                                     | F07C  | Two-way front speakers                         |
| F07D  | Two-way rear speakers                            | F07E  | Trailer Brake Control Module                   |
| F07F  | Family Entertainment System                      | F080  | Mirror Turn Signals                            |
| F081  | Vehicle Door Configuration                       | F082  | Fuel Tank Configuration                        |
| F083  | Fuel Tank Size                                   | F084  | Rear Tire Size (Rev/Mile)                      |
| F085  | Trim Switch Inhibit                              | F086  | Fob panic activation                           |
| F087  | Tilt-Telescope Steering Wheel                    | F088  | Autolamp Delay Time                            |
| F089  | Global Close                                     | F08A  | Global Open                                    |
| F08B  | Auto Lock  | F08C  | Security Horn Alarm                            |
| F08D  | Illuminated Exit                                 | F08E  | ABS Tire Warning                               |
| F08F  | Sliding Door Caution                             | F090  | Smart Lock                                     |
| F091  | Horn   | F092  | Outside Air Temperature Display                |
| F093  | Answer Back Buzzer                               | F094  | Automatic Locks                                |
| F095  | Card Key Battery Low Warning                     | F096  | Two(2) stage door unlocking by request switch. |
| F097  | Two(2) stage door unlocking by transmitter.      | F098  | Auto relock timer (with AKE)                   |
| F099  | (PCM) Oil Life Used                              | F09A  | GCC vehicle                                    |
| F09B  | Accessory Protocol Interface Module              | F09C  | Tuner setting                                  |
| F09D  | Smart Rear Wipe                                  | F09E  | Drip Wipe                                      |
| F09F  | Safety Belt Warning                              | FOA0  | Hazzard Warning Switch                         |
| FOA1  | Global Closing With REMOTE                       | FOA2  | Tailgate release available when ignition on    |
| FOA3  | Select the type of liftgate striker plate fitted | FOA4  | Reset Alarm System Via Key                     |
| FOA5  | One-touch-up window function fitted              | FOA6  | Auto high beam sensitivity                     |
| FOA7  | Unlock sequence                                  | FOA8  | Daytime dimming rate setting                   |
| FOA9  | Fuel logic                                       | FOAA  | Fuel Meter Response Setting                    |
| FOAB  | Voice Recognition Module                         | FOAC  | Door ajar                                      |
| FOAD  | Cargo Unlock Setting                             | FOAE  | General Unlock Setting                         |
| FOAF  | Rear Door Reverse Cycling                        | FOB0  | Mirror Puddle Lamps                            |
| FOB1  | RHT Buzzer                                       | FOB2  | Electronic-Controlled Power Steering           |
| FOB3  | Heated windshield                                | FOB4  | Speed dependent wiper function                 |
| FOB5  | Audio Repeater Display                           | FOB6  | Power Folding Mirrors                          |
| FOB7  | Approach Lamps                                   | FOB8  | Key Out Apply                                  |

# Module Programming

| Vehicle                                    | Capacity | EngineType      | Year | Module Programming               | System                 | Flags |
|--|----------|-----------------|------|----------------------------------|------------------------|-------|
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Parameters          | Personality            | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Parameters          | Exterior Lighting      | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Parameters          | Security               | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Module Installation | ABS                    | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Module Installation | GEM                    | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 2.3L     | DURATEC-HE / I4 | 2005 | Programmable Module Installation | IC                     | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Parameters          | Personality            | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Parameters          | Exterior Lighting      | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Parameters          | Security               | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Module Installation | ABS                    | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Module Installation | GEM                    | ●     |
| (All MY05) Escape/Tribute/Maverick/Mariner | 3.0L     | 4V              | 2005 | Programmable Module Installation | IC                     | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Parameters          | Personality            | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Parameters          | Power Seats            | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Parameters          | Security               | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | EATC                   | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | DSM                    | ※     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | IC                     | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | NAV                    | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | VEMS                   | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | TPM                    | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | VAPS                   | ●     |
| Aviator                                    | 4.6L     | 4V              | 2003 | Programmable Module Installation | VSM                    | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Parameters          | Personality            | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Parameters          | Power Seats            | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Parameters          | Audio Configure        | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Module Installation | EATC                   | ●     |
| Aviator                                    | 4.6L     | 4V              | 2004 | Programmable Module Installation | DSM                    | ※     |

| Vehicle   | Capacity | EngineType                                     | Year    | Module Programming               | System                       | Flags |
|-----------|----------|--|---------|----------------------------------|------------------------------|-------|
| Aviator   | 4.6L     | 4V   | 2004    | Programmable Module Installation | IC                           | ●     |
| Aviator   | 4.6L     | 4V   | 2004    | Programmable Module Installation | NAV                          | ●     |
| Aviator   | 4.6L     | 4V   | 2004    | Programmable Module Installation | TPM                          | ●     |
| Aviator   | 4.6L     | 4V   | 2004    | Programmable Module Installation | VAPS                         | ●     |
| Aviator   | 4.6L     | 4V   | 2004    | Programmable Module Installation | VSM                          | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Parameters          | Personality                  | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Parameters          | Power Seats                  | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Parameters          | Audio Configure              | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Parameters          | Power Door Locks             | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | ABS/TCS                      | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | EATC                         | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | DSM                          | ※     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | IC                           | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | NAV                          | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | TPM                          | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | VAPS                         | ●     |
| Aviator   | 4.6L     | 4V   | 2005    | Programmable Module Installation | VSM                          | ●     |
| Bantam    | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2009.25 | Programmable Module Installation | IC                           | ●     |
| Bantam    | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2009.25 | Programmable Module Installation | RCM                          | ●     |
| Blackwood | 5.4L     | 4V   | 2002    | Programmable Parameters          | Washer / Wiper               | ●     |
| Blackwood | 5.4L     | 4V   | 2002    | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Blackwood | 5.4L     | 4V   | 2002    | Programmable Parameters          | Power Door Locks             | ●     |
| Blackwood | 5.4L     | 4V   | 2002    | Programmable Parameters          | Security                     | ●     |
| Blackwood | 5.4L     | 4V   | 2002    | Programmable Module Installation | GEM                          | ●     |
| Blackwood | 5.4L     | 4V   | 2002    | Programmable Module Installation | RAP                          | ●     |
| Blackwood | 5.4L     | 4V   | 2003    | Programmable Parameters          | Washer / Wiper               | ●     |
| Blackwood | 5.4L     | 4V   | 2003    | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Blackwood | 5.4L     | 4V   | 2003    | Programmable Parameters          | Power Door Locks             | ●     |
| Blackwood | 5.4L     | 4V   | 2003    | Programmable Parameters          | Security                     | ●     |
| Blackwood | 5.4L     | 4V   | 2003    | Programmable Module Installation | GEM                          | ●     |
| Blackwood | 5.4L     | 4V   | 2003    | Programmable Module Installation | RAP                          | ●     |
| Cargo     | Other    | ISBe   | 2009    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Cargo     | Other    | ISBe   | 2009    | Programmable Module Installation | TBM                          | ●     |
| Cargo     | Other    | ISBe   | 2012    | Programmable Module Installation | HEC                          | ●     |
| Cargo     | Other    | ISBe   | 2012    | Programmable Module Installation | RKE                          | ●     |
| Cargo     | Other    | ISCe   | 2009    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Cargo     | Other    | ISCe   | 2009    | Programmable Module Installation | TBM                          | ●     |
| Cargo     | Other    | ISCe   | 2012    | Programmable Module Installation | HEC                          | ●     |
| Cargo     | Other    | ISCe   | 2012    | Programmable Module Installation | RKE                          | ●     |

| Vehicle        | Capacity | EngineType | Year | Module Programming               | System                       | Flags |
|----------------|----------|------------|------|----------------------------------|------------------------------|-------|
| Cargo          | Other    | Mechanical | 2009 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Cargo          | Other    | Mechanical | 2009 | Programmable Module Installation | TBM                          | ●     |
| Cargo          | Other    | Mechanical | 2012 | Programmable Module Installation | HEC                          | ●     |
| Cargo          | Other    | Mechanical | 2012 | Programmable Module Installation | RKE                          | ●     |
| Continental    | 4. 6L    | 4V         | 1998 | Programmable Parameters          | Exterior Lighting            | ●     |
| Continental    | 4. 6L    | 4V         | 1998 | Programmable Module Installation | ACM                          | ●     |
| Continental    | 4. 6L    | 4V         | 1998 | Programmable Module Installation | LCM                          | ●     |
| Continental    | 4. 6L    | 4V         | 1999 | Programmable Parameters          | Exterior Lighting            | ●     |
| Continental    | 4. 6L    | 4V         | 1999 | Programmable Module Installation | ACM                          | ●     |
| Continental    | 4. 6L    | 4V         | 1999 | Programmable Module Installation | LCM                          | ●     |
| Continental    | 4. 6L    | 4V         | 2000 | Programmable Parameters          | Exterior Lighting            | ●     |
| Continental    | 4. 6L    | 4V         | 2000 | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Continental    | 4. 6L    | 4V         | 2000 | Programmable Module Installation | LCM                          | ●     |
| Continental    | 4. 6L    | 4V         | 2002 | Programmable Parameters          | Exterior Lighting            | ●     |
| Continental    | 4. 6L    | 4V         | 2002 | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Continental    | 4. 6L    | 4V         | 2002 | Programmable Module Installation | LCM                          | ●     |
| Cougar         | 2. 5L    | Duratec-VE | 2001 | Programmable Module Installation | ABS                          | ●     |
| Cougar         | 2. 5L    | Duratec-VE | 2001 | Programmable Module Installation | IC                           | ●     |
| Cougar         | 2. 5L    | Duratec-VE | 2001 | Programmable Module Installation | MC                           | ●     |
| Cougar         | 2. 5L    | Duratec-VE | 2001 | Programmable Module Installation | REM                          | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2000 | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2000 | Programmable Parameters          | Power Door Locks             | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2000 | Programmable Parameters          | Security                     | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2000 | Programmable Module Installation | DDM                          | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2000 | Programmable Module Installation | LCM                          | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2002 | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2002 | Programmable Parameters          | Power Door Locks             | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2002 | Programmable Parameters          | Security                     | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2002 | Programmable Module Installation | DDM                          | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2002 | Programmable Module Installation | LCM                          | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2003 | Programmable Parameters          | Power Door Locks             | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2003 | Programmable Parameters          | Security                     | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2003 | Programmable Module Installation | DDM                          | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2003 | Programmable Module Installation | RASM                         | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2003 | Programmable Module Installation | VAPS                         | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2004 | Programmable Parameters          | Power Door Locks             | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2004 | Programmable Parameters          | Security                     | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2004 | Programmable Module Installation | DDM                          | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2004 | Programmable Module Installation | RASM                         | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2004 | Programmable Module Installation | VAPS                         | ●     |
| Crown Victoria | 4. 6L    | 2V         | 2005 | Programmable Parameters          | Power Door Locks             | ●     |

| Vehicle        | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|----------------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Crown Victoria | 4.6L     | 2V         | 2005 | Programmable Parameters          | Security                        | ●     |
| Crown Victoria | 4.6L     | 2V         | 2005 | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2005 | Programmable Module Installation | RASM                            | ●     |
| Crown Victoria | 4.6L     | 2V         | 2005 | Programmable Module Installation | RCM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2005 | Programmable Module Installation | VAPS                            | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Parameters          | Interior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Parameters          | Exterior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Parameters          | Police Mode                     | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Module Installation | IC                              | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Module Installation | LCM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Module Installation | RASM                            | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Module Installation | RCM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2006 | Programmable Module Installation | VAPS                            | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Parameters          | Interior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Parameters          | Police Mode                     | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Module Installation | IC                              | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Module Installation | LCM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Module Installation | RCM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2007 | Programmable Module Installation | VDM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Parameters          | Interior Lighting               | ※     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Module Installation | IC                              | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Module Installation | LCM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Module Installation | RCM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2008 | Programmable Module Installation | VDM                             | ●     |
| Crown Victoria | 4.6L     | 2V         | 2009 | Programmable Parameters          | Interior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V         | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Crown Victoria | 4.6L     | 2V         | 2009 | Programmable Parameters          | Power Door Locks                | ●     |
| Crown Victoria | 4.6L     | 2V         | 2009 | Programmable Parameters          | Police Mode                     | ●     |



| Vehicle        | Capacity | EngineType  | Year    | Module Programming               | System                          | Flags |
|----------------|----------|-------------|---------|----------------------------------|---------------------------------|-------|
| Crown Victoria | 4.6L     | 2V          | 2009    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Crown Victoria | 4.6L     | 2V          | 2009    | Programmable Module Installation | ABS                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2009    | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2009    | Programmable Module Installation | IC                              | ●     |
| Crown Victoria | 4.6L     | 2V          | 2009    | Programmable Module Installation | LCM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2009    | Programmable Module Installation | RCM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2009    | Programmable Module Installation | VDM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Parameters          | Interior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Parameters          | Exterior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Parameters          | Power Door Locks                | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Parameters          | Police Mode                     | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Module Installation | ABS                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Module Installation | IC                              | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Module Installation | LCM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2010    | Programmable Module Installation | RCM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Parameters          | Interior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Parameters          | Exterior Lighting               | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Parameters          | Power Door Locks                | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Parameters          | Police Mode                     | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Module Installation | ABS                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Module Installation | IC                              | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Module Installation | LCM                             | ●     |
| Crown Victoria | 4.6L     | 2V          | 2011    | Programmable Module Installation | RCM                             | ●     |
| Crown Victoria | 4.6L     | 2V NGV      | 2000    | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Crown Victoria | 4.6L     | 2V NGV      | 2000    | Programmable Parameters          | Power Door Locks                | ●     |
| Crown Victoria | 4.6L     | 2V NGV      | 2000    | Programmable Parameters          | Security                        | ●     |
| Crown Victoria | 4.6L     | 2V NGV      | 2000    | Programmable Module Installation | DDM                             | ●     |
| Crown Victoria | 4.6L     | 2V NGV      | 2000    | Programmable Module Installation | LCM                             | ●     |
| Econovan       | 2.0L     | OHC         | 2008    | Programmable Module Installation | IC                              | ●     |
| EcoSport       | 1.0L     | Zetec Rocam | 2003.25 | Programmable Parameters          | Personality                     | ※     |
| EcoSport       | 1.0L     | Zetec Rocam | 2003.25 | Programmable Parameters          | Interior Lighting               | ※     |
| EcoSport       | 1.0L     | Zetec Rocam | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes          | ※     |
| EcoSport       | 1.0L     | Zetec Rocam | 2003.25 | Programmable Parameters          | Power Door Locks                | ●     |
| EcoSport       | 1.0L     | Zetec Rocam | 2003.25 | Programmable Parameters          | Security                        | ※     |
| EcoSport       | 1.0L     | Zetec Rocam | 2003.25 | Programmable Module Installation | IC                              | ※     |

| Vehicle  | Capacity | EngineType                                  | Year    | Module Programming               | System                       | Flags |
|----------|----------|---|---------|----------------------------------|------------------------------|-------|
| EcoSport | 1.0L     | Zetec Rocam                                 | 2003.25 | Programmable Module Installation | RKE                          | ✖     |
| EcoSport | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Parameters          | Power Door Locks             | ●     |
| EcoSport | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Parameters          | Security                     | ✖     |
| EcoSport | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | IC                           | ✖     |
| EcoSport | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RKE                          | ✖     |
| EcoSport | 1.5L     | Duratorq-Turbo Diesel Common Rail Injection | 2012    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| EcoSport | 1.5L     | Duratorq-Turbo Diesel Common Rail Injection | 2012    | Programmable Module Installation | TBM                          | ✖     |
| EcoSport | 1.6L     | FFV   | 2003.25 | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 1.6L     | FFV   | 2003.25 | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 1.6L     | FFV   | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 1.6L     | FFV   | 2003.25 | Programmable Parameters          | Power Door Locks             | ●     |
| EcoSport | 1.6L     | FFV   | 2003.25 | Programmable Parameters          | Security                     | ✖     |
| EcoSport | 1.6L     | FFV   | 2003.25 | Programmable Module Installation | IC                           | ✖     |
| EcoSport | 1.6L     | FFV   | 2003.25 | Programmable Module Installation | RKE                          | ✖     |
| EcoSport | 1.6L     | FFV   | 2006    | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 1.6L     | FFV   | 2006    | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 1.6L     | FFV   | 2006    | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 1.6L     | FFV   | 2006    | Programmable Parameters          | Power Door Locks             | ●     |
| EcoSport | 1.6L     | FFV   | 2006    | Programmable Parameters          | Security                     | ✖     |
| EcoSport | 1.6L     | FFV   | 2006    | Programmable Module Installation | IC                           | ✖     |
| EcoSport | 1.6L     | FFV   | 2006    | Programmable Module Installation | RKE                          | ✖     |
| EcoSport | 1.6L     | FFV   | 2009    | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 1.6L     | FFV   | 2009    | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 1.6L     | FFV   | 2009    | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 1.6L     | FFV   | 2009    | Programmable Parameters          | Security                     | ✖     |
| EcoSport | 1.6L     | FFV   | 2009    | Programmable Module Installation | IC                           | ✖     |
| EcoSport | 1.6L     | FFV   | 2009    | Programmable Module Installation | RKE                          | ✖     |
| EcoSport | 1.6L     | FFV   | 2011    | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 1.6L     | FFV   | 2011    | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 1.6L     | FFV   | 2011    | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 1.6L     | FFV   | 2011    | Programmable Parameters          | Power Door Locks             | ✖     |
| EcoSport | 1.6L     | FFV   | 2011    | Programmable Parameters          | Security                     | ✖     |

| Vehicle  | Capacity | EngineType      | Year    | Module Programming               | System                       | Flags |
|----------|----------|-----------------|---------|----------------------------------|------------------------------|-------|
| EcoSport | 1.6L     | FFV             | 2011    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| EcoSport | 1.6L     | FFV             | 2011    | Programmable Module Installation | IC                           | ※     |
| EcoSport | 1.6L     | FFV             | 2011    | Programmable Module Installation | RKE                          | ※     |
| EcoSport | 1.6L     | FFV             | 2011    | Programmable Module Installation | TBM                          | ●     |
| EcoSport | 1.6L     | Sigma           | 2012    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| EcoSport | 1.6L     | Sigma           | 2012    | Programmable Module Installation | TBM                          | ●     |
| EcoSport | 1.6L     | Zetec Rocam     | 2003.25 | Programmable Parameters          | Personality                  | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2003.25 | Programmable Parameters          | Interior Lighting            | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2003.25 | Programmable Parameters          | Power Door Locks             | ●     |
| EcoSport | 1.6L     | Zetec Rocam     | 2003.25 | Programmable Parameters          | Security                     | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2003.25 | Programmable Module Installation | IC                           | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2003.25 | Programmable Module Installation | RKE                          | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2009    | Programmable Parameters          | Personality                  | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2009    | Programmable Parameters          | Interior Lighting            | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2009    | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2009    | Programmable Parameters          | Security                     | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2009    | Programmable Module Installation | IC                           | ※     |
| EcoSport | 1.6L     | Zetec Rocam     | 2009    | Programmable Module Installation | RKE                          | ※     |
| EcoSport | 2.0L     | DURATEC         | 2013    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| EcoSport | 2.0L     | DURATEC         | 2013    | Programmable Module Installation | TBM                          | ●     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Personality                  | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Interior Lighting            | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Security                     | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | IC                           | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RKE                          | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Personality                  | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Interior Lighting            | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Power Door Locks             | ●     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Security                     | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | IC                           | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | RKE                          | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Personality                  | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Interior Lighting            | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Security                     | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | IC                           | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | RKE                          | ※     |
| EcoSport | 2.0L     | DURATEC-HE / I4 | 2012    | Programmable Parameters          | Tracking And Blocking Module | ●     |

| Vehicle  | Capacity | EngineType                                   | Year | Module Programming               | System                       | Flags |
|----------|----------|--|------|----------------------------------|------------------------------|-------|
| EcoSport | 2.0L     | DURATEC-HE / I4                              | 2012 | Programmable Module Installation | TBM                          | ●     |
| EcoSport | 2.0L     | FFV  | 2009 | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 2.0L     | FFV  | 2009 | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 2.0L     | FFV  | 2009 | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 2.0L     | FFV  | 2009 | Programmable Parameters          | Security                     | ✖     |
| EcoSport | 2.0L     | FFV  | 2009 | Programmable Module Installation | IC                           | ✖     |
| EcoSport | 2.0L     | FFV  | 2009 | Programmable Module Installation | RKE                          | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Parameters          | Power Door Locks             | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Parameters          | Security                     | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Module Installation | IC                           | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Module Installation | RKE                          | ✖     |
| EcoSport | 2.0L     | FFV  | 2011 | Programmable Module Installation | TBM                          | ●     |
| EcoSport | 2.0L     | Zetec Rocam                                  | 2009 | Programmable Parameters          | Personality                  | ✖     |
| EcoSport | 2.0L     | Zetec Rocam                                  | 2009 | Programmable Parameters          | Interior Lighting            | ✖     |
| EcoSport | 2.0L     | Zetec Rocam                                  | 2009 | Programmable Parameters          | Warning Lamps / Chimes       | ✖     |
| EcoSport | 2.0L     | Zetec Rocam                                  | 2009 | Programmable Parameters          | Security                     | ✖     |
| EcoSport | 2.0L     | Zetec Rocam                                  | 2009 | Programmable Module Installation | IC                           | ✖     |
| EcoSport | 2.0L     | Zetec Rocam                                  | 2009 | Programmable Module Installation | RKE                          | ✖     |
| Edge     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DCSM                         | ●     |
| Edge     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | TBM                          | ●     |
| Edge     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM                         | ●     |
| Edge     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | TBM                          | ●     |
| Edge     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Parameters          | Tracking And Blocking Module | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System                         | Flags |
|---------|----------|--|------|----------------------------------|--------------------------------|-------|
| Edge    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM                           | ●     |
| Edge    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | TBM                            | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Personality                    | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Interior Lighting              | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Audio Configure                | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Brake System Configuration     | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Tracking And Blocking Module   | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | ABS                            | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | ACM                            | ✘     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | DSM                            | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | IC                             | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | PAM                            | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | RCM                            | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | RETM                           | ●     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | SDARS                          | ✘     |
| Edge    | 3.5L     | 4V   | 2007 | Programmable Module Installation | TBM                            | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Parameters          | Brake System Configuration     | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Parameters          | Tracking And Blocking Module   | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Module Installation | ABS                            | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Module Installation | DSM                            | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Module Installation | PAM                            | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Module Installation | RCM                            | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Module Installation | RETM                           | ●     |
| Edge    | 3.5L     | 4V   | 2008 | Programmable Module Installation | TBM                            | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Parameters          | Personality                    | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Parameters          | Interior Lighting              | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Parameters          | Brake System Configuration     | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Parameters          | Tracking And Blocking Module   | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Module Installation | ABS                            | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Module Installation | IC                             | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Module Installation | PAM                            | ●     |
| Edge    | 3.5L     | 4V   | 2009 | Programmable Module Installation | RCM                            | ●     |

| Vehicle                 | Capacity | EngineType        | Year | Module Programming               | System                       | Flags |
|-------------------------|----------|-------------------|------|----------------------------------|------------------------------|-------|
| Edge                    | 3.5L     | 4V                | 2009 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Parameters          | Personality                  | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Parameters          | Interior Lighting            | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Module Installation | IC                           | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Module Installation | PAM                          | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Module Installation | RCM                          | ●     |
| Edge                    | 3.5L     | 4V                | 2010 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.5L     | TiVCT             | 2011 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.5L     | TiVCT             | 2011 | Programmable Parameters          | Tracking And Blocking Module | ✘     |
| Edge                    | 3.5L     | TiVCT             | 2011 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.5L     | TiVCT             | 2011 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.5L     | TiVCT             | 2011 | Programmable Module Installation | DCSM                         | ✘     |
| Edge                    | 3.5L     | TiVCT             | 2011 | Programmable Module Installation | TBM                          | ✘     |
| Edge                    | 3.5L     | TiVCT             | 2012 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.5L     | TiVCT             | 2012 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.5L     | TiVCT             | 2012 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.5L     | TiVCT             | 2013 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.5L     | TiVCT             | 2013 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.5L     | TiVCT             | 2013 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.5L     | TiVCT             | 2014 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.5L     | TiVCT             | 2014 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.5L     | TiVCT             | 2014 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.7L     | TiVCT             | 2011 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.7L     | TiVCT             | 2011 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.7L     | TiVCT             | 2011 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.7L     | TiVCT             | 2012 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.7L     | TiVCT             | 2012 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.7L     | TiVCT             | 2012 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.7L     | TiVCT             | 2013 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.7L     | TiVCT             | 2013 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.7L     | TiVCT             | 2013 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | 3.7L     | TiVCT             | 2014 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | 3.7L     | TiVCT             | 2014 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | 3.7L     | TiVCT             | 2014 | Programmable Module Installation | TBM                          | ●     |
| Edge                    | Other    | Other             | 2014 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Edge                    | Other    | Other             | 2014 | Programmable Module Installation | DCSM                         | ●     |
| Edge                    | Other    | Other             | 2014 | Programmable Module Installation | TBM                          | ●     |
| Escape / Mariner Hybrid | 2.3L     | HEV / ATKINSON 4V | 2005 | Programmable Parameters          | Personality                  | ●     |
| Escape / Mariner Hybrid | 2.3L     | HEV / ATKINSON 4V | 2005 | Programmable Parameters          | Exterior Lighting            | ●     |

| Vehicle                       | Capacity | EngineType        | Year | Module Programming               | System                 | Flags |
|-------------------------------|----------|-------------------|------|----------------------------------|------------------------|-------|
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2005 | Programmable Parameters          | Security               | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2005 | Programmable Module Installation | GEM                    | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2005 | Programmable Module Installation | IC                     | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2006 | Programmable Parameters          | Personality            | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2006 | Programmable Parameters          | Exterior Lighting      | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2006 | Programmable Parameters          | Security               | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2006 | Programmable Module Installation | GEM                    | ※     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2006 | Programmable Module Installation | IC                     | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Parameters          | Personality            | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Parameters          | Exterior Lighting      | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Parameters          | Power Door Locks       | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Parameters          | Security               | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Module Installation | ABS                    | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Module Installation | GEM                    | ●     |
| Escape / Mariner Hybrid       | 2.3L     | HEV / ATKINSON 4V | 2007 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute ( - 2006/3 ) | 2.3L     | L3                | 2003 | Programmable Module Installation | ABS                    | ●     |
| Escape / Tribute ( - 2006/3 ) | 2.3L     | L3                | 2003 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute ( - 2006/3 ) | 2.3L     | L3                | 2003 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute ( 2006/4 - ) | 2.3L     | L3                | 2006 | Programmable Parameters          | Module Reset           | ●     |
| Escape / Tribute ( 2006/4 - ) | 2.3L     | L3                | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute ( 2006/4 - ) | 2.3L     | L3                | 2006 | Programmable Module Installation | ABS                    | ●     |
| Escape / Tribute ( 2006/4 - ) | 2.3L     | L3                | 2006 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute ( 2006/4 - ) | 2.3L     | L3                | 2006 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2001 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2001 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2001 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2001 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2001 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2002 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2002 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2002 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2002 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2003 | Programmable Parameters          | Personality            | ※     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick   | 2.0L     | Zetec             | 2003 | Programmable Parameters          | Security               | ●     |

| Vehicle                     | Capacity | EngineType      | Year | Module Programming               | System                 | Flags |
|-----------------------------|----------|-----------------|------|----------------------------------|------------------------|-------|
| Escape / Tribute / Maverick | 2.0L     | Zetec           | 2003 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 2.0L     | Zetec           | 2003 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 2.0L     | Zetec           | 2004 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 2.0L     | Zetec           | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 2.0L     | Zetec           | 2004 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 2.0L     | Zetec           | 2004 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 2.0L     | Zetec           | 2004 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Exterior Lighting      | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | ABS                    | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Exterior Lighting      | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Power Door Locks       | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | ABS                    | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2001 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2001 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2001 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2001 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2001 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2002 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2002 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2002 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2002 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2003 | Programmable Parameters          | Personality            | ※     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2003 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2003 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2003 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2004 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V              | 2004 | Programmable Parameters          | Security               | ●     |



| Vehicle                     | Capacity | EngineType        | Year | Module Programming               | System                 | Flags |
|-----------------------------|----------|-------------------|------|----------------------------------|------------------------|-------|
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2004 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2004 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Parameters          | Exterior Lighting      | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Module Installation | ABS                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2006 | Programmable Module Installation | IC                     | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Parameters          | Personality            | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Parameters          | Exterior Lighting      | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Parameters          | Power Door Locks       | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Parameters          | Security               | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Module Installation | ABS                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Module Installation | GEM                    | ●     |
| Escape / Tribute / Maverick | 3.0L     | 4V                | 2007 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Parameters          | Audio Configure        | ●     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | ABS                    | ●     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | ACM                    | ※     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | PSCM                   | ※     |
| Escape /Tribute / Mariner   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | RCM                    | ●     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Parameters          | Audio Configure        | ●     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Module Installation | ABS                    | ●     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Module Installation | ACM                    | ※     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Module Installation | PSCM                   | ※     |
| Escape /Tribute / Mariner   | 2.3L     | HEV / ATKINSON 4V | 2008 | Programmable Module Installation | RCM                    | ●     |
| Escape /Tribute / Mariner   | 2.5L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner   | 2.5L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | PSCM                   | ※     |
| Escape /Tribute / Mariner   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | ABS                    | ●     |
| Escape /Tribute / Mariner   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | PSCM                   | ●     |

| Vehicle                   | Capacity | EngineType        | Year | Module Programming               | System                 | Flags |
|---------------------------|----------|-------------------|------|----------------------------------|------------------------|-------|
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | ABS                    | ●     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | PSCM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | ABS                    | ●     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | ACM                    | ※     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | PSCM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2009 | Programmable Module Installation | PSCM                   | ※     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | PSCM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | PSCM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | ACM                    | ※     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | PSCM                   | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Parameters          | Audio Configure        | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Module Installation | ABS                    | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Module Installation | ACM                    | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Module Installation | PSCM                   | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2008 | Programmable Module Installation | RCM                    | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2009 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2009 | Programmable Module Installation | PSCM                   | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2010 | Programmable Module Installation | ABS                    | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2010 | Programmable Module Installation | FDIM                   | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2010 | Programmable Module Installation | HVAC                   | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2010 | Programmable Module Installation | IC                     | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2010 | Programmable Module Installation | PSCM                   | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V                | 2011 | Programmable Module Installation | ABS                    | ●     |

| Vehicle                   | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------------------------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2011 | Programmable Module Installation | HVAC                            | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2011 | Programmable Module Installation | IC                              | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2011 | Programmable Module Installation | PSCM                            | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2012 | Programmable Module Installation | ABS                             | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2012 | Programmable Module Installation | ACM                             | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2012 | Programmable Module Installation | HVAC                            | ※     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2012 | Programmable Module Installation | IC                              | ●     |
| Escape /Tribute / Mariner | 3.0L     | 4V         | 2012 | Programmable Module Installation | PSCM                            | ●     |
| E-Series                  | 4.6L     | 2V         | 2004 | Programmable Parameters          | Personality                     | ●     |
| E-Series                  | 4.6L     | 2V         | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series                  | 4.6L     | 2V         | 2004 | Programmable Parameters          | Driveline                       | ●     |
| E-Series                  | 4.6L     | 2V         | 2004 | Programmable Module Installation | IC                              | ●     |
| E-Series                  | 4.6L     | 2V         | 2004 | Programmable Module Installation | RAP                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2005 | Programmable Parameters          | Personality                     | ●     |
| E-Series                  | 4.6L     | 2V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series                  | 4.6L     | 2V         | 2005 | Programmable Parameters          | Driveline                       | ●     |
| E-Series                  | 4.6L     | 2V         | 2005 | Programmable Module Installation | IC                              | ●     |
| E-Series                  | 4.6L     | 2V         | 2005 | Programmable Module Installation | RAP                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2006 | Programmable Parameters          | Personality                     | ●     |
| E-Series                  | 4.6L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series                  | 4.6L     | 2V         | 2006 | Programmable Module Installation | IC                              | ●     |
| E-Series                  | 4.6L     | 2V         | 2006 | Programmable Module Installation | RAP                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2007 | Programmable Parameters          | Personality                     | ●     |
| E-Series                  | 4.6L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series                  | 4.6L     | 2V         | 2007 | Programmable Module Installation | IC                              | ●     |
| E-Series                  | 4.6L     | 2V         | 2007 | Programmable Module Installation | PAM                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2007 | Programmable Module Installation | VSM                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Parameters          | Personality                     | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Module Installation | ABS                             | ※     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Module Installation | IC                              | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Module Installation | PAM                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Module Installation | RCM                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2008 | Programmable Module Installation | VSM                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2009 | Programmable Module Installation | ABS                             | ※     |
| E-Series                  | 4.6L     | 2V         | 2009 | Programmable Module Installation | PAM                             | ●     |
| E-Series                  | 4.6L     | 2V         | 2010 | Programmable Module Installation | ABS                             | ※     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|----------|----------|------------|------|----------------------------------|---------------------------------|-------|
| E-Series | 4.6L     | 2V         | 2010 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 4.6L     | 2V         | 2011 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 4.6L     | 2V         | 2011 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 4.6L     | 2V         | 2012 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 4.6L     | 2V         | 2012 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 4.6L     | 2V         | 2013 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 4.6L     | 2V         | 2013 | Programmable Module Installation | ACM                             | ※     |
| E-Series | 4.6L     | 2V         | 2013 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 4.6L     | 2V         | 2014 | Programmable Parameters          | Audio Configure                 | ※     |
| E-Series | 4.6L     | 2V         | 2014 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 4.6L     | 2V         | 2014 | Programmable Module Installation | ACM                             | ※     |
| E-Series | 4.6L     | 2V         | 2014 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V         | 2004 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 5.4L     | 2V         | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 5.4L     | 2V         | 2004 | Programmable Parameters          | Driveline                       | ●     |
| E-Series | 5.4L     | 2V         | 2004 | Programmable Module Installation | IC                              | ●     |
| E-Series | 5.4L     | 2V         | 2004 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 5.4L     | 2V         | 2005 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 5.4L     | 2V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 5.4L     | 2V         | 2005 | Programmable Parameters          | Driveline                       | ●     |
| E-Series | 5.4L     | 2V         | 2005 | Programmable Module Installation | IC                              | ●     |
| E-Series | 5.4L     | 2V         | 2005 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 5.4L     | 2V         | 2006 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 5.4L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 5.4L     | 2V         | 2006 | Programmable Module Installation | IC                              | ●     |
| E-Series | 5.4L     | 2V         | 2006 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 5.4L     | 2V         | 2007 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 5.4L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series | 5.4L     | 2V         | 2007 | Programmable Module Installation | IC                              | ●     |
| E-Series | 5.4L     | 2V         | 2007 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V         | 2007 | Programmable Module Installation | VSM                             | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Module Installation | IC                              | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Module Installation | RCM                             | ●     |
| E-Series | 5.4L     | 2V         | 2008 | Programmable Module Installation | VSM                             | ●     |
| E-Series | 5.4L     | 2V         | 2009 | Programmable Module Installation | ABS                             | ※     |

| Vehicle  | Capacity | EngineType         | Year | Module Programming               | System                          | Flags |
|----------|----------|--------------------|------|----------------------------------|---------------------------------|-------|
| E-Series | 5.4L     | 2V                 | 2009 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V                 | 2010 | Programmable Module Installation | ABS                             | ✖     |
| E-Series | 5.4L     | 2V                 | 2010 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V                 | 2011 | Programmable Module Installation | ABS                             | ✖     |
| E-Series | 5.4L     | 2V                 | 2011 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V                 | 2012 | Programmable Module Installation | ABS                             | ✖     |
| E-Series | 5.4L     | 2V                 | 2012 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V                 | 2013 | Programmable Module Installation | ABS                             | ✖     |
| E-Series | 5.4L     | 2V                 | 2013 | Programmable Module Installation | ACM                             | ✖     |
| E-Series | 5.4L     | 2V                 | 2013 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 5.4L     | 2V                 | 2014 | Programmable Parameters          | Audio Configure                 | ✖     |
| E-Series | 5.4L     | 2V                 | 2014 | Programmable Module Installation | ABS                             | ✖     |
| E-Series | 5.4L     | 2V                 | 2014 | Programmable Module Installation | ACM                             | ✖     |
| E-Series | 5.4L     | 2V                 | 2014 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Driveline                       | ●     |
| E-Series | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | FICM                            | ●     |
| E-Series | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Driveline                       | ●     |
| E-Series | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | FICM                            | ●     |
| E-Series | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2006 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.0L     | Direct Injection - | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.0L     | Direct Injection - | 2006 | Programmable Module Installation | FICM                            | ●     |
| E-Series | 6.0L     | Direct Injection - | 2006 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.0L     | Direct Injection - | 2006 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2007 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.0L     | Direct Injection - | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series | 6.0L     | Direct Injection - | 2007 | Programmable Module Installation | FICM                            | ●     |
| E-Series | 6.0L     | Direct Injection - | 2007 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.0L     | Direct Injection - | 2007 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2007 | Programmable Module Installation | VSM                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |

| Vehicle  | Capacity | EngineType         | Year | Module Programming               | System                          | Flags |
|----------|----------|--------------------|------|----------------------------------|---------------------------------|-------|
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Module Installation | FICM                            | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Module Installation | RCM                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2008 | Programmable Module Installation | VSM                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2009 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 6.0L     | Direct Injection - | 2009 | Programmable Module Installation | FICM                            | ●     |
| E-Series | 6.0L     | Direct Injection - | 2009 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 6.0L     | Direct Injection - | 2010 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 6.0L     | Direct Injection - | 2010 | Programmable Module Installation | FICM                            | ●     |
| E-Series | 6.0L     | Direct Injection - | 2010 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 6.8L     | 2V                 | 2004 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.8L     | 2V                 | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.8L     | 2V                 | 2004 | Programmable Parameters          | Driveline                       | ●     |
| E-Series | 6.8L     | 2V                 | 2004 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.8L     | 2V                 | 2004 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 6.8L     | 2V                 | 2005 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.8L     | 2V                 | 2005 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.8L     | 2V                 | 2005 | Programmable Parameters          | Driveline                       | ●     |
| E-Series | 6.8L     | 2V                 | 2005 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.8L     | 2V                 | 2005 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 6.8L     | 2V                 | 2006 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.8L     | 2V                 | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.8L     | 2V                 | 2006 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.8L     | 2V                 | 2006 | Programmable Module Installation | RAP                             | ●     |
| E-Series | 6.8L     | 2V                 | 2007 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.8L     | 2V                 | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series | 6.8L     | 2V                 | 2007 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.8L     | 2V                 | 2007 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 6.8L     | 2V                 | 2007 | Programmable Module Installation | VSM                             | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Parameters          | Personality                     | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Module Installation | ABS                             | ※     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Module Installation | IC                              | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Module Installation | PAM                             | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Module Installation | RCM                             | ●     |
| E-Series | 6.8L     | 2V                 | 2008 | Programmable Module Installation | VSM                             | ●     |
| E-Series | 6.8L     | 2V                 | 2009 | Programmable Module Installation | ABS                             | ※     |

| Vehicle              | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|----------------------|----------|------------|------|----------------------------------|------------------------|-------|
| E-Series             | 6.8L     | 2V         | 2009 | Programmable Module Installation | PAM                    | ●     |
| E-Series             | 6.8L     | 2V         | 2010 | Programmable Module Installation | ABS                    | ※     |
| E-Series             | 6.8L     | 2V         | 2010 | Programmable Module Installation | PAM                    | ●     |
| E-Series             | 6.8L     | 2V         | 2011 | Programmable Module Installation | ABS                    | ※     |
| E-Series             | 6.8L     | 2V         | 2011 | Programmable Module Installation | PAM                    | ●     |
| E-Series             | 6.8L     | 2V         | 2012 | Programmable Module Installation | ABS                    | ※     |
| E-Series             | 6.8L     | 2V         | 2012 | Programmable Module Installation | PAM                    | ●     |
| E-Series             | 6.8L     | 2V         | 2013 | Programmable Module Installation | ABS                    | ※     |
| E-Series             | 6.8L     | 2V         | 2013 | Programmable Module Installation | ACM                    | ※     |
| E-Series             | 6.8L     | 2V         | 2013 | Programmable Module Installation | PAM                    | ●     |
| E-Series             | 6.8L     | 2V         | 2014 | Programmable Parameters          | Audio Configure        | ※     |
| E-Series             | 6.8L     | 2V         | 2014 | Programmable Module Installation | ABS                    | ※     |
| E-Series             | 6.8L     | 2V         | 2014 | Programmable Module Installation | ACM                    | ※     |
| E-Series             | 6.8L     | 2V         | 2014 | Programmable Module Installation | PAM                    | ●     |
| E-Series             | Other    | Other      | 2014 | Programmable Parameters          | Audio Configure        | ※     |
| E-Series             | Other    | Other      | 2014 | Programmable Module Installation | ABS                    | ※     |
| E-Series             | Other    | Other      | 2014 | Programmable Module Installation | ACM                    | ※     |
| E-Series             | Other    | Other      | 2014 | Programmable Module Installation | PAM                    | ●     |
| E-Series Shuttle Bus | 6.8L     | H2ICE      | 2006 | Programmable Parameters          | Personality            | ●     |
| E-Series Shuttle Bus | 6.8L     | H2ICE      | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| E-Series Shuttle Bus | 6.8L     | H2ICE      | 2006 | Programmable Module Installation | IC                     | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Parameters          | Personality            | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Parameters          | Security               | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Module Installation | DSM                    | ※     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Module Installation | GEM                    | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Module Installation | HEC                    | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Module Installation | OTC                    | ●     |
| Excursion            | 5.4L     | 2V         | 2004 | Programmable Module Installation | VSM                    | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Parameters          | Personality            | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Parameters          | Security               | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Module Installation | DSM                    | ※     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Module Installation | GEM                    | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Module Installation | HEC                    | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Module Installation | OTC                    | ●     |
| Excursion            | 5.4L     | 2V         | 2005 | Programmable Module Installation | VSM                    | ●     |
| Excursion            | 5.4L     | Other      | 2000 | Programmable Parameters          | Personality            | ●     |
| Excursion            | 5.4L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |

| Vehicle   | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|-----------|----------|--------------------|------|----------------------------------|------------------------|-------|
| Excursion | 5.4L     | Other              | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion | 5.4L     | Other              | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 5.4L     | Other              | 2000 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Parameters          | Personality            | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Parameters          | Security               | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Module Installation | CSM                    | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Module Installation | DSM                    | ※     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Module Installation | HEC                    | ●     |
| Excursion | 5.4L     | Other              | 2002 | Programmable Module Installation | OTC                    | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Parameters          | Personality            | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Parameters          | Security               | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Module Installation | DSM                    | ※     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Module Installation | HEC                    | ●     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Module Installation | OTC                    | ※     |
| Excursion | 5.4L     | Other              | 2003 | Programmable Module Installation | VSM                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Personality            | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Security               | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | DSM                    | ※     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | FICM                   | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | HEC                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | OTC                    | ※     |
| Excursion | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | VSM                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Personality            | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Security               | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | DSM                    | ※     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | FICM                   | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | GEM                    | ●     |



| Vehicle   | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|-----------|----------|--------------------|------|----------------------------------|------------------------|-------|
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | HEC                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | OTC                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | VSM                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Personality            | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Security               | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | DSM                    | ※     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | FICM                   | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | HEC                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | OTC                    | ●     |
| Excursion | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | VSM                    | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Parameters          | Personality            | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Parameters          | Security               | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Module Installation | DSM                    | ※     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Module Installation | HEC                    | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Module Installation | OTC                    | ●     |
| Excursion | 6.8L     | 2V                 | 2004 | Programmable Module Installation | VSM                    | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Parameters          | Personality            | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Parameters          | Security               | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Module Installation | DSM                    | ※     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Module Installation | HEC                    | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Module Installation | OTC                    | ●     |
| Excursion | 6.8L     | 2V                 | 2005 | Programmable Module Installation | VSM                    | ●     |
| Excursion | 6.8L     | Other              | 2000 | Programmable Parameters          | Personality            | ●     |
| Excursion | 6.8L     | Other              | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| Excursion | 6.8L     | Other              | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion | 6.8L     | Other              | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion | 6.8L     | Other              | 2000 | Programmable Module Installation | GEM                    | ●     |
| Excursion | 6.8L     | Other              | 2002 | Programmable Parameters          | Personality            | ●     |
| Excursion | 6.8L     | Other              | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion | 6.8L     | Other              | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion | 6.8L     | Other              | 2002 | Programmable Parameters          | Security               | ●     |
| Excursion | 6.8L     | Other              | 2002 | Programmable Module Installation | ABS/TCS                | ●     |

| Vehicle    | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|------------|----------|--------------------|------|----------------------------------|------------------------|-------|
| Excursion  | 6.8L     | Other              | 2002 | Programmable Module Installation | CSM                    | ●     |
| Excursion  | 6.8L     | Other              | 2002 | Programmable Module Installation | DSM                    | ※     |
| Excursion  | 6.8L     | Other              | 2002 | Programmable Module Installation | GEM                    | ●     |
| Excursion  | 6.8L     | Other              | 2002 | Programmable Module Installation | HEC                    | ●     |
| Excursion  | 6.8L     | Other              | 2002 | Programmable Module Installation | OTC                    | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Parameters          | Personality            | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Parameters          | Security               | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Module Installation | DSM                    | ※     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Module Installation | GEM                    | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Module Installation | HEC                    | ●     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Module Installation | OTC                    | ※     |
| Excursion  | 6.8L     | Other              | 2003 | Programmable Module Installation | VSM                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Personality            | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2000 | Programmable Module Installation | GEM                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Personality            | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Security               | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | CSM                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | DSM                    | ※     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | GEM                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | HEC                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | OTC                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Personality            | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Security               | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | DSM                    | ※     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | GEM                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | HEC                    | ●     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | OTC                    | ※     |
| Excursion  | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | VSM                    | ●     |
| Expedition | 4.6L     | 2V                 | 2003 | Programmable Parameters          | Personality            | ●     |

| Vehicle    | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|------------|----------|------------|------|----------------------------------|------------------------|-------|
| Expedition | 4.6L     | 2V         | 2003 | Programmable Parameters          | Power Seats            | ●     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Parameters          | Security               | ●     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Module Installation | EATC                   | ●     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Module Installation | DSM                    | ※     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Module Installation | HEC                    | ●     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Module Installation | TPM                    | ●     |
| Expedition | 4.6L     | 2V         | 2003 | Programmable Module Installation | VSM                    | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Parameters          | Personality            | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Parameters          | Power Seats            | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Parameters          | Security               | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Module Installation | EATC                   | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Module Installation | DSM                    | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Module Installation | HEC                    | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Module Installation | TPM                    | ●     |
| Expedition | 4.6L     | 2V         | 2004 | Programmable Module Installation | VSM                    | ●     |
| Expedition | 4.6L     | Other      | 1997 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition | 4.6L     | Other      | 1997 | Programmable Module Installation | GEM                    | ●     |
| Expedition | 4.6L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition | 4.6L     | Other      | 1998 | Programmable Module Installation | GEM                    | ●     |
| Expedition | 4.6L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition | 4.6L     | Other      | 1999 | Programmable Module Installation | GEM                    | ●     |
| Expedition | 4.6L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition | 4.6L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Expedition | 4.6L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Expedition | 4.6L     | Other      | 2000 | Programmable Parameters          | Security               | ※     |
| Expedition | 4.6L     | Other      | 2000 | Programmable Module Installation | GEM                    | ●     |
| Expedition | 4.6L     | Other      | 2000 | Programmable Module Installation | RAP                    | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Parameters          | Personality            | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Parameters          | Power Seats            | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Parameters          | Security               | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Module Installation | EATC                   | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Module Installation | DSM                    | ※     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Module Installation | HEC                    | ●     |

| Vehicle    | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Expedition | 5.4L     | 2V         | 2003 | Programmable Module Installation | TPM                            | ●     |
| Expedition | 5.4L     | 2V         | 2003 | Programmable Module Installation | VSM                            | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Parameters          | Personality                    | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Parameters          | Power Door Locks               | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Parameters          | Security                       | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Module Installation | ABS/TCS                        | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Module Installation | EATC                           | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Module Installation | HEC                            | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Module Installation | TPM                            | ●     |
| Expedition | 5.4L     | 2V         | 2004 | Programmable Module Installation | VSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Door Locks               | ●     |
| Expedition | 5.4L     | 3V         | 2005 | Programmable Module Installation | ABS                            | ●     |
| Expedition | 5.4L     | 3V         | 2005 | Programmable Module Installation | EATC                           | ●     |
| Expedition | 5.4L     | 3V         | 2005 | Programmable Module Installation | DCSM                           | ●     |
| Expedition | 5.4L     | 3V         | 2005 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2005 | Programmable Module Installation | VSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Door Locks               | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Module Installation | EATC                           | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Module Installation | DCSM                           | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Module Installation | IC                             | ●     |
| Expedition | 5.4L     | 3V         | 2006 | Programmable Module Installation | VSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Mirrors                  | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSP                            | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | IC                             | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | PAM                            | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCU                            | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Expedition | 5.4L     | 3V         | 2007 | Programmable Module Installation | SDARS                          | ●     |

| Vehicle    | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Expedition | 5.4L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSP                            | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | IC                             | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCU                            | ●     |
| Expedition | 5.4L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Mirrors                  | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Parameters          | Climate Control Seats          | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | DCSM                           | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | IC                             | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | PAM                            | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCU                            | ●     |
| Expedition | 5.4L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Mirrors                  | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Parameters          | Climate Control Seats          | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Module Installation | DCSM                           | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Module Installation | IC                             | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Module Installation | PAM                            | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCM                            | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCU                            | ●     |
| Expedition | 5.4L     | 3V         | 2010 | Programmable Module Installation | RETM                           | ●     |
| Expedition | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Mirrors                  | ●     |
| Expedition | 5.4L     | 3V         | 2011 | Programmable Parameters          | Climate Control Seats          | ●     |
| Expedition | 5.4L     | 3V         | 2011 | Programmable Module Installation | DCSM                           | ●     |
| Expedition | 5.4L     | 3V         | 2011 | Programmable Module Installation | DSM                            | ●     |
| Expedition | 5.4L     | 3V         | 2011 | Programmable Module Installation | IC                             | ●     |
| Expedition | 5.4L     | 3V         | 2011 | Programmable Module Installation | RCU                            | ●     |

| Vehicle       | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------------|----------|------------|------|----------------------------------|------------------------|-------|
| Expedition    | 5.4L     | 3V         | 2011 | Programmable Module Installation | RETM                   | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Seats            | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Mirrors          | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Parameters          | Climate Control Seats  | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Module Installation | DCSM                   | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Module Installation | DSM                    | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Module Installation | IC                     | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Module Installation | PAM                    | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Module Installation | RCU                    | ●     |
| Expedition    | 5.4L     | 3V         | 2012 | Programmable Module Installation | RETM                   | ●     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Seats            | ●     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Parameters          | Audio Configure        | ※     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Mirrors          | ●     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Parameters          | Climate Control Seats  | ●     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Module Installation | DCSM                   | ●     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Module Installation | DSM                    | ●     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Module Installation | IC                     | ●     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Module Installation | PAM                    | ※     |
| Expedition    | 5.4L     | 3V         | 2013 | Programmable Module Installation | RCU                    | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Seats            | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Parameters          | Audio Configure        | ※     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Mirrors          | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Parameters          | Climate Control Seats  | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Module Installation | DCSM                   | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Module Installation | DSM                    | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Module Installation | IC                     | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Module Installation | PAM                    | ●     |
| Expedition    | 5.4L     | 3V         | 2014 | Programmable Module Installation | RCU                    | ●     |
| Expedition    | 5.4L     | Other      | 1997 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition    | 5.4L     | Other      | 1997 | Programmable Module Installation | GEM                    | ●     |
| Expedition    | 5.4L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition    | 5.4L     | Other      | 1998 | Programmable Module Installation | GEM                    | ●     |
| Expedition    | 5.4L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition    | 5.4L     | Other      | 1999 | Programmable Module Installation | GEM                    | ●     |
| Expedition    | 5.4L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| Expedition    | 5.4L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Expedition    | 5.4L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Expedition    | 5.4L     | Other      | 2000 | Programmable Parameters          | Security               | ※     |
| Expedition    | 5.4L     | Other      | 2000 | Programmable Module Installation | GEM                    | ●     |
| Expedition    | 5.4L     | Other      | 2000 | Programmable Module Installation | RAP                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Seats            | ●     |

| Vehicle       | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Mirrors                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSP                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | IC                             | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | PAM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCU                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Expedition EL | 5.4L     | 3V         | 2007 | Programmable Module Installation | SDARS                          | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSP                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | IC                             | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCU                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Mirrors                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Parameters          | Climate Control Seats          | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | DCSM                           | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | IC                             | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | PAM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCU                            | ●     |
| Expedition EL | 5.4L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Mirrors                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Parameters          | Climate Control Seats          | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Module Installation | DCSM                           | ●     |

| Vehicle       | Capacity | EngineType | Year | Module Programming               | System                | Flags |
|---------------|----------|------------|------|----------------------------------|-----------------------|-------|
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Module Installation | DSM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Module Installation | IC                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Module Installation | PAM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCU                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2010 | Programmable Module Installation | RETM                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Seats           | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Mirrors         | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Parameters          | Climate Control Seats | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Module Installation | DCSM                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Module Installation | DSM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Module Installation | IC                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Module Installation | RCU                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2011 | Programmable Module Installation | RETM                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Seats           | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Mirrors         | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Parameters          | Climate Control Seats | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Module Installation | ACM                   | ※     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Module Installation | DCSM                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Module Installation | DSM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Module Installation | IC                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Module Installation | PAM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Module Installation | RCU                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2012 | Programmable Module Installation | RETM                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Seats           | ●     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Parameters          | Audio Configure       | ※     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Mirrors         | ●     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Parameters          | Climate Control Seats | ●     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Module Installation | DCSM                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Module Installation | DSM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Module Installation | IC                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Module Installation | PAM                   | ※     |
| Expedition EL | 5.4L     | 3V         | 2013 | Programmable Module Installation | RCU                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Seats           | ●     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Parameters          | Audio Configure       | ※     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Mirrors         | ●     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Parameters          | Climate Control Seats | ●     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Module Installation | DCSM                  | ●     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Module Installation | DSM                   | ●     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Module Installation | IC                    | ●     |
| Expedition EL | 5.4L     | 3V         | 2014 | Programmable Module Installation | PAM                   | ●     |



| Vehicle       | Capacity | EngineType                                   | Year | Module Programming               | System | Flags |
|---------------|----------|--|------|----------------------------------|--------|-------|
| Expedition EL | 5.4L     | 3V   | 2014 | Programmable Module Installation | RCU    | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 3.5L     | TiVCT  | 2011 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 3.5L     | TiVCT  | 2011 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 3.5L     | TiVCT  | 2012 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 3.5L     | TiVCT  | 2012 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 3.5L     | TiVCT  | 2014 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 3.5L     | TiVCT  | 2014 | Programmable Module Installation | DSM    | ●     |
| Explorer      | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DCSM   | ●     |
| Explorer      | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DSM    | ●     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|----------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Explorer | 3.7L     | TiVCT      | 2014 | Programmable Module Installation | DCSM                           | ●     |
| Explorer | 3.7L     | TiVCT      | 2014 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Parameters          | Audio Configure                | ※     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | ACM                            | ※     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | EATC                           | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | PAM                            | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.0L     | 2V         | 2006 | Programmable Module Installation | SDARS                          | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Parameters          | Audio Configure                | ※     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | EATC                           | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.0L     | 2V         | 2007 | Programmable Module Installation | SDARS                          | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Module Installation | GEM / SJB                      | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Module Installation | HVAC                           | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.0L     | 2V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Module Installation | GEM / SJB                      | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Module Installation | HVAC                           | ●     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|----------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Explorer | 4.0L     | 2V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.0L     | 2V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Module Installation | GEM / SJB                      | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Module Installation | HVAC                           | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.0L     | 2V         | 2010 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.0L     | Other      | 1996 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | Other      | 1997 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | Other      | 1998 | Programmable Parameters          | Vehicle                        | ●     |
| Explorer | 4.0L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Explorer | 4.0L     | Other      | 1998 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 4.0L     | Other      | 1998 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | Other      | 1998 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.0L     | Other      | 1998 | Programmable Module Installation | RAP                            | ●     |
| Explorer | 4.0L     | Other      | 1999 | Programmable Parameters          | Vehicle                        | ●     |
| Explorer | 4.0L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Explorer | 4.0L     | Other      | 1999 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.0L     | Other      | 1999 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 4.0L     | Other      | 1999 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | Other      | 1999 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.0L     | Other      | 1999 | Programmable Module Installation | RAP                            | ●     |
| Explorer | 4.0L     | Other      | 2000 | Programmable Parameters          | Vehicle                        | ●     |
| Explorer | 4.0L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Explorer | 4.0L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.0L     | Other      | 2000 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 4.0L     | Other      | 2000 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | Other      | 2000 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.0L     | Other      | 2000 | Programmable Module Installation | RAP                            | ●     |
| Explorer | 4.0L     | V6 OHV     | 1996 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | V6 OHV     | 1997 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | V6 OHV     | 1998 | Programmable Parameters          | Vehicle                        | ●     |
| Explorer | 4.0L     | V6 OHV     | 1998 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Explorer | 4.0L     | V6 OHV     | 1998 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 4.0L     | V6 OHV     | 1998 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 4.0L     | V6 OHV     | 1998 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.0L     | V6 OHV     | 1998 | Programmable Module Installation | RAP                            | ●     |

| Vehicle  | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|----------|----------|------------|--------|----------------------------------|------------------------|-------|
| Explorer | 4.0L     | V6 OHV     | 1999   | Programmable Parameters          | Vehicle                | ●     |
| Explorer | 4.0L     | V6 OHV     | 1999   | Programmable Parameters          | Washer / Wiper         | ●     |
| Explorer | 4.0L     | V6 OHV     | 1999   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 OHV     | 1999   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 OHV     | 1999   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.0L     | V6 OHV     | 1999   | Programmable Module Installation | GEM                    | ●     |
| Explorer | 4.0L     | V6 OHV     | 1999   | Programmable Module Installation | RAP                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1997   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1998   | Programmable Parameters          | Vehicle                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1998   | Programmable Parameters          | Washer / Wiper         | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1998   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1998   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1998   | Programmable Module Installation | GEM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1998   | Programmable Module Installation | RAP                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Vehicle                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Washer / Wiper         | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1999   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1999   | Programmable Module Installation | GEM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 1999   | Programmable Module Installation | RAP                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Vehicle                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Washer / Wiper         | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2000   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2000   | Programmable Module Installation | GEM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2000   | Programmable Module Installation | RAP                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Washer / Wiper         | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Climate Control        | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | CSM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | GEM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | IC                     | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Power Seats            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Security               | ●     |

| Vehicle  | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|----------|----------|------------|--------|----------------------------------|------------------------|-------|
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Climate Control        | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | CSM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | DSM                    | ※     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | HEC                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | TPM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Power Seats            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Security               | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Climate Control        | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | DSM                    | ※     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | HEC                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | TPM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | VSM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Power Seats            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | ABS                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | DSM                    | ※     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | IC                     | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | TPM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | VSM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Power Seats            | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Security               | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | ABS                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | DSM                    | ※     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | IC                     | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | TPM                    | ●     |
| Explorer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | VSM                    | ●     |
| Explorer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Personality            | ●     |

| Vehicle  | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|----------|----------|------------|--------|----------------------------------|------------------------|-------|
| Explorer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Washer / Wiper         | ●     |
| Explorer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Climate Control        | ●     |
| Explorer | 4.6L     | 2V         | 2002   | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.6L     | 2V         | 2002   | Programmable Module Installation | CSM                    | ●     |
| Explorer | 4.6L     | 2V         | 2002   | Programmable Module Installation | GEM                    | ●     |
| Explorer | 4.6L     | 2V         | 2002   | Programmable Module Installation | IC                     | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Power Seats            | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Security               | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Climate Control        | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | CSM                    | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | DSM                    | ※     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | HEC                    | ●     |
| Explorer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | TPM                    | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Power Seats            | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Security               | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Climate Control        | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Module Installation | DSM                    | ※     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Module Installation | HEC                    | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Module Installation | TPM                    | ●     |
| Explorer | 4.6L     | 2V         | 2003   | Programmable Module Installation | VSM                    | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Personality            | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Power Seats            | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Module Installation | ABS                    | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Module Installation | EATC                   | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Module Installation | DSM                    | ※     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Module Installation | IC                     | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Module Installation | TPM                    | ●     |
| Explorer | 4.6L     | 2V         | 2004   | Programmable Module Installation | VSM                    | ●     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|----------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Explorer | 4.6L     | 2V         | 2005 | Programmable Parameters          | Personality                    | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Parameters          | Security                       | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Module Installation | EATC                           | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Module Installation | DSM                            | ✘     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Module Installation | IC                             | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Module Installation | TPM                            | ●     |
| Explorer | 4.6L     | 2V         | 2005 | Programmable Module Installation | VSM                            | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Parameters          | Audio Configure                | ✘     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | ACM                            | ✘     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | EATC                           | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | PAM                            | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.6L     | 3V         | 2006 | Programmable Module Installation | SDARS                          | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Audio Configure                | ✘     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | ACM                            | ✘     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | EATC                           | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.6L     | 3V         | 2007 | Programmable Module Installation | SDARS                          | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Module Installation | GEM / SJB                      | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Module Installation | HVAC                           | ●     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|----------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Explorer | 4.6L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.6L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Module Installation | GEM / SJB                      | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Module Installation | HVAC                           | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.6L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Module Installation | ABS                            | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Module Installation | GEM / SJB                      | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Module Installation | HVAC                           | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Module Installation | RCM                            | ●     |
| Explorer | 4.6L     | 3V         | 2010 | Programmable Module Installation | RETM                           | ●     |
| Explorer | 5.0L     | Other      | 1996 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 5.0L     | Other      | 1997 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 5.0L     | Other      | 1998 | Programmable Parameters          | Vehicle                        | ●     |
| Explorer | 5.0L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Explorer | 5.0L     | Other      | 1998 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 5.0L     | Other      | 1998 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 5.0L     | Other      | 1998 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 5.0L     | Other      | 1998 | Programmable Module Installation | RAP                            | ●     |
| Explorer | 5.0L     | Other      | 1999 | Programmable Parameters          | Vehicle                        | ●     |
| Explorer | 5.0L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Explorer | 5.0L     | Other      | 1999 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 5.0L     | Other      | 1999 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 5.0L     | Other      | 1999 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 5.0L     | Other      | 1999 | Programmable Module Installation | GEM                            | ●     |
| Explorer | 5.0L     | Other      | 1999 | Programmable Module Installation | RAP                            | ●     |
| Explorer | 5.0L     | Other      | 2000 | Programmable Parameters          | Vehicle                        | ●     |
| Explorer | 5.0L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Explorer | 5.0L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Explorer | 5.0L     | Other      | 2000 | Programmable Parameters          | Power Door Locks               | ●     |
| Explorer | 5.0L     | Other      | 2000 | Programmable Module Installation | ABS/TCS                        | ●     |
| Explorer | 5.0L     | Other      | 2000 | Programmable Module Installation | GEM                            | ●     |



| Vehicle            | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|--------------------|----------|------------|--------|----------------------------------|------------------------|-------|
| Explorer           | 5.0L     | Other      | 2000   | Programmable Module Installation | RAP                    | ●     |
| Explorer           | Other    | Other      | 2015   | Programmable Module Installation | DCSM                   | ●     |
| Explorer           | Other    | Other      | 2015   | Programmable Module Installation | DSM                    | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000.5 | Programmable Parameters          | Washer / Wiper         | ※     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000.5 | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000.5 | Programmable Module Installation | GEM                    | ※     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2000.5 | Programmable Module Installation | RAP                    | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2001   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2001   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2001   | Programmable Parameters          | Security               | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2001   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2001   | Programmable Module Installation | GEM                    | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2001   | Programmable Module Installation | RAP                    | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Security               | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | GEM                    | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | RAP                    | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Security               | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | GEM                    | ●     |
| Explorer Sport     | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | RAP                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Parameters          | Audio Configure        | ※     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | ACM                    | ※     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | EATC                   | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | GEM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | RETM                   | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2007   | Programmable Module Installation | SDARS                  | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2008   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2008   | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2008   | Programmable Module Installation | GEM / SJB              | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2008   | Programmable Module Installation | HVAC                   | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2008   | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2008   | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2008   | Programmable Module Installation | RETM                   | ●     |

| Vehicle            | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|--------------------|----------|------------|--------|----------------------------------|------------------------|-------|
| Explorer SportTrac | 4.0L     | 2V         | 2009   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2009   | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2009   | Programmable Module Installation | GEM / SJB              | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2009   | Programmable Module Installation | HVAC                   | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2009   | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2009   | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2009   | Programmable Module Installation | RETM                   | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2010   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2010   | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2010   | Programmable Module Installation | GEM / SJB              | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2010   | Programmable Module Installation | HVAC                   | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2010   | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2010   | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.0L     | 2V         | 2010   | Programmable Module Installation | RETM                   | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000.5 | Programmable Parameters          | Washer / Wiper         | ※     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000.5 | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000.5 | Programmable Module Installation | GEM                    | ※     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2000.5 | Programmable Module Installation | RAP                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2001   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2001   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2001   | Programmable Parameters          | Security               | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2001   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2001   | Programmable Module Installation | GEM                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2001   | Programmable Module Installation | RAP                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Security               | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | ABS/TCS                | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | GEM                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | RAP                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Power Door Locks       | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Security               | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | GEM                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | RAP                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Security               | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | HEC                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | RAP                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Security               | ●     |

| Vehicle            | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|--------------------|----------|--|------|----------------------------------|------------------------|-------|
| Explorer SportTrac | 4.0L     | V6 SOHC                                      | 2005 | Programmable Module Installation | HEC                    | ●     |
| Explorer SportTrac | 4.0L     | V6 SOHC                                      | 2005 | Programmable Module Installation | RAP                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Parameters          | Audio Configure        | ※     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | ACM                    | ※     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | EATC                   | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | GEM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | RETM                   | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2007 | Programmable Module Installation | SDARS                  | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2008 | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2008 | Programmable Module Installation | GEM / SJB              | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2008 | Programmable Module Installation | HVAC                   | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2008 | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2008 | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2008 | Programmable Module Installation | RETM                   | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2009 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2009 | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2009 | Programmable Module Installation | GEM / SJB              | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2009 | Programmable Module Installation | HVAC                   | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2009 | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2009 | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2009 | Programmable Module Installation | RETM                   | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2010 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2010 | Programmable Module Installation | ABS                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2010 | Programmable Module Installation | GEM / SJB              | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2010 | Programmable Module Installation | HVAC                   | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2010 | Programmable Module Installation | PAM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2010 | Programmable Module Installation | RCM                    | ●     |
| Explorer SportTrac | 4.6L     | 3V   | 2010 | Programmable Module Installation | RETM                   | ●     |
| F-150              | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DCSM                   | ●     |
| F-150              | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DSM                    | ●     |
| F-150              | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | FDIM                   | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System           | Flags |
|---------|----------|--|------|----------------------------------|------------------|-------|
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DCSM             | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DSM              | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | FDIM             | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM             | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM              | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | FDIM             | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM             | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM              | ●     |
| F-150   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | FDIM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2011 | Programmable Module Installation | DCSM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2011 | Programmable Module Installation | DSM              | ●     |
| F-150   | 3.7L     | TiVCT  | 2011 | Programmable Module Installation | FDIM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2012 | Programmable Module Installation | DCSM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2012 | Programmable Module Installation | DSM              | ●     |
| F-150   | 3.7L     | TiVCT  | 2012 | Programmable Module Installation | FDIM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DCSM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DSM              | ●     |
| F-150   | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | FDIM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DCSM             | ●     |
| F-150   | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DSM              | ●     |
| F-150   | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | FDIM             | ●     |
| F-150   | 4.2L     | 2V   | 2005 | Programmable Parameters          | Power Door Locks | ●     |
| F-150   | 4.2L     | 2V   | 2005 | Programmable Module Installation | ABS              | ●     |
| F-150   | 4.2L     | 2V   | 2005 | Programmable Module Installation | DSM              | ※     |
| F-150   | 4.2L     | 2V   | 2005 | Programmable Module Installation | VSM              | ●     |
| F-150   | 4.2L     | 2V   | 2006 | Programmable Parameters          | Power Door Locks | ●     |
| F-150   | 4.2L     | 2V   | 2006 | Programmable Module Installation | ABS              | ●     |
| F-150   | 4.2L     | 2V   | 2006 | Programmable Module Installation | DSM              | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------|----------|------------|------|----------------------------------|---------------------------------|-------|
| F-150   | 4.2L     | 2V         | 2006 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Parameters          | Personality                     | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Parameters          | Fuel                            | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Parameters          | Climate Control                 | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Module Installation | IC                              | ●     |
| F-150   | 4.2L     | 2V         | 2007 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Parameters          | Climate Control                 | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Module Installation | IC                              | ●     |
| F-150   | 4.2L     | 2V         | 2008 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 4.2L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper                  | ●     |
| F-150   | 4.2L     | Other      | 1998 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.2L     | Other      | 1998 | Programmable Module Installation | GEM                             | ●     |
| F-150   | 4.2L     | Other      | 1998 | Programmable Module Installation | RAP                             | ●     |
| F-150   | 4.2L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper                  | ●     |
| F-150   | 4.2L     | Other      | 1999 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.2L     | Other      | 1999 | Programmable Module Installation | GEM                             | ●     |
| F-150   | 4.2L     | Other      | 1999 | Programmable Module Installation | RAP                             | ●     |
| F-150   | 4.2L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper                  | ●     |
| F-150   | 4.2L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| F-150   | 4.2L     | Other      | 2000 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.2L     | Other      | 2000 | Programmable Parameters          | Security                        | ※     |
| F-150   | 4.2L     | Other      | 2000 | Programmable Module Installation | GEM                             | ●     |
| F-150   | 4.2L     | Other      | 2000 | Programmable Module Installation | RAP                             | ●     |
| F-150   | 4.2L     | Other      | 2002 | Programmable Parameters          | Washer / Wiper                  | ●     |
| F-150   | 4.2L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| F-150   | 4.2L     | Other      | 2002 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.2L     | Other      | 2002 | Programmable Parameters          | Security                        | ●     |
| F-150   | 4.2L     | Other      | 2002 | Programmable Module Installation | GEM                             | ●     |
| F-150   | 4.2L     | Other      | 2002 | Programmable Module Installation | RAP                             | ●     |
| F-150   | 4.2L     | Other      | 2003 | Programmable Parameters          | Washer / Wiper                  | ●     |
| F-150   | 4.2L     | Other      | 2003 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| F-150   | 4.2L     | Other      | 2003 | Programmable Parameters          | Power Door Locks                | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------|----------|------------|------|----------------------------------|------------------------|-------|
| F-150   | 4.2L     | Other      | 2003 | Programmable Parameters          | Security               | ●     |
| F-150   | 4.2L     | Other      | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.2L     | Other      | 2003 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.2L     | Other      | 2004 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 4.2L     | Other      | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 4.2L     | Other      | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.2L     | Other      | 2004 | Programmable Parameters          | Security               | ●     |
| F-150   | 4.2L     | Other      | 2004 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.2L     | Other      | 2004 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.2L     | Other      | 2005 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 4.2L     | Other      | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 4.2L     | Other      | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.2L     | Other      | 2005 | Programmable Parameters          | Security               | ●     |
| F-150   | 4.2L     | Other      | 2005 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.2L     | Other      | 2005 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.2L     | Other      | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.2L     | Other      | 2006 | Programmable Parameters          | Security               | ●     |
| F-150   | 4.2L     | Other      | 2006 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.2L     | Other      | 2006 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.6L     | 2V         | 2003 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 4.6L     | 2V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 4.6L     | 2V         | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.6L     | 2V         | 2003 | Programmable Parameters          | Security               | ●     |
| F-150   | 4.6L     | 2V         | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.6L     | 2V         | 2003 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Parameters          | Climate Control        | ●     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Parameters          | Washer / Wiper         | ※     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Parameters          | Security               | ※     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Module Installation | ABS                    | ●     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Module Installation | DSM                    | ※     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Module Installation | IC                     | ●     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Module Installation | VSM                    | ●     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Module Installation | GEM                    | ※     |
| F-150   | 4.6L     | 2V         | 2004 | Programmable Module Installation | RAP                    | ※     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Parameters          | Washer / Wiper         | ※     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Parameters          | Security               | ※     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Module Installation | ABS                    | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------|----------|------------|------|----------------------------------|---------------------------------|-------|
| F-150   | 4.6L     | 2V         | 2005 | Programmable Module Installation | DSM                             | ※     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Module Installation | GEM                             | ※     |
| F-150   | 4.6L     | 2V         | 2005 | Programmable Module Installation | RAP                             | ※     |
| F-150   | 4.6L     | 2V         | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.6L     | 2V         | 2006 | Programmable Parameters          | Security                        | ※     |
| F-150   | 4.6L     | 2V         | 2006 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 4.6L     | 2V         | 2006 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2006 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2006 | Programmable Module Installation | GEM                             | ※     |
| F-150   | 4.6L     | 2V         | 2006 | Programmable Module Installation | RAP                             | ※     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Parameters          | Personality                     | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Parameters          | Fuel                            | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Parameters          | Climate Control                 | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Module Installation | IC                              | ●     |
| F-150   | 4.6L     | 2V         | 2007 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Parameters          | Climate Control                 | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Module Installation | IC                              | ●     |
| F-150   | 4.6L     | 2V         | 2008 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2009 | Programmable Parameters          | Power Seats                     | ●     |
| F-150   | 4.6L     | 2V         | 2009 | Programmable Module Installation | DCSM                            | ●     |
| F-150   | 4.6L     | 2V         | 2009 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2009 | Programmable Module Installation | FDIM                            | ●     |
| F-150   | 4.6L     | 2V         | 2010 | Programmable Parameters          | Power Seats                     | ●     |
| F-150   | 4.6L     | 2V         | 2010 | Programmable Module Installation | DCSM                            | ●     |
| F-150   | 4.6L     | 2V         | 2010 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.6L     | 2V         | 2010 | Programmable Module Installation | FDIM                            | ●     |
| F-150   | 4.6L     | 3V         | 2009 | Programmable Parameters          | Power Seats                     | ●     |
| F-150   | 4.6L     | 3V         | 2009 | Programmable Module Installation | DCSM                            | ●     |
| F-150   | 4.6L     | 3V         | 2009 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 4.6L     | 3V         | 2009 | Programmable Module Installation | FDIM                            | ●     |
| F-150   | 4.6L     | 3V         | 2010 | Programmable Parameters          | Power Seats                     | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------|----------|------------|------|----------------------------------|------------------------|-------|
| F-150   | 4.6L     | 3V         | 2010 | Programmable Module Installation | DCSM                   | ●     |
| F-150   | 4.6L     | 3V         | 2010 | Programmable Module Installation | DSM                    | ●     |
| F-150   | 4.6L     | 3V         | 2010 | Programmable Module Installation | FDIM                   | ●     |
| F-150   | 4.6L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 4.6L     | Other      | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.6L     | Other      | 1998 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.6L     | Other      | 1998 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.6L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 4.6L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.6L     | Other      | 1999 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.6L     | Other      | 1999 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.6L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 4.6L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 4.6L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.6L     | Other      | 2000 | Programmable Parameters          | Security               | ※     |
| F-150   | 4.6L     | Other      | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.6L     | Other      | 2000 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 4.6L     | Other      | 2002 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 4.6L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 4.6L     | Other      | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 4.6L     | Other      | 2002 | Programmable Parameters          | Security               | ●     |
| F-150   | 4.6L     | Other      | 2002 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 4.6L     | Other      | 2002 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.0L     | TivCT      | 2011 | Programmable Module Installation | DCSM                   | ●     |
| F-150   | 5.0L     | TivCT      | 2011 | Programmable Module Installation | DSM                    | ●     |
| F-150   | 5.0L     | TivCT      | 2011 | Programmable Module Installation | FDIM                   | ●     |
| F-150   | 5.0L     | TivCT      | 2012 | Programmable Module Installation | DCSM                   | ●     |
| F-150   | 5.0L     | TivCT      | 2012 | Programmable Module Installation | DSM                    | ●     |
| F-150   | 5.0L     | TivCT      | 2012 | Programmable Module Installation | FDIM                   | ●     |
| F-150   | 5.0L     | TivCT      | 2013 | Programmable Module Installation | DCSM                   | ●     |
| F-150   | 5.0L     | TivCT      | 2013 | Programmable Module Installation | DSM                    | ●     |
| F-150   | 5.0L     | TivCT      | 2013 | Programmable Module Installation | FDIM                   | ●     |
| F-150   | 5.0L     | TivCT      | 2014 | Programmable Module Installation | DCSM                   | ●     |
| F-150   | 5.0L     | TivCT      | 2014 | Programmable Module Installation | DSM                    | ●     |
| F-150   | 5.0L     | TivCT      | 2014 | Programmable Module Installation | FDIM                   | ●     |
| F-150   | 5.4L     | 2V         | 2004 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | 2V         | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 5.4L     | 2V         | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | 2V         | 2004 | Programmable Parameters          | Security               | ●     |
| F-150   | 5.4L     | 2V         | 2004 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | 2V         | 2004 | Programmable Module Installation | RAP                    | ●     |



| Vehicle | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------|----------|------------|------|----------------------------------|---------------------------------|-------|
| F-150   | 5.4L     | 3V         | 2004 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 5.4L     | 3V         | 2004 | Programmable Parameters          | Climate Control                 | ●     |
| F-150   | 5.4L     | 3V         | 2004 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 5.4L     | 3V         | 2004 | Programmable Module Installation | DSM                             | ✖     |
| F-150   | 5.4L     | 3V         | 2004 | Programmable Module Installation | IC                              | ●     |
| F-150   | 5.4L     | 3V         | 2004 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Door Locks                | ✖     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Module Installation | DSM                             | ✖     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Module Installation | ABS                             | ✖     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Module Installation | DSM                             | ✖     |
| F-150   | 5.4L     | 3V         | 2005 | Programmable Module Installation | VSM                             | ✖     |
| F-150   | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 5.4L     | 3V         | 2006 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 5.4L     | 3V         | 2006 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2006 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Parameters          | Personality                     | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Parameters          | Fuel                            | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Parameters          | Climate Control                 | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Module Installation | IC                              | ●     |
| F-150   | 5.4L     | 3V         | 2007 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Parameters          | Climate Control                 | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Module Installation | ABS                             | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Module Installation | IC                              | ●     |
| F-150   | 5.4L     | 3V         | 2008 | Programmable Module Installation | VSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Seats                     | ●     |
| F-150   | 5.4L     | 3V         | 2009 | Programmable Module Installation | DCSM                            | ●     |
| F-150   | 5.4L     | 3V         | 2009 | Programmable Module Installation | DSM                             | ●     |
| F-150   | 5.4L     | 3V         | 2009 | Programmable Module Installation | FDIM                            | ●     |
| F-150   | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Seats                     | ●     |
| F-150   | 5.4L     | 3V         | 2010 | Programmable Module Installation | DCSM                            | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------|----------|------------|------|----------------------------------|------------------------|-------|
| F-150   | 5.4L     | 3V         | 2010 | Programmable Module Installation | DSM                    | ●     |
| F-150   | 5.4L     | 3V         | 2010 | Programmable Module Installation | FDIM                   | ●     |
| F-150   | 5.4L     | BIF        | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | BIF        | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | BIF        | 1998 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | BIF        | 1998 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.4L     | BIF        | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | BIF        | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | BIF        | 1999 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | BIF        | 1999 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.4L     | BIF        | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | BIF        | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 5.4L     | BIF        | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | BIF        | 2000 | Programmable Parameters          | Security               | ※     |
| F-150   | 5.4L     | BIF        | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | BIF        | 2000 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.4L     | NGV        | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | NGV        | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 5.4L     | NGV        | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | NGV        | 2000 | Programmable Parameters          | Security               | ※     |
| F-150   | 5.4L     | NGV        | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | NGV        | 2000 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.4L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | Other      | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | Other      | 1998 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | Other      | 1998 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.4L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | Other      | 1999 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | Other      | 1999 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.4L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 5.4L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | Other      | 2000 | Programmable Parameters          | Security               | ※     |
| F-150   | 5.4L     | Other      | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-150   | 5.4L     | Other      | 2000 | Programmable Module Installation | RAP                    | ●     |
| F-150   | 5.4L     | Other      | 2002 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150   | 5.4L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150   | 5.4L     | Other      | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150   | 5.4L     | Other      | 2002 | Programmable Parameters          | Security               | ●     |
| F-150   | 5.4L     | Other      | 2002 | Programmable Module Installation | GEM                    | ●     |

| Vehicle                             | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|-------------------------------------|----------|------------|------|----------------------------------|------------------------|-------|
| F-150                               | 5.4L     | Other      | 2002 | Programmable Module Installation | RAP                    | ●     |
| F-150                               | 5.4L     | Other      | 2003 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150                               | 5.4L     | Other      | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150                               | 5.4L     | Other      | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150                               | 5.4L     | Other      | 2003 | Programmable Parameters          | Security               | ●     |
| F-150                               | 5.4L     | Other      | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-150                               | 5.4L     | Other      | 2003 | Programmable Module Installation | RAP                    | ●     |
| F-150                               | 6.2L     | 2V         | 2010 | Programmable Parameters          | Power Seats            | ●     |
| F-150                               | 6.2L     | 2V         | 2010 | Programmable Module Installation | DCSM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2010 | Programmable Module Installation | DSM                    | ●     |
| F-150                               | 6.2L     | 2V         | 2010 | Programmable Module Installation | FDIM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2011 | Programmable Module Installation | DCSM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2011 | Programmable Module Installation | DSM                    | ●     |
| F-150                               | 6.2L     | 2V         | 2011 | Programmable Module Installation | FDIM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2012 | Programmable Module Installation | DCSM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2012 | Programmable Module Installation | DSM                    | ●     |
| F-150                               | 6.2L     | 2V         | 2012 | Programmable Module Installation | FDIM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2013 | Programmable Module Installation | DCSM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2013 | Programmable Module Installation | DSM                    | ●     |
| F-150                               | 6.2L     | 2V         | 2013 | Programmable Module Installation | FDIM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2014 | Programmable Module Installation | DCSM                   | ●     |
| F-150                               | 6.2L     | 2V         | 2014 | Programmable Module Installation | DSM                    | ●     |
| F-150                               | 6.2L     | 2V         | 2014 | Programmable Module Installation | FDIM                   | ●     |
| F-150                               | Other    | Other      | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150                               | Other    | Other      | 2004 | Programmable Parameters          | Climate Control        | ●     |
| F-150                               | Other    | Other      | 2004 | Programmable Module Installation | ABS                    | ●     |
| F-150                               | Other    | Other      | 2004 | Programmable Module Installation | DSM                    | ※     |
| F-150                               | Other    | Other      | 2004 | Programmable Module Installation | IC                     | ●     |
| F-150                               | Other    | Other      | 2004 | Programmable Module Installation | VSM                    | ●     |
| F-150                               | Other    | Other      | 2014 | Programmable Module Installation | DCSM                   | ●     |
| F-150                               | Other    | Other      | 2014 | Programmable Module Installation | DSM                    | ●     |
| F-150                               | Other    | Other      | 2014 | Programmable Module Installation | FDIM                   | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | 2V         | 2003 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | 2V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | 2V         | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | 2V         | 2003 | Programmable Parameters          | Security               | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | 2V         | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | 2V         | 2003 | Programmable Module Installation | RAP                    | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other      | 2001 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other      | 2001 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other      | 2001 | Programmable Parameters          | Power Door Locks       | ●     |

| Vehicle                             | Capacity | EngineType     | Year | Module Programming               | System                 | Flags |
|-------------------------------------|----------|----------------|------|----------------------------------|------------------------|-------|
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2001 | Programmable Parameters          | Security               | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2001 | Programmable Module Installation | GEM                    | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2001 | Programmable Module Installation | RAP                    | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2002 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2002 | Programmable Parameters          | Security               | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2002 | Programmable Module Installation | GEM                    | ●     |
| F-150 SuperCrew (4 full size doors) | 4.6L     | Other          | 2002 | Programmable Module Installation | RAP                    | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | 2V             | 2003 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | 2V             | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | 2V             | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | 2V             | 2003 | Programmable Parameters          | Security               | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | 2V             | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | 2V             | 2003 | Programmable Module Installation | RAP                    | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2001 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2001 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2001 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2001 | Programmable Parameters          | Security               | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2001 | Programmable Module Installation | GEM                    | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2001 | Programmable Module Installation | RAP                    | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Security               | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Washer / Wiper         | ※     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Power Door Locks       | ※     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Parameters          | Security               | ※     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Module Installation | GEM                    | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Module Installation | RAP                    | ●     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Module Installation | GEM                    | ※     |
| F-150 SuperCrew (4 full size doors) | 5.4L     | Other          | 2002 | Programmable Module Installation | RAP                    | ※     |
| F-250                               | 3.9L     | Cummins Diesel | 2006 | Programmable Module Installation | 4X4                    | ●     |
| F-250                               | 3.9L     | Cummins Diesel | 2006 | Programmable Module Installation | ABS/TCS                | ●     |
| F-250                               | 3.9L     | Cummins Diesel | 2006 | Programmable Module Installation | HEC                    | ●     |
| F-250                               | 3.9L     | Cummins Diesel | 2006 | Programmable Module Installation | TBM                    | ●     |
| F-250 Light Duty                    | 4.2L     | Other          | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty                    | 4.2L     | Other          | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty                    | 4.2L     | Other          | 1999 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty                    | 4.2L     | Other          | 1999 | Programmable Module Installation | RAP                    | ●     |

| Vehicle          | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|------------------|----------|------------|------|----------------------------------|------------------------|-------|
| F-250 Light Duty | 4.6L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 4.6L     | Other      | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 4.6L     | Other      | 1998 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 4.6L     | Other      | 1998 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 4.6L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 4.6L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 4.6L     | Other      | 1999 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 4.6L     | Other      | 1999 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 4.6L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 4.6L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-250 Light Duty | 4.6L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 4.6L     | Other      | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 4.6L     | Other      | 2000 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1998 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1998 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1999 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 5.4L     | BIF        | 1999 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1998 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1998 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1999 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 1999 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 5.4L     | NGV        | 2000 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | Other      | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | Other      | 1998 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 5.4L     | Other      | 1998 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | Other      | 1999 | Programmable Module Installation | GEM                    | ●     |

| Vehicle          | Capacity | EngineType     | Year | Module Programming               | System                 | Flags |
|------------------|----------|----------------|------|----------------------------------|------------------------|-------|
| F-250 Light Duty | 5.4L     | Other          | 1999 | Programmable Module Installation | RAP                    | ●     |
| F-250 Light Duty | 5.4L     | Other          | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-250 Light Duty | 5.4L     | Other          | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-250 Light Duty | 5.4L     | Other          | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-250 Light Duty | 5.4L     | Other          | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-250 Light Duty | 5.4L     | Other          | 2000 | Programmable Module Installation | RAP                    | ●     |
| F350/4000        | 3.9L     | Cummins Diesel | 2009 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F350/4000        | 3.9L     | Cummins Diesel | 2009 | Programmable Parameters          | Driveline              | ●     |
| F350/4000        | 3.9L     | Cummins Diesel | 2009 | Programmable Module Installation | 4X4                    | ●     |
| F350/4000        | 3.9L     | Cummins Diesel | 2009 | Programmable Module Installation | GEM                    | ※     |
| F350/4000        | 3.9L     | Cummins Diesel | 2009 | Programmable Module Installation | TBM                    | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Parameters          | Vehicle                | ※     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Parameters          | Interior Lighting      | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2002 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2002 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2002 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2002 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2003 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2003 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2003 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2004 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2004 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2004 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2004 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2005 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2005 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2005 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2005 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2006 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750    | 5.9L     | Cummins Diesel | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |

| Vehicle       | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|---------------|----------|--------------------|------|----------------------------------|------------------------|-------|
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2006 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2006 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2006 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2007 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2007 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2007 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 5.9L     | Cummins Diesel     | 2007 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2005 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2006 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2006 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2006 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2006 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2007 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2007 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2007 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.0L     | Direct Injection - | 2007 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2008 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2008 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2008 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2008 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2008 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2009 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2009 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2009 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2009 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2009 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2009 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel     | 2010 | Programmable Parameters          | Vehicle                | ●     |

| Vehicle       | Capacity | EngineType     | Year | Module Programming               | System                 | Flags |
|---------------|----------|----------------|------|----------------------------------|------------------------|-------|
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2010 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2010 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2010 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2010 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2011 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2011 | Programmable Parameters          | Audio Configure        | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2011 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2011 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2011 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2011 | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2011 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2012 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2012 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2012 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2012 | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2012 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2013 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2013 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2013 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2013 | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2013 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2015 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2015 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2015 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2015 | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750 | 6.7L     | Cummins Diesel | 2015 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2012 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2012 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2012 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2012 | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2012 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2013 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2013 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2013 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2013 | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2013 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2015 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2015 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2015 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2015 | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750 | 6.8L     | 3V             | 2015 | Programmable Module Installation | GEM / SJB              | ●     |



| Vehicle       | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|---------------|----------|--------------------|------|----------------------------------|------------------------|-------|
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Parameters          | Vehicle                | ※     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Parameters          | Interior Lighting      | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2002 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2002 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2002 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2002 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2003 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2003 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2003 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2004 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2004 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2004 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2004 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2005 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2005 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2005 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2005 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2006 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2006 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2006 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2006 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2007 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2007 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2007 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2007 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2008 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2008 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ●     |

| Vehicle       | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|---------------|----------|--------------------|------|----------------------------------|------------------------|-------|
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2008 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2008 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2008 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2009 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2009 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2009 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2009 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2009 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2009 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2010 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2010 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2010 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2010 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.2L     | Caterpillar Diesel | 2010 | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Vehicle                | ※     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Interior Lighting      | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Washer / Wiper         | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2000 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | Other    | Other              | 2005 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | Other    | Other              | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | Other    | Other              | 2005 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | Other    | Other              | 2005 | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750 | Other    | Other              | 2005 | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750 | Other    | Other              | 2006 | Programmable Parameters          | Vehicle                | ●     |
| F-650 / F-750 | Other    | Other              | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750 | Other    | Other              | 2006 | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750 | Other    | Other              | 2006 | Programmable Parameters          | Power Windows          | ●     |

| Vehicle        | Capacity | EngineType | Year  | Module Programming               | System                 | Flags |
|----------------|----------|------------|-------|----------------------------------|------------------------|-------|
| F-650 / F-750  | Other    | Other      | 2006  | Programmable Module Installation | GEM                    | ●     |
| F-650 / F-750  | Other    | Other      | 2013  | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750  | Other    | Other      | 2013  | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750  | Other    | Other      | 2013  | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750  | Other    | Other      | 2013  | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750  | Other    | Other      | 2013  | Programmable Module Installation | GEM / SJB              | ●     |
| F-650 / F-750  | Other    | Other      | 2015  | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-650 / F-750  | Other    | Other      | 2015  | Programmable Parameters          | Driveline              | ●     |
| F-650 / F-750  | Other    | Other      | 2015  | Programmable Parameters          | Power Windows          | ●     |
| F-650 / F-750  | Other    | Other      | 2015  | Programmable Module Installation | ACM                    | ●     |
| F-650 / F-750  | Other    | Other      | 2015  | Programmable Module Installation | GEM / SJB              | ●     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Personality            | ●     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Police Mode            | ●     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Alarm                  | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Climate Control        | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Module Installation | BEM                    | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Module Installation | HIM                    | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2003  | Programmable Module Installation | PAM                    | ●     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Personality            | ●     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Police Mode            | ●     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Alarm                  | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Climate Control        | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | ABS                    | ●     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | BEM                    | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | HIM                    | ※     |
| Fairlane / LTD | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | PAM                    | ●     |
| Fairlane / LTD | 4.0L     | Other      | Other | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Fairlane / LTD | 4.0L     | Other      | Other | Programmable Module Installation | IC                     | ●     |
| Fairlane / LTD | 5.0L     | Other      | Other | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Fairlane / LTD | 5.0L     | Other      | Other | Programmable Module Installation | IC                     | ●     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Parameters          | Personality            | ●     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Parameters          | Police Mode            | ●     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Parameters          | Alarm                  | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Parameters          | Climate Control        | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Module Installation | BEM                    | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Module Installation | HIM                    | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2003  | Programmable Module Installation | PAM                    | ●     |

| Vehicle        | Capacity | EngineType | Year  | Module Programming               | System                 | Flags |
|----------------|----------|------------|-------|----------------------------------|------------------------|-------|
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Parameters          | Personality            | ●     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Parameters          | Police Mode            | ●     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Parameters          | Alarm                  | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Parameters          | Climate Control        | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Module Installation | ABS                    | ●     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Module Installation | BEM                    | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Module Installation | HIM                    | ※     |
| Fairlane / LTD | 5.4L     | 3V         | 2006  | Programmable Module Installation | PAM                    | ●     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Personality            | ●     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Police Mode            | ●     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Alarm                  | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Parameters          | Climate Control        | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Module Installation | BEM                    | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Module Installation | HIM                    | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2003  | Programmable Module Installation | PAM                    | ●     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Personality            | ●     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Police Mode            | ●     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Alarm                  | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Parameters          | Climate Control        | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | ABS                    | ●     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | BEM                    | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | HIM                    | ※     |
| Fairmont       | 4.0L     | DOHC VCT   | 2006  | Programmable Module Installation | PAM                    | ●     |
| Fairmont       | 4.0L     | Other      | Other | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Fairmont       | 4.0L     | Other      | Other | Programmable Module Installation | IC                     | ●     |
| Fairmont       | 5.0L     | Other      | Other | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Fairmont       | 5.0L     | Other      | Other | Programmable Module Installation | IC                     | ●     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Parameters          | Personality            | ●     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Parameters          | Police Mode            | ●     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Parameters          | Alarm                  | ※     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Parameters          | Climate Control        | ※     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Module Installation | BEM                    | ※     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Module Installation | HIM                    | ※     |
| Fairmont       | 5.4L     | 3V         | 2003  | Programmable Module Installation | PAM                    | ●     |
| Fairmont       | 5.4L     | 3V         | 2006  | Programmable Parameters          | Personality            | ●     |

| Vehicle                           | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|-----------------------------------|----------|--|------|----------------------------------|------------------------|-------|
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Parameters          | Exterior Lighting      | ※     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Parameters          | Police Mode            | ●     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Parameters          | Alarm                  | ※     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Parameters          | Climate Control        | ※     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Module Installation | ABS                    | ●     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Module Installation | BEM                    | ※     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Module Installation | HIM                    | ※     |
| Fairmont                          | 5.4L     | 3V   | 2006 | Programmable Module Installation | PAM                    | ●     |
| Falcon                            | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Falcon                            | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | BEM                    | ●     |
| Falcon                            | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | HIM                    | ●     |
| Falcon                            | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | PAM                    | ●     |
| Falcon                            | 4.0L     | DOHC VCT                                     | 2011 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Falcon                            | 4.0L     | DOHC VCT                                     | 2011 | Programmable Module Installation | BEM                    | ●     |
| Falcon                            | 4.0L     | DOHC VCT                                     | 2011 | Programmable Module Installation | HIM                    | ●     |
| Falcon                            | 4.0L     | DOHC VCT                                     | 2011 | Programmable Module Installation | PAM                    | ●     |
| Falcon                            | 4.0L     | DOHC_VCT_LPG                                 | 2011 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Falcon                            | 4.0L     | DOHC_VCT_LPG                                 | 2011 | Programmable Module Installation | BEM                    | ●     |
| Falcon                            | 4.0L     | DOHC_VCT_LPG                                 | 2011 | Programmable Module Installation | HIM                    | ●     |
| Falcon                            | 4.0L     | DOHC_VCT_LPG                                 | 2011 | Programmable Module Installation | PAM                    | ●     |
| Falcon                            | 5.0L     | 4V   | 2011 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Falcon                            | 5.0L     | 4V   | 2011 | Programmable Module Installation | BEM                    | ●     |
| Falcon                            | 5.0L     | 4V   | 2011 | Programmable Module Installation | HIM                    | ●     |
| Falcon                            | 5.0L     | 4V   | 2011 | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Parameters          | Exterior Lighting      | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Parameters          | Alarm                  | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Parameters          | Climate Control        | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Module Installation | BEM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2003 | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2004 | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT                                     | 2004 | Programmable Parameters          | Exterior Lighting      | ●     |

| Vehicle                           | Capacity | EngineType   | Year  | Module Programming               | System                 | Flags |
|-----------------------------------|----------|--------------|-------|----------------------------------|------------------------|-------|
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2004  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2004  | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2004  | Programmable Module Installation | BEM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2004  | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2004  | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Parameters          | Exterior Lighting      | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Parameters          | Alarm                  | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Parameters          | Climate Control        | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Module Installation | ABS                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Module Installation | BEM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2006  | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Parameters          | Security               | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Parameters          | Body Type              | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Parameters          | Police Mode            | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Module Installation | ABS                    | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Module Installation | BEM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Module Installation | HIM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC VCT     | 2008  | Programmable Module Installation | RCM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Parameters          | Security               | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Parameters          | Body Type              | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Parameters          | Police Mode            | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Module Installation | ABS                    | ※     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Module Installation | BEM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Module Installation | HIM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | DOHC_VCT_LPG | 2008  | Programmable Module Installation | RCM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | Other        | Other | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Falcon Forte S / Futura / XR / XT | 4.0L     | Other        | Other | Programmable Module Installation | IC                     | ●     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Parameters          | Security               | ●     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Parameters          | Body Type              | ●     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Parameters          | Police Mode            | ※     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Module Installation | ABS                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Module Installation | BEM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Module Installation | HIM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | 4V           | 2010  | Programmable Module Installation | RCM                    | ●     |

| Vehicle                           | Capacity | EngineType | Year  | Module Programming               | System                 | Flags |
|-----------------------------------|----------|------------|-------|----------------------------------|------------------------|-------|
| Falcon Forte S / Futura / XR / XT | 5.0L     | Other      | Other | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Falcon Forte S / Futura / XR / XT | 5.0L     | Other      | Other | Programmable Module Installation | IC                     | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Parameters          | Exterior Lighting      | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Parameters          | Alarm                  | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Parameters          | Climate Control        | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Module Installation | BEM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2003  | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Parameters          | Exterior Lighting      | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Parameters          | Alarm                  | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Parameters          | Climate Control        | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Module Installation | ABS                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Module Installation | BEM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 3V         | 2006  | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Parameters          | Exterior Lighting      | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Parameters          | Alarm                  | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Parameters          | Climate Control        | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Module Installation | BEM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2003  | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2004  | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2004  | Programmable Parameters          | Exterior Lighting      | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2004  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2004  | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2004  | Programmable Module Installation | BEM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2004  | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2004  | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2006  | Programmable Parameters          | Personality            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2006  | Programmable Parameters          | Exterior Lighting      | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2006  | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2006  | Programmable Parameters          | Police Mode            | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2006  | Programmable Parameters          | Alarm                  | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V         | 2006  | Programmable Parameters          | Climate Control        | ※     |

| Vehicle                           | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|-----------------------------------|----------|--|------|----------------------------------|------------------------|-------|
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2006 | Programmable Module Installation | ABS                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2006 | Programmable Module Installation | BEM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2006 | Programmable Module Installation | HIM                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2006 | Programmable Module Installation | PAM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Parameters          | Security               | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Parameters          | Body Type              | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Parameters          | Police Mode            | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Module Installation | ABS                    | ※     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Module Installation | BEM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Module Installation | HIM                    | ●     |
| Falcon Forte S / Futura / XR / XT | 5.4L     | 4V   | 2008 | Programmable Module Installation | RCM                    | ●     |
| Fiesta                            | 1.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2015 | Programmable Parameters          | Power Door Locks       | ●     |
| Fiesta                            | 1.25L    | DURATEC 16V                                  | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Fiesta                            | 1.25L    | DURATEC 16V                                  | 2002 | Programmable Module Installation | GEM                    | ●     |
| Fiesta                            | 1.25L    | DURATEC 16V                                  | 2002 | Programmable Module Installation | IC                     | ●     |
| Fiesta                            | 1.25L    | DURATEC 16V                                  | 2006 | Programmable Module Installation | ACM                    | ●     |
| Fiesta                            | 1.25L    | DURATEC 16V                                  | 2006 | Programmable Module Installation | IC                     | ※     |
| Fiesta                            | 1.3L     | DURATEC 8V                                   | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Fiesta                            | 1.3L     | DURATEC 8V                                   | 2002 | Programmable Module Installation | GEM                    | ●     |
| Fiesta                            | 1.3L     | DURATEC 8V                                   | 2002 | Programmable Module Installation | IC                     | ●     |
| Fiesta                            | 1.3L     | DURATEC 8V                                   | 2006 | Programmable Module Installation | ACM                    | ●     |
| Fiesta                            | 1.3L     | DURATEC 8V                                   | 2006 | Programmable Module Installation | IC                     | ※     |
| Fiesta                            | 1.4L     | DURATEC 16V                                  | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Fiesta                            | 1.4L     | DURATEC 16V                                  | 2002 | Programmable Module Installation | GEM                    | ●     |
| Fiesta                            | 1.4L     | DURATEC 16V                                  | 2002 | Programmable Module Installation | IC                     | ●     |
| Fiesta                            | 1.4L     | DURATEC 16V                                  | 2006 | Programmable Module Installation | ACM                    | ●     |
| Fiesta                            | 1.4L     | DURATEC 16V                                  | 2006 | Programmable Module Installation | IC                     | ※     |
| Fiesta                            | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection  | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Fiesta                            | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection  | 2002 | Programmable Module Installation | GEM                    | ●     |
| Fiesta                            | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection  | 2002 | Programmable Module Installation | IC                     | ●     |
| Fiesta                            | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection  | 2006 | Programmable Module Installation | ACM                    | ●     |
| Fiesta                            | 1.4L     | Duratorq-Turbo Diesel Common Rail Injection  | 2006 | Programmable Module Installation | IC                     | ※     |
| Fiesta                            | 1.6L     | DURATEC 16V                                  | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Fiesta                            | 1.6L     | DURATEC 16V                                  | 2002 | Programmable Module Installation | GEM                    | ●     |
| Fiesta                            | 1.6L     | DURATEC 16V                                  | 2002 | Programmable Module Installation | IC                     | ●     |



| Vehicle       | Capacity | EngineType   | Year    | Module Programming               | System                          | Flags |
|---------------|----------|--|---------|----------------------------------|---------------------------------|-------|
| Fiesta        | 1.6L     | DURATEC 16V  | 2006    | Programmable Module Installation | ACM                             | ●     |
| Fiesta        | 1.6L     | DURATEC 16V  | 2006    | Programmable Module Installation | IC                              | ※     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2002    | Programmable Parameters          | Personality                     | ●     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2002    | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2002    | Programmable Module Installation | EPS                             | ●     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2002    | Programmable Module Installation | GEM                             | ●     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2002    | Programmable Module Installation | IC                              | ●     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2006    | Programmable Module Installation | ACM                             | ●     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2006    | Programmable Module Installation | EPS                             | ●     |
| Fiesta        | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2006    | Programmable Module Installation | IC                              | ※     |
| Fiesta        | 1.6L     | EcoBoost - Gas<br>Turbocharged Direct<br>Injection | 2015    | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta        | 1.6L     | Sigma  | 2012    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fiesta        | 1.6L     | Sigma  | 2012    | Programmable Module Installation | TBM                             | ●     |
| Fiesta        | 1.6L     | Sigma  | 2012    | Programmable Module Installation | VSM                             | ●     |
| Fiesta        | 1.6L     | TiVCT  | 2011    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fiesta        | 1.6L     | TiVCT  | 2011    | Programmable Module Installation | VSM                             | ●     |
| Fiesta        | 1.6L     | TiVCT  | 2012    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fiesta        | 1.6L     | TiVCT  | 2012    | Programmable Module Installation | VSM                             | ●     |
| Fiesta        | 1.6L     | TiVCT  | 2013    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fiesta        | 1.6L     | TiVCT  | 2013    | Programmable Module Installation | VSM                             | ●     |
| Fiesta        | 1.6L     | TiVCT  | 2015    | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta / Ikon | 1.4 DV4  | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2006.25 | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta / Ikon | 1.4 DV4  | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2006.25 | Programmable Module Installation | GEM                             | ●     |
| Fiesta / Ikon | 1.4 DV4  | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2006.25 | Programmable Module Installation | IC                              | ※     |
| Fiesta / Ikon | 1.4 DV4  | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2006.25 | Programmable Module Installation | RCM                             | ●     |
| Fiesta / Ikon | 1.4L     | DURATEC 16V  | 2006.25 | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta / Ikon | 1.4L     | DURATEC 16V  | 2006.25 | Programmable Module Installation | GEM                             | ●     |
| Fiesta / Ikon | 1.4L     | DURATEC 16V  | 2006.25 | Programmable Module Installation | IC                              | ※     |
| Fiesta / Ikon | 1.4L     | DURATEC 16V  | 2006.25 | Programmable Module Installation | RCM                             | ●     |
| Fiesta / Ikon | 1.6L     | DURATEC 16V  | 2006.25 | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta / Ikon | 1.6L     | DURATEC 16V  | 2006.25 | Programmable Module Installation | GEM                             | ●     |
| Fiesta / Ikon | 1.6L     | DURATEC 16V  | 2006.25 | Programmable Module Installation | IC                              | ※     |

| Vehicle                     | Capacity | EngineType                                     | Year    | Module Programming               | System           | Flags |
|-----------------------------|----------|--|---------|----------------------------------|------------------|-------|
| Fiesta / Ikon               | 1.6L     | DURATEC 16V                                    | 2006.25 | Programmable Module Installation | RCM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.0L     | Zetec Rocam                                    | 1999.75 | Programmable Module Installation | GEM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE                                       | 1999.5  | Programmable Module Installation | GEM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.25L    | Zetec-SE                                       | 2000    | Programmable Module Installation | GEM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.3L     | Endura-E                                       | 1999.5  | Programmable Module Installation | GEM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.4L     | Zetec-SE                                       | 1999.5  | Programmable Module Installation | GEM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec Rocam                                    | 1999.75 | Programmable Module Installation | GEM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.6L     | Zetec-SE                                       | 2000    | Programmable Module Installation | GEM              | ●     |
| Fiesta / Mazda 121 / Bantam | 1.8L     | Endura DI                                      | 2000    | Programmable Module Installation | GEM              | ●     |
| Fiesta 3-door               | 1.25L    | DURATEC 16V                                    | 2002    | Programmable Parameters          | Personality      | ●     |
| Fiesta 3-door               | 1.25L    | DURATEC 16V                                    | 2002    | Programmable Parameters          | Power Door Locks | ●     |
| Fiesta 3-door               | 1.25L    | DURATEC 16V                                    | 2002    | Programmable Module Installation | GEM              | ●     |
| Fiesta 3-door               | 1.25L    | DURATEC 16V                                    | 2002    | Programmable Module Installation | IC               | ●     |
| Fiesta 3-door               | 1.25L    | DURATEC 16V                                    | 2006    | Programmable Module Installation | ACM              | ●     |
| Fiesta 3-door               | 1.25L    | DURATEC 16V                                    | 2006    | Programmable Module Installation | IC               | ※     |
| Fiesta 3-door               | 1.3L     | DURATEC 8V                                     | 2002    | Programmable Parameters          | Personality      | ●     |
| Fiesta 3-door               | 1.3L     | DURATEC 8V                                     | 2002    | Programmable Parameters          | Power Door Locks | ●     |
| Fiesta 3-door               | 1.3L     | DURATEC 8V                                     | 2002    | Programmable Module Installation | GEM              | ●     |
| Fiesta 3-door               | 1.3L     | DURATEC 8V                                     | 2002    | Programmable Module Installation | IC               | ●     |
| Fiesta 3-door               | 1.3L     | DURATEC 8V                                     | 2006    | Programmable Module Installation | ACM              | ●     |
| Fiesta 3-door               | 1.3L     | DURATEC 8V                                     | 2006    | Programmable Module Installation | IC               | ※     |
| Fiesta 3-door               | 1.4L     | DURATEC 16V                                    | 2002    | Programmable Parameters          | Personality      | ●     |
| Fiesta 3-door               | 1.4L     | DURATEC 16V                                    | 2002    | Programmable Parameters          | Power Door Locks | ●     |
| Fiesta 3-door               | 1.4L     | DURATEC 16V                                    | 2002    | Programmable Module Installation | GEM              | ●     |
| Fiesta 3-door               | 1.4L     | DURATEC 16V                                    | 2002    | Programmable Module Installation | IC               | ●     |
| Fiesta 3-door               | 1.4L     | DURATEC 16V                                    | 2006    | Programmable Module Installation | ACM              | ●     |
| Fiesta 3-door               | 1.4L     | DURATEC 16V                                    | 2006    | Programmable Module Installation | IC               | ※     |
| Fiesta 3-door               | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Personality      | ●     |
| Fiesta 3-door               | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Power Door Locks | ●     |
| Fiesta 3-door               | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | GEM              | ●     |
| Fiesta 3-door               | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | IC               | ●     |
| Fiesta 3-door               | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006    | Programmable Module Installation | ACM              | ●     |
| Fiesta 3-door               | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006    | Programmable Module Installation | IC               | ※     |
| Fiesta 3-door               | 1.6L     | DURATEC 16V                                    | 2002    | Programmable Parameters          | Personality      | ●     |
| Fiesta 3-door               | 1.6L     | DURATEC 16V                                    | 2002    | Programmable Parameters          | Power Door Locks | ●     |
| Fiesta 3-door               | 1.6L     | DURATEC 16V                                    | 2002    | Programmable Module Installation | GEM              | ●     |
| Fiesta 3-door               | 1.6L     | DURATEC 16V                                    | 2002    | Programmable Module Installation | IC               | ●     |

| Vehicle       | Capacity | EngineType                                     | Year    | Module Programming               | System                          | Flags |
|---------------|----------|--|---------|----------------------------------|---------------------------------|-------|
| Fiesta 3-door | 1.6L     | DURATEC 16V                                    | 2006    | Programmable Module Installation | ACM                             | ●     |
| Fiesta 3-door | 1.6L     | DURATEC 16V                                    | 2006    | Programmable Module Installation | IC                              | ※     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Personality                     | ●     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | EPS                             | ●     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | GEM                             | ●     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | IC                              | ●     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006    | Programmable Module Installation | ACM                             | ●     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006    | Programmable Module Installation | EPS                             | ●     |
| Fiesta 3-door | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006    | Programmable Module Installation | IC                              | ※     |
| Fiesta 3-door | 2.0L     | DURATEC-HE / I4                                | 2002    | Programmable Parameters          | Personality                     | ●     |
| Fiesta 3-door | 2.0L     | DURATEC-HE / I4                                | 2002    | Programmable Parameters          | Power Door Locks                | ●     |
| Fiesta 3-door | 2.0L     | DURATEC-HE / I4                                | 2002    | Programmable Module Installation | GEM                             | ●     |
| Fiesta 3-door | 2.0L     | DURATEC-HE / I4                                | 2002    | Programmable Module Installation | IC                              | ●     |
| Fiesta 3-door | 2.0L     | DURATEC-HE / I4                                | 2006    | Programmable Module Installation | ACM                             | ●     |
| Fiesta 3-door | 2.0L     | DURATEC-HE / I4                                | 2006    | Programmable Module Installation | IC                              | ※     |
| Fiesta MY2013 | 1.5L     | Zetec-SE                                       | 2013.25 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fiesta MY2013 | 1.5L     | Zetec-SE                                       | 2013.25 | Programmable Module Installation | TBM                             | ※     |
| Fiesta MY2013 | 1.6L     | TiVCT  | 2013.25 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fiesta MY2013 | 1.6L     | TiVCT  | 2013.25 | Programmable Module Installation | TBM                             | ※     |
| Fiesta SE     | 1.6L     | Sigma  | 2011    | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fiesta SE     | 1.6L     | Sigma  | 2011    | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fiesta SE     | 1.6L     | Sigma  | 2011    | Programmable Module Installation | TBM                             | ●     |
| Fiesta SE     | 1.6L     | Sigma  | 2011    | Programmable Module Installation | VSM                             | ●     |
| FIGO          | 1.19L    | DURATEC 16V                                    | 2010.25 | Programmable Module Installation | IC                              | ●     |
| FIGO          | 1.19L    | DURATEC 16V                                    | 2010.25 | Programmable Module Installation | RCM                             | ●     |
| FIGO          | 1.4 DV4  | Duratorq-Turbo Diesel<br>Common Rail Injection | 2010.25 | Programmable Module Installation | IC                              | ●     |
| FIGO          | 1.4 DV4  | Duratorq-Turbo Diesel<br>Common Rail Injection | 2010.25 | Programmable Module Installation | RCM                             | ●     |
| FIGO          | 1.4L     | DURATEC 16V                                    | 2010.25 | Programmable Module Installation | IC                              | ●     |
| FIGO          | 1.4L     | DURATEC 16V                                    | 2010.25 | Programmable Module Installation | RCM                             | ●     |
| FIGO          | 1.4L     | DURATEC 16V                                    | 2011.25 | Programmable Parameters          | Power Door Locks                | ●     |
| FIGO          | 1.4L     | DURATEC 16V                                    | 2011.25 | Programmable Module Installation | GEM                             | ●     |
| FIGO          | 1.4L     | DURATEC 16V                                    | 2011.25 | Programmable Module Installation | IC                              | ●     |
| FIGO          | 1.4L     | DURATEC 16V                                    | 2011.25 | Programmable Module Installation | RCM                             | ●     |
| FIGO          | 1.6L     | DURATEC 16V                                    | 2011.25 | Programmable Parameters          | Power Door Locks                | ●     |

| Vehicle                              | Capacity | EngineType  | Year    | Module Programming               | System                         | Flags |
|--------------------------------------|----------|-------------|---------|----------------------------------|--------------------------------|-------|
| FIGO                                 | 1.6L     | DURATEC 16V | 2011.25 | Programmable Module Installation | GEM                            | ●     |
| FIGO                                 | 1.6L     | DURATEC 16V | 2011.25 | Programmable Module Installation | IC                             | ●     |
| FIGO                                 | 1.6L     | DURATEC 16V | 2011.25 | Programmable Module Installation | RCM                            | ●     |
| FIGO                                 | Other    | DURATEC 16V | 2011.25 | Programmable Parameters          | Power Door Locks               | ●     |
| FIGO                                 | Other    | DURATEC 16V | 2011.25 | Programmable Module Installation | GEM                            | ●     |
| FIGO                                 | Other    | DURATEC 16V | 2011.25 | Programmable Module Installation | IC                             | ●     |
| FIGO                                 | Other    | DURATEC 16V | 2011.25 | Programmable Module Installation | RCM                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Parameters          | Personality                    | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Parameters          | Audio Configure                | ※     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Parameters          | Exterior Lighting              | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Parameters          | Power Door Locks               | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Module Installation | ABS                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Module Installation | ACM                            | ※     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Module Installation | DSM                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Module Installation | GEM                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2006    | Programmable Module Installation | IC                             | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Parameters          | Personality                    | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Parameters          | Audio Configure                | ※     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Parameters          | Exterior Lighting              | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Parameters          | Power Door Locks               | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Module Installation | ABS                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Module Installation | ACM                            | ※     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Module Installation | DSM                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Module Installation | GEM                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Module Installation | IC                             | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Module Installation | RCM                            | ●     |
| Five Hundred                         | 3.0L     | 4V          | 2007    | Programmable Module Installation | SDARS                          | ※     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Parameters          | Personality                    | ●     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Parameters          | Audio Configure                | ※     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Module Installation | ABS                            | ●     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Module Installation | ACM                            | ※     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Module Installation | DSM                            | ●     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Module Installation | IC                             | ●     |
| Five Hundred (MY05) / Montego (MY05) | 3.0L     | 4V          | 2005    | Programmable Module Installation | RCM                            | ●     |
| Flex                                 | 3.5L     | 4V          | 2009    | Programmable Parameters          | Personality                    | ●     |
| Flex                                 | 3.5L     | 4V          | 2009    | Programmable Parameters          | Power Seats                    | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|---------|----------|--|------|----------------------------------|------------------------|-------|
| Flex    | 3.5L     | 4V   | 2009 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Flex    | 3.5L     | 4V   | 2009 | Programmable Module Installation | ABS                    | ●     |
| Flex    | 3.5L     | 4V   | 2009 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | 4V   | 2009 | Programmable Module Installation | FDIM                   | ●     |
| Flex    | 3.5L     | 4V   | 2009 | Programmable Module Installation | IC                     | ●     |
| Flex    | 3.5L     | 4V   | 2009 | Programmable Module Installation | RCM                    | ●     |
| Flex    | 3.5L     | 4V   | 2009 | Programmable Module Installation | RETM                   | ※     |
| Flex    | 3.5L     | 4V   | 2010 | Programmable Parameters          | Personality            | ●     |
| Flex    | 3.5L     | 4V   | 2010 | Programmable Parameters          | Power Seats            | ●     |
| Flex    | 3.5L     | 4V   | 2010 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Flex    | 3.5L     | 4V   | 2010 | Programmable Module Installation | ACM                    | ※     |
| Flex    | 3.5L     | 4V   | 2010 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | 4V   | 2010 | Programmable Module Installation | FDIM                   | ●     |
| Flex    | 3.5L     | 4V   | 2010 | Programmable Module Installation | IC                     | ●     |
| Flex    | 3.5L     | 4V   | 2011 | Programmable Parameters          | Power Seats            | ●     |
| Flex    | 3.5L     | 4V   | 2011 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | 4V   | 2011 | Programmable Module Installation | FDIM                   | ●     |
| Flex    | 3.5L     | 4V   | 2012 | Programmable Parameters          | Personality            | ●     |
| Flex    | 3.5L     | 4V   | 2012 | Programmable Parameters          | Power Seats            | ●     |
| Flex    | 3.5L     | 4V   | 2012 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Flex    | 3.5L     | 4V   | 2012 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | 4V   | 2012 | Programmable Module Installation | FDIM                   | ●     |
| Flex    | 3.5L     | 4V   | 2012 | Programmable Module Installation | IC                     | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Personality            | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Power Seats            | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | ACM                    | ※     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | FDIM                   | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | IC                     | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|---------|----------|--|------|----------------------------------|------------------------|-------|
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Parameters          | Power Seats            | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | FDIM                   | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Personality            | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Power Seats            | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | FDIM                   | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | IC                     | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM                   | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DDM                    | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM                   | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DDM                    | ●     |
| Flex    | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DCSM                   | ●     |
| Flex    | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DDM                    | ●     |
| Flex    | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DSM                    | ●     |
| Flex    | 3.5L     | TiVCT  | 2014 | Programmable Module Installation | DCSM                   | ●     |

| Vehicle | Capacity | EngineType  | Year    | Module Programming               | System                        | Flags |
|---------|----------|-------------|---------|----------------------------------|-------------------------------|-------|
| Flex    | 3.5L     | TiVCT       | 2014    | Programmable Module Installation | DDM                           | ●     |
| Flex    | 3.5L     | TiVCT       | 2014    | Programmable Module Installation | DSM                           | ●     |
| Flex    | Other    | Other       | 2014    | Programmable Module Installation | DCSM                          | ●     |
| Flex    | Other    | Other       | 2014    | Programmable Module Installation | DDM                           | ●     |
| Flex    | Other    | Other       | 2014    | Programmable Module Installation | DSM                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | EATC                          | ※     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | CDP                           | ●     |

| Vehicle | Capacity | EngineType  | Year    | Module Programming               | System                 | Flags |
|---------|----------|-------------|---------|----------------------------------|------------------------|-------|
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | D_DCU                  | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GDM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GEM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | HCM                    | ※     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | IC                     | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RKE                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | NAV                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | PAM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | P_DCU                  | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RCM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RETM                   | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Parameters          | Module Reset           | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ABS                    | ※     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ACM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | EATC                   | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | CDP                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | CMR                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | D_DCU                  | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | GEM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | HCM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | PAM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | P_DCU                  | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | RCM                    | ●     |
| Focus   | 1.4L     | DURATEC 16V | 2008.25 | Programmable Module Installation | RETM                   | ●     |
| Focus   | 1.4L     | Zetec-SE    | 1999    | Programmable Module Installation | CTM                    | ●     |
| Focus   | 1.4L     | Zetec-SE    | 1999    | Programmable Module Installation | HEC                    | ●     |
| Focus   | 1.4L     | Zetec-SE    | 1999    | Programmable Module Installation | ECS                    | ●     |
| Focus   | 1.4L     | Zetec-SE    | 2002    | Programmable Parameters          | Washer / Wiper         | ●     |
| Focus   | 1.4L     | Zetec-SE    | 2002    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Focus   | 1.4L     | Zetec-SE    | 2002    | Programmable Parameters          | Power Door Locks       | ●     |
| Focus   | 1.4L     | Zetec-SE    | 2002    | Programmable Parameters          | Security               | ●     |
| Focus   | 1.4L     | Zetec-SE    | 2002    | Programmable Module Installation | GEM                    | ●     |
| Focus   | 1.4L     | Zetec-SE    | 2002    | Programmable Module Installation | HEC                    | ●     |
| Focus   | 1.4L     | Zetec-SE    | 2002    | Programmable Module Installation | ECS                    | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Module Reset           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Personality            | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Washer / Wiper         | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Power Door Locks       | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Security               | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Navigation System      | ●     |



| Vehicle | Capacity | EngineType  | Year    | Module Programming               | System                        | Flags |
|---------|----------|-------------|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | EATC                          | ※     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |

| Vehicle | Capacity | EngineType  | Year    | Module Programming               | System                        | Flags |
|---------|----------|-------------|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | EATC                          | ※     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |

| Vehicle | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|---------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Security                      | ●     |

| Vehicle | Capacity | EngineType                                  | Year    | Module Programming               | System                        | Flags |
|---------|----------|---|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | EATC                          | ※     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | FACM                          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Security                      | ●     |

| Vehicle | Capacity | EngineType                                  | Year    | Module Programming               | System                        | Flags |
|---------|----------|---|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | FACM                          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |

| Vehicle | Capacity | EngineType   | Year    | Module Programming               | System       | Flags |
|---------|----------|--|---------|----------------------------------|--------------|-------|
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.25 | Programmable Module Installation | FACM         | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.25 | Programmable Module Installation | GEM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.25 | Programmable Module Installation | HCM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.25 | Programmable Module Installation | PAM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.25 | Programmable Module Installation | P_DCU        | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.25 | Programmable Module Installation | RCM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.25 | Programmable Module Installation | RETM         | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Parameters          | Module Reset | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | ABS          | ※     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | ACM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | EATC         | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | CDP          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | CMR          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | D_DCU        | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | GEM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | HCM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | PAM          | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | P_DCU        | ●     |
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | RCM          | ●     |

| Vehicle | Capacity | EngineType   | Year    | Module Programming               | System                       | Flags |
|---------|----------|--|---------|----------------------------------|------------------------------|-------|
| Focus   | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.25 | Programmable Module Installation | RETM                         | ●     |
| Focus   | 1.6L     | FFV  | 2007    | Programmable Parameters          | Washer / Wiper               | ●     |
| Focus   | 1.6L     | FFV  | 2007    | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Focus   | 1.6L     | FFV  | 2007    | Programmable Parameters          | Power Door Locks             | ●     |
| Focus   | 1.6L     | FFV  | 2007    | Programmable Parameters          | Security                     | ●     |
| Focus   | 1.6L     | FFV  | 2007    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 1.6L     | FFV  | 2007    | Programmable Module Installation | IC                           | ●     |
| Focus   | 1.6L     | FFV  | 2007    | Programmable Module Installation | RCM                          | ●     |
| Focus   | 1.6L     | FFV  | 2009    | Programmable Parameters          | Washer / Wiper               | ●     |
| Focus   | 1.6L     | FFV  | 2009    | Programmable Parameters          | Power Door Locks             | ●     |
| Focus   | 1.6L     | FFV  | 2009    | Programmable Parameters          | Security                     | ●     |
| Focus   | 1.6L     | FFV  | 2009    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 1.6L     | FFV  | 2009    | Programmable Module Installation | RCM                          | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Parameters          | Module Reset                 | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | ABS                          | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | EATC                         | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | D_DCU                        | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | HCM                          | ※     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | RKE                          | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | PAM                          | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | P_DCU                        | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | RCM                          | ●     |
| Focus   | 1.6L     | FFV  | 2010    | Programmable Module Installation | TBM                          | ●     |
| Focus   | 1.6L     | OHC  | 2009    | Programmable Parameters          | Washer / Wiper               | ●     |
| Focus   | 1.6L     | OHC  | 2009    | Programmable Parameters          | Power Door Locks             | ●     |
| Focus   | 1.6L     | OHC  | 2009    | Programmable Parameters          | Security                     | ●     |
| Focus   | 1.6L     | OHC  | 2009    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 1.6L     | OHC  | 2009    | Programmable Module Installation | RCM                          | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Parameters          | Module Reset                 | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | ABS                          | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | EATC                         | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | D_DCU                        | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | HCM                          | ※     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | RKE                          | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | PAM                          | ●     |
| Focus   | 1.6L     | Sigma  | 2010    | Programmable Module Installation | P_DCU                        | ●     |

| Vehicle | Capacity | EngineType      | Year    | Module Programming               | System                        | Flags |
|---------|----------|-----------------|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.6L     | Sigma           | 2010    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.6L     | Sigma           | 2010    | Programmable Module Installation | TBM                           | ●     |
| Focus   | 1.6L     | Zetec           | 1999    | Programmable Module Installation | CTM                           | ●     |
| Focus   | 1.6L     | Zetec           | 1999    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.6L     | Zetec           | 1999    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.6L     | Zetec           | 2002    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | Zetec           | 2002    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | Zetec           | 2002    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.6L     | Zetec           | 2002    | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.6L     | Zetec           | 2002    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | Zetec           | 2002    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.6L     | Zetec           | 2002    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.6L     | Zetec Rocam     | 2002    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | Zetec Rocam     | 2002    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | Zetec Rocam     | 2002    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.6L     | Zetec Rocam     | 2002    | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.6L     | Zetec Rocam     | 2002    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | Zetec Rocam     | 2002    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.6L     | Zetec Rocam     | 2002    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.6L     | Zetec-SE        | 1999    | Programmable Module Installation | CTM                           | ●     |
| Focus   | 1.6L     | Zetec-SE        | 1999    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.6L     | Zetec-SE        | 1999    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.6L     | Zetec-SE        | 2002    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.6L     | Zetec-SE        | 2002    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.6L     | Zetec-SE        | 2002    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.6L     | Zetec-SE        | 2002    | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.6L     | Zetec-SE        | 2002    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.6L     | Zetec-SE        | 2002    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.6L     | Zetec-SE        | 2002    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | EATC                          | ※     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |



| Vehicle | Capacity | EngineType      | Year    | Module Programming               | System                        | Flags |
|---------|----------|-----------------|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | CMR                           | ●     |

| Vehicle | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|---------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2001.5  | Programmable Module Installation | CTM                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2001.5  | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2001.5  | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | HEC                           | ※     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002    | Programmable Module Installation | ECS                           | ※     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | EATC                          | ※     |

| Vehicle | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|---------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Power Steering                | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | ACM                           | ●     |

| Vehicle | Capacity | EngineType                                     | Year    | Module Programming               | System       | Flags |
|---------|----------|--|---------|----------------------------------|--------------|-------|
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | EATC         | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | CDP          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | D_DCU        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | GDM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | GEM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | HCM          | ※     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | IC           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RKE          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | NAV          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | PAM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | P_DCU        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RCM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RETM         | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Parameters          | Module Reset | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ABS          | ※     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ACM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | EATC         | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | CDP          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | CMR          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | D_DCU        | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | FACM         | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | GEM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | HCM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | PAM          | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | P_DCU        | ●     |

| Vehicle | Capacity | EngineType                                  | Year    | Module Programming               | System                        | Flags |
|---------|----------|---|---------|----------------------------------|-------------------------------|-------|
| Focus   | 1.8L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 1.8L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 1.8L     | Endura DI                                   | 1999    | Programmable Module Installation | CTM                           | ●     |
| Focus   | 1.8L     | Endura DI                                   | 1999    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.8L     | Endura DI                                   | 1999    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.8L     | Endura DI                                   | 2002    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.8L     | Endura DI                                   | 2002    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.8L     | Endura DI                                   | 2002    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.8L     | Endura DI                                   | 2002    | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.8L     | Endura DI                                   | 2002    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.8L     | Endura DI                                   | 2002    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.8L     | Endura DI                                   | 2002    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.8L     | Zetec                                       | 1999    | Programmable Module Installation | CTM                           | ●     |
| Focus   | 1.8L     | Zetec                                       | 1999    | Programmable Module Installation | HEC                           | ●     |
| Focus   | 1.8L     | Zetec                                       | 1999    | Programmable Module Installation | ECS                           | ●     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Parameters          | Security                      | ●     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Module Installation | AFCM                          | ●     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Module Installation | HEC                           | ※     |
| Focus   | 1.8L     | Zetec                                       | 2002    | Programmable Module Installation | ECS                           | ※     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Module Installation | MC                            | ●     |
| Focus   | 2.0L     | DURATEC 16V                                 | 2005.5  | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Security                      | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                             | 2003.25 | Programmable Module Installation | ABS                           | ●     |

| Vehicle | Capacity | EngineType      | Year    | Module Programming               | System                        | Flags |
|---------|----------|-----------------|---------|----------------------------------|-------------------------------|-------|
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | EATC                          | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2005    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2005    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | ABS                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | ABS                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | ABS                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |

| Vehicle | Capacity | EngineType      | Year    | Module Programming               | System                 | Flags |
|---------|----------|-----------------|---------|----------------------------------|------------------------|-------|
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | ABS                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | ACM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | EATC                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | CDP                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | D_DCU                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | GDM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | HCM                    | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | IC                     | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | RKE                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | NAV                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | PAM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | P_DCU                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2007.5  | Programmable Module Installation | RETM                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008    | Programmable Parameters          | Personality            | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008    | Programmable Parameters          | Audio Configure        | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008    | Programmable Module Installation | ACM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008    | Programmable Module Installation | FDIM                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008    | Programmable Module Installation | IC                     | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008    | Programmable Module Installation | SDARS                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Parameters          | Module Reset           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | ABS                    | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | ACM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | EATC                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | CDP                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | CMR                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | D_DCU                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | HCM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | PAM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | P_DCU                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2008.25 | Programmable Module Installation | RETM                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2009    | Programmable Parameters          | Personality            | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2009    | Programmable Parameters          | Audio Configure        | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2009    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2009    | Programmable Module Installation | ABS                    | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2009    | Programmable Module Installation | ACM                    | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2009    | Programmable Module Installation | FDIM                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4 | 2009    | Programmable Module Installation | IC                     | ●     |

| Vehicle | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|---------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2009    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Parameters          | Tracking And Blocking Module  | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Parameters          | Personality                   | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Parameters          | Audio Configure               | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Parameters          | Warning Lamps / Chimes        | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | ABS                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | EATC                          | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | HCM                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | RKE                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | PAM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | TBM                           | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | ACM                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | FDIM                          | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2010    | Programmable Module Installation | IC                            | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Parameters          | Personality                   | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Parameters          | Audio Configure               | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Module Installation | ABS                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Module Installation | ACM                           | ※     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Module Installation | FDIM                          | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.0L     | DURATEC-HE / I4                                | 2011    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Security                      | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |



| Vehicle | Capacity | EngineType                                  | Year    | Module Programming               | System                        | Flags |
|---------|----------|---|---------|----------------------------------|-------------------------------|-------|
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | EATC                          | ※     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | FACM                          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |

| Vehicle | Capacity | EngineType                                     | Year    | Module Programming               | System       | Flags |
|---------|----------|--|---------|----------------------------------|--------------|-------|
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | ABS          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | ACM          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | EATC         | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | CDP          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | D_DCU        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | FACM         | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | GDM          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | GEM          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | HCM          | ※     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | IC           | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RKE          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | NAV          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | PAM          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | P_DCU        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RCM          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RETM         | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Parameters          | Module Reset | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ABS          | ※     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ACM          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | EATC         | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | CDP          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | CMR          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | D_DCU        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | FACM         | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | GEM          | ●     |

| Vehicle | Capacity | EngineType                                  | Year    | Module Programming               | System                       | Flags |
|---------|----------|---|---------|----------------------------------|------------------------------|-------|
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | HCM                          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | PAM                          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | P_DCU                        | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | RCM                          | ●     |
| Focus   | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | RETM                         | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Parameters          | Module Reset                 | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | ABS                          | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | EATC                         | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | D_DCU                        | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | HCM                          | ※     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | RKE                          | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | PAM                          | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | P_DCU                        | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | RCM                          | ●     |
| Focus   | 2.0L     | FFV   | 2010    | Programmable Module Installation | TBM                          | ●     |
| Focus   | 2.0L     | SPI   | 2000    | Programmable Module Installation | CTM                          | ●     |
| Focus   | 2.0L     | SPI   | 2000    | Programmable Module Installation | HEC                          | ●     |
| Focus   | 2.0L     | SPI   | 2000    | Programmable Module Installation | ECS                          | ●     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Parameters          | Washer / Wiper               | ●     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Parameters          | Power Door Locks             | ●     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Parameters          | Security                     | ●     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Module Installation | HEC                          | ※     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Module Installation | ECS                          | ※     |
| Focus   | 2.0L     | SPI   | 2002    | Programmable Module Installation | RCM                          | ※     |
| Focus   | 2.0L     | SPI   | 2003    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 2.0L     | SPI   | 2003    | Programmable Module Installation | HEC                          | ●     |
| Focus   | 2.0L     | SPI   | 2003    | Programmable Module Installation | RCM                          | ●     |
| Focus   | 2.0L     | SPI   | 2004    | Programmable Parameters          | Personality                  | ●     |
| Focus   | 2.0L     | SPI   | 2004    | Programmable Module Installation | GEM                          | ●     |
| Focus   | 2.0L     | SPI   | 2004    | Programmable Module Installation | HEC                          | ●     |
| Focus   | 2.0L     | SPI   | 2004    | Programmable Module Installation | RCM                          | ●     |
| Focus   | 2.0L     | Zetec                                       | 1999    | Programmable Module Installation | CTM                          | ●     |
| Focus   | 2.0L     | Zetec                                       | 1999    | Programmable Module Installation | HEC                          | ●     |
| Focus   | 2.0L     | Zetec                                       | 1999    | Programmable Module Installation | ECS                          | ●     |

| Vehicle | Capacity | EngineType      | Year   | Module Programming               | System                 | Flags |
|---------|----------|-----------------|--------|----------------------------------|------------------------|-------|
| Focus   | 2.0L     | Zetec           | 2000   | Programmable Module Installation | CTM                    | ●     |
| Focus   | 2.0L     | Zetec           | 2000   | Programmable Module Installation | HEC                    | ●     |
| Focus   | 2.0L     | Zetec           | 2000   | Programmable Module Installation | ECS                    | ●     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Parameters          | Washer / Wiper         | ●     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Parameters          | Power Door Locks       | ●     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Parameters          | Security               | ●     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Module Installation | HEC                    | ※     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Module Installation | ECS                    | ※     |
| Focus   | 2.0L     | Zetec           | 2002   | Programmable Module Installation | RCM                    | ※     |
| Focus   | 2.0L     | Zetec           | 2003   | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | Zetec           | 2003   | Programmable Module Installation | HEC                    | ●     |
| Focus   | 2.0L     | Zetec           | 2003   | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.0L     | Zetec           | 2004   | Programmable Parameters          | Personality            | ●     |
| Focus   | 2.0L     | Zetec           | 2004   | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | Zetec           | 2004   | Programmable Module Installation | HEC                    | ●     |
| Focus   | 2.0L     | Zetec           | 2004   | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Parameters          | Washer / Wiper         | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Parameters          | Power Door Locks       | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Parameters          | Security               | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Module Installation | HEC                    | ※     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Module Installation | MC                     | ※     |
| Focus   | 2.0L     | ZETEC ST        | 2002   | Programmable Module Installation | ECS                    | ※     |
| Focus   | 2.0L     | ZETEC ST        | 2003   | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2003   | Programmable Module Installation | HEC                    | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2003   | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2004   | Programmable Parameters          | Personality            | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2004   | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2004   | Programmable Module Installation | HEC                    | ●     |
| Focus   | 2.0L     | ZETEC ST        | 2004   | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003.5 | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003.5 | Programmable Module Installation | IC                     | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2003.5 | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2004   | Programmable Parameters          | Personality            | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2004   | Programmable Module Installation | GEM                    | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2004   | Programmable Module Installation | IC                     | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2004   | Programmable Module Installation | RCM                    | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2005   | Programmable Parameters          | Washer / Wiper         | ●     |

| Vehicle | Capacity | EngineType      | Year    | Module Programming               | System                        | Flags |
|---------|----------|-----------------|---------|----------------------------------|-------------------------------|-------|
| Focus   | 2.3L     | DURATEC-HE / I4 | 2005    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | ABS                           | ※     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2005    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2006    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | ABS                           | ※     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2006    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2007    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | ABS                           | ※     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.3L     | DURATEC-HE / I4 | 2007    | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | MC                            | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.5L     | Duratec RS      | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Personality                   | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Security                      | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Module Installation | ABS                           | ●     |
| Focus   | 2.5L     | I5              | 2003.25 | Programmable Module Installation | EATC                          | ※     |

| Vehicle | Capacity | EngineType | Year    | Module Programming               | System                        | Flags |
|---------|----------|------------|---------|----------------------------------|-------------------------------|-------|
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | CDP                           | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | GDM                           | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | HCM                           | ※     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | RKE                           | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | MC                            | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | NAV                           | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | PAM                           | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.5L     | I5         | 2003.25 | Programmable Module Installation | RETM                          | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | HCM                           | ※     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | MC                            | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus   | 2.5L     | I5         | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus   | 2.5L     | I5         | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus   | 2.5L     | I5         | 2008.25 | Programmable Module Installation | ABS                           | ※     |

| Vehicle         | Capacity | EngineType  | Year    | Module Programming               | System                        | Flags |
|-----------------|----------|-------------|---------|----------------------------------|-------------------------------|-------|
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | MC                            | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus           | 2.5L     | I5          | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Parameters          | Personality                   | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Parameters          | Security                      | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | ABS                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | ACM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | EATC                          | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | CDP                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | GDM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | GEM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | HCM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | IC                            | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | NAV                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | PAM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | RCM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2006.75 | Programmable Module Installation | SRM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus Cabriolet | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | RCM                           | ●     |

| Vehicle         | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-----------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus Cabriolet | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Parameters          | Personality                   | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Parameters          | Security                      | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | ABS                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | ACM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | EATC                          | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | CDP                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | GDM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | GEM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | HCM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | IC                            | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | NAV                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | PAM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | RCM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2006.75 | Programmable Module Installation | SRM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Parameters          | Personality                   | ●     |



| Vehicle         | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-----------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Parameters          | Security                      | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | ABS                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | ACM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | EATC                          | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | CDP                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | FACM                          | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | GDM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | GEM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | HCM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | IC                            | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | NAV                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | PAM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | RCM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.75 | Programmable Module Installation | SRM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | FACM                          | ●     |

| Vehicle         | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-----------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus Cabriolet | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | EATC                          | ※     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2002.75 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX     | 1.4L     | DURATEC 16V                                    | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |

| Vehicle     | Capacity | EngineType  | Year    | Module Programming               | System                        | Flags |
|-------------|----------|-------------|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.4L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | EATC                          | ※     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2002.75 | Programmable Module Installation | RETM                          | ●     |

| Vehicle     | Capacity | EngineType  | Year    | Module Programming               | System                        | Flags |
|-------------|----------|-------------|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC 16V | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |

| Vehicle     | Capacity | EngineType  | Year    | Module Programming               | System                        | Flags |
|-------------|----------|-------------|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | EATC                          | ※     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2002.75 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT | 2007.5  | Programmable Module Installation | NAV                           | ●     |

| Vehicle     | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.6L     | DURATEC VCT                                    | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | EATC                          | ※     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | EPB                           | ●     |

| Vehicle     | Capacity | EngineType                                  | Year    | Module Programming               | System                        | Flags |
|-------------|----------|---|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | FACM                          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |

| Vehicle     | Capacity | EngineType                                  | Year    | Module Programming               | System       | Flags |
|-------------|----------|---|---------|----------------------------------|--------------|-------|
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | EPB          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | FACM         | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | GDM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | GEM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | HCM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | IC           | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RKE          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | NAV          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | PAM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | P_DCU        | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RCM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RETM         | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Parameters          | Module Reset | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | ABS          | ※     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | ACM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | EATC         | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | CDP          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | CMR          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | D_DCU        | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | FACM         | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | GEM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | HCM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | PAM          | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | P_DCU        | ●     |
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | RCM          | ●     |



| Vehicle     | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | EATC                          | ※     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | GDM                           | ●     |

| Vehicle     | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.8L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | EATC                          | ※     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | CDP                           | ●     |

| Vehicle     | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | EATC                          | ●     |

| Vehicle     | Capacity | EngineType                                     | Year    | Module Programming               | System       | Flags |
|-------------|----------|--|---------|----------------------------------|--------------|-------|
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | CDP          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | D_DCU        | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | EPB          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | GDM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | GEM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | HCM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | IC           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RKE          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | NAV          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | PAM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | P_DCU        | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RCM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.5  | Programmable Module Installation | RETM         | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Parameters          | Module Reset | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ABS          | ※     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | ACM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | EATC         | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | CDP          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | CMR          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | D_DCU        | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | FACM         | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | GEM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | HCM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | PAM          | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | P_DCU        | ●     |

| Vehicle     | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | EATC                          | ※     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2002.75 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | D_DCU                         | ●     |

| Vehicle     | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|-------------|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2007.5  | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | ABS                           | ※     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | ACM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | EATC                          | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | CMR                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 2.0L     | DURATEC-HE / I4                                | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | ABS                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.75 | Programmable Module Installation | EATC                          | ※     |

| Vehicle     | Capacity | EngineType                                  | Year    | Module Programming               | System                        | Flags |
|-------------|----------|---|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | CDP                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | D_DCU                         | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | EPB                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | FACM                          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | GDM                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | GEM                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | IC                            | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RKE                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | NAV                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2002.75 | Programmable Module Installation | RETM                          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Module Reset                  | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Personality                   | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Power Door Locks              | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Security                      | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Navigation System             | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | ABS                           | ●     |

| Vehicle     | Capacity | EngineType                                  | Year    | Module Programming               | System       | Flags |
|-------------|----------|---|---------|----------------------------------|--------------|-------|
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | ACM          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | EATC         | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | CDP          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | D_DCU        | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | EPB          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | FACM         | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | GDM          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | GEM          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | HCM          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | IC           | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RKE          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | NAV          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | PAM          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | P_DCU        | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RCM          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2007.5  | Programmable Module Installation | RETM         | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Parameters          | Module Reset | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | ABS          | ※     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | ACM          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | EATC         | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | CDP          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | CMR          | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | D_DCU        | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | FACM         | ●     |
| Focus C-MAX | 2.0L     | Duratorq-Turbo Diesel Common Rail Injection | 2008.25 | Programmable Module Installation | GEM          | ●     |



| Vehicle                                 | Capacity | EngineType                                     | Year    | Module Programming               | System                        | Flags |
|---|----------|--|---------|----------------------------------|-------------------------------|-------|
| Focus C-MAX                             | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | HCM                           | ●     |
| Focus C-MAX                             | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | PAM                           | ●     |
| Focus C-MAX                             | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | P_DCU                         | ●     |
| Focus C-MAX                             | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | RCM                           | ●     |
| Focus C-MAX                             | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008.25 | Programmable Module Installation | RETM                          | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Parameters          | Module Reset                  | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Parameters          | Personality                   | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Parameters          | Navigation System             | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | ABS                           | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | EATC                          | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | D_DCU                         | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | RL_DCU                        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | GEM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | HCM                           | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | IC                            | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | PAM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | P_DCU                         | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | RR_DCU                        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.6L     | BZ   | 2005    | Programmable Module Installation | RCM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Parameters          | Module Reset                  | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Parameters          | Personality                   | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Parameters          | Power Door Locks              | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Parameters          | Navigation System             | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | ABS                           | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | EATC                          | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | D_DCU                         | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | RL_DCU                        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | EPS                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | GEM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | HCM                           | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005    | Programmable Module Installation | IC                            | ●     |

| Vehicle                                 | Capacity | EngineType                                     | Year | Module Programming               | System                        | Flags |
|---|----------|--|------|----------------------------------|-------------------------------|-------|
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | PAM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | P_DCU                         | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 1.8L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | RCM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Parameters          | Module Reset                  | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Parameters          | Personality                   | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Parameters          | Navigation System             | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | ABS                           | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | EATC                          | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | D_DCU                         | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | RL_DCU                        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | EPS                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | GEM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | HCM                           | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | IC                            | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | PAM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | P_DCU                         | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | RR_DCU                        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | DURATEC-HE / I4                                | 2005 | Programmable Module Installation | RCM                           | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Parameters          | Module Reset                  | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Parameters          | Personality                   | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Parameters          | Washer / Wiper                | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Parameters          | Power Door Locks              | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Parameters          | Navigation System             | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | ABS                           | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | EATC                          | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | D_DCU                         | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | RL_DCU                        | ●     |

| Vehicle                                 | Capacity | EngineType                                     | Year | Module Programming               | System                 | Flags |
|---|----------|--|------|----------------------------------|------------------------|-------|
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | EPS                    | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | FACM                   | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | GEM                    | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | HCM                    | ※     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | IC                     | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | PAM                    | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | P_DCU                  | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | RR_DCU                 | ●     |
| Focus VIN = LFA / LVS / AFA / PE1 / FFJ | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2005 | Programmable Module Installation | RCM                    | ●     |
| Ford GT                                 | 5.4L     | 4V   | 2006 | Programmable Parameters          | Exterior Lighting      | ※     |
| Ford GT                                 | 5.4L     | 4V   | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Ford GT                                 | 5.4L     | 4V   | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| Ford GT                                 | 5.4L     | 4V   | 2006 | Programmable Module Installation | GEM                    | ※     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2004 | Programmable Parameters          | Exterior Lighting      | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2004 | Programmable Module Installation | DSM                    | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2004 | Programmable Module Installation | GEM                    | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2004 | Programmable Module Installation | IC                     | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2005 | Programmable Parameters          | Personality            | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2005 | Programmable Parameters          | Exterior Lighting      | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2005 | Programmable Module Installation | ABS/TCS                | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2005 | Programmable Module Installation | DSM                    | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2005 | Programmable Module Installation | GEM                    | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2005 | Programmable Module Installation | IC                     | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2006 | Programmable Parameters          | Personality            | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2006 | Programmable Module Installation | DSM                    | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2006 | Programmable Module Installation | GEM                    | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2006 | Programmable Module Installation | IC                     | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2007 | Programmable Parameters          | Personality            | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2007 | Programmable Module Installation | DSM                    | ●     |
| Freestar / Monterey                     | 3.9L     | V6 OHV   | 2007 | Programmable Module Installation | GEM                    | ●     |

| Vehicle             | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Freestar / Monterey | 3.9L     | V6 OHV     | 2007 | Programmable Module Installation | IC                             | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2004 | Programmable Parameters          | Exterior Lighting              | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2004 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2004 | Programmable Module Installation | ABS/TCS                        | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2004 | Programmable Module Installation | DSM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2004 | Programmable Module Installation | GEM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2004 | Programmable Module Installation | IC                             | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2005 | Programmable Parameters          | Personality                    | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2005 | Programmable Parameters          | Exterior Lighting              | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2005 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2005 | Programmable Module Installation | ABS/TCS                        | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2005 | Programmable Module Installation | DSM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2005 | Programmable Module Installation | GEM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2005 | Programmable Module Installation | IC                             | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2006 | Programmable Parameters          | Personality                    | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2006 | Programmable Module Installation | DSM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2006 | Programmable Module Installation | GEM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2006 | Programmable Module Installation | IC                             | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2007 | Programmable Parameters          | Personality                    | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2007 | Programmable Module Installation | DSM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2007 | Programmable Module Installation | GEM                            | ●     |
| Freestar / Monterey | 4.2L     | V6 OHV     | 2007 | Programmable Module Installation | IC                             | ●     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Parameters          | Personality                    | ●     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Parameters          | Audio Configure                | ※     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Module Installation | ABS                            | ●     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Module Installation | ACM                            | ※     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Module Installation | DSM                            | ●     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Module Installation | IC                             | ●     |
| Freestyle           | 3.0L     | 4V         | 2005 | Programmable Module Installation | RCM                            | ●     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Parameters          | Personality                    | ●     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Parameters          | Audio Configure                | ※     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Parameters          | Exterior Lighting              | ●     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Parameters          | Power Door Locks               | ●     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Module Installation | ACM                            | ※     |
| Freestyle           | 3.0L     | 4V         | 2006 | Programmable Module Installation | DSM                            | ●     |

| Vehicle             | Capacity | EngineType         | Year | Module Programming               | System                         | Flags |
|---------------------|----------|--------------------|------|----------------------------------|--------------------------------|-------|
| Freestyle           | 3.0L     | 4V                 | 2006 | Programmable Module Installation | GEM                            | ●     |
| Freestyle           | 3.0L     | 4V                 | 2006 | Programmable Module Installation | IC                             | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Parameters          | Personality                    | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Parameters          | Audio Configure                | ※     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Parameters          | Exterior Lighting              | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Parameters          | Power Door Locks               | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Module Installation | ABS                            | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Module Installation | ACM                            | ※     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Module Installation | DSM                            | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Module Installation | GEM                            | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Module Installation | IC                             | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Module Installation | RCM                            | ●     |
| Freestyle           | 3.0L     | 4V                 | 2007 | Programmable Module Installation | SDARS                          | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Parameters          | Personality                    | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Module Installation | ABS/TCS                        | ●     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Module Installation | HEC                            | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Module Installation | OTC                            | ※     |
| F-Series Super Duty | 4.2L     | Direct Injection - | 2003 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 4.2L     | Other              | 2001 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 4.2L     | Other              | 2001 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 4.2L     | Other              | 2001 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 4.2L     | Other              | 2001 | Programmable Module Installation | ABS/TCS                        | ●     |
| F-Series Super Duty | 4.2L     | Other              | 2001 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 4.2L     | Other              | 2001 | Programmable Module Installation | OTC                            | ●     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Parameters          | Personality                    | ※     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Module Installation | ABS/TCS                        | ●     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 5.4L     | 2V                 | 2004 | Programmable Module Installation | HEC                            | ※     |

| Vehicle             | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| F-Series Super Duty | 5.4L     | 2V         | 2004 | Programmable Module Installation | OTC                            | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2004 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes         | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Parameters          | Driveline                      | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Parameters          | Power Windows                  | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Module Installation | GEM                            | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Module Installation | IC                             | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2005 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Parameters          | Driveline                      | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Parameters          | Power Windows                  | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Module Installation | GEM                            | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Module Installation | IC                             | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2006 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Module Installation | ABS                            | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Module Installation | DSM                            | ✖     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Module Installation | IC                             | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| F-Series Super Duty | 5.4L     | 2V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes         | ✖     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Parameters          | Driveline                      | ✖     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Windows                  | ✖     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Module Installation | GEM                            | ✖     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Module Installation | IC                             | ✖     |
| F-Series Super Duty | 5.4L     | 3V         | 2005 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Parameters          | Personality                    | ●     |

| Vehicle             | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2006 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2007 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Module Installation | IC                             | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ※     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Module Installation | IC                             | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Module Installation | ABS                            | ●     |

| Vehicle             | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------------------|----------|------------|------|----------------------------------|------------------------|-------|
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Module Installation | DSM                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Module Installation | IC                     | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Module Installation | PAM                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCM                    | ●     |
| F-Series Super Duty | 5.4L     | 3V         | 2010 | Programmable Module Installation | RETM                   | ●     |
| F-Series Super Duty | 5.4L     | BIF        | 1999 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 5.4L     | BIF        | 1999 | Programmable Parameters          | Power Door Locks       | ※     |
| F-Series Super Duty | 5.4L     | BIF        | 1999 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 5.4L     | BIF        | 1999 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 5.4L     | BIF        | 1999 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 5.4L     | BIF        | 1999 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 5.4L     | BIF        | 1999 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 5.4L     | Other      | 1999 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 5.4L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ※     |
| F-Series Super Duty | 5.4L     | Other      | 1999 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 5.4L     | Other      | 1999 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 5.4L     | Other      | 1999 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 5.4L     | Other      | 1999 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 5.4L     | Other      | 1999 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2000 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2000 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2000 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2000 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2001 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2001 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2001 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2001 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2001 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2001 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Module Installation | CSM                    | ●     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 5.4L     | Other      | 2002 | Programmable Module Installation | HEC                    | ※     |



| Vehicle             | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|---------------------|----------|--------------------|------|----------------------------------|------------------------|-------|
| F-Series Super Duty | 5.4L     | Other              | 2002 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Parameters          | Personality            | ※     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Module Installation | OTC                    | ※     |
| F-Series Super Duty | 5.4L     | Other              | 2003 | Programmable Module Installation | VSM                    | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Personality            | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | FICM                   | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | OTC                    | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2003 | Programmable Module Installation | VSM                    | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Personality            | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | FICM                   | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2004 | Programmable Module Installation | VSM                    | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Personality            | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection - | 2005 | Programmable Parameters          | Security               | ●     |

| Vehicle             | Capacity | EngineType                                   | Year | Module Programming               | System                         | Flags |
|---------------------|----------|--|------|----------------------------------|--------------------------------|-------|
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2005 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2005 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2005 | Programmable Module Installation | FICM                           | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2005 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2005 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2005 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Module Installation | FICM                           | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2006 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Module Installation | FICM                           | ●     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 6.0L     | Direct Injection -                           | 2007 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2011 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2011 | Programmable Module Installation | SDARS                          | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2012 | Programmable Parameters          | Powertrain                     | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2012 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2013 | Programmable Parameters          | Powertrain                     | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2013 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2014 | Programmable Parameters          | Powertrain                     | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2014 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.2L     | 2V   | 2015 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |

| Vehicle             | Capacity | EngineType                                   | Year | Module Programming               | System                           | Flags |
|---------------------|----------|--|------|----------------------------------|----------------------------------|-------|
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 | Programmable Module Installation | ABS                              | ※     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 | Programmable Module Installation | DSM                              | ※     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 | Programmable Module Installation | RCM                              | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2008 | Programmable Module Installation | RETM                             | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Parameters          | Personality                      | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Parameters          | Power Seats                      | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Parameters          | Warning Lamps / Chimes           | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Parameters          | Oshkosh/Plasan Sand Cat Vehicles | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Parameters          | Rear Seat Entertainment Module   | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Module Installation | ABS                              | ※     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Module Installation | DSM                              | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Module Installation | IC                               | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Module Installation | RCM                              | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2009 | Programmable Module Installation | RETM                             | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Parameters          | Personality                      | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Parameters          | Power Seats                      | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Parameters          | Warning Lamps / Chimes           | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Parameters          | Oshkosh/Plasan Sand Cat Vehicles | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Parameters          | Rear Seat Entertainment Module   | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Module Installation | ABS                              | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Module Installation | DSM                              | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Module Installation | IC                               | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Module Installation | PAM                              | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Module Installation | RCM                              | ●     |
| F-Series Super Duty | 6.4L     | Power Stroke - Direct Injection Turbo Diesel | 2010 | Programmable Module Installation | RETM                             | ●     |

| Vehicle             | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|---------------------|----------|--|------|----------------------------------|------------------------|-------|
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 | Programmable Module Installation | DCSM                   | ●     |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2011 | Programmable Module Installation | SDARS                  | ●     |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2012 | Programmable Module Installation | DCSM                   | ●     |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2013 | Programmable Module Installation | DCSM                   | ●     |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2014 | Programmable Module Installation | DCSM                   | ●     |
| F-Series Super Duty | 6.7L     | Power Stroke - Direct Injection Turbo Diesel | 2015 | Programmable Module Installation | DCSM                   | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Parameters          | Personality            | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2004 | Programmable Module Installation | VSM                    | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Parameters          | Personality            | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Module Installation | ABS                    | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Module Installation | IC                     | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2005 | Programmable Module Installation | VSM                    | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Parameters          | Personality            | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Module Installation | ABS                    | ●     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Module Installation | IC                     | ※     |
| F-Series Super Duty | 6.8L     | 2V   | 2006 | Programmable Module Installation | VSM                    | ●     |

| Vehicle             | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 6.8L     | 2V         | 2007 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Module Installation | ABS                            | ※     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Module Installation | DSM                            | ※     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Module Installation | IC                             | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| F-Series Super Duty | 6.8L     | 2V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2005 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Parameters          | Power Door Locks               | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2006 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Parameters          | Power Door Locks               | ●     |

| Vehicle             | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Parameters          | Driveline                      | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Parameters          | Security                       | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Parameters          | Power Windows                  | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Module Installation | GEM                            | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Module Installation | IC                             | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2007 | Programmable Module Installation | VSM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Module Installation | IC                             | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Module Installation | IC                             | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Parameters          | Personality                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Module Installation | ABS                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Module Installation | IC                             | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Module Installation | PAM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Module Installation | RCM                            | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2010 | Programmable Module Installation | RETM                           | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2011 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2011 | Programmable Module Installation | SDARS                          | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2012 | Programmable Parameters          | Powertrain                     | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2012 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2013 | Programmable Parameters          | Powertrain                     | ※     |
| F-Series Super Duty | 6.8L     | 3V         | 2013 | Programmable Module Installation | DCSM                           | ●     |
| F-Series Super Duty | 6.8L     | 3V         | 2014 | Programmable Module Installation | DCSM                           | ●     |

| Vehicle             | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------------------|----------|------------|------|----------------------------------|------------------------|-------|
| F-Series Super Duty | 6.8L     | 3V         | 2015 | Programmable Module Installation | DCSM                   | ●     |
| F-Series Super Duty | 6.8L     | Other      | 1999 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.8L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ※     |
| F-Series Super Duty | 6.8L     | Other      | 1999 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | Other      | 1999 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | Other      | 1999 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.8L     | Other      | 1999 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | Other      | 1999 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2000 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2000 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2000 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2000 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2001 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2001 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2001 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2001 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2001 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2001 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Module Installation | CSM                    | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2002 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Parameters          | Personality            | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 6.8L     | Other      | 2003 | Programmable Module Installation | OTC                    | ※     |

| Vehicle             | Capacity | EngineType         | Year | Module Programming               | System                 | Flags |
|---------------------|----------|--------------------|------|----------------------------------|------------------------|-------|
| F-Series Super Duty | 6.8L     | Other              | 2003 | Programmable Module Installation | VSM                    | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 1999 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 1999 | Programmable Parameters          | Power Door Locks       | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 1999 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 1999 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 1999 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 1999 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 1999 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Power Door Locks       | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2000 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2000 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2000 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2001 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2001 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2001 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2001 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2001 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2001 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | CSM                    | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2002 | Programmable Module Installation | OTC                    | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Personality            | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Driveline              | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Security               | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Parameters          | Power Windows          | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | GEM                    | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | HEC                    | ※     |
| F-Series Super Duty | 7.3L     | Direct Injection - | 2003 | Programmable Module Installation | OTC                    | ※     |



| Vehicle             | Capacity | EngineType                                     | Year | Module Programming               | System           | Flags |
|---------------------|----------|--|------|----------------------------------|------------------|-------|
| F-Series Super Duty | 7.3L     | Direct Injection -                             | 2003 | Programmable Module Installation | VSM              | ●     |
| Fusion              | 1.25L    | DURATEC 16V                                    | 2002 | Programmable Parameters          | Personality      | ●     |
| Fusion              | 1.25L    | DURATEC 16V                                    | 2002 | Programmable Parameters          | Power Door Locks | ●     |
| Fusion              | 1.25L    | DURATEC 16V                                    | 2002 | Programmable Module Installation | GEM              | ●     |
| Fusion              | 1.25L    | DURATEC 16V                                    | 2002 | Programmable Module Installation | IC               | ●     |
| Fusion              | 1.25L    | DURATEC 16V                                    | 2006 | Programmable Module Installation | ACM              | ※     |
| Fusion              | 1.25L    | DURATEC 16V                                    | 2006 | Programmable Module Installation | IC               | ※     |
| Fusion              | 1.4L     | DURATEC 16V                                    | 2002 | Programmable Parameters          | Personality      | ●     |
| Fusion              | 1.4L     | DURATEC 16V                                    | 2002 | Programmable Parameters          | Power Door Locks | ●     |
| Fusion              | 1.4L     | DURATEC 16V                                    | 2002 | Programmable Module Installation | GEM              | ●     |
| Fusion              | 1.4L     | DURATEC 16V                                    | 2002 | Programmable Module Installation | IC               | ●     |
| Fusion              | 1.4L     | DURATEC 16V                                    | 2006 | Programmable Module Installation | ACM              | ※     |
| Fusion              | 1.4L     | DURATEC 16V                                    | 2006 | Programmable Module Installation | IC               | ※     |
| Fusion              | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Parameters          | Personality      | ●     |
| Fusion              | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Parameters          | Power Door Locks | ●     |
| Fusion              | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Module Installation | GEM              | ●     |
| Fusion              | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Module Installation | IC               | ●     |
| Fusion              | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006 | Programmable Module Installation | ACM              | ※     |
| Fusion              | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006 | Programmable Module Installation | IC               | ※     |
| Fusion              | 1.6L     | DURATEC 16V                                    | 2002 | Programmable Parameters          | Personality      | ●     |
| Fusion              | 1.6L     | DURATEC 16V                                    | 2002 | Programmable Parameters          | Power Door Locks | ●     |
| Fusion              | 1.6L     | DURATEC 16V                                    | 2002 | Programmable Module Installation | GEM              | ●     |
| Fusion              | 1.6L     | DURATEC 16V                                    | 2002 | Programmable Module Installation | IC               | ●     |
| Fusion              | 1.6L     | DURATEC 16V                                    | 2006 | Programmable Module Installation | ACM              | ※     |
| Fusion              | 1.6L     | DURATEC 16V                                    | 2006 | Programmable Module Installation | IC               | ※     |
| Fusion              | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Parameters          | Personality      | ●     |
| Fusion              | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Parameters          | Power Door Locks | ●     |
| Fusion              | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Module Installation | EPS              | ●     |
| Fusion              | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Module Installation | GEM              | ●     |
| Fusion              | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002 | Programmable Module Installation | IC               | ●     |
| Fusion              | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006 | Programmable Module Installation | ACM              | ※     |
| Fusion              | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006 | Programmable Module Installation | EPS              | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System                          | Flags |
|---------|----------|--|------|----------------------------------|---------------------------------|-------|
| Fusion  | 1.6L     | Duratorq-Turbo Diesel Common Rail Injection  | 2006 | Programmable Module Installation | IC                              | ※     |
| Fusion  | 1.6L     | EcoBoost - Gas Turbocharged Direct Injection | 2015 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2015 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.0L     | Full Hybrid Electric Vehicle                 | 2015 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.0L     | Plug-in Hybrid Electric Vehicle              | 2015 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Module Installation | ACM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Module Installation | GEM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Module Installation | IC                              | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2006 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Parameters          | Personality                     | ※     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Parameters          | Audio Configure                 | ※     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Module Installation | GEM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Module Installation | IC                              | ※     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Module Installation | SDARS                           | ※     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2007 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Parameters          | Personality                     | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Parameters          | Security                        | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4                              | 2008 | Programmable Module Installation | IC                              | ●     |

| Vehicle | Capacity | EngineType        | Year | Module Programming               | System                          | Flags |
|---------|----------|-------------------|------|----------------------------------|---------------------------------|-------|
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Personality                     | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Security                        | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | ABS                             | ※     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | IC                              | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | ABS                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | ABS                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | ABS                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.5L     | DURATEC-HE / I4   | 2012 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | TBM                             | ●     |

| Vehicle | Capacity | EngineType        | Year | Module Programming               | System                          | Flags |
|---------|----------|-------------------|------|----------------------------------|---------------------------------|-------|
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Module Installation | ACM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Module Installation | GEM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Module Installation | IC                              | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2006 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Parameters          | Personality                     | ※     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Parameters          | Audio Configure                 | ※     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Module Installation | GEM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Module Installation | IC                              | ※     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Module Installation | SDARS                           | ※     |
| Fusion  | 3.0L     | 4V                | 2007 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.0L     | 4V                | 2008 | Programmable Parameters          | Personality                     | ●     |
| Fusion  | 3.0L     | 4V                | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 3.0L     | 4V                | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 3.0L     | 4V                | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 3.0L     | 4V                | 2008 | Programmable Parameters          | Security                        | ●     |
| Fusion  | 3.0L     | 4V                | 2008 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.0L     | 4V                | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Fusion  | 3.0L     | 4V         | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Fusion  | 3.0L     | 4V         | 2008 | Programmable Module Installation | IC                              | ●     |
| Fusion  | 3.0L     | 4V         | 2008 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2008 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2008 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Parameters          | Personality                     | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Parameters          | Power Door Locks                | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Parameters          | Security                        | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Module Installation | ABS                             | ※     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Module Installation | IC                              | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Module Installation | RCM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2009 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 3.0L     | 4V         | 2010 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.0L     | 4V         | 2010 | Programmable Module Installation | ABS                             | ●     |
| Fusion  | 3.0L     | 4V         | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 3.0L     | 4V         | 2010 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2010 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2011 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 3.0L     | 4V         | 2011 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.0L     | 4V         | 2011 | Programmable Module Installation | ABS                             | ●     |
| Fusion  | 3.0L     | 4V         | 2011 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 3.0L     | 4V         | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 3.0L     | 4V         | 2011 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2011 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2012 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 3.0L     | 4V         | 2012 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.0L     | 4V         | 2012 | Programmable Module Installation | ABS                             | ●     |
| Fusion  | 3.0L     | 4V         | 2012 | Programmable Module Installation | ACM                             | ※     |
| Fusion  | 3.0L     | 4V         | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Fusion  | 3.0L     | 4V         | 2012 | Programmable Module Installation | PAM                             | ●     |
| Fusion  | 3.0L     | 4V         | 2012 | Programmable Module Installation | TBM                             | ●     |
| Fusion  | 3.5L     | 4V         | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Fusion  | 3.5L     | 4V         | 2010 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Fusion  | 3.5L     | 4V         | 2010 | Programmable Module Installation | ABS                             | ●     |

| Vehicle      | Capacity | EngineType   | Year   | Module Programming               | System                       | Flags |
|--------------|----------|--|--------|----------------------------------|------------------------------|-------|
| Fusion       | 3.5L     | 4V   | 2010   | Programmable Module Installation | FDIM                         | ●     |
| Fusion       | 3.5L     | 4V   | 2010   | Programmable Module Installation | PAM                          | ●     |
| Fusion       | 3.5L     | 4V   | 2010   | Programmable Module Installation | TBM                          | ●     |
| Fusion       | 3.5L     | 4V   | 2011   | Programmable Parameters          | Audio Configure              | ●     |
| Fusion       | 3.5L     | 4V   | 2011   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Fusion       | 3.5L     | 4V   | 2011   | Programmable Module Installation | ABS                          | ●     |
| Fusion       | 3.5L     | 4V   | 2011   | Programmable Module Installation | ACM                          | ※     |
| Fusion       | 3.5L     | 4V   | 2011   | Programmable Module Installation | FDIM                         | ●     |
| Fusion       | 3.5L     | 4V   | 2011   | Programmable Module Installation | PAM                          | ●     |
| Fusion       | 3.5L     | 4V   | 2011   | Programmable Module Installation | TBM                          | ●     |
| Fusion       | 3.5L     | 4V   | 2012   | Programmable Parameters          | Audio Configure              | ●     |
| Fusion       | 3.5L     | 4V   | 2012   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Fusion       | 3.5L     | 4V   | 2012   | Programmable Module Installation | ABS                          | ●     |
| Fusion       | 3.5L     | 4V   | 2012   | Programmable Module Installation | ACM                          | ※     |
| Fusion       | 3.5L     | 4V   | 2012   | Programmable Module Installation | FDIM                         | ●     |
| Fusion       | 3.5L     | 4V   | 2012   | Programmable Module Installation | PAM                          | ●     |
| Fusion       | 3.5L     | 4V   | 2012   | Programmable Module Installation | TBM                          | ●     |
| GALAXY\S-Max | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2010.5 | Programmable Module Installation | CDP                          | ●     |
| GALAXY\S-Max | 1.6L     | EcoBoost - Gas<br>Turbocharged Direct<br>Injection     | 2010.5 | Programmable Module Installation | CDP                          | ●     |
| GALAXY\S-Max | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2006.5 | Programmable Module Installation | CDP                          | ●     |
| GALAXY\S-Max | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2006.5 | Programmable Module Installation | GDM                          | ※     |
| GALAXY\S-Max | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2006.5 | Programmable Module Installation | NAV                          | ※     |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4  | 2006.5 | Programmable Module Installation | CDP                          | ●     |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4  | 2006.5 | Programmable Module Installation | GDM                          | ※     |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4  | 2006.5 | Programmable Module Installation | NAV                          | ※     |
| GALAXY\S-Max | 2.0L     | DURATEC-HE / I4  | 2010.5 | Programmable Module Installation | CDP                          | ●     |
| GALAXY\S-Max | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2006.5 | Programmable Module Installation | CDP                          | ●     |
| GALAXY\S-Max | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2006.5 | Programmable Module Installation | GDM                          | ※     |
| GALAXY\S-Max | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2006.5 | Programmable Module Installation | NAV                          | ※     |
| GALAXY\S-Max | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2010.5 | Programmable Module Installation | CDP                          | ●     |
| GALAXY\S-Max | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2010.5 | Programmable Module Installation | CDP                          | ●     |

| Vehicle       | Capacity | EngineType                                       | Year   | Module Programming               | System                 | Flags |
|---------------|----------|--|--------|----------------------------------|------------------------|-------|
| GALAXY\S-Max  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection     | 2010.5 | Programmable Module Installation | CDP                    | ●     |
| GALAXY\S-Max  | 2.2L     | Duratorq-Turbo Diesel Common Rail Injection      | 2006.5 | Programmable Module Installation | CDP                    | ●     |
| GALAXY\S-Max  | 2.2L     | Duratorq-Turbo Diesel Common Rail Injection      | 2006.5 | Programmable Module Installation | GDM                    | ※     |
| GALAXY\S-Max  | 2.2L     | Duratorq-Turbo Diesel Common Rail Injection      | 2006.5 | Programmable Module Installation | NAV                    | ※     |
| GALAXY\S-Max  | 2.2L     | Duratorq-Turbo Diesel Common Rail Injection      | 2010.5 | Programmable Module Installation | CDP                    | ●     |
| GALAXY\S-Max  | 2.2L     | Duratorq-Turbo Diesel Common Rail Injection StgV | 2010.5 | Programmable Module Installation | CDP                    | ●     |
| GALAXY\S-Max  | 2.3L     | DURATEC-HE / I4                                  | 2006.5 | Programmable Module Installation | CDP                    | ●     |
| GALAXY\S-Max  | 2.3L     | DURATEC-HE / I4                                  | 2006.5 | Programmable Module Installation | GDM                    | ※     |
| GALAXY\S-Max  | 2.3L     | DURATEC-HE / I4                                  | 2006.5 | Programmable Module Installation | NAV                    | ※     |
| GALAXY\S-Max  | 2.3L     | DURATEC-HE / I4                                  | 2010.5 | Programmable Module Installation | CDP                    | ●     |
| GALAXY\S-Max  | 2.5L     | I5   | 2006.5 | Programmable Module Installation | CDP                    | ●     |
| GALAXY\S-Max  | 2.5L     | I5   | 2006.5 | Programmable Module Installation | GDM                    | ※     |
| GALAXY\S-Max  | 2.5L     | I5   | 2006.5 | Programmable Module Installation | NAV                    | ※     |
| Grand Marquis | 4.6L     | 2V   | 2000   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Grand Marquis | 4.6L     | 2V   | 2000   | Programmable Parameters          | Power Door Locks       | ●     |
| Grand Marquis | 4.6L     | 2V   | 2000   | Programmable Parameters          | Security               | ●     |
| Grand Marquis | 4.6L     | 2V   | 2000   | Programmable Module Installation | DDM                    | ●     |
| Grand Marquis | 4.6L     | 2V   | 2000   | Programmable Module Installation | LCM                    | ●     |
| Grand Marquis | 4.6L     | 2V   | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Grand Marquis | 4.6L     | 2V   | 2002   | Programmable Parameters          | Power Door Locks       | ●     |
| Grand Marquis | 4.6L     | 2V   | 2002   | Programmable Parameters          | Security               | ●     |
| Grand Marquis | 4.6L     | 2V   | 2002   | Programmable Module Installation | DDM                    | ●     |
| Grand Marquis | 4.6L     | 2V   | 2002   | Programmable Module Installation | LCM                    | ●     |
| Grand Marquis | 4.6L     | 2V   | 2003   | Programmable Parameters          | Power Door Locks       | ●     |
| Grand Marquis | 4.6L     | 2V   | 2003   | Programmable Parameters          | Security               | ●     |
| Grand Marquis | 4.6L     | 2V   | 2003   | Programmable Module Installation | DDM                    | ●     |
| Grand Marquis | 4.6L     | 2V   | 2003   | Programmable Module Installation | RASM                   | ●     |
| Grand Marquis | 4.6L     | 2V   | 2003   | Programmable Module Installation | VAPS                   | ●     |
| Grand Marquis | 4.6L     | 2V   | 2004   | Programmable Parameters          | Power Door Locks       | ●     |
| Grand Marquis | 4.6L     | 2V   | 2004   | Programmable Parameters          | Security               | ●     |
| Grand Marquis | 4.6L     | 2V   | 2004   | Programmable Module Installation | DDM                    | ●     |
| Grand Marquis | 4.6L     | 2V   | 2004   | Programmable Module Installation | RASM                   | ●     |
| Grand Marquis | 4.6L     | 2V   | 2004   | Programmable Module Installation | VAPS                   | ●     |
| Grand Marquis | 4.6L     | 2V   | 2005   | Programmable Parameters          | Power Door Locks       | ●     |
| Grand Marquis | 4.6L     | 2V   | 2005   | Programmable Parameters          | Security               | ●     |
| Grand Marquis | 4.6L     | 2V   | 2005   | Programmable Module Installation | DDM                    | ●     |

| Vehicle       | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Grand Marquis | 4.6L     | 2V         | 2005 | Programmable Module Installation | RASM                            | ●     |
| Grand Marquis | 4.6L     | 2V         | 2005 | Programmable Module Installation | RCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2005 | Programmable Module Installation | VAPS                            | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Parameters          | Exterior Lighting               | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Module Installation | DDM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Module Installation | IC                              | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Module Installation | LCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Module Installation | RASM                            | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Module Installation | RCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2006 | Programmable Module Installation | VAPS                            | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Module Installation | DDM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Module Installation | IC                              | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Module Installation | LCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Module Installation | RCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2007 | Programmable Module Installation | VDM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Module Installation | DDM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Module Installation | IC                              | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Module Installation | LCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Module Installation | RCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2008 | Programmable Module Installation | VDM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Parameters          | Power Door Locks                | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Module Installation | ABS                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Module Installation | DDM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Module Installation | IC                              | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Module Installation | LCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Module Installation | RCM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2009 | Programmable Module Installation | VDM                             | ●     |
| Grand Marquis | 4.6L     | 2V         | 2010 | Programmable Parameters          | Exterior Lighting               | ●     |
| Grand Marquis | 4.6L     | 2V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |



| Vehicle       | Capacity | EngineType                                     | Year     | Module Programming               | System                          | Flags |
|---------------|----------|--|----------|----------------------------------|---------------------------------|-------|
| Grand Marquis | 4. 6L    | 2V   | 2010     | Programmable Parameters          | Power Door Locks                | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2010     | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2010     | Programmable Module Installation | ABS                             | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2010     | Programmable Module Installation | DDM                             | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2010     | Programmable Module Installation | IC                              | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2010     | Programmable Module Installation | LCM                             | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2010     | Programmable Module Installation | RCM                             | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Parameters          | Interior Lighting               | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Parameters          | Exterior Lighting               | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Parameters          | Power Door Locks                | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Parameters          | Police Mode                     | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Module Installation | ABS                             | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Module Installation | DDM                             | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Module Installation | IC                              | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Module Installation | LCM                             | ●     |
| Grand Marquis | 4. 6L    | 2V   | 2011     | Programmable Module Installation | RCM                             | ●     |
| Ikon          | 1. 3L    | Zetec Rocam                                    | 2003. 25 | Programmable Parameters          | Washer / Wiper                  | ●     |
| Ikon          | 1. 3L    | Zetec Rocam                                    | 2003. 25 | Programmable Parameters          | Power Door Locks                | ●     |
| Ikon          | 1. 3L    | Zetec Rocam                                    | 2003. 25 | Programmable Module Installation | GEM                             | ●     |
| Ikon          | 1. 3L    | Zetec Rocam                                    | 2003. 25 | Programmable Module Installation | ECS                             | ●     |
| Ikon          | 1. 4L    | Duratorq-Turbo Diesel<br>Common Rail Injection | 2009. 25 | Programmable Module Installation | IC                              | ●     |
| Ikon          | 1. 6L    | Other  | 2001     | Programmable Module Installation | ECS                             | ●     |
| Ikon          | 1. 6L    | Zetec Rocam                                    | 1999. 75 | Programmable Module Installation | ECS                             | ●     |
| Ikon          | 1. 6L    | Zetec Rocam                                    | 2003     | Programmable Module Installation | ECS                             | ●     |
| Ikon          | 1. 6L    | Zetec Rocam                                    | 2003. 25 | Programmable Parameters          | Washer / Wiper                  | ●     |
| Ikon          | 1. 6L    | Zetec Rocam                                    | 2003. 25 | Programmable Parameters          | Power Door Locks                | ●     |
| Ikon          | 1. 6L    | Zetec Rocam                                    | 2003. 25 | Programmable Module Installation | GEM                             | ●     |
| Ikon          | 1. 6L    | Zetec Rocam                                    | 2003. 25 | Programmable Module Installation | ECS                             | ●     |
| Ka            | 1. 0L    | HCS  | 1999     | Programmable Module Installation | ECS                             | ●     |
| Ka            | 1. 3L    | DURATEC 8V                                     | 2000     | Programmable Module Installation | GEM                             | ●     |
| Ka            | 1. 3L    | DURATEC 8V                                     | 2000     | Programmable Module Installation | ECS                             | ●     |
| Ka            | 1. 3L    | Endura-E                                       | 1999     | Programmable Module Installation | ECS                             | ●     |
| Ka            | 1. 3L    | Endura-E                                       | 2000     | Programmable Module Installation | GEM                             | ●     |
| Ka            | 1. 3L    | Endura-E                                       | 2000     | Programmable Module Installation | ECS                             | ●     |
| Ka            | 1. 6L    | DURATEC 8V                                     | 2000     | Programmable Module Installation | GEM                             | ●     |
| Ka            | 1. 6L    | DURATEC 8V                                     | 2000     | Programmable Module Installation | ECS                             | ●     |
| Ka            | 1. 6L    | Zetec Rocam                                    | 2001. 5  | Programmable Module Installation | ECS                             | ●     |
| Kuga          | 2. 0L    | Duratorq-Turbo Diesel<br>Common Rail Injection | 2008. 5  | Programmable Parameters          | Module Reset                    | ●     |

| Vehicle | Capacity | EngineType   | Year   | Module Programming               | System       | Flags |
|---------|----------|--|--------|----------------------------------|--------------|-------|
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | ABS          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | AWD          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | EATC         | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | CMR          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | D_DCU        | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | GEM          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | HCM          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | PAM          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | P_DCU        | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | RCM          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2008.5 | Programmable Module Installation | RETM         | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Parameters          | Module Reset | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | ABS          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | AWD          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | EATC         | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | CMR          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | D_DCU        | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | GEM          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | HCM          | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | PAM          | ●     |

| Vehicle | Capacity | EngineType   | Year   | Module Programming               | System                 | Flags |
|---------|----------|--|--------|----------------------------------|------------------------|-------|
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | P_DCU                  | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | RCM                    | ●     |
| Kuga    | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2008.5 | Programmable Module Installation | RETM                   | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Parameters          | Module Reset           | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | ABS                    | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | AWD                    | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | EATC                   | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | CMR                    | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | D_DCU                  | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | GEM                    | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | HCM                    | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | PAM                    | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | P_DCU                  | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | RCM                    | ●     |
| Kuga    | 2.5L     | I5   | 2008.5 | Programmable Module Installation | RETM                   | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Parameters          | Personality            | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Parameters          | Power Seats            | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Parameters          | Power Door Locks       | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Parameters          | Security               | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | ABS/TCS                | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | ACM                    | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | EATC                   | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | DDM                    | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | GEM                    | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | HEC                    | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | MC                     | ●     |
| LS      | 3.0L     | Other  | 2000   | Programmable Module Installation | REM                    | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Parameters          | Personality            | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Parameters          | Power Seats            | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Parameters          | Power Door Locks       | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Parameters          | Security               | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Module Installation | ABS/TCS                | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Module Installation | ACM                    | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Module Installation | EATC                   | ●     |
| LS      | 3.0L     | Other  | 2002   | Programmable Module Installation | DDM                    | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System           | Flags |
|---------|----------|------------|------|----------------------------------|------------------|-------|
| LS      | 3.0L     | Other      | 2002 | Programmable Module Installation | GEM              | ●     |
| LS      | 3.0L     | Other      | 2002 | Programmable Module Installation | HEC              | ●     |
| LS      | 3.0L     | Other      | 2002 | Programmable Module Installation | MC               | ●     |
| LS      | 3.0L     | Other      | 2002 | Programmable Module Installation | REM              | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Parameters          | Personality      | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Parameters          | Washer / Wiper   | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Parameters          | Power Seats      | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Parameters          | Power Door Locks | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Parameters          | Security         | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Parameters          | Climate Control  | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | ABS/TCS          | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | ACM              | ※     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | EATC             | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | DDM              | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | EPB              | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | GEM              | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | HEC              | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | MC               | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | NAV              | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | REM              | ●     |
| LS      | 3.0L     | Other      | 2003 | Programmable Module Installation | VEMS             | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Parameters          | Personality      | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Parameters          | Washer / Wiper   | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Parameters          | Power Seats      | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Parameters          | Power Door Locks | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Parameters          | Security         | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Parameters          | Climate Control  | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | ABS/TCS          | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | ACM              | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | EATC             | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | DDM              | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | EPB              | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | GEM              | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | HEC              | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | MC               | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | NAV              | ●     |
| LS      | 3.0L     | Other      | 2004 | Programmable Module Installation | REM              | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Parameters          | Personality      | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Parameters          | Washer / Wiper   | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Parameters          | Power Seats      | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Parameters          | Power Door Locks | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System           | Flags |
|---------|----------|------------|------|----------------------------------|------------------|-------|
| LS      | 3.0L     | Other      | 2005 | Programmable Parameters          | Security         | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Parameters          | Climate Control  | ※     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | ABS/TCS          | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | ACM              | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | EATC             | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | DDM              | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | EPB              | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | GEM              | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | HEC              | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | MC               | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | NAV              | ●     |
| LS      | 3.0L     | Other      | 2005 | Programmable Module Installation | REM              | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Parameters          | Personality      | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Parameters          | Washer / Wiper   | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Parameters          | Power Seats      | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Parameters          | Power Door Locks | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Parameters          | Security         | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Parameters          | Climate Control  | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | ABS/TCS          | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | ACM              | ※     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | EATC             | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | DDM              | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | EPB              | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | GEM              | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | HEC              | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | MC               | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | NAV              | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | REM              | ●     |
| LS      | 3.9L     | 4V         | 2003 | Programmable Module Installation | VEMS             | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Parameters          | Personality      | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Parameters          | Washer / Wiper   | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Parameters          | Power Seats      | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Parameters          | Power Door Locks | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Parameters          | Security         | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Parameters          | Climate Control  | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | ABS/TCS          | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | ACM              | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | EATC             | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | DDM              | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | EPB              | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | GEM              | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------|----------|------------|------|----------------------------------|------------------------|-------|
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | HEC                    | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | MC                     | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | NAV                    | ●     |
| LS      | 3.9L     | 4V         | 2004 | Programmable Module Installation | REM                    | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Parameters          | Personality            | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Parameters          | Washer / Wiper         | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Parameters          | Power Seats            | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Parameters          | Security               | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Parameters          | Climate Control        | ※     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | ABS/TCS                | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | ACM                    | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | EATC                   | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | DDM                    | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | EPB                    | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | GEM                    | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | HEC                    | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | MC                     | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | NAV                    | ●     |
| LS      | 3.9L     | 4V         | 2005 | Programmable Module Installation | REM                    | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Parameters          | Personality            | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Parameters          | Washer / Wiper         | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Parameters          | Security               | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | ABS/TCS                | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | ACM                    | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | EATC                   | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | DDM                    | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | EPB                    | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | GEM                    | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | HEC                    | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | MC                     | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | NAV                    | ●     |
| LS      | 3.9L     | 4V         | 2006 | Programmable Module Installation | REM                    | ●     |
| LS      | 3.9L     | Other      | 2000 | Programmable Parameters          | Personality            | ●     |
| LS      | 3.9L     | Other      | 2000 | Programmable Parameters          | Power Seats            | ●     |
| LS      | 3.9L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| LS      | 3.9L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| LS      | 3.9L     | Other      | 2000 | Programmable Parameters          | Security               | ●     |
| LS      | 3.9L     | Other      | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| LS      | 3.9L     | Other      | 2000 | Programmable Module Installation | ACM                    | ●     |

| Vehicle  | Capacity | EngineType      | Year | Module Programming               | System                 | Flags |
|----------|----------|-----------------|------|----------------------------------|------------------------|-------|
| LS       | 3.9L     | Other           | 2000 | Programmable Module Installation | EATC                   | ●     |
| LS       | 3.9L     | Other           | 2000 | Programmable Module Installation | DDM                    | ●     |
| LS       | 3.9L     | Other           | 2000 | Programmable Module Installation | GEM                    | ●     |
| LS       | 3.9L     | Other           | 2000 | Programmable Module Installation | HEC                    | ●     |
| LS       | 3.9L     | Other           | 2000 | Programmable Module Installation | MC                     | ●     |
| LS       | 3.9L     | Other           | 2000 | Programmable Module Installation | REM                    | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Parameters          | Personality            | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Parameters          | Power Seats            | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Parameters          | Security               | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | ACM                    | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | EATC                   | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | DDM                    | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | GEM                    | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | HEC                    | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | MC                     | ●     |
| LS       | 3.9L     | Other           | 2002 | Programmable Module Installation | REM                    | ●     |
| Marauder | 4.6L     | 4V              | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Marauder | 4.6L     | 4V              | 2003 | Programmable Parameters          | Security               | ●     |
| Marauder | 4.6L     | 4V              | 2003 | Programmable Module Installation | DDM                    | ●     |
| Marauder | 4.6L     | 4V              | 2003 | Programmable Module Installation | RASM                   | ●     |
| Marauder | 4.6L     | 4V              | 2003 | Programmable Module Installation | VAPS                   | ●     |
| Marauder | 4.6L     | 4V              | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| Marauder | 4.6L     | 4V              | 2004 | Programmable Parameters          | Security               | ●     |
| Marauder | 4.6L     | 4V              | 2004 | Programmable Module Installation | DDM                    | ●     |
| Marauder | 4.6L     | 4V              | 2004 | Programmable Module Installation | RASM                   | ●     |
| Marauder | 4.6L     | 4V              | 2004 | Programmable Module Installation | VAPS                   | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Personality            | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Exterior Lighting      | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Security               | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | ABS                    | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | GEM                    | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | IC                     | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Personality            | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Exterior Lighting      | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mariner  | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Power Door Locks       | ●     |

| Vehicle   | Capacity | EngineType      | Year | Module Programming               | System                          | Flags |
|---|----------|-----------------|------|----------------------------------|---------------------------------|-------|
| Mariner   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Security                        | ●     |
| Mariner   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | ABS                             | ●     |
| Mariner   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | GEM                             | ●     |
| Mariner   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | IC                              | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Parameters          | Personality                     | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Parameters          | Exterior Lighting               | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Parameters          | Security                        | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Module Installation | ABS                             | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Module Installation | GEM                             | ●     |
| Mariner   | 3.0L     | 4V              | 2006 | Programmable Module Installation | IC                              | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Parameters          | Personality                     | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Parameters          | Security                        | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Module Installation | ABS                             | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Module Installation | GEM                             | ●     |
| Mariner   | 3.0L     | 4V              | 2007 | Programmable Module Installation | IC                              | ●     |
| Mark LT   | 5.4L     | 3V              | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Mark LT   | 5.4L     | 3V              | 2006 | Programmable Module Installation | ABS                             | ●     |
| Mark LT   | 5.4L     | 3V              | 2006 | Programmable Module Installation | DSM                             | ※     |
| Mark LT   | 5.4L     | 3V              | 2006 | Programmable Module Installation | VSM                             | ●     |
| Mark LT   | 5.4L     | 3V              | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Mark LT   | 5.4L     | 3V              | 2007 | Programmable Module Installation | ABS                             | ●     |
| Mark LT   | 5.4L     | 3V              | 2007 | Programmable Module Installation | DSM                             | ※     |
| Mark LT   | 5.4L     | 3V              | 2007 | Programmable Module Installation | IC                              | ●     |
| Mark LT   | 5.4L     | 3V              | 2007 | Programmable Module Installation | VSM                             | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Parameters          | Climate Control                 | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Module Installation | ABS                             | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Module Installation | DSM                             | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Module Installation | IC                              | ●     |
| Mark LT   | 5.4L     | 3V              | 2008 | Programmable Module Installation | VSM                             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8              | 2005 | Programmable Parameters          | Interior Lighting               | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8              | 2005 | Programmable Parameters          | Exterior Lighting               | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8              | 2005 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8              | 2005 | Programmable Parameters          | RKE                             | ●     |



| Vehicle   | Capacity | EngineType | Year | Module Programming               | System                        | Flags |
|---|----------|------------|------|----------------------------------|-------------------------------|-------|
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2005 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2005 | Programmable Module Installation | ABS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2005 | Programmable Module Installation | EPS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2005 | Programmable Module Installation | GEM                           | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2005 | Programmable Module Installation | IC                            | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2005 | Programmable Module Installation | RKE                           | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2005 | Programmable Module Installation | RCM                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Parameters          | RKE                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Module Installation | ABS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Module Installation | EPS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Module Installation | IC                            | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Module Installation | RKE                           | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 1.8L     | L8         | 2007 | Programmable Module Installation | RCM                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Parameters          | Exterior Lighting             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Parameters          | RKE                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Module Installation | ABS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Module Installation | EPS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Module Installation | IC                            | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Module Installation | RKE                           | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2005 | Programmable Module Installation | RCM                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Parameters          | Interior Lighting             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Parameters          | Exterior Lighting             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Parameters          | RKE                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Module Installation | ABS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Module Installation | EPS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Module Installation | GEM                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Module Installation | IC                            | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Module Installation | RKE                           | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | LF         | 2007 | Programmable Module Installation | RCM                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T       | 2005 | Programmable Parameters          | Exterior Lighting             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T       | 2005 | Programmable Parameters          | Warning Lamps / Chimes        | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T       | 2005 | Programmable Parameters          | RKE                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T       | 2005 | Programmable Parameters          | Passenger Airbag Deactivation | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T       | 2005 | Programmable Module Installation | ABS                           | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T       | 2005 | Programmable Module Installation | FFH                           | ※     |

| Vehicle   | Capacity | EngineType      | Year | Module Programming               | System                          | Flags |
|---|----------|-----------------|------|----------------------------------|---------------------------------|-------|
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2005 | Programmable Module Installation | IC                              | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2005 | Programmable Module Installation | RKE                             | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2005 | Programmable Module Installation | RCM                             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Parameters          | Interior Lighting               | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Parameters          | RKE                             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Parameters          | Passenger Airbag Deactivation   | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Module Installation | ABS                             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Module Installation | FFH                             | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Module Installation | GEM                             | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Module Installation | IC                              | ●     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Module Installation | RKE                             | ※     |
| MAZDA5 (EURO STG3/4/5 and General Specs.) / i-MAX | 2.0L     | RF_T            | 2007 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | ACM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | GEM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | IC                              | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2006 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Personality                     | ※     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Audio Configure                 | ※     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | ACM                             | ※     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | GEM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | IC                              | ※     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | SDARS                           | ※     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Personality                     | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Security                        | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Module Installation | IC                              | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Module Installation | PAM                             | ●     |

| Vehicle | Capacity | EngineType        | Year | Module Programming               | System                          | Flags |
|---------|----------|-------------------|------|----------------------------------|---------------------------------|-------|
| Milan   | 2.3L     | DURATEC-HE / I4   | 2008 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Personality                     | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Security                        | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | ABS                             | ✘     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | IC                              | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 2.3L     | DURATEC-HE / I4   | 2009 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | ABS                             | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | ACM                             | ✘     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2010 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Parameters          | Audio Configure                 | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | ABS                             | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | ACM                             | ✘     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Milan   | 2.5L     | DURATEC-HE / I4   | 2011 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | ACM                             | ✘     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2010 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Parameters          | Audio Configure                 | ●     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | ACM                             | ✘     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Milan   | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 3.0L     | 4V                | 2006 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 3.0L     | 4V                | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Milan   | 3.0L     | 4V                | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 3.0L     | 4V                | 2006 | Programmable Module Installation | ACM                             | ●     |
| Milan   | 3.0L     | 4V                | 2006 | Programmable Module Installation | GEM                             | ●     |
| Milan   | 3.0L     | 4V                | 2006 | Programmable Module Installation | IC                              | ●     |
| Milan   | 3.0L     | 4V                | 2006 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 3.0L     | 4V                | 2007 | Programmable Parameters          | Personality                     | ✘     |
| Milan   | 3.0L     | 4V                | 2007 | Programmable Parameters          | Audio Configure                 | ✘     |
| Milan   | 3.0L     | 4V                | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 3.0L     | 4V                | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System                          | Flags |
|---------|----------|--|------|----------------------------------|---------------------------------|-------|
| Milan   | 3.0L     | 4V   | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 3.0L     | 4V   | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Milan   | 3.0L     | 4V   | 2007 | Programmable Module Installation | ACM                             | ※     |
| Milan   | 3.0L     | 4V   | 2007 | Programmable Module Installation | GEM                             | ●     |
| Milan   | 3.0L     | 4V   | 2007 | Programmable Module Installation | IC                              | ※     |
| Milan   | 3.0L     | 4V   | 2007 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 3.0L     | 4V   | 2007 | Programmable Module Installation | SDARS                           | ※     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Parameters          | Personality                     | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Parameters          | Security                        | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Module Installation | IC                              | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 3.0L     | 4V   | 2008 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Parameters          | Personality                     | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Parameters          | Power Door Locks                | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Parameters          | Security                        | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Module Installation | ABS                             | ※     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Module Installation | IC                              | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 3.0L     | 4V   | 2009 | Programmable Module Installation | RCM                             | ●     |
| Milan   | 3.0L     | 4V   | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Milan   | 3.0L     | 4V   | 2010 | Programmable Module Installation | ABS                             | ●     |
| Milan   | 3.0L     | 4V   | 2010 | Programmable Module Installation | ACM                             | ※     |
| Milan   | 3.0L     | 4V   | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Milan   | 3.0L     | 4V   | 2010 | Programmable Module Installation | PAM                             | ●     |
| Milan   | 3.0L     | 4V   | 2011 | Programmable Parameters          | Audio Configure                 | ●     |
| Milan   | 3.0L     | 4V   | 2011 | Programmable Module Installation | ABS                             | ●     |
| Milan   | 3.0L     | 4V   | 2011 | Programmable Module Installation | ACM                             | ※     |
| Milan   | 3.0L     | 4V   | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Milan   | 3.0L     | 4V   | 2011 | Programmable Module Installation | PAM                             | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Power Seats                     | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System          | Flags |
|---------|----------|--|------|----------------------------------|-----------------|-------|
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Audio Configure | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DCSM            | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DDM             | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DSM             | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | FDIM            | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Parameters          | Power Seats     | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Parameters          | Audio Configure | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DCSM            | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DDM             | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DSM             | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | FDIM            | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Power Seats     | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Audio Configure | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | ABS             | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DCSM            | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DDM             | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|---------|----------|--|------|----------------------------------|------------------------|-------|
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DSM                    | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | FDIM                   | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM                   | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DDM                    | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM                    | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM                   | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DDM                    | ●     |
| MKS     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM                    | ●     |
| MKS     | 3.7L     | 4V   | 2009 | Programmable Parameters          | Audio Configure        | ●     |
| MKS     | 3.7L     | 4V   | 2009 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| MKS     | 3.7L     | 4V   | 2009 | Programmable Module Installation | ABS                    | ●     |
| MKS     | 3.7L     | 4V   | 2009 | Programmable Module Installation | DCSM                   | ●     |
| MKS     | 3.7L     | 4V   | 2009 | Programmable Module Installation | DDM                    | ●     |
| MKS     | 3.7L     | 4V   | 2009 | Programmable Module Installation | FDIM                   | ●     |
| MKS     | 3.7L     | 4V   | 2009 | Programmable Module Installation | RCM                    | ●     |
| MKS     | 3.7L     | 4V   | 2010 | Programmable Parameters          | Power Seats            | ●     |
| MKS     | 3.7L     | 4V   | 2010 | Programmable Parameters          | Audio Configure        | ●     |
| MKS     | 3.7L     | 4V   | 2010 | Programmable Module Installation | DCSM                   | ●     |
| MKS     | 3.7L     | 4V   | 2010 | Programmable Module Installation | DDM                    | ●     |
| MKS     | 3.7L     | 4V   | 2010 | Programmable Module Installation | DSM                    | ●     |
| MKS     | 3.7L     | 4V   | 2010 | Programmable Module Installation | FDIM                   | ●     |
| MKS     | 3.7L     | 4V   | 2011 | Programmable Parameters          | Power Seats            | ●     |
| MKS     | 3.7L     | 4V   | 2011 | Programmable Parameters          | Audio Configure        | ●     |
| MKS     | 3.7L     | 4V   | 2011 | Programmable Module Installation | DCSM                   | ●     |
| MKS     | 3.7L     | 4V   | 2011 | Programmable Module Installation | DDM                    | ●     |
| MKS     | 3.7L     | 4V   | 2011 | Programmable Module Installation | DSM                    | ●     |
| MKS     | 3.7L     | 4V   | 2011 | Programmable Module Installation | FDIM                   | ●     |
| MKS     | 3.7L     | 4V   | 2012 | Programmable Parameters          | Power Seats            | ●     |
| MKS     | 3.7L     | 4V   | 2012 | Programmable Parameters          | Audio Configure        | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System      | Flags |
|---------|----------|--|------|----------------------------------|-------------|-------|
| MKS     | 3.7L     | 4V   | 2012 | Programmable Module Installation | ABS         | ●     |
| MKS     | 3.7L     | 4V   | 2012 | Programmable Module Installation | DCSM        | ●     |
| MKS     | 3.7L     | 4V   | 2012 | Programmable Module Installation | DDM         | ●     |
| MKS     | 3.7L     | 4V   | 2012 | Programmable Module Installation | DSM         | ●     |
| MKS     | 3.7L     | 4V   | 2012 | Programmable Module Installation | FDIM        | ●     |
| MKS     | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DCSM        | ●     |
| MKS     | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DDM         | ●     |
| MKS     | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DSM         | ●     |
| MKS     | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DCSM        | ●     |
| MKS     | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DDM         | ●     |
| MKS     | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DSM         | ●     |
| MKS     | Other    | Other  | 2015 | Programmable Module Installation | DCSM        | ●     |
| MKS     | Other    | Other  | 2015 | Programmable Module Installation | DDM         | ●     |
| MKS     | Other    | Other  | 2015 | Programmable Module Installation | DSM         | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DDM         | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM         | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DDM         | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM         | ●     |
| MKT     | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Power Seats | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DDM         | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System      | Flags |
|---------|----------|--|------|----------------------------------|-------------|-------|
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | FDIM        | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Parameters          | Power Seats | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | FDIM        | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Power Seats | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | FDIM        | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM        | ●     |



| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System      | Flags |
|---------|----------|--|------|----------------------------------|-------------|-------|
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.7L     | 4V   | 2010 | Programmable Parameters          | Power Seats | ●     |
| MKT     | 3.7L     | 4V   | 2010 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.7L     | 4V   | 2010 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.7L     | 4V   | 2010 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.7L     | 4V   | 2010 | Programmable Module Installation | FDIM        | ●     |
| MKT     | 3.7L     | 4V   | 2010 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.7L     | 4V   | 2011 | Programmable Parameters          | Power Seats | ●     |
| MKT     | 3.7L     | 4V   | 2011 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.7L     | 4V   | 2011 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.7L     | 4V   | 2011 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.7L     | 4V   | 2011 | Programmable Module Installation | FDIM        | ●     |
| MKT     | 3.7L     | 4V   | 2011 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.7L     | 4V   | 2012 | Programmable Parameters          | Power Seats | ●     |
| MKT     | 3.7L     | 4V   | 2012 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.7L     | 4V   | 2012 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.7L     | 4V   | 2012 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.7L     | 4V   | 2012 | Programmable Module Installation | FDIM        | ●     |
| MKT     | 3.7L     | 4V   | 2012 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DDM         | ●     |
| MKT     | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DSM         | ●     |
| MKT     | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | PCSM-2      | ●     |
| MKT     | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DCSM        | ●     |
| MKT     | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DDM         | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------|----------|------------|------|----------------------------------|--------------------------------|-------|
| MKT     | 3.7L     | TiVCT      | 2014 | Programmable Module Installation | DSM                            | ●     |
| MKT     | 3.7L     | TiVCT      | 2014 | Programmable Module Installation | PCSM-2                         | ●     |
| MKT     | Other    | Other      | 2014 | Programmable Module Installation | DCSM                           | ●     |
| MKT     | Other    | Other      | 2014 | Programmable Module Installation | DDM                            | ●     |
| MKT     | Other    | Other      | 2014 | Programmable Module Installation | DSM                            | ●     |
| MKT     | Other    | Other      | 2014 | Programmable Module Installation | PCSM-2                         | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Parameters          | Personality                    | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Parameters          | Interior Lighting              | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Parameters          | Audio Configure                | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Parameters          | Brake System Configuration     | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | DSP                            | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | IC                             | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | PAM                            | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| MKX     | 3.5L     | 4V         | 2007 | Programmable Module Installation | SDARS                          | ※     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Parameters          | Audio Configure                | ※     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Parameters          | Brake System Configuration     | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Module Installation | ACM                            | ※     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Module Installation | DSP                            | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| MKX     | 3.5L     | 4V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Parameters          | Personality                    | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Parameters          | Interior Lighting              | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Parameters          | Brake System Configuration     | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Module Installation | DCSM                           | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Module Installation | IC                             | ●     |
| MKX     | 3.5L     | 4V         | 2009 | Programmable Module Installation | PAM                            | ●     |

| Vehicle | Capacity | EngineType   | Year    | Module Programming               | System                 | Flags |
|---------|----------|--|---------|----------------------------------|------------------------|-------|
| MKX     | 3.5L     | 4V   | 2009    | Programmable Module Installation | RCM                    | ●     |
| MKX     | 3.5L     | 4V   | 2010    | Programmable Parameters          | Personality            | ●     |
| MKX     | 3.5L     | 4V   | 2010    | Programmable Parameters          | Interior Lighting      | ●     |
| MKX     | 3.5L     | 4V   | 2010    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| MKX     | 3.5L     | 4V   | 2010    | Programmable Module Installation | DCSM                   | ●     |
| MKX     | 3.5L     | 4V   | 2010    | Programmable Module Installation | IC                     | ●     |
| MKX     | 3.5L     | 4V   | 2010    | Programmable Module Installation | PAM                    | ●     |
| MKX     | 3.5L     | 4V   | 2010    | Programmable Module Installation | RCM                    | ●     |
| MKX     | 3.7L     | TiVCT  | 2011    | Programmable Module Installation | DCSM                   | ●     |
| MKX     | 3.7L     | TiVCT  | 2012    | Programmable Module Installation | DCSM                   | ●     |
| MKX     | 3.7L     | TiVCT  | 2013    | Programmable Module Installation | DCSM                   | ●     |
| MKX     | 3.7L     | TiVCT  | 2014    | Programmable Module Installation | DCSM                   | ●     |
| MKX     | Other    | Other  | 2014    | Programmable Module Installation | DCSM                   | ●     |
| Mondeo  | 1.6L     | DURATEC VCT  | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 1.6L     | DURATEC VCT  | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 1.6L     | Duratorq-Turbo Diesel<br>Common Rail Injection     | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 1.6L     | EcoBoost - Gas<br>Turbocharged Direct<br>Injection | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Parameters          | Security               | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Module Installation | GEM                    | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 1.8L     | DURATEC SCi  | 2001    | Programmable Module Installation | NAV                    | ※     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Parameters          | Security               | ●     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                    | 2001    | Programmable Module Installation | GEM                    | ●     |

| Vehicle | Capacity | EngineType                                     | Year    | Module Programming               | System                 | Flags |
|---------|----------|--|---------|----------------------------------|------------------------|-------|
| Mondeo  | 1.8L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 1.8L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | NAV                    | ※     |
| Mondeo  | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Parameters          | Security               | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Module Installation | GEM                    | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 1.8L     | Endura-DE                                      | Other   | Programmable Module Installation | NAV                    | ※     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Parameters          | Security               | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | GEM                    | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2001    | Programmable Module Installation | NAV                    | ※     |
| Mondeo  | 2.0L     | DURATEC-HE / I4                                | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Parameters          | Security               | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Module Installation | GEM                    | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 2.0L     | DURATORQ_DI                                    | 2001    | Programmable Module Installation | NAV                    | ※     |

| Vehicle | Capacity | EngineType   | Year    | Module Programming               | System                 | Flags |
|---------|----------|--|---------|----------------------------------|------------------------|-------|
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Security               | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | GEM                    | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | NAV                    | ※     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | EcoBoost - Gas<br>Turbocharged Direct<br>Injection     | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | EcoBoost - Gas<br>Turbocharged Direct<br>Injection     | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | Ecoboost GTDI -<br>Chinese market only                 | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.0L     | Ecoboost GTDI -<br>Chinese market only                 | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 2.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 2.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |

| Vehicle | Capacity | EngineType   | Year    | Module Programming               | System                 | Flags |
|---------|----------|--|---------|----------------------------------|------------------------|-------|
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Security               | ●     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | GEM                    | ●     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2001    | Programmable Module Installation | NAV                    | ※     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection         | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2. 2L    | Duratorq-Turbo Diesel<br>Common Rail Injection<br>StgV | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2. 3L    | DURATEC-HE / I4  | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2. 3L    | DURATEC-HE / I4  | 2011    | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Parameters          | Security               | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Parameters          | Power Windows          | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Module Installation | EATC                   | ※     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Module Installation | CDP                    | ※     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Module Installation | GDM                    | ※     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Module Installation | GEM                    | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Module Installation | HEC                    | ●     |
| Mondeo  | 2. 5L    | Duratec-VE   | 2001    | Programmable Module Installation | NAV                    | ※     |
| Mondeo  | 2. 5L    | I5   | 2007.25 | Programmable Module Installation | CDP                    | ●     |
| Mondeo  | 3. 0L    | Duratec-SE   | 2001    | Programmable Parameters          | Personality            | ●     |
| Mondeo  | 3. 0L    | Duratec-SE   | 2001    | Programmable Parameters          | Washer / Wiper         | ●     |
| Mondeo  | 3. 0L    | Duratec-SE   | 2001    | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mondeo  | 3. 0L    | Duratec-SE   | 2001    | Programmable Parameters          | Power Door Locks       | ●     |
| Mondeo  | 3. 0L    | Duratec-SE   | 2001    | Programmable Parameters          | Security               | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Mondeo  | 3.0L     | Duratec-SE | 2001 | Programmable Parameters          | Power Windows                  | ●     |
| Mondeo  | 3.0L     | Duratec-SE | 2001 | Programmable Module Installation | EATC                           | ※     |
| Mondeo  | 3.0L     | Duratec-SE | 2001 | Programmable Module Installation | CDP                            | ※     |
| Mondeo  | 3.0L     | Duratec-SE | 2001 | Programmable Module Installation | GDM                            | ※     |
| Mondeo  | 3.0L     | Duratec-SE | 2001 | Programmable Module Installation | GEM                            | ●     |
| Mondeo  | 3.0L     | Duratec-SE | 2001 | Programmable Module Installation | HEC                            | ●     |
| Mondeo  | 3.0L     | Duratec-SE | 2001 | Programmable Module Installation | NAV                            | ※     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Parameters          | Personality                    | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Parameters          | Power Door Locks               | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Parameters          | Security                       | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Parameters          | Power Windows                  | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Module Installation | EATC                           | ※     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Module Installation | CDP                            | ※     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Module Installation | GDM                            | ※     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Module Installation | GEM                            | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Module Installation | HEC                            | ●     |
| Mondeo  | 3.0L     | Duratec-ST | 2001 | Programmable Module Installation | NAV                            | ※     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Parameters          | Personality                    | ●     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Parameters          | Audio Configure                | ※     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Parameters          | Exterior Lighting              | ●     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Parameters          | Power Door Locks               | ●     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Module Installation | ACM                            | ※     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Module Installation | DSM                            | ●     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Module Installation | GEM                            | ●     |
| Montego | 3.0L     | 4V         | 2006 | Programmable Module Installation | IC                             | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Parameters          | Personality                    | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Parameters          | Audio Configure                | ※     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Parameters          | Exterior Lighting              | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Parameters          | Power Door Locks               | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Module Installation | GEM                            | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Module Installation | IC                             | ●     |
| Montego | 3.0L     | 4V         | 2007 | Programmable Module Installation | RCM                            | ●     |

| Vehicle                                 | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---|----------|------------|------|----------------------------------|--------------------------------|-------|
| Montego                                 | 3.0L     | 4V         | 2007 | Programmable Module Installation | SDARS                          | ※     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 2V         | 2004 | Programmable Module Installation | ABS/TCS                        | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2006 | Programmable Parameters          | Personality                    | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2006 | Programmable Module Installation | ABS/TCS                        | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2006 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2007 | Programmable Parameters          | Personality                    | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2007 | Programmable Module Installation | ABS/TCS                        | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2007 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2008 | Programmable Parameters          | Personality                    | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2008 | Programmable Module Installation | ABS/TCS                        | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2008 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2009 | Programmable Module Installation | ABS/TCS                        | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2009 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2011 | Programmable Parameters          | Vehicle                        | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2011 | Programmable Module Installation | ABS/TCS                        | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2011 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2012 | Programmable Parameters          | Vehicle                        | ※     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2012 | Programmable Module Installation | ABS                            | ※     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2012 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2013 | Programmable Parameters          | Vehicle                        | ※     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2013 | Programmable Module Installation | ABS                            | ※     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2013 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | 6.8L     | 3V         | 2014 | Programmable Module Installation | IC                             | ●     |
| Motorhome / Stripped Chassis / Step Van | Other    | Other      | 2014 | Programmable Module Installation | IC                             | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Parameters          | Audio Configure                | ※     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | ACM                            | ※     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | EATC                           | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | GEM                            | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2006 | Programmable Module Installation | SDARS                          | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer                             | 4.0L     | 2V         | 2007 | Programmable Parameters          | Audio Configure                | ※     |
| Mountaineer                             | 4.0L     | 2V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |



| Vehicle     | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|-------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | EATC                           | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | GEM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.0L     | 2V         | 2007 | Programmable Module Installation | SDARS                          | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Module Installation | GEM / SJB                      | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Module Installation | HVAC                           | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Module Installation | GEM / SJB                      | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Module Installation | HVAC                           | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Module Installation | GEM / SJB                      | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Module Installation | HVAC                           | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.0L     | 2V         | 2010 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1998 | Programmable Parameters          | Vehicle                        | ●     |

| Vehicle     | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|-------------|----------|------------|--------|----------------------------------|------------------------|-------|
| Mountaineer | 4.0L     | V6 SOHC    | 1998   | Programmable Parameters          | Washer / Wiper         | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1998   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1998   | Programmable Module Installation | ABS/TCS                | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1998   | Programmable Module Installation | GEM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1998   | Programmable Module Installation | RAP                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Vehicle                | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Washer / Wiper         | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1999   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1999   | Programmable Module Installation | ABS/TCS                | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1999   | Programmable Module Installation | GEM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 1999   | Programmable Module Installation | RAP                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Vehicle                | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Washer / Wiper         | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2000   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2000   | Programmable Module Installation | ABS/TCS                | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2000   | Programmable Module Installation | GEM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2000   | Programmable Module Installation | RAP                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Washer / Wiper         | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Parameters          | Climate Control        | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | CSM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | GEM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002   | Programmable Module Installation | IC                     | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Power Seats            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Security               | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Parameters          | Climate Control        | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | ABS/TCS                | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | CSM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | HEC                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2002.5 | Programmable Module Installation | TPM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Power Seats            | ●     |

| Vehicle     | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|-------------|----------|------------|--------|----------------------------------|------------------------|-------|
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Security               | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Parameters          | Climate Control        | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | ABS/TCS                | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | HEC                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | TPM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2003   | Programmable Module Installation | VSM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Power Seats            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | ABS                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | IC                     | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | TPM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2004   | Programmable Module Installation | VSM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Power Seats            | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Parameters          | Security               | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | ABS                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | IC                     | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | TPM                    | ●     |
| Mountaineer | 4.0L     | V6 SOHC    | 2005   | Programmable Module Installation | VSM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Washer / Wiper         | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Parameters          | Climate Control        | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Module Installation | CSM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Module Installation | GEM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2002   | Programmable Module Installation | IC                     | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Power Seats            | ●     |

| Vehicle     | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|-------------|----------|------------|--------|----------------------------------|------------------------|-------|
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Security               | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Parameters          | Climate Control        | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | ABS/TCS                | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | CSM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | HEC                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2002.5 | Programmable Module Installation | TPM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Power Seats            | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Security               | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Parameters          | Climate Control        | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Module Installation | ABS/TCS                | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Module Installation | HEC                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Module Installation | TPM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2003   | Programmable Module Installation | VSM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Power Seats            | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Module Installation | ABS                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Module Installation | IC                     | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Module Installation | TPM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2004   | Programmable Module Installation | VSM                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Parameters          | Personality            | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Parameters          | Power Seats            | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Parameters          | Power Door Locks       | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Parameters          | Security               | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Module Installation | ABS                    | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Module Installation | EATC                   | ●     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Module Installation | DSM                    | ※     |
| Mountaineer | 4.6L     | 2V         | 2005   | Programmable Module Installation | IC                     | ●     |

| Vehicle     | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|-------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Mountaineer | 4.6L     | 2V         | 2005 | Programmable Module Installation | TPM                            | ●     |
| Mountaineer | 4.6L     | 2V         | 2005 | Programmable Module Installation | VSM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Parameters          | Audio Configure                | ※     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | ACM                            | ※     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | EATC                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | GEM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2006 | Programmable Module Installation | SDARS                          | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Audio Configure                | ※     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | EATC                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | GEM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2007 | Programmable Module Installation | SDARS                          | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Module Installation | GEM / SJB                      | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Module Installation | HVAC                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |

| Vehicle     | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|-------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Module Installation | GEM / SJB                      | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Module Installation | HVAC                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Module Installation | ABS                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Module Installation | GEM / SJB                      | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Module Installation | HVAC                           | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Module Installation | PAM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Module Installation | RCM                            | ●     |
| Mountaineer | 4.6L     | 3V         | 2010 | Programmable Module Installation | RETM                           | ●     |
| Mountaineer | 5.0L     | Other      | 1997 | Programmable Module Installation | ABS/TCS                        | ●     |
| Mountaineer | 5.0L     | Other      | 1998 | Programmable Parameters          | Vehicle                        | ●     |
| Mountaineer | 5.0L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Mountaineer | 5.0L     | Other      | 1998 | Programmable Parameters          | Power Door Locks               | ●     |
| Mountaineer | 5.0L     | Other      | 1998 | Programmable Module Installation | ABS/TCS                        | ●     |
| Mountaineer | 5.0L     | Other      | 1998 | Programmable Module Installation | GEM                            | ●     |
| Mountaineer | 5.0L     | Other      | 1998 | Programmable Module Installation | RAP                            | ●     |
| Mountaineer | 5.0L     | Other      | 1999 | Programmable Parameters          | Vehicle                        | ●     |
| Mountaineer | 5.0L     | Other      | 1999 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Mountaineer | 5.0L     | Other      | 1999 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 5.0L     | Other      | 1999 | Programmable Parameters          | Power Door Locks               | ●     |
| Mountaineer | 5.0L     | Other      | 1999 | Programmable Module Installation | ABS/TCS                        | ●     |
| Mountaineer | 5.0L     | Other      | 1999 | Programmable Module Installation | GEM                            | ●     |
| Mountaineer | 5.0L     | Other      | 1999 | Programmable Module Installation | RAP                            | ●     |
| Mountaineer | 5.0L     | Other      | 2000 | Programmable Parameters          | Vehicle                        | ●     |
| Mountaineer | 5.0L     | Other      | 2000 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Mountaineer | 5.0L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Mountaineer | 5.0L     | Other      | 2000 | Programmable Parameters          | Power Door Locks               | ●     |
| Mountaineer | 5.0L     | Other      | 2000 | Programmable Module Installation | ABS/TCS                        | ●     |
| Mountaineer | 5.0L     | Other      | 2000 | Programmable Module Installation | GEM                            | ●     |
| Mountaineer | 5.0L     | Other      | 2000 | Programmable Module Installation | RAP                            | ●     |
| Mustang     | 3.7L     | TiVCT      | 2011 | Programmable Module Installation | FDIM                           | ●     |
| Mustang     | 3.7L     | TiVCT      | 2012 | Programmable Module Installation | FDIM                           | ●     |
| Mustang     | 3.7L     | TiVCT      | 2013 | Programmable Module Installation | FDIM                           | ●     |
| Mustang     | 3.7L     | TiVCT      | 2014 | Programmable Module Installation | FDIM                           | ●     |
| Mustang     | 3.8L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Mustang | 3.8L     | Other      | 2000 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 3.8L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 3.8L     | Other      | 2002 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 3.8L     | Other      | 2003 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 3.8L     | Other      | 2003 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 3.8L     | Other      | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 3.8L     | Other      | 2004 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 3.9L     | Other      | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 3.9L     | Other      | 2004 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2005 | Programmable Parameters          | Audio Configure                 | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2005 | Programmable Parameters          | Power Door Locks                | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2005 | Programmable Module Installation | ACM                             | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2005 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2005 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2006 | Programmable Parameters          | Audio Configure                 | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2006 | Programmable Module Installation | ACM                             | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2006 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2006 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2007 | Programmable Parameters          | Audio Configure                 | ※     |
| Mustang | 4.0L     | V6 SOHC    | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Mustang | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | ACM                             | ※     |
| Mustang | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | SDARS                           | ※     |
| Mustang | 4.0L     | V6 SOHC    | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2008 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2009 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.0L     | V6 SOHC    | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 4.6L     | 2V         | 2000 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 4.6L     | 2V         | 2000 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 2V         | 2002 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 4.6L     | 2V         | 2002 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 2V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 4.6L     | 2V         | 2003 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 2V         | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 4.6L     | 2V         | 2004 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 3V         | 2005 | Programmable Parameters          | Audio Configure                 | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|---------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Mustang | 4.6L     | 3V         | 2005 | Programmable Parameters          | Power Door Locks                | ●     |
| Mustang | 4.6L     | 3V         | 2005 | Programmable Module Installation | ACM                             | ●     |
| Mustang | 4.6L     | 3V         | 2005 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 3V         | 2005 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.6L     | 3V         | 2006 | Programmable Parameters          | Audio Configure                 | ●     |
| Mustang | 4.6L     | 3V         | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Mustang | 4.6L     | 3V         | 2006 | Programmable Module Installation | ACM                             | ●     |
| Mustang | 4.6L     | 3V         | 2006 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 3V         | 2006 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.6L     | 3V         | 2007 | Programmable Parameters          | Audio Configure                 | ※     |
| Mustang | 4.6L     | 3V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Mustang | 4.6L     | 3V         | 2007 | Programmable Module Installation | ACM                             | ※     |
| Mustang | 4.6L     | 3V         | 2007 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 3V         | 2007 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.6L     | 3V         | 2007 | Programmable Module Installation | SDARS                           | ※     |
| Mustang | 4.6L     | 3V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Mustang | 4.6L     | 3V         | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Mustang | 4.6L     | 3V         | 2008 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.6L     | 3V         | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Mustang | 4.6L     | 3V         | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Mustang | 4.6L     | 3V         | 2009 | Programmable Module Installation | IC                              | ●     |
| Mustang | 4.6L     | 3V         | 2010 | Programmable Module Installation | ABS                             | ●     |
| Mustang | 4.6L     | 3V         | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 4.6L     | 4V         | 2000 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 4.6L     | 4V         | 2000 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 4V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 4.6L     | 4V         | 2003 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 4.6L     | 4V         | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Mustang | 4.6L     | 4V         | 2004 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 5.0L     | BOSS       | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 5.0L     | BOSS       | 2013 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 5.0L     | TiVCT      | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 5.0L     | TiVCT      | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 5.0L     | TiVCT      | 2013 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 5.0L     | TiVCT      | 2014 | Programmable Module Installation | FDIM                            | ●     |
| Mustang | 5.4L     | 4V         | 2007 | Programmable Parameters          | Audio Configure                 | ※     |
| Mustang | 5.4L     | 4V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Mustang | 5.4L     | 4V         | 2007 | Programmable Module Installation | ACM                             | ※     |
| Mustang | 5.4L     | 4V         | 2007 | Programmable Module Installation | GEM                             | ●     |
| Mustang | 5.4L     | 4V         | 2007 | Programmable Module Installation | IC                              | ●     |
| Mustang | 5.4L     | 4V         | 2007 | Programmable Module Installation | SDARS                           | ※     |



| Vehicle   | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|-----------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Mustang   | 5.4L     | 4V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Mustang   | 5.4L     | 4V         | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Mustang   | 5.4L     | 4V         | 2008 | Programmable Module Installation | IC                              | ●     |
| Mustang   | 5.4L     | 4V         | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Mustang   | 5.4L     | 4V         | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Mustang   | 5.4L     | 4V         | 2009 | Programmable Module Installation | IC                              | ●     |
| Mustang   | 5.4L     | 4V         | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Mustang   | 5.4L     | 4V         | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Mustang   | 5.4L     | 4V         | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Mustang   | 5.8L     | 4V         | 2013 | Programmable Module Installation | FDIM                            | ●     |
| Mustang   | 5.8L     | 4V         | 2014 | Programmable Module Installation | FDIM                            | ●     |
| Mustang   | Other    | Other      | 2014 | Programmable Module Installation | FDIM                            | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Seats                     | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Parameters          | Audio Configure                 | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Door Locks                | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Parameters          | Power Steering                  | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Module Installation | ABS                             | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Module Installation | EATC                            | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Module Installation | DCSM                            | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Module Installation | DSM                             | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Module Installation | LTM                             | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Module Installation | NAV                             | ●     |
| Navigator | 5.4L     | 3V         | 2005 | Programmable Module Installation | VSM                             | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Seats                     | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Parameters          | Audio Configure                 | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Door Locks                | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Parameters          | Power Steering                  | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | ABS                             | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | EATC                            | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | DCSM                            | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | DSM                             | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | IC                              | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | LTM                             | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | NAV                             | ●     |
| Navigator | 5.4L     | 3V         | 2006 | Programmable Module Installation | VSM                             | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Seats                     | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Mirrors                   | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | ABS                             | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | ACM                             | ※     |

| Vehicle   | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|-----------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSP                            | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | IC                             | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | PAM                            | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCU                            | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Navigator | 5.4L     | 3V         | 2007 | Programmable Module Installation | SDARS                          | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Parameters          | Audio Configure                | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | ACM                            | ※     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSP                            | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | IC                             | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCU                            | ●     |
| Navigator | 5.4L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Mirrors                  | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Parameters          | Climate Control Seats          | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | DCSM                           | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | IC                             | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | PAM                            | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCU                            | ●     |
| Navigator | 5.4L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Mirrors                  | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Parameters          | Climate Control Seats          | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Module Installation | DCSM                           | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Module Installation | IC                             | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Module Installation | PAM                            | ●     |

| Vehicle   | Capacity | EngineType | Year | Module Programming               | System                | Flags |
|-----------|----------|------------|------|----------------------------------|-----------------------|-------|
| Navigator | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCM                   | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCU                   | ●     |
| Navigator | 5.4L     | 3V         | 2010 | Programmable Module Installation | RETM                  | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Seats           | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Mirrors         | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Parameters          | Climate Control Seats | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Module Installation | DCSM                  | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Module Installation | DSM                   | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Module Installation | IC                    | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Module Installation | RCU                   | ●     |
| Navigator | 5.4L     | 3V         | 2011 | Programmable Module Installation | RETM                  | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Seats           | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Mirrors         | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Parameters          | Climate Control Seats | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Module Installation | ACM                   | ※     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Module Installation | DCSM                  | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Module Installation | DSM                   | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Module Installation | IC                    | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Module Installation | PAM                   | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Module Installation | RCU                   | ●     |
| Navigator | 5.4L     | 3V         | 2012 | Programmable Module Installation | RETM                  | ●     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Seats           | ●     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Parameters          | Audio Configure       | ※     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Mirrors         | ●     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Parameters          | Climate Control Seats | ●     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Module Installation | DCSM                  | ●     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Module Installation | DSM                   | ●     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Module Installation | IC                    | ●     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Module Installation | PAM                   | ※     |
| Navigator | 5.4L     | 3V         | 2013 | Programmable Module Installation | RCU                   | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Seats           | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Parameters          | Audio Configure       | ※     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Mirrors         | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Parameters          | Climate Control Seats | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Module Installation | DCSM                  | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Module Installation | DSM                   | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Module Installation | IC                    | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Module Installation | PAM                   | ●     |
| Navigator | 5.4L     | 3V         | 2014 | Programmable Module Installation | RCU                   | ●     |
| Navigator | 5.4L     | 4V         | 1999 | Programmable Parameters          | Washer / Wiper        | ●     |
| Navigator | 5.4L     | 4V         | 1999 | Programmable Module Installation | GEM                   | ●     |

| Vehicle     | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|-------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Navigator   | 5.4L     | 4V         | 2000 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Navigator   | 5.4L     | 4V         | 2000 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator   | 5.4L     | 4V         | 2000 | Programmable Parameters          | Power Door Locks               | ●     |
| Navigator   | 5.4L     | 4V         | 2000 | Programmable Parameters          | Security                       | ※     |
| Navigator   | 5.4L     | 4V         | 2000 | Programmable Module Installation | GEM                            | ●     |
| Navigator   | 5.4L     | 4V         | 2000 | Programmable Module Installation | RAP                            | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Parameters          | Personality                    | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Parameters          | Power Seats                    | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Parameters          | Power Door Locks               | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Parameters          | Security                       | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | ABS/TCS                        | ※     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | EATC                           | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | DSM                            | ※     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | HEC                            | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | LTM                            | ※     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | NAV                            | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | TPM                            | ●     |
| Navigator   | 5.4L     | 4V         | 2003 | Programmable Module Installation | VSM                            | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Parameters          | Personality                    | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Parameters          | Power Seats                    | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Parameters          | Power Door Locks               | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Parameters          | Security                       | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | ABS/TCS                        | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | EATC                           | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | DSM                            | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | HEC                            | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | LTM                            | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | NAV                            | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | TPM                            | ●     |
| Navigator   | 5.4L     | 4V         | 2004 | Programmable Module Installation | VSM                            | ●     |
| Navigator   | 5.4L     | Other      | 1998 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Navigator   | 5.4L     | Other      | 1998 | Programmable Module Installation | GEM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Seats                    | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Parameters          | Power Mirrors                  | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | ABS                            | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | ACM                            | ※     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | DSP                            | ●     |

| Vehicle     | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|-------------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | IC                             | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | PAM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | RCU                            | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | RETM                           | ●     |
| Navigator L | 5.4L     | 3V         | 2007 | Programmable Module Installation | SDARS                          | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Parameters          | Audio Configure                | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | ACM                            | ※     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | DSP                            | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | IC                             | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | RCU                            | ●     |
| Navigator L | 5.4L     | 3V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Parameters          | Power Mirrors                  | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Parameters          | Climate Control Seats          | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | DCSM                           | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | DSM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | IC                             | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | PAM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | RCU                            | ●     |
| Navigator L | 5.4L     | 3V         | 2009 | Programmable Module Installation | RETM                           | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Seats                    | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Parameters          | Power Mirrors                  | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Parameters          | Climate Control Seats          | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Module Installation | DCSM                           | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Module Installation | DSM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Module Installation | IC                             | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Module Installation | PAM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCM                            | ●     |
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Module Installation | RCU                            | ●     |

| Vehicle     | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|-------------|----------|------------|------|----------------------------------|------------------------|-------|
| Navigator L | 5.4L     | 3V         | 2010 | Programmable Module Installation | RETM                   | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Seats            | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Parameters          | Power Mirrors          | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Parameters          | Climate Control Seats  | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Module Installation | DCSM                   | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Module Installation | DSM                    | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Module Installation | IC                     | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Module Installation | RCU                    | ●     |
| Navigator L | 5.4L     | 3V         | 2011 | Programmable Module Installation | RETM                   | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Seats            | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Parameters          | Power Mirrors          | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Parameters          | Climate Control Seats  | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Module Installation | ACM                    | ※     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Module Installation | DCSM                   | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Module Installation | DSM                    | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Module Installation | IC                     | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Module Installation | PAM                    | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Module Installation | RCU                    | ●     |
| Navigator L | 5.4L     | 3V         | 2012 | Programmable Module Installation | RETM                   | ●     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Seats            | ●     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Parameters          | Audio Configure        | ※     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Parameters          | Power Mirrors          | ●     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Parameters          | Climate Control Seats  | ●     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Module Installation | DCSM                   | ●     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Module Installation | DSM                    | ●     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Module Installation | IC                     | ●     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Module Installation | PAM                    | ※     |
| Navigator L | 5.4L     | 3V         | 2013 | Programmable Module Installation | RCU                    | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Seats            | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Parameters          | Audio Configure        | ※     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Parameters          | Power Mirrors          | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Parameters          | Climate Control Seats  | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Module Installation | DCSM                   | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Module Installation | DSM                    | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Module Installation | IC                     | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Module Installation | PAM                    | ●     |
| Navigator L | 5.4L     | 3V         | 2014 | Programmable Module Installation | RCU                    | ●     |
| NOVO KA     | 1.0L     | FFV        | 2008 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| NOVO KA     | 1.0L     | FFV        | 2008 | Programmable Parameters          | Security               | ●     |
| NOVO KA     | 1.0L     | FFV        | 2008 | Programmable Parameters          | Power Windows          | ●     |
| NOVO KA     | 1.0L     | FFV        | 2008 | Programmable Module Installation | IC                     | ※     |

| Vehicle | Capacity | EngineType  | Year | Module Programming               | System                       | Flags |
|---------|----------|-------------|------|----------------------------------|------------------------------|-------|
| NOVO KA | 1.0L     | FFV         | 2008 | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Parameters          | Personality                  | ※     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.0L     | FFV         | 2009 | Programmable Module Installation | TBM                          | ●     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Parameters          | Power Door Locks             | ※     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Module Installation | RKE                          | ※     |
| NOVO KA | 1.0L     | FFV         | 2011 | Programmable Module Installation | TBM                          | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2008 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.0L     | Zetec Rocam | 2008 | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2008 | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2008 | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.0L     | Zetec Rocam | 2008 | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Parameters          | Personality                  | ※     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.0L     | Zetec Rocam | 2009 | Programmable Module Installation | TBM                          | ●     |
| NOVO KA | 1.6L     | FFV         | 2008 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.6L     | FFV         | 2008 | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.6L     | FFV         | 2008 | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.6L     | FFV         | 2008 | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.6L     | FFV         | 2008 | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.6L     | FFV         | 2009 | Programmable Parameters          | Personality                  | ※     |
| NOVO KA | 1.6L     | FFV         | 2009 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.6L     | FFV         | 2009 | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.6L     | FFV         | 2009 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| NOVO KA | 1.6L     | FFV         | 2009 | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.6L     | FFV         | 2009 | Programmable Module Installation | IC                           | ※     |

| Vehicle | Capacity | EngineType      | Year   | Module Programming               | System                       | Flags |
|---------|----------|-----------------|--------|----------------------------------|------------------------------|-------|
| NOVO KA | 1.6L     | FFV             | 2009   | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.6L     | FFV             | 2009   | Programmable Module Installation | TBM                          | ●     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Parameters          | Power Door Locks             | ※     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Module Installation | RKE                          | ※     |
| NOVO KA | 1.6L     | FFV             | 2011   | Programmable Module Installation | TBM                          | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2008   | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2008   | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2008   | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2008   | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2008   | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Parameters          | Personality                  | ※     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Parameters          | Security                     | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Module Installation | IC                           | ※     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Module Installation | RKE                          | ●     |
| NOVO KA | 1.6L     | Zetec Rocam     | 2009   | Programmable Module Installation | TBM                          | ●     |
| NOVO KA | Other    | Other           | 2008   | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| NOVO KA | Other    | Other           | 2008   | Programmable Parameters          | Security                     | ●     |
| NOVO KA | Other    | Other           | 2008   | Programmable Parameters          | Power Windows                | ●     |
| NOVO KA | Other    | Other           | 2008   | Programmable Module Installation | IC                           | ※     |
| NOVO KA | Other    | Other           | 2008   | Programmable Module Installation | RKE                          | ●     |
| Puma    | 1.4L     | Zetec-SE        | 1999.5 | Programmable Parameters          | Power Door Locks             | ●     |
| Puma    | 1.4L     | Zetec-SE        | 1999.5 | Programmable Module Installation | GEM                          | ●     |
| Puma    | 1.6L     | Zetec-SE        | 2001   | Programmable Module Installation | GEM                          | ●     |
| Puma    | 1.7L     | Zetec-SE        | 1999.5 | Programmable Parameters          | Power Door Locks             | ●     |
| Puma    | 1.7L     | Zetec-SE        | 1999.5 | Programmable Module Installation | GEM                          | ●     |
| Puma    | 1.7L     | Zetec-SE        | 2001   | Programmable Module Installation | GEM                          | ●     |
| Ranger  | 2.3L     | DURATEC-HE / I4 | 2006   | Programmable Parameters          | Personality                  | ※     |
| Ranger  | 2.3L     | DURATEC-HE / I4 | 2006   | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| Ranger  | 2.3L     | DURATEC-HE / I4 | 2006   | Programmable Parameters          | Airbag                       | ※     |
| Ranger  | 2.3L     | DURATEC-HE / I4 | 2006   | Programmable Parameters          | Driveline                    | ●     |
| Ranger  | 2.3L     | DURATEC-HE / I4 | 2006   | Programmable Parameters          | Security                     | ●     |
| Ranger  | 2.3L     | DURATEC-HE / I4 | 2006   | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger  | 2.3L     | DURATEC-HE / I4 | 2006   | Programmable Module Installation | GEM                          | ●     |



| Vehicle                                  | Capacity | EngineType                                     | Year   | Module Programming               | System                       | Flags |
|--|----------|--|--------|----------------------------------|------------------------------|-------|
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2006   | Programmable Module Installation | IC                           | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Parameters          | Interior Lighting            | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Parameters          | Driveline                    | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Parameters          | Security                     | ※     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Parameters          | Power Windows                | ※     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Module Installation | GEM                          | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Module Installation | IC                           | ●     |
| Ranger                                   | 2.3L     | DURATEC-HE / I4                                | 2009.5 | Programmable Module Installation | TBM                          | ●     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Personality                  | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Interior Lighting            | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Warning Lamps / Chimes       | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Airbag                       | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Driveline                    | ●     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Security                     | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Parameters          | Power Windows                | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Module Installation | GEM                          | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Module Installation | IC                           | ※     |
| Ranger                                   | 3.0L     | I4 DSL Electronic                              | 2005.5 | Programmable Module Installation | TBM                          | ●     |
| Ranger / Courier / Mazda B-Series /Bravo | 4.0L     | V6 SOHC  | 2003   | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier        | 2.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Ranger / Mazda B-Series / Courier        | 2.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Module Installation | TBM                          | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2004   | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2004   | Programmable Parameters          | Security                     | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2004   | Programmable Module Installation | GEM                          | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2004   | Programmable Module Installation | IC                           | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2005   | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2005   | Programmable Parameters          | Security                     | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2005   | Programmable Module Installation | GEM                          | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2005   | Programmable Module Installation | IC                           | ※     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2006   | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2006   | Programmable Parameters          | Security                     | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2006   | Programmable Module Installation | GEM                          | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2006   | Programmable Module Installation | IC                           | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2007   | Programmable Parameters          | Personality                  | ●     |
| Ranger / Mazda B-Series / Courier        | 2.3L     | DURATEC-HE / I4                                | 2007   | Programmable Parameters          | Warning Lamps / Chimes       | ●     |

| Vehicle                           | Capacity | EngineType      | Year | Module Programming               | System                          | Flags |
|-----------------------------------|----------|-----------------|------|----------------------------------|---------------------------------|-------|
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | RCM                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2007 | Programmable Module Installation | SDARS                           | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2008 | Programmable Module Installation | RCM                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2009 | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2009 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2009 | Programmable Module Installation | RCM                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2010 | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2010 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2010 | Programmable Module Installation | ABS                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2010 | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2010 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2011 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2011 | Programmable Module Installation | ABS                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2011 | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | DURATEC-HE / I4 | 2011 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | OHC             | 1995 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | OHC             | 1996 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | OHC             | 1997 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 1996 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 1997 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2001 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2001 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2001 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2001 | Programmable Module Installation | GEM                             | ※     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2001 | Programmable Module Installation | RAP                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2002 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2002 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2002 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2002 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2002 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2002 | Programmable Module Installation | RAP                             | ●     |

| Vehicle                           | Capacity | EngineType      | Year | Module Programming               | System                       | Flags |
|-----------------------------------|----------|-----------------|------|----------------------------------|------------------------------|-------|
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2003 | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2003 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2003 | Programmable Parameters          | Security                     | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2003 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2003 | Programmable Module Installation | GEM                          | ●     |
| Ranger / Mazda B-Series / Courier | 2.3L     | Other           | 2003 | Programmable Module Installation | RAP                          | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011 | Programmable Parameters          | Tracking And Blocking Module | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | DURATEC-HE / I4 | 2011 | Programmable Module Installation | TBM                          | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 | Programmable Parameters          | Vehicle                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 | Programmable Module Installation | GEM                          | ※     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1998 | Programmable Module Installation | RAP                          | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1999 | Programmable Parameters          | Vehicle                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1999 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1999 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1999 | Programmable Module Installation | GEM                          | ※     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 1999 | Programmable Module Installation | RAP                          | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2000 | Programmable Parameters          | Vehicle                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2000 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2000 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2000 | Programmable Module Installation | GEM                          | ※     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2000 | Programmable Module Installation | RAP                          | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2001 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2001 | Programmable Parameters          | Security                     | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2001 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2001 | Programmable Module Installation | GEM                          | ※     |
| Ranger / Mazda B-Series / Courier | 2.5L     | Other           | 2001 | Programmable Module Installation | RAP                          | ●     |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001 | Programmable Parameters          | Security                     | ●     |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001 | Programmable Module Installation | GEM                          | ※     |
| Ranger / Mazda B-Series / Courier | 2.8L     | Other           | 2001 | Programmable Module Installation | RAP                          | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 | Programmable Parameters          | Vehicle                      | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 | Programmable Module Installation | ABS/TCS                      | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 | Programmable Module Installation | GEM                          | ※     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 1999 | Programmable Module Installation | RAP                          | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 2000 | Programmable Parameters          | Vehicle                      | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 2000 | Programmable Parameters          | Power Door Locks             | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV             | 2000 | Programmable Module Installation | ABS/TCS                      | ●     |

| Vehicle                           | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|-----------------------------------|----------|------------|------|----------------------------------|------------------------|-------|
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV        | 2000 | Programmable Module Installation | GEM                    | ※     |
| Ranger / Mazda B-Series / Courier | 3.0L     | FFV        | 2000 | Programmable Module Installation | RAP                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1995 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1996 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1997 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1998 | Programmable Parameters          | Vehicle                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1998 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1998 | Programmable Module Installation | GEM                    | ※     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1998 | Programmable Module Installation | RAP                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1999 | Programmable Parameters          | Vehicle                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1999 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1999 | Programmable Module Installation | GEM                    | ※     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 1999 | Programmable Module Installation | RAP                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2000 | Programmable Parameters          | Vehicle                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2000 | Programmable Module Installation | GEM                    | ※     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2000 | Programmable Module Installation | RAP                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2001 | Programmable Parameters          | Power Door Locks       | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2001 | Programmable Parameters          | Security               | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2001 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2001 | Programmable Module Installation | GEM                    | ※     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2001 | Programmable Module Installation | RAP                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2002 | Programmable Parameters          | Security               | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2002 | Programmable Module Installation | GEM                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2002 | Programmable Module Installation | RAP                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2003 | Programmable Parameters          | Security               | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2003 | Programmable Module Installation | GEM                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2003 | Programmable Module Installation | RAP                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2004 | Programmable Parameters          | Security               | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2004 | Programmable Module Installation | GEM                    | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other      | 2004 | Programmable Module Installation | IC                     | ●     |

| Vehicle                           | Capacity | EngineType                                     | Year | Module Programming               | System                          | Flags |
|-----------------------------------|----------|--|------|----------------------------------|---------------------------------|-------|
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2005 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2005 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2005 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2005 | Programmable Module Installation | IC                              | ※     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2006 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2006 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2006 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2007 | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2007 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2007 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2007 | Programmable Module Installation | RCM                             | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2007 | Programmable Module Installation | SDARS                           | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2008 | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2008 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 3.0L     | Other  | 2008 | Programmable Module Installation | RCM                             | ●     |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011 | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Ranger / Mazda B-Series / Courier | 3.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011 | Programmable Module Installation | TBM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1995 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1996 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1997 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1998 | Programmable Parameters          | Vehicle                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1998 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1998 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1998 | Programmable Module Installation | GEM                             | ※     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1998 | Programmable Module Installation | RAP                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1999 | Programmable Parameters          | Vehicle                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1999 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1999 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1999 | Programmable Module Installation | GEM                             | ※     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 1999 | Programmable Module Installation | RAP                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 2000 | Programmable Parameters          | Vehicle                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 2000 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 2000 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 2000 | Programmable Module Installation | GEM                             | ※     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other  | 2000 | Programmable Module Installation | RAP                             | ●     |

| Vehicle                           | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|-----------------------------------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2001 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2001 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2001 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2001 | Programmable Module Installation | GEM                             | ※     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2001 | Programmable Module Installation | RAP                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2002 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2002 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2002 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2002 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | Other      | 2002 | Programmable Module Installation | RAP                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2003 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2003 | Programmable Parameters          | Power Door Locks                | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2003 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2003 | Programmable Module Installation | ABS/TCS                         | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2003 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2003 | Programmable Module Installation | RAP                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2004 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2004 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2004 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2004 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2005 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2005 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2005 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2005 | Programmable Module Installation | IC                              | ※     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2006 | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2006 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2006 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2007 | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | RCM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2007 | Programmable Module Installation | SDARS                           | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2008 | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2008 | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC    | 2008 | Programmable Module Installation | RCM                             | ●     |

| Vehicle                           | Capacity | EngineType  | Year   | Module Programming               | System                          | Flags |
|-----------------------------------|----------|-------------|--------|----------------------------------|---------------------------------|-------|
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2009   | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2009   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2009   | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2009   | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2009   | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2009   | Programmable Module Installation | RCM                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2010   | Programmable Parameters          | Personality                     | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2010   | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2010   | Programmable Module Installation | ABS                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2010   | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2010   | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2011   | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2011   | Programmable Module Installation | ABS                             | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2011   | Programmable Module Installation | GEM / SJB                       | ●     |
| Ranger / Mazda B-Series / Courier | 4.0L     | V6 SOHC     | 2011   | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004   | Programmable Parameters          | Security                        | ●     |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004   | Programmable Module Installation | GEM                             | ●     |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2004   | Programmable Module Installation | IC                              | ●     |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011   | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| Ranger / Mazda B-Series / Courier | Other    | Other       | 2011   | Programmable Module Installation | TBM                             | ●     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006   | Programmable Parameters          | Personality                     | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006   | Programmable Parameters          | Warning Lamps / Chimes          | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006   | Programmable Parameters          | Security                        | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006   | Programmable Module Installation | IC                              | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2006   | Programmable Module Installation | RKE                             | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2009   | Programmable Parameters          | Personality                     | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2009   | Programmable Parameters          | Warning Lamps / Chimes          | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2009   | Programmable Parameters          | Security                        | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2009   | Programmable Parameters          | Ship Mode                       | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2009   | Programmable Module Installation | IC                              | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2009   | Programmable Module Installation | RKE                             | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Parameters          | Personality                     | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Parameters          | Warning Lamps / Chimes          | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Parameters          | Security                        | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Parameters          | Ship Mode                       | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Parameters          | Tracking And Blocking Module    | ●     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Module Installation | IC                              | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Module Installation | RKE                             | ※     |
| S. A. Fiesta                      | 1.0L     | FFV         | 2010   | Programmable Module Installation | TBM                             | ●     |
| S. A. Fiesta                      | 1.0L     | Zetec Rocam | 2002.5 | Programmable Parameters          | Personality                     | ※     |

| Vehicle      | Capacity | EngineType                                     | Year   | Module Programming               | System                 | Flags |
|--------------|----------|--|--------|----------------------------------|------------------------|-------|
| S. A. Fiesta | 1.0L     | Zetec Rocam                                    | 2002.5 | Programmable Parameters          | Interior Lighting      | ※     |
| S. A. Fiesta | 1.0L     | Zetec Rocam                                    | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| S. A. Fiesta | 1.0L     | Zetec Rocam                                    | 2002.5 | Programmable Parameters          | Security               | ※     |
| S. A. Fiesta | 1.0L     | Zetec Rocam                                    | 2002.5 | Programmable Parameters          | Ship Mode              | ※     |
| S. A. Fiesta | 1.0L     | Zetec Rocam                                    | 2002.5 | Programmable Module Installation | IC                     | ※     |
| S. A. Fiesta | 1.0L     | Zetec Rocam                                    | 2002.5 | Programmable Module Installation | RKE                    | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Parameters          | Personality            | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Parameters          | Interior Lighting      | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Parameters          | Security               | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Parameters          | Ship Mode              | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Module Installation | IC                     | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Module Installation | RKE                    | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Parameters          | Personality            | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Parameters          | Interior Lighting      | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Parameters          | Security               | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Parameters          | Ship Mode              | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Module Installation | IC                     | ※     |
| S. A. Fiesta | 1.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2011   | Programmable Module Installation | RKE                    | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2002.5 | Programmable Parameters          | Personality            | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2002.5 | Programmable Parameters          | Interior Lighting      | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2002.5 | Programmable Parameters          | Security               | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2002.5 | Programmable Parameters          | Ship Mode              | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2002.5 | Programmable Module Installation | IC                     | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2002.5 | Programmable Module Installation | RKE                    | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2006   | Programmable Parameters          | Personality            | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2006   | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2006   | Programmable Parameters          | Security               | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2006   | Programmable Module Installation | IC                     | ※     |
| S. A. Fiesta | 1.6L     | FFV  | 2006   | Programmable Module Installation | RKE                    | ※     |



| Vehicle      | Capacity | EngineType  | Year   | Module Programming               | System                       | Flags |
|--------------|----------|-------------|--------|----------------------------------|------------------------------|-------|
| S. A. Fiesta | 1.6L     | FFV         | 2009   | Programmable Parameters          | Personality                  | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2009   | Programmable Parameters          | Warning Lamps / Chimes       | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2009   | Programmable Parameters          | Security                     | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2009   | Programmable Parameters          | Ship Mode                    | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2009   | Programmable Module Installation | IC                           | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2009   | Programmable Module Installation | RKE                          | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Parameters          | Personality                  | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Parameters          | Warning Lamps / Chimes       | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Parameters          | Security                     | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Parameters          | Ship Mode                    | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Module Installation | IC                           | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Module Installation | RKE                          | ✳     |
| S. A. Fiesta | 1.6L     | FFV         | 2011   | Programmable Module Installation | TBM                          | ●     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2002.5 | Programmable Parameters          | Personality                  | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2002.5 | Programmable Parameters          | Interior Lighting            | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes       | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2002.5 | Programmable Parameters          | Security                     | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2002.5 | Programmable Parameters          | Ship Mode                    | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2002.5 | Programmable Module Installation | IC                           | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2002.5 | Programmable Module Installation | RKE                          | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2006   | Programmable Parameters          | Personality                  | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2006   | Programmable Parameters          | Warning Lamps / Chimes       | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2006   | Programmable Parameters          | Security                     | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2006   | Programmable Module Installation | IC                           | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2006   | Programmable Module Installation | RKE                          | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2009   | Programmable Parameters          | Personality                  | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2009   | Programmable Parameters          | Warning Lamps / Chimes       | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2009   | Programmable Parameters          | Security                     | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2009   | Programmable Parameters          | Ship Mode                    | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2009   | Programmable Module Installation | IC                           | ✳     |
| S. A. Fiesta | 1.6L     | Zetec Rocam | 2009   | Programmable Module Installation | RKE                          | ✳     |
| S.A. Courier | 1.6L     | FFV         | 2009   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| S.A. Courier | 1.6L     | FFV         | 2009   | Programmable Module Installation | TBM                          | ●     |
| S.A. Courier | 1.6L     | FFV         | 2011   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| S.A. Courier | 1.6L     | FFV         | 2011   | Programmable Module Installation | TBM                          | ●     |
| S.A. Courier | 1.6L     | Zetec Rocam | 2009   | Programmable Parameters          | Tracking And Blocking Module | ●     |
| S.A. Courier | 1.6L     | Zetec Rocam | 2009   | Programmable Module Installation | TBM                          | ●     |
| Sable        | 3.0L     | 2V          | 2003   | Programmable Parameters          | Warning Lamps / Chimes       | ●     |
| Sable        | 3.0L     | 2V          | 2003   | Programmable Parameters          | Power Door Locks             | ●     |
| Sable        | 3.0L     | 2V          | 2003   | Programmable Parameters          | Security                     | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|---------|----------|------------|------|----------------------------------|------------------------|-------|
| Sable   | 3.0L     | 2V         | 2003 | Programmable Module Installation | GEM                    | ●     |
| Sable   | 3.0L     | 2V         | 2004 | Programmable Module Installation | IC                     | ●     |
| Sable   | 3.0L     | 2V         | 2005 | Programmable Module Installation | IC                     | ●     |
| Sable   | 3.0L     | 4V         | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | 4V         | 1998 | Programmable Module Installation | RAP                    | ●     |
| Sable   | 3.0L     | 4V         | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | 4V         | 1999 | Programmable Module Installation | RAP                    | ●     |
| Sable   | 3.0L     | 4V         | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Sable   | 3.0L     | 4V         | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | 4V         | 2000 | Programmable Parameters          | Security               | ●     |
| Sable   | 3.0L     | 4V         | 2000 | Programmable Module Installation | GEM                    | ●     |
| Sable   | 3.0L     | 4V         | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Sable   | 3.0L     | 4V         | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | 4V         | 2002 | Programmable Parameters          | Security               | ●     |
| Sable   | 3.0L     | 4V         | 2002 | Programmable Module Installation | GEM                    | ●     |
| Sable   | 3.0L     | 4V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Sable   | 3.0L     | 4V         | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | 4V         | 2003 | Programmable Parameters          | Security               | ●     |
| Sable   | 3.0L     | 4V         | 2003 | Programmable Module Installation | GEM                    | ●     |
| Sable   | 3.0L     | 4V         | 2004 | Programmable Module Installation | IC                     | ●     |
| Sable   | 3.0L     | 4V         | 2005 | Programmable Module Installation | IC                     | ●     |
| Sable   | 3.0L     | FFV        | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Sable   | 3.0L     | FFV        | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | FFV        | 2000 | Programmable Parameters          | Security               | ●     |
| Sable   | 3.0L     | FFV        | 2000 | Programmable Module Installation | GEM                    | ●     |
| Sable   | 3.0L     | FFV        | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Sable   | 3.0L     | FFV        | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | FFV        | 2002 | Programmable Parameters          | Security               | ●     |
| Sable   | 3.0L     | FFV        | 2002 | Programmable Module Installation | GEM                    | ●     |
| Sable   | 3.0L     | FFV        | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Sable   | 3.0L     | FFV        | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | FFV        | 2003 | Programmable Parameters          | Security               | ●     |
| Sable   | 3.0L     | FFV        | 2003 | Programmable Module Installation | GEM                    | ●     |
| Sable   | 3.0L     | Other      | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | Other      | 1998 | Programmable Module Installation | RAP                    | ●     |
| Sable   | 3.0L     | Other      | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | Other      | 1999 | Programmable Module Installation | RAP                    | ●     |
| Sable   | 3.0L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Sable   | 3.0L     | Other      | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Sable   | 3.0L     | Other      | 2000 | Programmable Parameters          | Security               | ●     |
| Sable   | 3.0L     | Other      | 2000 | Programmable Module Installation | GEM                    | ●     |

| Vehicle   | Capacity | EngineType                                   | Year   | Module Programming               | System                         | Flags |
|-----------|----------|--|--------|----------------------------------|--------------------------------|-------|
| Sable     | 3.0L     | Other  | 2002   | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Sable     | 3.0L     | Other  | 2002   | Programmable Parameters          | Power Door Locks               | ●     |
| Sable     | 3.0L     | Other  | 2002   | Programmable Parameters          | Security                       | ●     |
| Sable     | 3.0L     | Other  | 2002   | Programmable Module Installation | GEM                            | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Parameters          | Power Seats                    | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Parameters          | Audio Configure                | ✖     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Parameters          | Rear Seat Entertainment Module | ✖     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Module Installation | ABS                            | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Module Installation | ACM                            | ✖     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Module Installation | DSM                            | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Module Installation | PAM                            | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Module Installation | RCM                            | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Module Installation | RETM                           | ●     |
| Sable     | 3.5L     | 4V   | 2008   | Programmable Module Installation | SECM                           | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Parameters          | Personality                    | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Parameters          | Power Seats                    | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Parameters          | Audio Configure                | ✖     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Parameters          | Rear Seat Entertainment Module | ✖     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | ABS                            | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | ACM                            | ✖     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | DSM                            | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | IC                             | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | PAM                            | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | RCM                            | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | RETM                           | ●     |
| Sable     | 3.5L     | 4V   | 2009   | Programmable Module Installation | SECM                           | ●     |
| Street Ka | 1.6L     | DURATEC 8V                                   | 2003.5 | Programmable Parameters          | Washer / Wiper                 | ●     |
| Street Ka | 1.6L     | DURATEC 8V                                   | 2003.5 | Programmable Module Installation | GEM                            | ●     |
| Street Ka | 1.6L     | DURATEC 8V                                   | 2003.5 | Programmable Module Installation | ECS                            | ●     |
| Taurus    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013   | Programmable Module Installation | DCSM                           | ●     |
| Taurus    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013   | Programmable Module Installation | DDM                            | ●     |
| Taurus    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2013   | Programmable Module Installation | DSM                            | ●     |
| Taurus    | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014   | Programmable Module Installation | DCSM                           | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System                 | Flags |
|---------|----------|--|------|----------------------------------|------------------------|-------|
| Taurus  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DDM                    | ●     |
| Taurus  | 2.0L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM                    | ●     |
| Taurus  | 3.0L     | 2V   | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Taurus  | 3.0L     | 2V   | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | 2V   | 2003 | Programmable Parameters          | Security               | ●     |
| Taurus  | 3.0L     | 2V   | 2003 | Programmable Module Installation | GEM                    | ●     |
| Taurus  | 3.0L     | 2V   | 2004 | Programmable Module Installation | IC                     | ●     |
| Taurus  | 3.0L     | 2V   | 2005 | Programmable Module Installation | IC                     | ●     |
| Taurus  | 3.0L     | 2V   | 2006 | Programmable Module Installation | IC                     | ●     |
| Taurus  | 3.0L     | 2V   | 2007 | Programmable Module Installation | IC                     | ●     |
| Taurus  | 3.0L     | 4V   | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | 4V   | 1998 | Programmable Module Installation | RAP                    | ●     |
| Taurus  | 3.0L     | 4V   | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | 4V   | 1999 | Programmable Module Installation | RAP                    | ●     |
| Taurus  | 3.0L     | 4V   | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Taurus  | 3.0L     | 4V   | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | 4V   | 2000 | Programmable Parameters          | Security               | ●     |
| Taurus  | 3.0L     | 4V   | 2000 | Programmable Module Installation | GEM                    | ●     |
| Taurus  | 3.0L     | 4V   | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Taurus  | 3.0L     | 4V   | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | 4V   | 2002 | Programmable Parameters          | Security               | ●     |
| Taurus  | 3.0L     | 4V   | 2002 | Programmable Module Installation | GEM                    | ●     |
| Taurus  | 3.0L     | 4V   | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Taurus  | 3.0L     | 4V   | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | 4V   | 2003 | Programmable Parameters          | Security               | ●     |
| Taurus  | 3.0L     | 4V   | 2003 | Programmable Module Installation | GEM                    | ●     |
| Taurus  | 3.0L     | 4V   | 2004 | Programmable Module Installation | IC                     | ●     |
| Taurus  | 3.0L     | 4V   | 2005 | Programmable Module Installation | IC                     | ●     |
| Taurus  | 3.0L     | FFV  | 1998 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | FFV  | 1998 | Programmable Module Installation | RAP                    | ●     |
| Taurus  | 3.0L     | FFV  | 1999 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | FFV  | 1999 | Programmable Module Installation | RAP                    | ●     |
| Taurus  | 3.0L     | FFV  | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Taurus  | 3.0L     | FFV  | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Taurus  | 3.0L     | FFV  | 2000 | Programmable Parameters          | Security               | ●     |
| Taurus  | 3.0L     | FFV  | 2000 | Programmable Module Installation | GEM                    | ●     |
| Taurus  | 3.0L     | FFV  | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Taurus  | 3.0L     | FFV  | 2002 | Programmable Parameters          | Power Door Locks       | ●     |

| Vehicle | Capacity | EngineType | Year | Module Programming               | System                         | Flags |
|---------|----------|------------|------|----------------------------------|--------------------------------|-------|
| Taurus  | 3.0L     | FFV        | 2002 | Programmable Parameters          | Security                       | ●     |
| Taurus  | 3.0L     | FFV        | 2002 | Programmable Module Installation | GEM                            | ●     |
| Taurus  | 3.0L     | FFV        | 2003 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Taurus  | 3.0L     | FFV        | 2003 | Programmable Parameters          | Power Door Locks               | ●     |
| Taurus  | 3.0L     | FFV        | 2003 | Programmable Parameters          | Security                       | ●     |
| Taurus  | 3.0L     | FFV        | 2003 | Programmable Module Installation | GEM                            | ●     |
| Taurus  | 3.0L     | Other      | 1998 | Programmable Parameters          | Power Door Locks               | ●     |
| Taurus  | 3.0L     | Other      | 1998 | Programmable Module Installation | RAP                            | ●     |
| Taurus  | 3.0L     | Other      | 1999 | Programmable Parameters          | Power Door Locks               | ●     |
| Taurus  | 3.0L     | Other      | 1999 | Programmable Module Installation | RAP                            | ●     |
| Taurus  | 3.0L     | Other      | 2000 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Taurus  | 3.0L     | Other      | 2000 | Programmable Parameters          | Power Door Locks               | ●     |
| Taurus  | 3.0L     | Other      | 2000 | Programmable Parameters          | Security                       | ●     |
| Taurus  | 3.0L     | Other      | 2000 | Programmable Module Installation | GEM                            | ●     |
| Taurus  | 3.0L     | Other      | 2002 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Taurus  | 3.0L     | Other      | 2002 | Programmable Parameters          | Power Door Locks               | ●     |
| Taurus  | 3.0L     | Other      | 2002 | Programmable Parameters          | Security                       | ●     |
| Taurus  | 3.0L     | Other      | 2002 | Programmable Module Installation | GEM                            | ●     |
| Taurus  | 3.4L     | SHO        | 1998 | Programmable Parameters          | Power Door Locks               | ●     |
| Taurus  | 3.4L     | SHO        | 1998 | Programmable Module Installation | RAP                            | ●     |
| Taurus  | 3.4L     | SHO        | 1999 | Programmable Parameters          | Power Door Locks               | ●     |
| Taurus  | 3.4L     | SHO        | 1999 | Programmable Module Installation | RAP                            | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Parameters          | Audio Configure                | ※     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Module Installation | ABS                            | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Module Installation | ACM                            | ※     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Module Installation | DSM                            | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Module Installation | PAM                            | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Module Installation | RCM                            | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Module Installation | RETM                           | ●     |
| Taurus  | 3.5L     | 4V         | 2008 | Programmable Module Installation | SECM                           | ●     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Parameters          | Personality                    | ●     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Parameters          | Audio Configure                | ※     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Module Installation | ABS                            | ●     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Module Installation | ACM                            | ※     |
| Taurus  | 3.5L     | 4V         | 2009 | Programmable Module Installation | DSM                            | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System          | Flags |
|---------|----------|--|------|----------------------------------|-----------------|-------|
| Taurus  | 3.5L     | 4V   | 2009 | Programmable Module Installation | IC              | ●     |
| Taurus  | 3.5L     | 4V   | 2009 | Programmable Module Installation | PAM             | ●     |
| Taurus  | 3.5L     | 4V   | 2009 | Programmable Module Installation | RCM             | ●     |
| Taurus  | 3.5L     | 4V   | 2009 | Programmable Module Installation | RETM            | ●     |
| Taurus  | 3.5L     | 4V   | 2009 | Programmable Module Installation | SECM            | ●     |
| Taurus  | 3.5L     | 4V   | 2010 | Programmable Parameters          | Power Seats     | ●     |
| Taurus  | 3.5L     | 4V   | 2010 | Programmable Parameters          | Audio Configure | ●     |
| Taurus  | 3.5L     | 4V   | 2010 | Programmable Module Installation | ACM             | ※     |
| Taurus  | 3.5L     | 4V   | 2010 | Programmable Module Installation | DCSM            | ●     |
| Taurus  | 3.5L     | 4V   | 2010 | Programmable Module Installation | DDM             | ●     |
| Taurus  | 3.5L     | 4V   | 2010 | Programmable Module Installation | DSM             | ●     |
| Taurus  | 3.5L     | 4V   | 2010 | Programmable Module Installation | FDIM            | ●     |
| Taurus  | 3.5L     | 4V   | 2011 | Programmable Parameters          | Power Seats     | ●     |
| Taurus  | 3.5L     | 4V   | 2011 | Programmable Parameters          | Audio Configure | ●     |
| Taurus  | 3.5L     | 4V   | 2011 | Programmable Module Installation | DCSM            | ●     |
| Taurus  | 3.5L     | 4V   | 2011 | Programmable Module Installation | DDM             | ●     |
| Taurus  | 3.5L     | 4V   | 2011 | Programmable Module Installation | DSM             | ●     |
| Taurus  | 3.5L     | 4V   | 2011 | Programmable Module Installation | FDIM            | ●     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Parameters          | Power Seats     | ●     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Parameters          | Audio Configure | ●     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Module Installation | ABS             | ●     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Module Installation | ACM             | ※     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Module Installation | DCSM            | ●     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Module Installation | DDM             | ●     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Module Installation | DSM             | ●     |
| Taurus  | 3.5L     | 4V   | 2012 | Programmable Module Installation | FDIM            | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Power Seats     | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Parameters          | Audio Configure | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | ACM             | ※     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DCSM            | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DDM             | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | DSM             | ●     |

| Vehicle | Capacity | EngineType                                   | Year | Module Programming               | System          | Flags |
|---------|----------|--|------|----------------------------------|-----------------|-------|
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2010 | Programmable Module Installation | FDIM            | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Parameters          | Power Seats     | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Parameters          | Audio Configure | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DCSM            | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DDM             | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | DSM             | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2011 | Programmable Module Installation | FDIM            | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Power Seats     | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Parameters          | Audio Configure | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | ABS             | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | ACM             | ※     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DCSM            | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DDM             | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | DSM             | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2012 | Programmable Module Installation | FDIM            | ●     |
| Taurus  | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DCSM            | ●     |

| Vehicle  | Capacity | EngineType                                   | Year | Module Programming               | System                         | Flags |
|----------|----------|--|------|----------------------------------|--------------------------------|-------|
| Taurus   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DDM                            | ●     |
| Taurus   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2013 | Programmable Module Installation | DSM                            | ●     |
| Taurus   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DCSM                           | ●     |
| Taurus   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DDM                            | ●     |
| Taurus   | 3.5L     | EcoBoost - Gas Turbocharged Direct Injection | 2014 | Programmable Module Installation | DSM                            | ●     |
| Taurus   | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DCSM                           | ●     |
| Taurus   | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DDM                            | ●     |
| Taurus   | 3.5L     | TiVCT  | 2013 | Programmable Module Installation | DSM                            | ●     |
| Taurus   | 3.5L     | TiVCT  | 2014 | Programmable Module Installation | DCSM                           | ●     |
| Taurus   | 3.5L     | TiVCT  | 2014 | Programmable Module Installation | DDM                            | ●     |
| Taurus   | 3.5L     | TiVCT  | 2014 | Programmable Module Installation | DSM                            | ●     |
| Taurus   | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DCSM                           | ●     |
| Taurus   | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DDM                            | ●     |
| Taurus   | 3.7L     | TiVCT  | 2013 | Programmable Module Installation | DSM                            | ●     |
| Taurus   | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DCSM                           | ●     |
| Taurus   | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DDM                            | ●     |
| Taurus   | 3.7L     | TiVCT  | 2014 | Programmable Module Installation | DSM                            | ●     |
| Taurus   | Other    | Other  | 2015 | Programmable Module Installation | DCSM                           | ●     |
| Taurus   | Other    | Other  | 2015 | Programmable Module Installation | DDM                            | ●     |
| Taurus   | Other    | Other  | 2015 | Programmable Module Installation | DSM                            | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Parameters          | Power Seats                    | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Parameters          | Audio Configure                | ※     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Module Installation | ABS                            | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Module Installation | ACM                            | ※     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Module Installation | DSM                            | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Module Installation | PAM                            | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Module Installation | RCM                            | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Module Installation | RETM                           | ●     |
| Taurus X | 3.5L     | 4V   | 2008 | Programmable Module Installation | SECM                           | ●     |
| Taurus X | 3.5L     | 4V   | 2009 | Programmable Parameters          | Personality                    | ●     |
| Taurus X | 3.5L     | 4V   | 2009 | Programmable Parameters          | Power Seats                    | ●     |
| Taurus X | 3.5L     | 4V   | 2009 | Programmable Parameters          | Audio Configure                | ※     |



| Vehicle     | Capacity | EngineType         | Year | Module Programming               | System                         | Flags |
|-------------|----------|--------------------|------|----------------------------------|--------------------------------|-------|
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Parameters          | Warning Lamps / Chimes         | ●     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Parameters          | Rear Seat Entertainment Module | ※     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | ABS                            | ●     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | ACM                            | ※     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | DSM                            | ●     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | IC                             | ●     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | PAM                            | ●     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | RCM                            | ●     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | RETM                           | ●     |
| Taurus X    | 3.5L     | 4V                 | 2009 | Programmable Module Installation | SECM                           | ●     |
| Territory   | 2.7L     | Direct Injection - | 2011 | Programmable Module Installation | BEM                            | ●     |
| Territory   | 2.7L     | Direct Injection - | 2011 | Programmable Module Installation | HIM                            | ●     |
| Territory   | 2.7L     | Direct Injection - | 2011 | Programmable Module Installation | PAM                            | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Parameters          | Personality                    | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Parameters          | Exterior Lighting              | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Parameters          | Police Mode                    | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Parameters          | Climate Control                | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Module Installation | BEM                            | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Module Installation | HIM                            | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Module Installation | PAM                            | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2004 | Programmable Module Installation | ABS                            | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Parameters          | Personality                    | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Parameters          | Exterior Lighting              | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Parameters          | Police Mode                    | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Parameters          | Climate Control                | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Module Installation | ABS                            | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Module Installation | BEM                            | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Module Installation | HIM                            | ※     |
| Territory   | 4.0L     | DOHC VCT           | 2006 | Programmable Module Installation | PAM                            | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2011 | Programmable Module Installation | BEM                            | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2011 | Programmable Module Installation | HIM                            | ●     |
| Territory   | 4.0L     | DOHC VCT           | 2011 | Programmable Module Installation | PAM                            | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Parameters          | Personality                    | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Parameters          | Power Seats                    | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Parameters          | Audio Configure                | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Parameters          | Power Door Locks               | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Parameters          | Security                       | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Module Installation | ABS/TCS                        | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Module Installation | ACM                            | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Module Installation | DDM                            | ●     |
| Thunderbird | 3.9L     | 4V                 | 2002 | Programmable Module Installation | GEM                            | ●     |

| Vehicle     | Capacity | EngineType | Year | Module Programming               | System            | Flags |
|-------------|----------|------------|------|----------------------------------|-------------------|-------|
| Thunderbird | 3.9L     | 4V         | 2002 | Programmable Module Installation | HEC               | ●     |
| Thunderbird | 3.9L     | 4V         | 2002 | Programmable Module Installation | REM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Parameters          | Personality       | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Parameters          | Power Seats       | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Parameters          | Power Door Locks  | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Parameters          | Security          | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Module Installation | ABS/TCS           | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Module Installation | DDM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Module Installation | GEM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Module Installation | HEC               | ●     |
| Thunderbird | 3.9L     | 4V         | 2003 | Programmable Module Installation | REM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Parameters          | Personality       | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Parameters          | Power Seats       | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Parameters          | Power Door Locks  | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Parameters          | Security          | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Module Installation | ABS/TCS           | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Module Installation | DDM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Module Installation | GEM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Module Installation | HEC               | ●     |
| Thunderbird | 3.9L     | 4V         | 2004 | Programmable Module Installation | REM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Parameters          | Personality       | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Parameters          | Power Seats       | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Parameters          | Power Door Locks  | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Parameters          | Security          | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Module Installation | ABS/TCS           | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Module Installation | DDM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Module Installation | GEM               | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Module Installation | HEC               | ●     |
| Thunderbird | 3.9L     | 4V         | 2005 | Programmable Module Installation | REM               | ●     |
| Town Car    | 4.6L     | 2V         | 1998 | Programmable Parameters          | Exterior Lighting | ●     |
| Town Car    | 4.6L     | 2V         | 1998 | Programmable Parameters          | Power Door Locks  | ●     |
| Town Car    | 4.6L     | 2V         | 1998 | Programmable Parameters          | Security          | ●     |
| Town Car    | 4.6L     | 2V         | 1998 | Programmable Module Installation | ACM               | ●     |
| Town Car    | 4.6L     | 2V         | 1998 | Programmable Module Installation | DDM               | ●     |
| Town Car    | 4.6L     | 2V         | 1998 | Programmable Module Installation | LCM               | ●     |
| Town Car    | 4.6L     | 2V         | 1999 | Programmable Parameters          | Exterior Lighting | ●     |
| Town Car    | 4.6L     | 2V         | 1999 | Programmable Parameters          | Power Door Locks  | ●     |
| Town Car    | 4.6L     | 2V         | 1999 | Programmable Parameters          | Security          | ●     |
| Town Car    | 4.6L     | 2V         | 1999 | Programmable Module Installation | ACM               | ●     |
| Town Car    | 4.6L     | 2V         | 1999 | Programmable Module Installation | DDM               | ●     |
| Town Car    | 4.6L     | 2V         | 1999 | Programmable Module Installation | LCM               | ●     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|----------|----------|------------|------|----------------------------------|------------------------|-------|
| Town Car | 4.6L     | 2V         | 2000 | Programmable Parameters          | Power Seats            | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Parameters          | Exterior Lighting      | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Parameters          | Power Door Locks       | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Parameters          | Security               | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Module Installation | ACM                    | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Module Installation | DDM                    | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Module Installation | DSM                    | ●     |
| Town Car | 4.6L     | 2V         | 2000 | Programmable Module Installation | LCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Parameters          | Power Seats            | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Parameters          | Exterior Lighting      | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Parameters          | Security               | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Module Installation | ACM                    | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Module Installation | DDM                    | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Module Installation | DSM                    | ●     |
| Town Car | 4.6L     | 2V         | 2002 | Programmable Module Installation | LCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Parameters          | Power Seats            | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Parameters          | Audio Configure        | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Parameters          | Exterior Lighting      | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Parameters          | Security               | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Module Installation | ACM                    | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Module Installation | DDM                    | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Module Installation | DSM                    | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Module Installation | LCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Module Installation | NAV                    | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Module Installation | RASM                   | ●     |
| Town Car | 4.6L     | 2V         | 2003 | Programmable Module Installation | RCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Parameters          | Power Seats            | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Parameters          | Audio Configure        | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Parameters          | Exterior Lighting      | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Parameters          | Power Door Locks       | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Parameters          | Security               | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Module Installation | ACM                    | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Module Installation | DDM                    | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Module Installation | DSM                    | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Module Installation | LCM                    | ●     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                 | Flags |
|----------|----------|------------|------|----------------------------------|------------------------|-------|
| Town Car | 4.6L     | 2V         | 2004 | Programmable Module Installation | NAV                    | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Module Installation | RASM                   | ●     |
| Town Car | 4.6L     | 2V         | 2004 | Programmable Module Installation | RCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Parameters          | Power Seats            | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Parameters          | Audio Configure        | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Parameters          | Exterior Lighting      | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Parameters          | Power Door Locks       | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Parameters          | Security               | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | ACM                    | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | EATC                   | ※     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | DDM                    | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | DSM                    | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | LCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | NAV                    | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | RASM                   | ●     |
| Town Car | 4.6L     | 2V         | 2005 | Programmable Module Installation | RCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Parameters          | Power Seats            | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Parameters          | Audio Configure        | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Parameters          | Exterior Lighting      | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Parameters          | Power Door Locks       | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | EATC                   | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | DDM                    | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | DSM                    | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | IC                     | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | LCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | NAV                    | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | RATC                   | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | RASM                   | ●     |
| Town Car | 4.6L     | 2V         | 2006 | Programmable Module Installation | RCM                    | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Parameters          | Power Seats            | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Parameters          | Audio Configure        | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Parameters          | Exterior Lighting      | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Parameters          | Power Door Locks       | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | EATC                   | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | DDM                    | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | DSM                    | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | IC                     | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | LCM                    | ●     |

| Vehicle  | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|----------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | NAV                             | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | RATC                            | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | RCM                             | ●     |
| Town Car | 4.6L     | 2V         | 2007 | Programmable Module Installation | VDM                             | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Parameters          | Power Seats                     | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Module Installation | DDM                             | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Module Installation | DSM                             | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Module Installation | HVAC                            | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Module Installation | IC                              | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Module Installation | LCM                             | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Module Installation | RATC                            | ●     |
| Town Car | 4.6L     | 2V         | 2008 | Programmable Module Installation | RCM                             | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Parameters          | Power Seats                     | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Module Installation | ABS                             | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Module Installation | DSM                             | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Module Installation | HVAC                            | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Module Installation | IC                              | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Module Installation | LCM                             | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Module Installation | RATC                            | ●     |
| Town Car | 4.6L     | 2V         | 2009 | Programmable Module Installation | RCM                             | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Parameters          | Power Seats                     | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Parameters          | Exterior Lighting               | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Parameters          | Power Door Locks                | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | ABS                             | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | DDM                             | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | DSM                             | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | HVAC                            | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | IC                              | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | LCM                             | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | RATC                            | ●     |
| Town Car | 4.6L     | 2V         | 2010 | Programmable Module Installation | RCM                             | ●     |
| Town Car | 4.6L     | 2V         | 2011 | Programmable Parameters          | Power Seats                     | ●     |
| Town Car | 4.6L     | 2V         | 2011 | Programmable Parameters          | Exterior Lighting               | ●     |

| Vehicle  | Capacity | EngineType                                     | Year   | Module Programming               | System                          | Flags |
|----------|----------|--|--------|----------------------------------|---------------------------------|-------|
| Town Car | 4.6L     | 2V   | 2011   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Parameters          | Power Door Locks                | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | ABS                             | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | DDM                             | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | DSM                             | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | HVAC                            | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | IC                              | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | LCM                             | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | RATC                            | ●     |
| Town Car | 4.6L     | 2V   | 2011   | Programmable Module Installation | RCM                             | ●     |
| Transit  | 2.0L     | DURATORQ_DI                                    | 2001   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Transit  | 2.0L     | DURATORQ_DI                                    | 2001   | Programmable Parameters          | Vehicle Speed Limiter           | ●     |
| Transit  | 2.0L     | DURATORQ_DI                                    | 2001   | Programmable Module Installation | CSM                             | ●     |
| Transit  | 2.0L     | DURATORQ_DI                                    | 2001   | Programmable Module Installation | EPB                             | ●     |
| Transit  | 2.0L     | DURATORQ_DI                                    | 2001   | Programmable Module Installation | HEC                             | ●     |
| Transit  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2001   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Transit  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2001   | Programmable Parameters          | Vehicle Speed Limiter           | ●     |
| Transit  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2001   | Programmable Module Installation | CSM                             | ●     |
| Transit  | 2.0L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2001   | Programmable Module Installation | HEC                             | ●     |
| Transit  | 2.2L     | Duratorq-Turbo Diesel<br>Common Rail Inj Stage | 2006.5 | Programmable Module Installation | ACM                             | ※     |
| Transit  | 2.2L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2006.5 | Programmable Module Installation | ACM                             | ※     |
| Transit  | 2.3L     | DOHC SFI(16V)                                  | 2001   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Transit  | 2.3L     | DOHC SFI(16V)                                  | 2001   | Programmable Module Installation | CSM                             | ●     |
| Transit  | 2.3L     | DOHC SFI(16V)                                  | 2001   | Programmable Module Installation | HEC                             | ●     |
| Transit  | 2.3L     | DURATEC-HE / I4                                | 2006.5 | Programmable Module Installation | ACM                             | ※     |
| Transit  | 2.4L     | DURATORQ_DI                                    | 2000   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Transit  | 2.4L     | DURATORQ_DI                                    | 2000   | Programmable Parameters          | Vehicle Speed Limiter           | ●     |
| Transit  | 2.4L     | DURATORQ_DI                                    | 2000   | Programmable Module Installation | CSM                             | ●     |
| Transit  | 2.4L     | DURATORQ_DI                                    | 2000   | Programmable Module Installation | EPB                             | ●     |
| Transit  | 2.4L     | DURATORQ_DI                                    | 2000   | Programmable Module Installation | HEC                             | ●     |
| Transit  | 2.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2000   | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Transit  | 2.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2000   | Programmable Parameters          | Vehicle Speed Limiter           | ●     |
| Transit  | 2.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2000   | Programmable Module Installation | CSM                             | ●     |
| Transit  | 2.4L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2000   | Programmable Module Installation | HEC                             | ●     |

| Vehicle         | Capacity | EngineType                                  | Year   | Module Programming               | System                 | Flags |
|-----------------|----------|---|--------|----------------------------------|------------------------|-------|
| Transit         | 2.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2006.5 | Programmable Module Installation | ACM                    | ※     |
| Transit         | 2.4L     | Duratorq-Turbo Diesel Common Rail Injection | 2006.5 | Programmable Module Installation | TBM                    | ●     |
| Transit         | 3.2L     | Duratorq-Turbo Diesel Common Rail Injection | 2006.5 | Programmable Module Installation | ACM                    | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010   | Programmable Parameters          | Personality            | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010   | Programmable Parameters          | Audio Configure        | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010   | Programmable Module Installation | ACM                    | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010   | Programmable Module Installation | IC                     | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010   | Programmable Module Installation | RCM                    | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2010   | Programmable Module Installation | VSM                    | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2011   | Programmable Parameters          | Personality            | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2011   | Programmable Parameters          | Audio Configure        | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2011   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2011   | Programmable Module Installation | ACM                    | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2011   | Programmable Module Installation | IC                     | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2011   | Programmable Module Installation | VSM                    | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Parameters          | Personality            | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Parameters          | Audio Configure        | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Parameters          | Power Door Locks       | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Module Installation | ABS                    | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Module Installation | ACM                    | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Module Installation | GEM / SJB              | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Module Installation | IC                     | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2012   | Programmable Module Installation | VSM                    | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Parameters          | Personality            | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Parameters          | Audio Configure        | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Parameters          | Power Door Locks       | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Module Installation | ABS                    | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Module Installation | ACM                    | ※     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Module Installation | GEM / SJB              | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Module Installation | IC                     | ●     |
| Transit Connect | 2.0L     | DURATEC-HE / I4                             | 2013   | Programmable Module Installation | VSM                    | ●     |
| Transit Connect | 28kWh    | Battery Electric                            | 2011   | Programmable Parameters          | Personality            | ●     |
| Transit Connect | 28kWh    | Battery Electric                            | 2011   | Programmable Parameters          | Audio Configure        | ※     |
| Transit Connect | 28kWh    | Battery Electric                            | 2011   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect | 28kWh    | Battery Electric                            | 2011   | Programmable Module Installation | ACM                    | ※     |
| Transit Connect | 28kWh    | Battery Electric                            | 2011   | Programmable Module Installation | IC                     | ●     |

| Vehicle                           | Capacity | EngineType                                     | Year   | Module Programming               | System                 | Flags |
|-----------------------------------|----------|--|--------|----------------------------------|------------------------|-------|
| Transit Connect                   | 28kWh    | Battery Electric                               | 2011   | Programmable Module Installation | VSM                    | ●     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Parameters          | Personality            | ●     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Parameters          | Audio Configure        | ※     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Parameters          | Power Door Locks       | ●     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Module Installation | ABS                    | ※     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Module Installation | ACM                    | ※     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Module Installation | GEM / SJB              | ●     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Module Installation | IC                     | ●     |
| Transit Connect                   | 28kWh    | Battery Electric                               | 2013   | Programmable Module Installation | VSM                    | ●     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Parameters          | Personality            | ●     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Parameters          | Audio Configure        | ※     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Parameters          | Power Door Locks       | ●     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Module Installation | ABS                    | ※     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Module Installation | ACM                    | ※     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Module Installation | GEM / SJB              | ●     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Module Installation | IC                     | ●     |
| Transit Connect                   | Other    | Other  | 2013   | Programmable Module Installation | VSM                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Parameters          | Vehicle Speed Limiter  | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Module Installation | CSM                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Module Installation | HEC                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2002.5 | Programmable Module Installation | ECS                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007   | Programmable Parameters          | Audio Configure        | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007   | Programmable Module Installation | ABS                    | ※     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007   | Programmable Module Installation | CSM                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007   | Programmable Module Installation | ECS                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2007   | Programmable Module Installation | SRM                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2009.5 | Programmable Module Installation | ACM                    | ※     |
| Transit Connect / Tourneo Connect | 1.8L     | Duratorq-Turbo Diesel<br>Common Rail Injection | 2009.5 | Programmable Module Installation | RCM                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                      | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI                                      | 2002.5 | Programmable Parameters          | Vehicle Speed Limiter  | ●     |



| Vehicle                           | Capacity | EngineType | Year   | Module Programming               | System                 | Flags |
|-----------------------------------|----------|------------|--------|----------------------------------|------------------------|-------|
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI  | 2002.5 | Programmable Module Installation | CSM                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI  | 2002.5 | Programmable Module Installation | HEC                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Endura DI  | 2002.5 | Programmable Module Installation | ECS                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec      | 2002.5 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec      | 2002.5 | Programmable Module Installation | CSM                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec      | 2002.5 | Programmable Module Installation | HEC                    | ●     |
| Transit Connect / Tourneo Connect | 1.8L     | Zetec      | 2002.5 | Programmable Module Installation | ECS                    | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Interior Lighting      | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Washer / Wiper         | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Exterior Lighting      | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Power Door Locks       | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Security               | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Outside temperature    | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Parameters          | Climate Control        | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Module Installation | ABS/TCS                | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Module Installation | DDM                    | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Module Installation | FEM                    | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Module Installation | IC                     | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Module Installation | MC                     | ●     |
| Windstar                          | 3.0L     | V6 OHV     | 1999   | Programmable Module Installation | REM                    | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Interior Lighting      | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Washer / Wiper         | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Exterior Lighting      | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Power Door Locks       | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Security               | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Outside temperature    | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Parameters          | Climate Control        | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Module Installation | ABS/TCS                | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Module Installation | DDM                    | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Module Installation | FEM                    | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Module Installation | IC                     | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Module Installation | MC                     | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 1999   | Programmable Module Installation | REM                    | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 2000   | Programmable Parameters          | Personality            | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 2000   | Programmable Parameters          | Interior Lighting      | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 2000   | Programmable Parameters          | Exterior Lighting      | ●     |
| Windstar                          | 3.8L     | V6 OHV     | 2000   | Programmable Parameters          | Warning Lamps / Chimes | ※     |
| Windstar                          | 3.8L     | V6 OHV     | 2000   | Programmable Parameters          | Power Door Locks       | ※     |
| Windstar                          | 3.8L     | V6 OHV     | 2000   | Programmable Parameters          | Security               | ※     |

| Vehicle    | Capacity | EngineType        | Year | Module Programming               | System                 | Flags |
|------------|----------|-------------------|------|----------------------------------|------------------------|-------|
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Parameters          | Outside temperature    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Parameters          | Washer / Wiper         | ※     |
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Module Installation | ABS/TCS                | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Module Installation | DDM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Module Installation | FEM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Module Installation | IC                     | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Module Installation | MC                     | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2000 | Programmable Module Installation | REM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Parameters          | Personality            | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Parameters          | Interior Lighting      | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Parameters          | Exterior Lighting      | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Parameters          | Power Door Locks       | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Parameters          | Security               | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Module Installation | ABS/TCS                | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Module Installation | DDM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Module Installation | FEM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Module Installation | IC                     | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Module Installation | MC                     | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2002 | Programmable Module Installation | REM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Parameters          | Personality            | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Parameters          | Interior Lighting      | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Parameters          | Exterior Lighting      | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Parameters          | Warning Lamps / Chimes | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Parameters          | Power Door Locks       | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Parameters          | Security               | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Module Installation | ABS/TCS                | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Module Installation | DDM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Module Installation | FEM                    | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Module Installation | IC                     | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Module Installation | MC                     | ●     |
| Windstar   | 3.8L     | V6 OHV            | 2003 | Programmable Module Installation | REM                    | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Parameters          | Power Seats            | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Parameters          | Audio Configure        | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | DCSM                   | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | DDM                    | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | DSM                    | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | FDIM                   | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2011 | Programmable Module Installation | PAM                    | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Parameters          | Power Seats            | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Parameters          | Audio Configure        | ●     |

| Vehicle    | Capacity | EngineType        | Year | Module Programming               | System                          | Flags |
|------------|----------|-------------------|------|----------------------------------|---------------------------------|-------|
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | DCSM                            | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | DDM                             | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | DSM                             | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Zephyr/MKZ | 2.5L     | HEV / ATKINSON 4V | 2012 | Programmable Module Installation | PAM                             | ●     |
| Zephyr/MKZ | 3.0L     | 4V                | 2006 | Programmable Parameters          | Audio Configure                 | ※     |
| Zephyr/MKZ | 3.0L     | 4V                | 2006 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Zephyr/MKZ | 3.0L     | 4V                | 2006 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Zephyr/MKZ | 3.0L     | 4V                | 2006 | Programmable Module Installation | ACM                             | ※     |
| Zephyr/MKZ | 3.0L     | 4V                | 2006 | Programmable Module Installation | DSP                             | ●     |
| Zephyr/MKZ | 3.0L     | 4V                | 2006 | Programmable Module Installation | IC                              | ●     |
| Zephyr/MKZ | 3.0L     | 4V                | 2006 | Programmable Module Installation | RCM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Parameters          | Personality                     | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Parameters          | Power Seats                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Parameters          | Audio Configure                 | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Parameters          | Exterior Lighting               | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Parameters          | Power Door Locks                | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Module Installation | ACM                             | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Module Installation | DSM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Module Installation | DSP                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Module Installation | GEM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Module Installation | IC                              | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Module Installation | RCM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2007 | Programmable Module Installation | SDARS                           | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Personality                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Power Seats                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Audio Configure                 | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Exterior Lighting               | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Power Door Locks                | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Security                        | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Rear Seat Entertainment Module  | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Module Installation | ACM                             | ※     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Module Installation | DSM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Module Installation | DSP                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Module Installation | GEM / SJB                       | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Module Installation | IC                              | ●     |
| Zephyr/MKZ | 3.5L     | 4V                | 2008 | Programmable Module Installation | PAM                             | ●     |

| Vehicle    | Capacity | EngineType | Year | Module Programming               | System                          | Flags |
|------------|----------|------------|------|----------------------------------|---------------------------------|-------|
| Zephyr/MKZ | 3.5L     | 4V         | 2008 | Programmable Module Installation | RCM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Parameters          | Personality                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Parameters          | Power Seats                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Parameters          | Exterior Lighting               | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Parameters          | Warning Lamps / Chimes          | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Parameters          | Power Door Locks                | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Parameters          | Security                        | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Parameters          | Tire Pressure Monitoring System | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Module Installation | ABS                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Module Installation | DCSM                            | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Module Installation | DSM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Module Installation | GEM / SJB                       | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Module Installation | IC                              | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Module Installation | PAM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2009 | Programmable Module Installation | RCM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Parameters          | Power Seats                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Parameters          | Audio Configure                 | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Module Installation | ABS                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Module Installation | DCSM                            | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Module Installation | DDM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Module Installation | DSM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Module Installation | FDIM                            | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2010 | Programmable Module Installation | PAM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Parameters          | Power Seats                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Parameters          | Audio Configure                 | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Module Installation | ABS                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Module Installation | DCSM                            | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Module Installation | DDM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Module Installation | DSM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Module Installation | FDIM                            | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2011 | Programmable Module Installation | PAM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Parameters          | Power Seats                     | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Parameters          | Audio Configure                 | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Module Installation | ABS                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Module Installation | DCSM                            | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Module Installation | DDM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Module Installation | DSM                             | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Module Installation | FDIM                            | ●     |
| Zephyr/MKZ | 3.5L     | 4V         | 2012 | Programmable Module Installation | PAM                             | ●     |