

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
China MG3 Zero(2013)	Rain sensor	Rain sensor	●	●	●	●	●	○	
China MG3 Zero(2013)	SAS	SAS	●	●	○	●	●	○	0064 0065
Thailand MG3 TT	Engine	EMS	●	●	●	●	●	●	0027 0028
Thailand MG3 TT	Engine	EMS	●	●	●	●	●	●	0027 0028
Thailand MG3 TT	Engine	EMS	●	●	●	●	●	●	0017 0028 0025
Thailand MG3 TT	Engine	EMS	●	●	●	●	●	●	0028
Thailand MG3 TT	AT System	TCM	●	●	○	●	●	●	0071
Thailand MG3 TT	ABS	ABS/SCS	●	●	○	●	●	●	0001
Thailand MG3 TT	ABS	ABS/SCS	●	●	○	●	●	●	0001 0034
Thailand MG3 TT	SRS System	SRS	●	●	○	●	●	●	
Thailand MG3 TT	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
Thailand MG3 TT	VECU System	BCM	●	●	●	●	●	●	0019 0056
Thailand MG3 TT	Rain sensor	Rain sensor	●	●	●	●	●	○	
Thailand MG3 TT	SAS	SAS	●	●	○	●	●	○	0064 0065
China MG5	Engine	EMS	●	●	●	●	●	●	0028
China MG5	Engine	EMS	●	●	●	●	●	●	0017 0045 0028 0025
China MG5	AT System	TCM	●	●	○	●	●	●	0011
China MG5	AT System	TCM	●	●	○	●	●	●	0009 0011
China MG5	AT System	TCM	●	●	●	●	●	●	0009
China MG5	ABS	ABS/SCS	●	●	●	●	●	●	
China MG5	ABS	ABS/SCS	●	●	●	●	●	●	
China MG5	ABS	ABS/SCS	●	●	○	●	●	●	0034
China MG5	ABS	ABS/SCS	●	●	○	●	●	●	0007
China MG5	SRS System	SRS	●	●	○	●	●	●	
China MG5	Instrument Panel System	IPK	●	●	●	●	●	●	0057 0008
China MG5	VECU System	BCM	●	●	●	●	●	●	0019 0056
China MG5	Automatic Air-	AC	●	●	●	●	●	●	
China MG5	SAS	SAS	●	●	○	○	●	○	0029
China MG6	Engine	EMS	●	●	●	●	●	●	0028
China MG6	Engine	EMS	●	●	●	●	●	●	0028
China MG6	Engine	EMS	●	●	●	●	●	●	0028
China MG6	AT System	AT	●	●	○	●	●	○	0070
China MG6	ABS	ABS/SCS	●	●	○	●	●	●	0001 0051
China MG6	ABS	ABS/SCS	●	●	○	●	●	●	0001 0051
China MG6	ABS	ABS/SCS	●	●	○	●	●	●	0001 0051
China MG6	ABS	ABS/SCS	●	●	○	●	●	●	0001 0051

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
China MG6	SRS System	SRS	●	●	○	●	●	○	
China MG6	SRS System	SRS	●	●	○	●	●	●	
China MG6	Instrument Panel	IPK	●	●	●	●	●	●	0008 0057
China MG6	VECU System	BCM	●	●	●	●	●	●	0016 0019 0056
China MG6	Automatic Air-conditioning System	ATC	●	●	●	●	●	○	
China MG6	Rain sensor	Rain sensor	●	●	○	●	●	○	
China MG6	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	
China MG6	PDC	PDC	●	●	○	●	●	○	
China MG6	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	○	0012
China MG6	ETC	ETC	●	●	○	●	●	○	
China MG6(2013)	Engine	EMS	●	●	●	●	●	●	0027 0017 0028
China MG6(2013)	AT System	TCM	●	●	○	●	●	●	0023 0067 0069 0072
China MG6(2013)	ABS	ABS/SCS	●	●	○	●	●	●	0001 0002 0051
China MG6(2013)	ABS	ABS/SCS	●	●	○	●	●	●	0001 0002 0051
China MG6(2013)	SRS System	SRS	●	●	○	●	●	●	
China MG6(2013)	Instrument Panel	IPK	●	●	●	●	●	●	0008 0057
China MG6(2013)	EPB	EPB	●	●	●	●	●	●	0035 0063 0049 0048 0047
China MG6(2013)	VECU System	BCM	●	●	●	●	●	●	0019 0056
China MG6(2013)	Automatic Air-conditioning System	ATC	●	●	●	●	●	●	
China MG6(2013)	Rain sensor	Rain sensor	●	●	○	●	●	○	
China MG6(2013)	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	
China MG6(2013)	PDC	PDC	●	●	○	●	●	○	
China MG6(2013)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	○	0012
China MG6(2013)	ETC	ETC	●	●	○	●	●	○	
China MG6(2013)	SCU	SCU	●	●	●	●	●	●	
China MG6(2014)	Engine	EMS	●	●	●	●	●	●	0027 0038 0040 0017 0028 0025
China MG6(2014)	Engine	EMS	●	●	●	●	●	●	0027 0038 0028 0025
China MG6(2014)	Engine	EMS	●	●	●	●	●	●	0013 0041
China MG6(2014)	AT System	TCM	●	●	○	●	●	●	0023 0067 0069 0068
China MG6(2014)	DSC	DSC	●	●	○	●	●	●	0001 0052 0051
China MG6(2014)	SRS System	SRS	●	●	○	●	●	●	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
China MG6(2014)	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
China MG6(2014)	EPB	EPB	●	●	●	●	●	●	0035 0063 0049 0048 0047
China MG6(2014)	VECU System	BCM	●	●	●	●	●	●	0019 0056
China MG6(2014)	Automatic Air-	ATC	●	●	●	●	●	●	
China MG6(2014)	EHPS	EHPS	●	●	○	●	●	○	
China MG6(2014)	AFS	AFS	●	●	●	●	●	●	0053 0033
China MG6(2014)	SAS	SAS	●	●	○	●	●	○	0031 0032
China MG6(2014)	Rain sensor	Rain sensor	●	●	○	●	●	○	
China MG6(2014)	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	
China MG6(2014)	PDC	PDC	●	●	○	●	●	○	
China MG6(2014)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	0058
China MG6(2014)	In-Vehicle	In-Vehicle	●	●	●	●	●	●	
China MG6(2014)	ETC	ETC	●	●	○	●	●	○	
China MG6(2014)	SCU	SCU	●	●	○	●	●	●	
China MG6(2014)	TBOX	TBOX	●	●	○	●	●	●	0004 0006 0005
EU MG6 EU(2014)	Engine	EMS	●	●	●	●	●	●	0027 0038 0040 0017 0028 0025
EU MG6 EU(2014)	Engine	EMS	●	●	●	●	●	●	0027 0038 0028 0025
EU MG6 EU(2014)	Engine	EMS	●	●	●	●	●	●	0013 0041
EU MG6 EU(2014)	AT System	TCM	●	●	○	●	●	●	0023 0067 0069 0068
EU MG6 EU(2014)	DSC	DSC	●	●	○	●	●	●	0001 0052 0051
EU MG6 EU(2014)	SRS System	SRS	●	●	○	●	●	●	
EU MG6 EU(2014)	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
EU MG6 EU(2014)	EPB	EPB	●	●	●	●	●	●	0035 0063 0049 0048 0047
EU MG6 EU(2014)	VECU System	BCM	●	●	●	●	●	●	0019 0056
EU MG6 EU(2014)	Automatic Air-conditioning System	ATC	●	●	●	●	●	●	
EU MG6 EU(2014)	EHPS	EHPS	●	●	○	●	●	○	
EU MG6 EU(2014)	AFS	AFS	●	●	●	●	●	●	0053 0033
EU MG6 EU(2014)	SAS	SAS	●	●	○	●	●	○	0031 0032
EU MG6 EU(2014)	Rain sensor	Rain sensor	●	●	○	●	●	○	
EU MG6 EU(2014)	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	
EU MG6 EU(2014)	PDC	PDC	●	●	○	●	●	○	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
EU MG6 EU(2014)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	0058
EU MG6 EU(2014)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	
EU MG6 EU(2014)	ETC	ETC	●	●	○	●	●	○	
EU MG6 EU(2014)	SCU	SCU	●	●	○	●	●	●	
EU MG6 EU(2014)	TBOX	TBOX	●	●	○	●	●	●	0004 0006 0005
Thailand MG6 TT(2015)	Engine	EMS	●	●	●	●	●	●	0027 0038 0040 0017 0028 0025
Thailand MG6 TT(2015)	Engine	EMS	●	●	●	●	●	●	0027 0038 0028 0025
Thailand MG6 TT(2015)	Engine	EMS	●	●	●	●	●	●	0013 0041
Thailand MG6 TT(2015)	AT System	TCM	●	●	○	●	●	●	0023 0067 0069 0068
Thailand MG6 TT(2015)	DSC	DSC	●	●	○	●	●	●	0001 0052 0051
Thailand MG6 TT(2015)	SRS System	SRS	●	●	○	●	●	●	
Thailand MG6 TT(2015)	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
Thailand MG6 TT(2015)	EPB	EPB	●	●	●	●	●	●	0035 0063 0049 0048 0047 0044 0043 0042
Thailand MG6 TT(2015)	VECU System	BCM	●	●	●	●	●	●	0019 0056
Thailand MG6 TT(2015)	Automatic Air-conditioning System	ATC	●	●	●	●	●	●	
Thailand MG6 TT(2015)	EHPS	EHPS	●	●	○	●	●	○	
Thailand MG6 TT(2015)	AFS	AFS	●	●	●	●	●	●	0053 0033
Thailand MG6 TT(2015)	SAS	SAS	●	●	○	●	●	○	0031 0032
Thailand MG6 TT(2015)	Rain sensor	Rain sensor	●	●	○	●	●	○	
Thailand MG6 TT(2015)	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
Thailand MG6 TT (2015)	PDC	PDC	●	●	○	●	●	○	
Thailand MG6 TT (2015)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	0058
Thailand MG6 TT (2015)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	
Thailand MG6 TT (2015)	ETC	ETC	●	●	○	●	●	○	
Thailand MG6 TT (2015)	SCU	SCU	●	●	○	●	●	●	
Thailand MG6 TT (2015)	TBOX	TBOX	●	●	○	●	●	●	0004 0006 0005
China MG7 (2008)	Engine	EMS	●	●	●	●	●	●	0028
China MG7 (2008)	AT System	AT System	●	●	○	●	●	●	0011 0010
China MG7 (2008)	ABS	ABS/SCS	●	●	○	●	●	○	0036
China MG7 (2008)	ABS	ABS/SCS	●	●	○	●	●	○	
China MG7 (2008)	SRS System	Rain sensor	●	●	○	●	●	○	
China MG7 (2008)	Instrument Panel System	IPK	●	●	●	●	●	○	0008
China MG7 (2008)	VECU System	BCM	●	●	●	●	●	○	0055
China MG7 (2008)	Automatic Air-conditioning System	ATC	●	●	●	●	●	○	
China MG7 (2008)	Skylight	Skylight	●	●	●	●	●	○	
China MG7 (2008)	Immobilizer System	Immobilizer System	●	●	●	●	●	○	0056
China MG7 (2008)	Gateway	Gateway	●	●	○	○	●	●	
China MG7 (2008)	Light	Light	●	●	●	●	●	○	0016
China MG7 (2008)	Rain sensor	Rain sensor	●	●	○	●	●	○	
China MG7 (2008)	Seat with memory function	Seat with memory function	●	●	●	●	●	○	
China MG7 (2009)	Engine	EMS	●	●	●	●	●	●	0028
China MG7 (2009)	AT System	AT System	●	●	○	●	●	●	0010
China MG7 (2009)	AT System	AT System	●	●	○	●	●	●	0011 0010
China MG7 (2009)	ABS	ABS/SCS	●	●	○	●	●	○	0036
China MG7 (2009)	ABS	ABS/SCS	●	●	○	●	●	○	0036
China MG7 (2009)	ABS	ABS/SCS	●	●	○	●	●	○	0036 0066
China MG7 (2009)	SRS System	Rain sensor	●	●	○	●	●	○	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
China MG7(2009)	Instrument Panel System	IPK	●	●	○	●	●	○	0008
China MG7(2009)	VECU System	BCM	●	●	●	○	●	○	
China MG7(2009)	Automatic Air-conditioning System	ATC	●	●	●	●	●	○	
China MG7(2009)	Power Window	Power Window	●	●	○	○	●	○	
China MG7(2009)	Immobilizer System	Immobilizer System	●	●	●	●	●	○	0056
China MG7(2009)	Gateway	Gateway	●	●	○	○	●	●	
China MG7(2009)	Light	Light	●	●	○	○	●	○	
China MG7(2009)	FRSM	FRSM	●	●	○	○	●	○	
China MG7(2009)	RLSM	RLSM	●	●	○	○	●	○	
China MG7(2009)	RRSM	RRSM	●	●	○	○	●	○	
China MG7(2009)	Rain sensor	Rain sensor	●	●	○	○	●	○	
China MG7(2009)	Seat with memory function	Seat with memory function	●	●	○	○	●	○	
China MG7-L	Engine	EMS	●	●	●	●	●	●	0028
China MG7-L	AT System	AT System	●	●	○	●	●	●	0010
China MG7-L	ABS	ABS/SCS	●	●	○	●	●	○	0036
China MG7-L	SRS System	Rain sensor	●	●	○	●	●	○	
China MG7-L	Instrument Panel System	IPK	●	●	●	●	●	○	0008
China MG7-L	VECU System	BCM	●	●	●	●	●	○	0056
China MG7-L	Automatic Air-conditioning System	ATC	●	●	●	●	●	○	
China MG7-L	Skylight	Skylight	●	●	●	●	●	○	
China MG7-L	Immobilizer System	Immobilizer System	●	●	●	●	●	○	0056
China MG7-L	Light	Light	●	●	●	●	●	○	0016
China MG7-L	Rain sensor	Rain sensor	●	●	○	●	●	○	
China MG7-L	Seat with memory function	Seat with memory function	●	●	●	●	●	○	
China MG GT(1.4T)	Engine	EMS	●	●	●	●	●	●	0017 0045 0028 0025
China MG GT(1.4T)	AT System	TCM	●	●	●	●	●	●	
China MG GT(1.4T)	ABS	ABS/SCS	●	●	○	●	●	●	0001 0034
China MG GT(1.4T)	ABS	ABS/SCS	●	●	○	●	●	●	0001 0007
China MG GT(1.4T)	SRS System	SRS	●	●	●	●	●	●	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
China MG GT(1.4T)	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
China MG GT(1.4T)	VECU System	BCM	●	●	●	●	●	●	0019 0056
China MG GT(1.4T)	Electronic Power Steering System	Electronic Power Steering	●	●	●	●	●	●	0030
China MG GT(1.4T)	Automatic Air-conditioning System	ATC	●	●	●	●	●	●	0037
China MG GT(1.4T)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	
China MG GT(1.4T)	Gateway	Gateway	●	●	●	●	●	●	0046 0059
China MG GT(1.4T)	SAS	SAS	●	●	○	●	●	●	0029
China MG GT(1.4T)	TBOX	TBOX	●	●	●	●	●	●	0004 0006
China MG GT(1.5VCT/1.5T)	Engine	EMS	●	●	●	●	●	●	0017 0045 0028 0025
China MG GT(1.5VCT/1.5T)	AT System	TCM	●	●	○	●	●	●	0009 0011
China MG GT(1.5VCT/1.5T)	AT System	TCM	●	●	●	●	●	●	0009
China MG GT(1.5VCT/1.5T)	ABS	ABS/SCS	●	●	○	●	●	●	0001 0034
China MG GT(1.5VCT/1.5T)	ABS	ABS/SCS	●	●	○	●	●	●	0007 0001
China MG GT(1.5VCT/1.5T)	SRS System	SRS	●	●	●	●	●	●	
China MG GT(1.5VCT/1.5T)	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
China MG GT(1.5VCT/1.5T)	VECU System	BCM	●	●	●	●	●	●	0019 0056
China MG GT(1.5VCT/1.5T)	Electronic Power Steering System	Electronic Power Steering	●	●	●	●	●	●	0030
China MG GT(1.5VCT/1.5T)	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	
China MG GT(1.5VCT/1.5T)	SAS	SAS	●	●	○	●	●	●	0029
China MG GT(1.5VCT/1.5T)	TBOX	TBOX	●	●	●	●	●	●	0004 0006
China MG GT(1.5VCT/1.5T)	TBOX	TBOX	●	●	○	●	●	●	0004 0006

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
Thailand MG5	Engine	EMS	●	●	●	●	●	●	0017 0045 0028 0025
Thailand MG5	AT System	TCM	●	●	○	●	●	●	0009 0011
Thailand MG5	AT System	TCM	●	●	●	●	●	●	0009
Thailand MG5	ABS	ABS/SCS	●	●	○	●	●	●	0001 0034
Thailand MG5	ABS	ABS/SCS	●	●	○	●	●	●	0007 0001
Thailand MG5	SRS System	SRS	●	●	●	●	●	●	
Thailand MG5	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
Thailand MG5	VECU System	BCM	●	●	●	●	●	●	0019 0056
Thailand MG5	Electronic Power Steering System	Electronic Power Steering	●	●	●	●	●	●	0030
Thailand MG5	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	
Thailand MG5	SAS	SAS	●	●	○	●	●	●	0029
Thailand MG5	TBOX	TBOX	●	●	●	●	●	●	0004 0006
Thailand MG5	TBOX	TBOX	●	●	○	●	●	●	0004 0006
China MG GS	Engine	EMS	●	●	●	●	●	●	0028
China MG GS	Engine	EMS	●	●	●	●	●	●	0028
China MG GS	AT System	TCM	●	●	○	●	●	●	0023 0069 0072 0015
China MG GS	AT System	TCM	●	●	●	●	●	●	0073
China MG GS	ABS	DSC	●	●	○	●	●	●	0036 0039 0022
China MG GS	ABS	DSC	●	●	○	●	●	●	0036
China MG GS	SRS System	SRS	●	●	○	●	●	●	
China MG GS	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
China MG GS	EPB	EPB	●	●	○	●	●	●	0021 0020 0061 0062
China MG GS	VECU System	BCM	●	●	●	●	●	●	0014
China MG GS	PEPS	PEPS	●	●	○	●	●	●	
China MG GS	Automatic Air-conditioning System	AC	●	●	●	●	●	●	0037
China MG GS	AFS	AFS	●	●	●	●	●	●	0033
China MG GS	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	0018
China MG GS	SCU	SCU	●	●	○	●	●	●	
China MG GS	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	●	●	●	
China MG GS	Gateway	Gateway	●	●	○	●	●	●	0054 0060
China MG GS	PDC	PDC	●	●	●	●	●	●	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
China MG GS	PMC	PMC	●	●	○	●	●	●	
China MG GS	SAS	SAS	●	●	○	●	●	●	0031 0032
China MG GS	TBOX	TBOX	●	●	○	●	●	●	0004 0006
China MG GS	TBOX	TBOX	●	●	○	●	●	●	
China MG GS	TCCM	TCCM	●	●	●	●	●	●	0050
EU MG3 EU	Engine	EMS	●	●	●	●	●	●	0027 0028
EU MG3 EU	Engine	EMS	●	●	●	●	●	●	0017 0028 0025
EU MG3 EU	ABS	DSC	●	●	○	●	●	●	0001 0034
EU MG3 EU	SRS System	SRS	●	●	○	●	●	●	
EU MG3 EU	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
EU MG3 EU	VECU System	BCM	●	●	●	●	●	●	0019 0056
EU MG3 EU	Rain sensor	Rain sensor	●	●	●	●	●	○	
EU MG3 EU	SAS	SAS	●	●	○	●	●	○	0065 0064
EU MG6 EU	Engine	EMS	●	●	●	●	●	●	0028
EU MG6 EU	ABS	ABS/SCS	●	●	○	●	●	●	0001 0002 0051
EU MG6 EU	SRS System	SRS	●	●	○	●	●	●	
EU MG6 EU	Instrument Panel System	IPK	●	●	●	●	●	●	0057
EU MG6 EU	VECU System	BCM	●	●	●	●	●	●	0016 0056
EU MG6 EU	Automatic Air-conditioning System	ATC	●	●	●	●	●	○	
EU MG6 EU	Rain sensor	Rain sensor	●	●	●	●	●	○	
EU MG6 EU	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	
EU MG6 EU	PDC	PDC	●	●	○	●	●	○	
EU MG6 EU	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	○	●	○	0012
EU MG6 EU	ETC	ETC	●	●	○	●	●	○	
EU MG6 EU DIESEL	Engine	EMS	●	●	●	●	●	●	0013 0041
EU MG6 EU DIESEL	ABS	ABS/SCS	●	●	○	●	●	●	0001 0002 0051
EU MG6 EU DIESEL	SRS System	SRS	●	●	○	●	●	●	
EU MG6 EU DIESEL	Instrument Panel System	IPK	●	●	●	●	●	●	0057
EU MG6 EU DIESEL	VECU System	BCM	●	●	●	●	●	●	0016 0056
EU MG6 EU DIESEL	Automatic Air-conditioning System	ATC	●	●	●	●	●	○	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
EU MG6 EU DIESEL	Rain sensor	Rain sensor	●	●	●	●	●	○	
EU MG6 EU DIESEL	EHPS	EHPS	●	●	○	●	●	○	
EU MG6 EU DIESEL	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	
EU MG6 EU DIESEL	PDC	PDC	●	●	○	●	●	○	
EU MG6 EU DIESEL	In-Vehicle entertainment	In-Vehicle entertainment	●	●	●	○	●	○	0012
MG 750	Engine	EMS	●	●	●	●	●	●	0028
MG 750	AT System	AT System	●	●	○	●	●	●	0010
MG 750	ABS	ABS/SCS	●	●	○	●	●	○	0036
MG 750	SRS System	Rain sensor	●	●	○	●	●	○	
MG 750	Instrument Panel System	IPK	●	●	●	●	●	○	0008
MG 750	VECU System	BCM	●	●	●	●	●	○	0055
MG 750	Automatic Air-conditioning System	ATC	●	●	●	●	●	○	
MG 750	Skylight	Skylight	●	●	●	●	●	○	
MG 750	Immobilizer System	Immobilizer System	●	●	●	●	●	○	0056
MG 750	Light	Light	●	●	●	●	●	○	0016
MG 750	Rain sensor	Rain sensor	●	●	○	●	●	○	
MG 750	Seat with memory function	Seat with memory function	●	●	●	●	●	○	
Thailand MG6 TT	Engine	EMS	●	●	●	●	●	●	0027 0028
Thailand MG6 TT	AT System	TCM	●	●	○	●	●	●	0023 0067 0069 0068
Thailand MG6 TT	ABS	ABS/SCS	●	●	○	●	●	●	0001
Thailand MG6 TT	ABS	ABS/SCS	●	●	○	●	●	●	0001 0002 0051、
Thailand MG6 TT	SRS System	SRS	●	●	○	●	●	●	
Thailand MG6 TT	Instrument Panel System	IPK	●	●	●	●	●	●	0008 0057
Thailand MG6 TT	EPB	EPB	●	●	●	●	●	●	0035 0063 0049 0048 0047 0044 0043 0042
Thailand MG6 TT	VECU System	BCM	●	●	●	●	●	●	0019 0056
Thailand MG6 TT	Automatic Air-conditioning System	ATC	●	●	●	●	●	●	
Thailand MG6 TT	Electronic Power Steering System	Electronic Power Steering	●	●	○	●	●	●	

Model	System	System Type	Read Codes	Erase Codes	Active Test	Live Data	Ecu Info.	Freeze Frame	Special Function
Thailand MG6 TT	Rain sensor	Rain sensor	●	●	○	●	●	○	
Thailand MG6 TT	PDC	PDC	●	●	○	●	●	○	
Thailand MG6 TT	ETC	ETC	●	●	○	●	●	○	
Thailand MG6 TT	SCU	SCU	●	●	●	●	●	●	

Special_Function

index	Special Function Name	index	Special Function Name
0001	ABS/SCS Brake Bleeding	0037	ATC Motor Calibration
0002	AX Sensor Calibration	0038	Reset the counter of crash detection
0003	SCU EKA Coding	0039	YAW sensor Calibration
0004	TBOX Battery Calibration	0040	Reset the counter of starter useage
0005	Restart TBOX	0041	Stop Start Battery Override
0006	Activate TBOX	0042	Apply EPB both Actuators
0007	iTPMS Reset	0043	Apply EPB Right Actuator
0008	Service Interval Announcement Reset	0044	Apply EPB Left Actuator
0009	TCM Adaption Reset	0045	Starter start stop time reset
0010	TCM Adaption Reset	0046	Set the system operating mode
0011	TCM N Level Selflearn	0047	Release EPB Both Actuators
0012	Colour screen selftest	0048	Release EPB Right Actuator
0013	DPF Regeneration	0049	Release EPB Left Actuator
0014	Set Power Mode	0050	TCCM On-Demand self Test
0015	Transmission Sensor Test	0051	iTPMS Reset
0016	Headlight test	0052	Yaw Rate Sensor Calibration
0017	Write Battery ID process	0053	Cornering Light Test
0018	EPS Calibration	0054	GW Set Power Mode
0019	Set Power Mode	0055	Remote controller match
0020	EPB Brake	0056	Match Key
0021	EPB Release	0057	IPK Selftest
0022	SCS Pressure Sensor Calibration	0058	Speaker Selftest
0023	Read SubRom	0059	Brake pedal zero learning
0024	Read Alarm Trigger Store	0060	GW Brake Sensor Zero-point Learning
0025	Reset Throttle Adaptive Value	0061	EPB brake cable adjustment
0026	Set ECM Ignition Angle Offset	0062	EPB Brake Cable Fully Release
0027	Idle speed adjustment test	0063	Hand brake system component replacement
0028	ECM Adaption Reset	0064	SAS Calibration
0029	Steering Wheel Angle sensor calibration	0065	SAS De-calibration
0030	Steering Wheel center calibration	0066	Steering angle transducer Calibration
0031	SAS Calibration	0067	TCM Sensor Selftest
0032	SAS De-calibration	0068	TCM Self-learning
0033	DHL Axle Sensor Zero Position Learning	0069	Reset EEPROM
0034	IMU Calibration	0070	TCM Adaption Reset
0035	G-sensor Calibration	0071	Automatic transmission module replacement value
0036	Brake Bleeding	0072	TCM Self-learning

		0073	TCM fast learning
--	--	------	-------------------