



# MaxiSys\_Benz\_V8.02 Function List (Note:For reference only)

NOTES:

- This function is supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
- This function is not supported. ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 11/2005	A-Class	169	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
Up to 11/2005	A-Class	169	Drive	FCVT-Continuously variable automatic transmission	●	●	●	●	●	●	○	●		F002 F003 F004 F005 F006
Up to 11/2005	A-Class	169	Drive	ME-SFI-Gasoline engine control	●	●	●	●	●	●	●	●	C002	F007 F008 F009 F00A F00B F00C F00D F00E F00F F010
Up to 11/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection	●	●	●	●	●	●	●	●	C003 C004	F011 F012 F013 F014 F015 F016 F017
Up to 11/2005	A-Class	169	Chassis	ES-Electrical power steering	●	●	●	●	●	○	○	●		
Up to 11/2005	A-Class	169	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F018 F019 F01A
Up to 11/2005	A-Class	169	Body	CGW-Central gateway	●	●	○	●	○	○	○		C005 C006 C007	F01B F01C F01D
Up to 11/2005	A-Class	169	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○	●	C008 C009 C00A C00B C007 C00C C00D C00E C00F C010 C011 C012 C013 C014 C015 C016 C017 C018 C019 C01A C01B	F01E F01F F020 F021 F022 F023
Up to 11/2005	A-Class	169	Body	AB-Airbag	●	●	●	●	●	●	○	●	C001 C01C C01D C01E C01F C020 C021 C022 C023 C024	
Up to 11/2005	A-Class	169	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C025	
Up to 11/2005	A-Class	169	Body	ATA-Anti-theft alarm system	●	●	●	●	●	○	●	●	C026 C027	
Up to 11/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	●	●	●	●	●	○	●	●	C028 C029 C02A	F024
Up to 11/2005	A-Class	169	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
Up to 11/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●	●		F025
Up to 11/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●	●		
Up to 11/2005	A-Class	169	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
Up to 11/2005	A-Class	169	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
Up to 11/2005	A-Class	169	Body	System diagnosis (CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
Up to 11/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 11/2005	A-Class	169	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	○			
Up to 11/2005	A-Class	169	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F027 F028
Up to 11/2005	A-Class	169	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○		C02F	F029
Up to 11/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○			F02A F02B F02C F02D
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●	●	●	○			
Up to 11/2005	A-Class	169	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 11/2005	A-Class	169	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
Up to 11/2005	A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
Up to 11/2005	A-Class	169	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
Up to 11/2005	A-Class	169	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
Up to 11/2005	A-Class	169	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
Up to 11/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 11/2005	A-Class	169	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C044	
Up to 11/2005	A-Class	169	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C045	
Up to 11/2005	A-Class	169	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
Up to 11/2005	A-Class	169	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
Up to 11/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●	●	C007 C046 C047	F02F F030 F031 F032
As of 12/2005	A-Class	169	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
As of 12/2005	A-Class	169	Drive	FCVT-Continuously variable automatic transmission	●	●	●	●	●	●	○	●		F002 F003 F004 F005 F006
As of 12/2005	A-Class	169	Drive	ME-SFI-Gasoline engine control	●	●	●	●	●	●	●	●	C002	F007 F008 F009 F00A F00B F00C F00D F00E F00F F010
As of 12/2005	A-Class	169	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●	●		
As of 12/2005	A-Class	169	Drive	BSA-Belt-driven starter/alternator	●	●	●	●	●	●	○			
As of 12/2005	A-Class	169	Drive	TV-IV tuner	●	●	●	●	●	●	○			
As of 12/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C004	F011 F012 F013 F014 F015 F016 F017
As of 12/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection	●	●	●	●	●	●	●		C048 C049 C04A C04B	F011 F013 F016 F033 F034 F035 F036 F037 F038 F039 F008 F014 F03A F03B
As of 12/2005	A-Class	169	Chassis	ES-Electrical power steering	●	●	●	●	●	○	○	●		
As of 12/2005	A-Class	169	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F018 F019 F01A
As of 12/2005	A-Class	169	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
As of 12/2005	A-Class	169	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
As of 12/2005	A-Class	169	Body	CGW-Central gateway	●	●	○	●	○	○	○		C005 C006 C007	F01B F01C F01D
As of 12/2005	A-Class	169	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○	●	C008 C009 C00A C00B C007 C00C C00D C00E C00F C010 C011 C012 C013 C014 C015 C016 C017 C018 C019 C01A C01B	F01E F01F F020 F021 F022 F023
As of 12/2005	A-Class	169	Body	AB-Airbag	●	●	●	●	●	●	○	●	C001 C01C C01D C01E C01F C020 C021 C022 C023 C024	
As of 12/2005	A-Class	169	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C025	
As of 12/2005	A-Class	169	Body	ATA-Anti-theft alarm system	●	●	●	●	●	○	●	●	C026 C027	
As of 12/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	●	●	●	●	●	○	●	●	C028 C029 C02A	F024
As of 12/2005	A-Class	169	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
As of 12/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
As of 12/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			
As of 12/2005	A-Class	169	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
As of 12/2005	A-Class	169	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
As of 12/2005	A-Class	169	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
As of 12/2005	A-Class	169	Body	N93/4 (Vehicle gateway control unit)	●	●	●	●	○	○	○			
As of 12/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 12/2005	A-Class	169	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	○			
As of 12/2005	A-Class	169	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F027 F028
As of 12/2005	A-Class	169	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○		C02F	F029
As of 12/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○			F02A F02B F02C F02D
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●	●	●	○			
As of 12/2005	A-Class	169	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 12/2005	A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 12/2005	A-Class	169	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 12/2005	A-Class	169	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 12/2005	A-Class	169	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
As of 12/2005	A-Class	169	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●	●	C04C C04D C04E C04F C050	
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 12/2005	A-Class	169	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 12/2005	A-Class	169	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 12/2005	A-Class	169	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 12/2005	A-Class	169	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
As of 12/2005	A-Class	169	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
As of 12/2005	A-Class	169	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C044	
As of 12/2005	A-Class	169	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C045	
As of 12/2005	A-Class	169	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
As of 12/2005	A-Class	169	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
As of 12/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●	●	C007 C046 C047	F02F F030 F031 F032
As of 12/2005	A-Class	169	Air conditioning	EKMK-Electric refrigerant compressor	●	●	●	●	●	○	○			
As of 12/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●			
From 1998 to 2004	A-Class	168	Drive	ECM-Engine control monolith	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Drive	ECM-Engine control monolith	●	●	●	●	●	※	○			
From 1998 to 2004	A-Class	168	Drive	ACS-Automatic clutch system	●	●	●	●	●	※	○			
From 1998 to 2004	A-Class	168	Drive	FTC-Front transmission control	●	●	●	●	●	※	○			
From 1998 to 2004	A-Class	168	Drive	FTC2 -Front transmission control2	●	●	●	●	●	※	○			
From 1998 to 2004	A-Class	168	Drive	GRM-Gear recognition module	●	●	●	●	●	※	●			
From 1998 to 2004	A-Class	168	Drive	CDI-Common Rail Diesel Injection	●	●	●	●	●	※	●			F025
From 1998 to 2004	A-Class	168	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			F03D
From 1998 to 2004	A-Class	168	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
From 1998 to 2004	A-Class	168	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
From 1998 to 2004	A-Class	168	Body	AB-Airbag	●	●	○	●	○	※	○			
From 1998 to 2004	A-Class	168	Body	RFL-Radio frequency locking/electric central locking	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Body	LCP-Lower control panel	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Body	ATA-Anti-theft alarm system	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Body	APS-Auto pilot system	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Body	HB-Heater booster	●	●	○	●	○	※	○			
From 1998 to 2004	A-Class	168	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
From 1998 to 2004	A-Class	168	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 1998 to 2004	A-Class	168	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 1998 to 2004	A-Class	168	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 1998 to 2004	A-Class	168	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●			
From 1998 to 2004	A-Class	168	Seats and doors	DCM-FL-Door control module front left	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Seats and doors	DCM-FR-Door control module front right	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Seats and doors	DCM-RL-Door control module rear left	●	●	○	●	●	※	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 1998 to 2004	A-Class	168	Seats and doors	DCM-RR-Door control module rear right	●	●	○	●	●	※	○			
From 1998 to 2004	A-Class	168	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
From 1998 to 2004	A-Class	168	Air conditioning	TAC-Automatic temperature control	●	●	●	●	●	※	●			
As of 2012	A-Class	176	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Drive	VG - All-wheel drive	●	●	○	●	○	●	○			
As of 2012	A-Class	176	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2012	A-Class	176	Drive	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Drive	DKG-Electronic transmission control for double-plate clutch transmission	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2012	A-Class	176	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Chassis	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Chassis	EPB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2012	A-Class	176	Body	EZS-Electronic ignition switch	●	●	○	●	●	●	○			F05C F05D F05E F05F F060 F061 F062 F063
As of 2012	A-Class	176	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Body	ATA-ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	SRS-Supplemental restraint system	●	●	○	●	●	●	●			F064 F065
As of 2012	A-Class	176	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2012	A-Class	176	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2012	A-Class	176	Body	Trailer recognition module-Trailer recognition	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2012	A-Class	176	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2012	A-Class	176	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	A-Class	176	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	Audio-Audio 5 USB	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	SOUND - Sound system (N40/3)	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2012	A-Class	176	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2012	A-Class	176	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Information and communication	DSI-DIRECT SELECT interface	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Seats and doors	DCU-LF-Left front door	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Seats and doors	DCU-RF-Right front door	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Air conditioning	STH-Stationary heater	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2012	A-Class	176	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Driver assistance system	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012	A-Class	176	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2012	A-Class	176	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
Up to 11/2005	B-Class	245	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
Up to 11/2005	B-Class	245	Drive	FCVT-Continuously variable automatic transmission	●	●	●	●	●	●	○	●		F002 F003 F004 F005 F006

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 11/2005	B-Class	245	Drive	ME-SFI-Gasoline engine control	●	●	●	●	●	●	●	●	C002	F007 F008 F009 F00A F00B F00C F00D F00E F00F F010
Up to 11/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C004	F011 F012 F013 F014 F015 F016 F017
Up to 11/2005	B-Class	245	Chassis	ES-Electrical power steering	●	●	●	●	●	○	○	●		
Up to 11/2005	B-Class	245	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F018 F019 F01A
Up to 11/2005	B-Class	245	Body	CGW-Central gateway	●	●	○	●	○	○	○		C005 C006 C007	F01B F01C F01D
Up to 11/2005	B-Class	245	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○	●	C008 C009 C00A C00B C007 C00C C00D C00E C00F C010 C011 C012 C013 C014 C015 C016 C017 C018 C019 C01A C01B	F01E F01F F020 F021 F022 F023
Up to 11/2005	B-Class	245	Body	AB-Airbag	●	●	●	●	●	●	○	●	C001 C01C C01D C01E C01F C020 C021 C022 C023 C024	
Up to 11/2005	B-Class	245	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C025	
Up to 11/2005	B-Class	245	Body	ATA-Anti-theft alarm system	●	●	●	●	●	○	●	●	C026 C027	
Up to 11/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module	●	●	●	●	●	○	●		C028 C029 C02A	F024
Up to 11/2005	B-Class	245	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
Up to 11/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
Up to 11/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			
Up to 11/2005	B-Class	245	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	○	●		C004 C065 C066	
Up to 11/2005	B-Class	245	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	○	●		C004 C067 C066	
Up to 11/2005	B-Class	245	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
Up to 11/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 11/2005	B-Class	245	Information and communication	CM-Compass module	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F027 F028
Up to 11/2005	B-Class	245	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○		C02F	F029
Up to 11/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○			F02A F02B F02C F02D
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	AUD10	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 11/2005	B-Class	245	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
Up to 11/2005	B-Class	245	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
Up to 11/2005	B-Class	245	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
Up to 11/2005	B-Class	245	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
Up to 11/2005	B-Class	245	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
Up to 11/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
Up to 11/2005	B-Class	245	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C044	
Up to 11/2005	B-Class	245	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C045	
Up to 11/2005	B-Class	245	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
Up to 11/2005	B-Class	245	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
Up to 11/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●	●	C007 C046 C047	F02F F030 F031 F032
As of 12/2005	B-Class	245	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
As of 12/2005	B-Class	245	Drive	FCVT-Continuously variable automatic transmission	●	●	●	●	●	●	○	●		F002 F003 F004 F005 F006
As of 12/2005	B-Class	245	Drive	ME-SFI-Gasoline engine control	●	●	●	●	●	●	●	●	C002	F007 F008 F009 F00A F00B F00C F00D F00E F00F F010
As of 12/2005	B-Class	245	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●	●		
As of 12/2005	B-Class	245	Drive	ME-SFI-CNG compressed natural gas	●	●	●	●	●	●	●	●	C048 C002 C049 C04B	F011 F007 F008 F009 F06A F00A F00B F06B F00C F00D F06C F00E F00F F06D F06E F010
As of 12/2005	B-Class	245	Drive	BSA-Belt-driven starter/alternator	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Drive	TV-TV tuner	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	●	●	●	●	●	●	●	●	C003 C004	F011 F012 F013 F014 F015 F016 F017
As of 12/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	●	●	●	●	●	●	●	●	C048 C049 C04A C04B	F011 F013 F016 F033 F034 F035 F036 F037 F038 F039 F008 F014 F03A F03B
As of 12/2005	B-Class	245	Chassis	ES-Electrical power steering	●	●	●	●	●	○	○	●		
As of 12/2005	B-Class	245	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F018 F019 F01A
As of 12/2005	B-Class	245	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●	●		
As of 12/2005	B-Class	245	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●	●		
As of 12/2005	B-Class	245	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●	●		F06F F070
As of 12/2005	B-Class	245	Body	CGW-Central gateway	●	●	○	●	○	○	○		C005 C006 C007	F01B F01C F01D
As of 12/2005	B-Class	245	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○	●	C008 C009 C00A C00B C007 C00C C00D C00E C00F C010 C011 C012 C013 C014 C015 C016 C017 C018 C019 C01A C01B	F01E F01F F020 F021 F022 F023
As of 12/2005	B-Class	245	Body	AB-Airbag	●	●	●	●	●	●	○	●	C001 C01C C01D C01E C01F C020 C021 C022 C023 C024	
As of 12/2005	B-Class	245	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C025	
As of 12/2005	B-Class	245	Body	ATA-Anti-theft alarm system	●	●	●	●	●	○	●	●	C026 C027	
As of 12/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module	●	●	●	●	●	○	●	●	C028 C029 C02A	F024
As of 12/2005	B-Class	245	Body	AHE-Trailer recognition	●	●	●	●	●	○	○	●		
As of 12/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●	●		F025
As of 12/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●	●		
As of 12/2005	B-Class	245	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	○	●	●	C004 C065 C066	
As of 12/2005	B-Class	245	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	○	●	●	C004 C067 C066	
As of 12/2005	B-Class	245	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
As of 12/2005	B-Class	245	Body	N93/4 (Vehicle gateway control unit)	●	●	●	●	○	○	○			
As of 12/2005	B-Class	245	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
As of 12/2005	B-Class	245	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F027 F028
As of 12/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 12/2005	B-Class	245	Information and communication	CM-Compass module	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●	●	C04C C04D C04E C04F C050	
As of 12/2005	B-Class	245	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○		C02F	F029
As of 12/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○			F02A F02B F02C F02D
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 12/2005	B-Class	245	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 12/2005	B-Class	245	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 12/2005	B-Class	245	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 12/2005	B-Class	245	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
As of 12/2005	B-Class	245	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
As of 12/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
As of 12/2005	B-Class	245	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 12/2005	B-Class	245	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 12/2005	B-Class	245	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 12/2005	B-Class	245	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 12/2005	B-Class	245	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
As of 12/2005	B-Class	245	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 12/2005	B-Class	245	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
As of 12/2005	B-Class	245	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C044	
As of 12/2005	B-Class	245	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001 C041 C042 C043 C045	
As of 12/2005	B-Class	245	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
As of 12/2005	B-Class	245	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001 C041 C042 C043	
As of 12/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●	●	C007 C046 C047	F02F F030 F031 F032
As of 12/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●			
As of 12/2005	B-Class	245	Air conditioning	EKMK-Electric refrigerant compressor	●	●	●	●	●	○	○			
As of 2012	B-Class	246	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Drive	ME - Motro electronics CNGCM246 for combustion engine 379CNG	●	●	○	●	●	error	○			
As of 2012	B-Class	246	Drive	VG - All-wheel drive	●	●	○	●	○	●	○			
As of 2012	B-Class	246	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2012	B-Class	246	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Drive	DKG-Electronic transmission control for double-plate clutch transmission	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	B-Class	246	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2012	B-Class	246	Drive	CDI-Motor electronics 'CRRI' for combustion engine 'OM607'	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Chassis	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Chassis	EFB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2012	B-Class	246	Body	EZS-Electronic ignition switch	●	●	○	●	●	●	○			F05C F05D F05E F05F F060 F061 F062 F063
As of 2012	B-Class	246	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Body	ATA-ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	SRS-Supplemental restraint system	●	●	○	●	●	●	●			F064 F065
As of 2012	B-Class	246	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2012	B-Class	246	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2012	B-Class	246	Body	Trailer recognition module-Trailer recognition	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	●			F071 F072 F073 F074
As of 2012	B-Class	246	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	●			F075 F076
As of 2012	B-Class	246	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2012	B-Class	246	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2012	B-Class	246	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2012	B-Class	246	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2012	B-Class	246	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	B-Class	246	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2012	B-Class	246	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Seats and doors	DCU-LF-Left front door	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Seats and doors	DCU-RF-Right front door	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Air conditioning	STH-Stationary heater	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2012	B-Class	246	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Driver assistance system	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012	B-Class	246	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2012	B-Class	246	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 2008	C-Class	204	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 2008	C-Class	204	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO'	●	●	●	●	●	●	●			F094 F095 F096 F097 F098 F099 F09A F040 F09B F09C F09D F09E
As of 2008	C-Class	204	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C002 C049 C04B	F007 F008 F09F F009 F0A0 F0A1 F00C F00D F00E F00F F06D F010 F0A2 F0A3
As of 2008	C-Class	204	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
As of 2008	C-Class	204	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
As of 2008	C-Class	204	Drive	FSCU-Fuel pump	●	●	●	●	●	●	○		C069 C002 C049	
As of 2008	C-Class	204	Drive	ESM[EWM] - Electronic selector module	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
As of 2008	C-Class	204	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		F0A4 F007 F008 F009 F0AF F082 F0A7 F0A9 F0AA F0AB F0AC F0AD F0AE F011

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	C-Class	204	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●	●	●	●		C004	FOA4 FOB0 F008 F007 FOA5 FOA6 FOB1 FOA7 FOA8 FOA3 FOA9 FOAB FOAC FOB2 FOAE FOB3 FOB4 FOB5 FOB6 FOB7
As of 2008	C-Class	204	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2008	C-Class	204	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●	●	●	●		C069 C002 C049 C04B C04A	FOB8 F007 F009 FOA5 FOB9 FOB1 FOA7 FOA3 FOBA FOA1 FOBB FOBC FO0E FO0F F06D FOBD FOBE FOBF FOAA FOAB FOC0 FOAD FOAE
As of 2008	C-Class	204	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	○			
As of 2008	C-Class	204	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	○			
As of 2008	C-Class	204	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Drive	ISM-Shift module	●	●	●	●	●	●	●		C06B	FOC1 FOC2
As of 2008	C-Class	204	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Drive	SCR-Selective Catalytic Reduction	●	●	●	●	●	●	●		C069 C049 C04B C04A	FOC3 FOC4 FOC5
As of 2008	C-Class	204	Drive	FSCU-Fuel pump	●	●	●	●	○	●	○			
As of 2008	C-Class	204	Drive	CDID-Common Rail Diesel Injection	●	●	●	●	●	●	●		C04A C06C	F015 FOC6 FOC7 F016 F013 F007 FOC8 F008 FOC9 FOCA FOCB FOCC FOCd
As of 2008	C-Class	204	Drive	CDID-Common Rail Diesel Injection	●	●	●	●	●	●	●		C048 C049 C04A	FOCE FOcF FOD0 FOD1 FOD2
As of 2008	C-Class	204	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C048 C049 C04A	F016 F011 F033 F034 F008 F03B FOD3 FOD4 FOD5 FOC9
As of 2008	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●		C001	FOD6 F016 F033 F007 F034 F008 FOD7 F013 F036 FOD8 F014 F03A F03B FOD9 FODA FOB3 FOB4
As of 2008	C-Class	204	Drive	CDI 60LS-Common Rail Diesel Injection	●	●	●	●	●	●	●			F016 F033 F034 F013 F036 F038 FODB FODC F007 F008 F014 FOD7 F03A F03B F011 FODD FODE FODF FOE0 FOE1
As of 2008	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 FOE2 FODC FOE3 FOE4 F036 FOE5 FODB FOE6 FOE7 FOE8 F038 FOC5 F008 F014 FOD7 F03A FOE9 F03B F016 F033 F034 F035
As of 2008	C-Class	204	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 F036 FODB FOE8 F038 F008 F014 FOD7 F03A F03B F016 F033 F034
As of 2008	C-Class	204	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 FOEA FOEB FOEC FOED
As of 2008	C-Class	204	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			F06F F070
As of 2008	C-Class	204	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	●	●			FOEE
As of 2008	C-Class	204	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			FOEF FOF0 FOF1 FOF2
As of 2008	C-Class	204	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			FOF3 FOF4
As of 2008	C-Class	204	Chassis	DTR-Distronic	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Chassis	EHPS-Electrohydraulic Power Steering	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			FOEF
As of 2008	C-Class	204	Body	CGW-Central gateway	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2008	C-Class	204	Body	CGW-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2008	C-Class	204	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			FOF6 F05C F05D FOF7 FOF8 FOF9 F0FA
As of 2008	C-Class	204	Body	KG-KEYLESS GO	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Body	Trailer recognition module	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	AB-Airbag	●	●	●	●	●	●	○		C06D C062	FOFB FOFC
As of 2008	C-Class	204	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Body	OCP-Overhead control panel	●	●	○	●	●	●	●			FOFD
As of 2008	C-Class	204	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	●			FOFD
As of 2008	C-Class	204	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	●			FOFD
As of 2008	C-Class	204	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	C-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	AHE-Trailer recognition	●	●	●	●	●	●	●	●		
As of 2008	C-Class	204	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	SCM [MRM]-Steering column module	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Body	SCCM-Steering column module	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Body	OCP-Overhead control panel	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	Multifunction control unit-Multifunction control unit	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Body	EZS-Electronic ignition lock	●	●	●	●	●	●	○			FOF6 F05C F05D F0F7 F0F8 F0F9 FOFE
As of 2008	C-Class	204	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Body	MPK-Multifunction camera	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Body	SGR-Radar sensors control unit	●	●	●	●	○	●	○			
As of 2008	C-Class	204	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	●	●		C02D C02E	F028 F0FF F100
As of 2008	C-Class	204	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2008	C-Class	204	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Information and communication	PTS-Parktronic	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Information and communication	PTS-PARKTRONIC	●	●	●	●	●	●	●		C04D C04F C04E C06E	
As of 2008	C-Class	204	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Information and communication	RFK-Backup camera	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Information and communication	COU [ZBE]-Central operating unit	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Information and communication	ZAN-Central display	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Information and communication	CTEL-Cellular telephone (JAPAN)	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	C-Class	204	Information and communication	DAB-Digital radio	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 2008	C-Class	204	Information and communication	AVE-H - DVD player	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Information and communication	Left rear screen	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Information and communication	Right rear screen	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
As of 2008	C-Class	204	Information and communication	AMG PM-AMG Performance Media	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Information and communication	AMG DRVU-AMG DRIVE UNIT	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Information and communication	Drive-side SAM-Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Information and communication	MPK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2008	C-Class	204	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Information and communication	360camera-360camera	●	●	○	●	●	●	●			F101 F102 F103 F104 F105
As of 2008	C-Class	204	Information and communication	TV-TV tuner (AGW)	●	●	○	●	○	●	○			
As of 2008	C-Class	204	Information and communication	NAVI20 - Navigation	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	DCU-LF-Left front door	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	DCU-RF-Right front door	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	DCU-LR-Left rear door	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	DCU-RR-Right rear door	●	●	○	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	HKS-Tailgate control (N121/1)	●	●	●	●	●	●	●		C001	
As of 2008	C-Class	204	Seats and doors	ESA Driver - Electric seat adjustmet Driver	●	●	○	●	●	○	●			F106 F107 F108
As of 2008	C-Class	204	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'	●	●	○	●	●	●	●			F106 F107 F108
As of 2008	C-Class	204	Seats and doors	ESA passenger	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Seats and doors	ESA-Electirc seat adjustment 'Front passenger'	●	●	●	●	●	●	●			F106 F107
As of 2008	C-Class	204	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	●			F106 F107
As of 2008	C-Class	204	Air conditioning	STH - Stationary heater	●	●	●	●	●	●	●			
As of 2008	C-Class	204	Air conditioning	AAC-Air conditioning	●	●	●	●	●	●	●		C007 C046 C047 C06F	F02F F030 F031 F032
As of 2008	C-Class	204	Air conditioning	AAC-Air conditioning	●	●	●	●	●	●	●			F109 F10A F10B
As of 2008	C-Class	204	Air conditioning	EKMK-Electric refrigerant compressor	●	●	○	●	●	●	●			
As of 2008	C-Class	204	LIN Bus	LCP-Lower control panel	●	●	○	●	○	●	○			
As of 2008	C-Class	204	LIN Bus	GTO-Garage door opener	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	C-Class	204	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front	●	●	○	●	●	●	○			
As of 2008	C-Class	204	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2008	C-Class	204	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2008	C-Class	204	Driver assistance system	RFK-Backup camera	●	●	○	●	●	●	●			
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	●	●	○	●	●	※	●			F077 F082 F10E F081 F10F F110 F111 F112 F113 F114 F08D F115 F116 F117 F118 F119 F11A F11B F001 F11C F11D F11E F11F F002 F089 F120
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 08/2003	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
Up to 08/2003	C-Class	203	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C001 C002 C069	FOA4 F007 F09F F009 F12D
Up to 08/2003	C-Class	203	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FOA0 F008
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D F00B FOA0 F12F F130 F008
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
Up to 08/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C001 C004	F015 F016 F034 F0C7 F013 F014 F0DA
Up to 08/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●			F015 F016 F034 F0C7
Up to 08/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●			F015 F016 F034 F0C7
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F137
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F0EB F0EA F138
Up to 08/2003	C-Class	203	Chassis	BAS-Brake assist	●	●	○	●	●	●	●			
Up to 08/2003	C-Class	203	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F019 F137
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○	●	C007 C071 C00F C011 C072 C073 C074 C075 C015 C076 C077 C078 C079 C017 C07A C07B C07C C016 C07D C07E C012 C07F C00A C080 C081 C082 C083 C084 C085 C086 C087	F01E F139 F01F F13A F022
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
Up to 08/2003	C-Class	203	Body	AB-Airbag	●	●	●	●	●	●	○		C001 C08E C01C C05C C08F C05E C024	
Up to 08/2003	C-Class	203	Body	OCP-Overhead control panel	●	●	●	●	●	○	●		C090 C02A C091 C092 C093 C025 C001 C094	F13B F13C F13D F13E
Up to 08/2003	C-Class	203	Body	LCP-Lower control panel	●	●	●	●	●	○	●			
Up to 08/2003	C-Class	203	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
Up to 08/2003	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
Up to 08/2003	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
Up to 08/2003	C-Class	203	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●	●		F025
Up to 08/2003	C-Class	203	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
Up to 08/2003	C-Class	203	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○	●	C001	
Up to 08/2003	C-Class	203	Body	CGW-Central gateway	●	●	●	●	●	●	○	●	C001	F025
Up to 08/2003	C-Class	203	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
Up to 08/2003	C-Class	203	Body	WSS-Weight sensing system	●	●	●	●	●	●	○	●		
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
Up to 08/2003	C-Class	203	Body	System diagnosis (CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
Up to 08/2003	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C09B C02C C09C C09D C02F C09E C09F C0A0 C0A1 C0A2	F13F F100 F140 F08C
Up to 08/2003	C-Class	203	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	TV-TV tuner	●	●	●	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○	●		
Up to 08/2003	C-Class	203	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○	●		
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○	●		
Up to 08/2003	C-Class	203	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○	●		
Up to 08/2003	C-Class	203	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	AUDIO	●	●	●	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	COMAND	●	●	○	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	●	●	●	●	○	○	○	●		
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○	●		
Up to 08/2003	C-Class	203	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○	●		
Up to 08/2003	C-Class	203	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○	●		
Up to 08/2003	C-Class	203	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●	●		
Up to 08/2003	C-Class	203	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○	●		
Up to 08/2003	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C0A3	F141
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
Up to 08/2003	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
Up to 08/2003	C-Class	203	Information and communication	AUDIO	●	●	●	●	●	●	●	●	C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 08/2003	C-Class	203	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○	●		
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	●	●	○	●	●	●	○	●		F02E
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●	●		
Up to 08/2003	C-Class	203	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●	●		F02E

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2003	C-Class	203	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
Up to 08/2003	C-Class	203	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
Up to 08/2003	C-Class	203	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
Up to 08/2003	C-Class	203	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
Up to 08/2003	C-Class	203	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●		C001	
Up to 08/2003	C-Class	203	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●		C001	
Up to 08/2003	C-Class	203	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●		C001	
Up to 08/2003	C-Class	203	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●		C001	
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F142 F145
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
Up to 08/2003	C-Class	203	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030
Up to 08/2003	C-Class	203	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F151 F152
Up to 08/2003	C-Class	203	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 09/2003 to 12/2007	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
From 09/2003 to 12/2007	C-Class	203	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FOA0 F008
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FOA0 F008
From 09/2003 to 12/2007	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE F011
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C001 C004	F015 F016 F034 F0C7 F013 F014 F0DA
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●			F015 F016 F034 F0C7
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●			F015 F016 F034 F0C7
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
From 09/2003 to 12/2007	C-Class	203	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 FOEB FOEA F138
From 09/2003 to 12/2007	C-Class	203	Body	CGW-Central gateway	●	●	●	●	●	●	○		C001	F025



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2003 to 12/2007	C-Class	203	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
From 09/2003 to 12/2007	C-Class	203	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
From 09/2003 to 12/2007	C-Class	203	Body	OCP-Overhead control panel	●	●	●	●	●	○	●		C090 C02A C091 C092 C093 C025 C001 C094	F13B F13C F13D F13E
From 09/2003 to 12/2007	C-Class	203	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Body	LCP-Lower control panel	●	●	●	●	●	○	●			
From 09/2003 to 12/2007	C-Class	203	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
From 09/2003 to 12/2007	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
From 09/2003 to 12/2007	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
From 09/2003 to 12/2007	C-Class	203	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
From 09/2003 to 12/2007	C-Class	203	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
From 09/2003 to 12/2007	C-Class	203	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
From 09/2003 to 12/2007	C-Class	203	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
From 09/2003 to 12/2007	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●		C0A3	F141
From 09/2003 to 12/2007	C-Class	203	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
From 09/2003 to 12/2007	C-Class	203	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
From 09/2003 to 12/2007	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
From 09/2003 to 12/2007	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
From 09/2003 to 12/2007	C-Class	203	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
From 09/2003 to 12/2007	C-Class	203	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
From 09/2003 to 12/2007	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
From 09/2003 to 12/2007	C-Class	203	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 09/2003 to 12/2007	C-Class	203	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
From 09/2003 to 12/2007	C-Class	203	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
From 09/2003 to 12/2007	C-Class	203	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●		C001	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●		C001	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●		C001	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2003 to 12/2007	C-Class	203	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●		C001	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F142 F145
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
From 09/2003 to 12/2007	C-Class	203	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030
From 09/2003 to 12/2007	C-Class	203	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 01/2008	C-Class	203	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
As of 01/2008	C-Class	203	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	F0A4 F009 F007 F09F F12D F0A0 F008
As of 01/2008	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
As of 01/2008	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C001 C004	F015 F016 F034 F0C7 F013 F014 F0DA
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	●	●	○	●	●	※	●			F077 F082 F10E F081 F10F F110 F111 F112 F113 F114 F08D F115 F116 F117 F118 F119 F11A F11B F001 F11C F11D F11E F11F F002 F089 F120
As of 01/2008	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
As of 01/2008	C-Class	203	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	F0A4 F009 F007 F09F F12D F00B F0A0 F12F F130 F008
As of 01/2008	C-Class	203	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
As of 01/2008	C-Class	203	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F0EB F0EA F138
As of 01/2008	C-Class	203	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F137
As of 01/2008	C-Class	203	Chassis	BAS-Brake assist	●	●	○	●	●	●	●			
As of 01/2008	C-Class	203	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F019 F137
As of 01/2008	C-Class	203	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
As of 01/2008	C-Class	203	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
As of 01/2008	C-Class	203	Body	OCP-Overhead control panel	●	●	●	●	●	○	●		C090 C02A C091 C092 C093 C025 C001 C094	F13B F13C F13D F13E
As of 01/2008	C-Class	203	Body	LCP-Lower control panel	●	●	●	●	●	○	●			
As of 01/2008	C-Class	203	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
As of 01/2008	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
As of 01/2008	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
As of 01/2008	C-Class	203	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
As of 01/2008	C-Class	203	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●		C001 C004 C0A4	F026
As of 01/2008	C-Class	203	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○	●	C007 C071 C00F C011 C072 C073 C074 C075 C015 C076 C077 C078 C079 C017 C07A C07B C07C C016 C07D C07E C012 C07F C00A C080 C081 C082 C083 C084 C085 C086 C087	F01E F139 F01F F13A F022

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 01/2008	C-Class	203	Body	AB-Airbag	●	●	●	●	●	●	○		C001 C08E C01C C05C C08F C05E C024	
As of 01/2008	C-Class	203	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
As of 01/2008	C-Class	203	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
As of 01/2008	C-Class	203	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
As of 01/2008	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●		COA3	F141
As of 01/2008	C-Class	203	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	●	●	C04D C04E C0A5 C0A6 C0A7	
As of 01/2008	C-Class	203	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 01/2008	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 01/2008	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
As of 01/2008	C-Class	203	Information and communication	AUDIO	●	●	●	●	●	●	●	●	C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 01/2008	C-Class	203	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 01/2008	C-Class	203	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 01/2008	C-Class	203	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
As of 01/2008	C-Class	203	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 01/2008	C-Class	203	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 01/2008	C-Class	203	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 01/2008	C-Class	203	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 01/2008	C-Class	203	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
As of 01/2008	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●		C09B C02C C09C C09D C02F C09E C09F C0A0 C0A1 C0A2	F13F F100 F140 F08C
As of 01/2008	C-Class	203	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○			
As of 01/2008	C-Class	203	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
As of 01/2008	C-Class	203	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
As of 01/2008	C-Class	203	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
As of 01/2008	C-Class	203	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	AUDIO	●	●	●	●	●	●	●			
As of 01/2008	C-Class	203	Information and communication	COMAND	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 01/2008	C-Class	203	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
As of 01/2008	C-Class	203	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
As of 01/2008	C-Class	203	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
As of 01/2008	C-Class	203	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
As of 01/2008	C-Class	203	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●		C001	
As of 01/2008	C-Class	203	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●		C001	
As of 01/2008	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
As of 01/2008	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
As of 01/2008	C-Class	203	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●		C001	
As of 01/2008	C-Class	203	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●		C001	
As of 01/2008	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
As of 01/2008	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
As of 01/2008	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F142 F145
As of 01/2008	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
As of 01/2008	C-Class	203	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030
As of 01/2008	C-Class	203	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
As of 01/2008	C-Class	203	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F151 F152
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	●	●	○	●	○	※	●			F12E
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	●	●	○	●	●	※	●			F077 F082 F10E F081 F10F F110 F111 F112 F113 F114 F08D F115 F116 F117 F118 F119 F11A F11B F001 F11C F11D F11E F11F F002 F089 F120
As of 06/97	C-Class	202	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
As of 06/97	C-Class	202	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●			FOA4 F155
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 06/97	C-Class	202	Drive	DFI-Electronic distributor injection system diesel	●	●	○	●	○	※	○			
As of 06/97	C-Class	202	Drive	IFI-Electronic in-line injection system diesel	●	●	○	●	○	※	○			
As of 06/97	C-Class	202	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	○	※	○			
As of 06/97	C-Class	202	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C001 C002 C069	FOA4 F007 F09F F009 F12D
As of 06/97	C-Class	202	Chassis	ABS-Antilock brake system	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F019 F137
As of 06/97	C-Class	202	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			F03D
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
As of 06/97	C-Class	202	Chassis	BAS-Brake assist	●	●	○	●	●	※	●			
As of 06/97	C-Class	202	Chassis	BAS-Brake assist	●	●	○	●	●	●	●			
As of 06/97	C-Class	202	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
As of 06/97	C-Class	202	Body	AB-Airbag	●	●	○	●	○	※	○			
As of 06/97	C-Class	202	Body	EZS-Electronic ignition switch	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Body	OCP-Overhead control panel	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Body	LCP-Lower control panel	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Body	PSE-Pneumatic system equipment	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	※	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 06/97	C-Class	202	Body	MSS-Special vehicle multifunction control module	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Body	HRA-Headlamp range adjustment	●	●	○	●	○	※	○			
As of 06/97	C-Class	202	Body	APS-Auto pilot system	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Body	HB-Heater booster	●	●	○	●	○	※	○			
As of 06/97	C-Class	202	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
As of 06/97	C-Class	202	Information and communication	AUDIO	●	●	●	●	●	●	●			
As of 06/97	C-Class	202	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
As of 06/97	C-Class	202	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
As of 06/97	C-Class	202	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
As of 06/97	C-Class	202	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
As of 06/97	C-Class	202	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●			
As of 06/97	C-Class	202	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○			
As of 06/97	C-Class	202	Information and communication	E-call [USA]-Emergency call system	●	●	●	●	○	○	○			
As of 06/97	C-Class	202	Information and communication	TELE AID-Emergency call system	●	●	●	●	●	●	○			
As of 06/97	C-Class	202	Information and communication	TELE AID-Telematic system	●	●	○	●	○	●	○			
As of 06/97	C-Class	202	Information and communication	DN-Dynamic navigation by means of CTEL	●	●	●	●	●	○	○			
As of 06/97	C-Class	202	Seats and doors	DCM1-Door control module front driver side	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Seats and doors	DCM2-Door control module front passenger side	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Seats and doors	DCM3-Door control module rear driver side	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Seats and doors	DCM4-Door control module rear passenger side	●	●	○	●	●	※	○			
As of 06/97	C-Class	202	Air conditioning	TAC-Automatic temperature control	●	●	○	●	●	※	●			
As of 06/97	C-Class	202	Air conditioning	AAC-Automatic air conditioning	●	●	○	●	○	※	○			
As of 06/97	C-Class	202	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
Up to 03/2004	CLK	209	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 03/2004	CLK	209	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
Up to 03/2004	CLK	209	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
Up to 03/2004	CLK	209	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
Up to 03/2004	CLK	209	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
Up to 03/2004	CLK	209	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FOA0 F008
Up to 03/2004	CLK	209	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D F00B FOA0 F12F F130 F008
Up to 03/2004	CLK	209	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 03/2004	CLK	209	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
Up to 03/2004	CLK	209	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 FOEB FOEA F138
Up to 03/2004	CLK	209	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
Up to 03/2004	CLK	209	Body	AB-Airbag	●	●	●	●	●	●	○		C001 C08E C01C C05C C08F C05E C024	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 03/2004	CLK	209	Body	OCP-Overhead control panel	●	●	●	●	●	○	●		C090 C02A C091 C092 C093 C025 C001 C094	F13B F13C F13D F13E
Up to 03/2004	CLK	209	Body	LCP-Lower control panel	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
Up to 03/2004	CLK	209	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
Up to 03/2004	CLK	209	Body	RVC-Rollover bar soft top control module	●	●	●	●	●	○	○			
Up to 03/2004	CLK	209	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
Up to 03/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
Up to 03/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
Up to 03/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
Up to 03/2004	CLK	209	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
Up to 03/2004	CLK	209	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
Up to 03/2004	CLK	209	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
Up to 03/2004	CLK	209	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
Up to 03/2004	CLK	209	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance (USA, Canada),Tele diagnosis (ECE)	●	●	●	●	●	●	○			
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
Up to 03/2004	CLK	209	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			
Up to 03/2004	CLK	209	Information and communication	AUDIO	●	●	●	●	●	●	●			
Up to 03/2004	CLK	209	Information and communication	COMAND	●	●	○	●	●	●	●			
Up to 03/2004	CLK	209	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
Up to 03/2004	CLK	209	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
Up to 03/2004	CLK	209	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
Up to 03/2004	CLK	209	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
Up to 03/2004	CLK	209	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
Up to 03/2004	CLK	209	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
Up to 03/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
Up to 03/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
Up to 03/2004	CLK	209	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	○	●			
Up to 03/2004	CLK	209	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
Up to 03/2004	CLK	209	Seats and doors	RCM-Rear control module	●	●	●	●	●	○	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 03/2004	CLK	209	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030
Up to 03/2004	CLK	209	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F151 F152
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 04/2004	CLK	209	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 04/2004	CLK	209	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
As of 04/2004	CLK	209	Drive	DTR-Distronic	●	●	●	●	●	●	○			
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FOA0 F008
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FO0B FOA0 F12F F130 F008
As of 04/2004	CLK	209	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE F011
As of 04/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 FO0B FOA2 F132 F133 F134 F135
As of 04/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 FO0B FOA2 F132 F133 F134 F135
As of 04/2004	CLK	209	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE F011
As of 04/2004	CLK	209	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	●		C001	F156
As of 04/2004	CLK	209	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	●		C001	F156
As of 04/2004	CLK	209	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C001 C004	F015 F016 F034 F0C7 F013 F014 F0DA
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C001 C048 C002 C049	F0DA
As of 04/2004	CLK	209	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
As of 04/2004	CLK	209	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 FOEB FOEA F138
As of 04/2004	CLK	209	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			F06F F070
As of 04/2004	CLK	209	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
As of 04/2004	CLK	209	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
As of 04/2004	CLK	209	Body	OCP-Overhead control panel	●	●	●	●	●	○	●		C090 C02A C091 C092 C093 C025 C001 C094	F13B F13C F13D F13E
As of 04/2004	CLK	209	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 04/2004	CLK	209	Body	LCP-Lower control panel	●	●	●	●	●	○	●			
As of 04/2004	CLK	209	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
As of 04/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
As of 04/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
As of 04/2004	CLK	209	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
As of 04/2004	CLK	209	Body	RVC-Rollover bar soft top control module	●	●	●	●	●	○	○			
As of 04/2004	CLK	209	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
As of 04/2004	CLK	209	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
As of 04/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
As of 04/2004	CLK	209	Body	On board electrical system(voltage supply)	●	●	●	●	●	●	○			
As of 04/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 04/2004	CLK	209	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
As of 04/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 04/2004	CLK	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 04/2004	CLK	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
As of 04/2004	CLK	209	Information and communication	AUDIO	●	●	●	●	●	●	●	●	C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 04/2004	CLK	209	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●	●		
As of 04/2004	CLK	209	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○	○		
As of 04/2004	CLK	209	Information and communication	CDC-CD changer	●	●	○	●	●	●	○	○		F02E
As of 04/2004	CLK	209	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●	●		
As of 04/2004	CLK	209	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●	●		F02E
As of 04/2004	CLK	209	Information and communication	TV-TV tuner	●	●	○	●	●	●	●	●		
As of 04/2004	CLK	209	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●	●	C09B C0A9	
As of 04/2004	CLK	209	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○	○		
As of 04/2004	CLK	209	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●	●		
As of 04/2004	CLK	209	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○	○		
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○	○		
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○	○		
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○	○		
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○	○		
As of 04/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●		F142 F143 F144 F145 F146
As of 04/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
As of 04/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●	●		F14E F142 F143 F144 F145 F146
As of 04/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
As of 04/2004	CLK	209	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	○	●	●		
As of 04/2004	CLK	209	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	○	●	●		
As of 04/2004	CLK	209	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●	●	C001	
As of 04/2004	CLK	209	Seats and doors	RCM-Rear control module	●	●	●	●	●	○	○	○		
As of 04/2004	CLK	209	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C001	F02F F030
As of 04/2004	CLK	209	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●	●		F152
From 1996 to 2003	CLK	208	Drive	ETC-Electronic transmission control	●	●	○	●	○	※	●	●		F12E
From 1996 to 2003	CLK	208	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 1996 to 2003	CLK	208	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●	●	C070 C04C C068 C069	F12C
From 1996 to 2003	CLK	208	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●	●		
From 1996 to 2003	CLK	208	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●	●		FOA4 F155
From 1996 to 2003	CLK	208	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●	●	C001 C002 C069	FOA4 F007 F09F F009 F12D
From 1996 to 2003	CLK	208	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 1996 to 2003	CLK	208	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 1996 to 2003	CLK	208	Chassis	ABS-Antilock brake system	●	●	○	●	●	※	○	○		
From 1996 to 2003	CLK	208	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●	●		F03D
From 1996 to 2003	CLK	208	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○	○		F019 F137



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 1996 to 2003	CLK	208	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Chassis	BAS-Brake assist	●	●	○	●	●	※	●			
From 1996 to 2003	CLK	208	Chassis	BAS-Brake assist	●	●	○	●	●	●	●			
From 1996 to 2003	CLK	208	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
From 1996 to 2003	CLK	208	Body	AB-Airbag	●	●	○	●	○	※	○			
From 1996 to 2003	CLK	208	Body	EZS-Electronic ignition switch	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Body	OCP-Overhead control panel	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Body	LCP-Lower control panel	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Body	PSE-Pneumatic system equipment	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Body	HRA-Headlamp range adjustment	●	●	○	●	○	※	○			
From 1996 to 2003	CLK	208	Body	HRA-Headlamp range adjustment	●	●	○	●	●	○	○			
From 1996 to 2003	CLK	208	Body	APS-Auto pilot system	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Body	RVC-Rollover bar soft top control module	●	●	○	●	●	※	●			
From 1996 to 2003	CLK	208	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
From 1996 to 2003	CLK	208	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	●	○			
From 1996 to 2003	CLK	208	Information and communication	COMAND	●	●	○	●	●	●	●			
From 1996 to 2003	CLK	208	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 1996 to 2003	CLK	208	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 1996 to 2003	CLK	208	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 1996 to 2003	CLK	208	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 1996 to 2003	CLK	208	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 1996 to 2003	CLK	208	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●			
From 1996 to 2003	CLK	208	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
From 1996 to 2003	CLK	208	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○			
From 1996 to 2003	CLK	208	Information and communication	E-call [USA]-Emergency call system	●	●	●	●	○	○	○			
From 1996 to 2003	CLK	208	Information and communication	TELE AID-Emergency call system	●	●	●	●	●	●	○			
From 1996 to 2003	CLK	208	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
From 1996 to 2003	CLK	208	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
From 1996 to 2003	CLK	208	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
From 1996 to 2003	CLK	208	Information and communication	DN-Dynamic navigation by means of CTEL	●	●	●	●	●	○	○			
From 1996 to 2003	CLK	208	Seats and doors	DCM1-Door control module front driver side	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Seats and doors	DCM2-Door control module front passenger side	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	○	●	●	※	○			
From 1996 to 2003	CLK	208	Air conditioning	TAC-Automatic temperature control	●	●	○	●	●	※	●			
From 1996 to 2003	CLK	208	Air conditioning	AAC-Automatic air conditioning	●	●	○	●	○	※	○			
From 1996 to 2003	CLK	208	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 05/2005	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
Up to 05/2005	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
Up to 05/2005	E-Class	211	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 05/2005	E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
Up to 05/2005	E-Class	211	Body	On board electrical system(voltage supply)	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●	●	C065	F026 F164 F165
Up to 05/2005	E-Class	211	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●	●	C004 C065	F164 F165
Up to 05/2005	E-Class	211	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
Up to 05/2005	E-Class	211	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 05/2005	E-Class	211	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
Up to 05/2005	E-Class	211	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E C09B C02C C09C C0D0 C0D1 C0D2 C0D3	F166 F028
Up to 05/2005	E-Class	211	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	
Up to 05/2005	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	●	●	●	●	○	●	C0D4 C02C C0D5 C0D6	F167 F02C
Up to 05/2005	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
Up to 05/2005	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
Up to 05/2005	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
Up to 05/2005	E-Class	211	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
Up to 05/2005	E-Class	211	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
Up to 05/2005	E-Class	211	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●		C09B C0A9	
Up to 05/2005	E-Class	211	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	GPS box	●	●	○	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	●	●	C04D C04E C0A5 C0A6 C0A7	
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
Up to 05/2005	E-Class	211	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
Up to 05/2005	E-Class	211	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
Up to 05/2005	E-Class	211	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
Up to 05/2005	E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
Up to 05/2005	E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
Up to 05/2005	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
Up to 05/2005	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
Up to 05/2005	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
Up to 05/2005	E-Class	211	Seats and doors	HS-Seat heater	●	●	●	●	○	○	○			
Up to 05/2005	E-Class	211	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
Up to 05/2005	E-Class	211	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	E-Class	211	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	E-Class	211	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
Up to 05/2005	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	●	●	●	●	●	●	●			
Up to 05/2005	E-Class	211	Seats and doors	RWT-Rear-end door control module	●	●	●	●	●	○	●		C001	F16A F16B
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C0D8 C001	F16C F16D
Up to 05/2005	E-Class	211	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C007 C046 C047 C06F	F02F F030 F025
Up to 05/2005	E-Class	211	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	●	●			F025
Up to 05/2005	E-Class	211	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
Up to 05/2005	E-Class	211	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 06/2005 to 05/2006	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 06/2005 to 05/2006	E-Class	211	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	F0A4 F009 F007 F09F F12D F0A0 F008
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	F0A4 F009 F007 F09F F12D F00B F0A0 F12F F130 F008
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●			F0A4 F008 F007 F09F F009 F158 F0A0 F12D F00B F159 F0A2 F011
From 06/2005 to 05/2006	E-Class	211	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
From 06/2005 to 05/2006	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C001 C004	F015 F016 F034 F0C7 F013 F014 F0DA
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●			F015 F016 F034 F0C7
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C001 C048 C002 C049	F0DA
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
From 06/2005 to 05/2006	E-Class	211	Drive	CDI5-Common Rail Diesel Injection(USA)	●	●	●	●	●	●	●		C003 C048	F007 F015 F016 F034 F16E F16F F0D6 F009 F013 F170 F171 F172 F014 F03A F03B F0C9
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C048	F007 F009 F013 F0D6 F034 F015 F016 F014 F171 F03B F03A F173 F0D7 F174 F175 F176 F177

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 06/2005 to 05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
From 06/2005 to 05/2006	E-Class	211	Chassis	AIRmatic	●	●	●	●	●	○	●			F06F F15A F15B
From 06/2005 to 05/2006	E-Class	211	Chassis	Suspension	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Body	CGW-Central gateway	●	●	●	●	○	○	○	●	C007 C006 C00F C010 C011 C012 C074 C013 C014 C015 C016 C076 C077 C078 C079 C017 C07A C07C C08B C0AA C0AB C0AC C005	F01B F01C F01D
From 06/2005 to 05/2006	E-Class	211	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	●	●		F01E F01F F020 F13A F022 F15D F023 F15E
From 06/2005 to 05/2006	E-Class	211	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
From 06/2005 to 05/2006	E-Class	211	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Body	BCM-Battery control module	●	●	○	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
From 06/2005 to 05/2006	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	○	●		C04D C04E C04F C075 C0B0 C0B1 C0B2 C0B3 C0B4 C0B5 C0B6 C0B7 C0B8 C0B9 C0BA C0BB	
From 06/2005 to 05/2006	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●		C070 C04D C0BC C0B3 C0B5 C0BD C0BA C0B9 C0BE	
From 06/2005 to 05/2006	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●		C0BF C0C0 C0C1 C0C2 C0C3 C0C4 C0C5 C0C6 C0C7 C0C8	
From 06/2005 to 05/2006	E-Class	211	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●	C04C C0C9	
From 06/2005 to 05/2006	E-Class	211	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
From 06/2005 to 05/2006	E-Class	211	Body	LCP-Lower control panel	●	●	●	●	●	○	●	●		
From 06/2005 to 05/2006	E-Class	211	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●		
From 06/2005 to 05/2006	E-Class	211	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C0CA C025 C0CB C092 C093 C0CC C0CD C091 C0CE C094 C0CF	F13C F15F F13B F160 F13E F161 F162 F163
From 06/2005 to 05/2006	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001	
From 06/2005 to 05/2006	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001	
From 06/2005 to 05/2006	E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
From 06/2005 to 05/2006	E-Class	211	Body	On board electrical system(voltage supply)	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
From 06/2005 to 05/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E C09B C02C C09C C0D0 C0D1 C0D2 C0D3	F166 F028
From 06/2005 to 05/2006	E-Class	211	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	
From 06/2005 to 05/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	●	●	●	●	○	●	C0D4 C02C C0D5 C0D6	F167 F02C
From 06/2005 to 05/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
From 06/2005 to 05/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
From 06/2005 to 05/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
From 06/2005 to 05/2006	E-Class	211	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 06/2005 to 05/2006	E-Class	211	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
From 06/2005 to 05/2006	E-Class	211	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 06/2005 to 05/2006	E-Class	211	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●		C09B C0A9	
From 06/2005 to 05/2006	E-Class	211	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	GPS box	●	●	○	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	●	●	●	●	○	○	○			
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	E-Class	211	Seats and doors	RWT-Rear-end door control module	●	●	●	●	●	○	●		C001	F16A F16B
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C0D8 C001	F16C F16D
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ARWT-Automatic rear-end door	●	●	●	●	●	○	●			
From 06/2005 to 05/2006	E-Class	211	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C007 C046 C047 C06F	F02F F030 F025
From 06/2005 to 05/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	●	●			F025
From 06/2005 to 05/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
From 06/2005 to 05/2006	E-Class	211	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 06/2006	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 06/2006	E-Class	211	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FOA0 F008
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FO0B FOA0 F12F F130 F008



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 06/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
As of 06/2006	E-Class	211	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E C09B C02C C09C C0D0 C0D1 C0D2 C0D3	F166 F028
As of 06/2006	E-Class	211	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	
As of 06/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	●	●	●	●	○	●	C0D4 C02C C0D5 C0D6	F167 F02C
As of 06/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 06/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
As of 06/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	Telephone adapter for portable CTET-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 06/2006	E-Class	211	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 06/2006	E-Class	211	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 06/2006	E-Class	211	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 06/2006	E-Class	211	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	GPS box	●	●	○	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 06/2006	E-Class	211	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 06/2006	E-Class	211	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 06/2006	E-Class	211	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 06/2006	E-Class	211	Information and communication	SDAR-Satellite radio (Valid for USA)	●	●	●	●	●	●	●			
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 06/2006	E-Class	211	Information and communication	CTEL-Cellular telephone (JAPAN)	●	●	○	●	●	○	●			
As of 06/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
As of 06/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
As of 06/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
As of 06/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 06/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
As of 06/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
As of 06/2006	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
As of 06/2006	E-Class	211	Seats and doors	HS-Seat heater	●	●	●	●	○	○	○			
As of 06/2006	E-Class	211	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
As of 06/2006	E-Class	211	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	E-Class	211	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	E-Class	211	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
As of 06/2006	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	●	●	●	●	●	●	●			
As of 06/2006	E-Class	211	Seats and doors	RWT-Rear-end door control module	●	●	●	●	●	○	●		C001	F16A F16B
As of 06/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C0D8 C001	F16C F16D
As of 06/2006	E-Class	211	Seats and doors	ARWT-Automatic rear-end door	●	●	●	●	●	○	●			
As of 06/2006	E-Class	211	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C007 C046 C047 C06F	F02F F030 F025
As of 06/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	●	●			F025
As of 06/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
As of 06/2006	E-Class	211	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
As of 03/97 DAS 3	E-Class	210	Drive	ETC-Electronic transmission control	●	●	○	●	○	※	●			F12E
As of 03/97 DAS 3	E-Class	210	Drive	ETC-Electronic transmission control	●	●	○	●	●	※	●			F077 F082 F10E F081 F10F F110 F111 F112 F113 F114 F08D F115 F116 F117 F118 F119 F11A F11B F001 F11C F11D F11E F11F F002 F089 F120
As of 03/97 DAS 3	E-Class	210	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 03/97 DAS 3	E-Class	210	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●			FOA4 F155
As of 03/97 DAS 3	E-Class	210	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C001 C002 C069	FOA4 F007 F09F F009 F12D
As of 03/97 DAS 3	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 03/97 DAS 3	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 03/97 DAS 3	E-Class	210	Drive	DFI-Electronic distributor injection system diesel	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Drive	IFI-Electronic in-line injection system diesel	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
As of 03/97 DAS 3	E-Class	210	Chassis	ABS-Antilock brake system	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			F019 F137
As of 03/97 DAS 3	E-Class	210	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			F03D
As of 03/97 DAS 3	E-Class	210	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Chassis	BAS-Brake assist	●	●	○	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Chassis	BAS-Brake assist	●	●	○	●	●	●	●			
As of 03/97 DAS 3	E-Class	210	Chassis	SPS-Speed-sensitive power steering	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
As of 03/97 DAS 3	E-Class	210	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
As of 03/97 DAS 3	E-Class	210	Body	AB-Airbag	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Body	EZS-Electronic ignition switch	●	●	○	●	●	※	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/97 DAS 3	E-Class	210	Body	OCP-Overhead control panel	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Body	LCP-Lower control panel	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Body	PSE-Pneumatic system equipment	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Body	MSS-Special vehicle multifunction control module	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Body	HRA-Headlamp range adjustment	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Body	HRA-Headlamp range adjustment	●	●	○	●	●	○	○			
As of 03/97 DAS 3	E-Class	210	Body	APS-Auto pilot system	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Body	HB-Heater booster	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
As of 03/97 DAS 3	E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	●	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	COMAND	●	●	○	●	●	●	●			
As of 03/97 DAS 3	E-Class	210	Information and communication	AUDIO	●	●	●	●	●	●	●			
As of 03/97 DAS 3	E-Class	210	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
As of 03/97 DAS 3	E-Class	210	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	ICS-Information and communication system	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [USA]-Emergency call system	●	●	●	●	○	○	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Emergency call system	●	●	●	●	●	●	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Telematic system	●	●	○	●	○	●	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
As of 03/97 DAS 3	E-Class	210	Information and communication	DN-Dynamic navigation by means of CTEL	●	●	●	●	●	○	○			
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM1-Door control module front driver side	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM2-Door control module front passenger side	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM3-Door control module rear driver side	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM4-Door control module rear passenger side	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	○	●	●	※	○			
As of 03/97 DAS 3	E-Class	210	Air conditioning	TAC-Automatic temperature control	●	●	○	●	●	※	●			
As of 03/97 DAS 3	E-Class	210	Air conditioning	AAC-Automatic air conditioning	●	●	○	●	○	※	○			
As of 03/97 DAS 3	E-Class	210	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
Up to 05/2005	CLS	219	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 05/2005	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●	●	C070 C04C C068 C069	F12C
Up to 05/2005	CLS	219	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 05/2005	CLS	219	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FO11
Up to 05/2005	CLS	219	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
Up to 05/2005	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●	●	●	●	●	C069 C002 C049 C04B C04A	FOB8 F007 F009 FOA5 FOB9 FOB1 FOA7 FOA3 FOBA FOA1 FOBB FOBC FO0E FO0F F06D F0BD FOBE FOBF FOAA FOAB FOCO FOAD FOAE
Up to 05/2005	CLS	219	Drive	FSCU-Fuel pump	●	●	●	●	○	●	●	●	C068	
Up to 05/2005	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 05/2005	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 05/2005	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FO11
Up to 05/2005	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	○	●		
Up to 05/2005	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	○	●		
Up to 05/2005	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●	●	C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
Up to 05/2005	CLS	219	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●	●		F019
Up to 05/2005	CLS	219	Chassis	AIRmatic	●	●	●	●	●	○	●	●		F06F F15A F15B
Up to 05/2005	CLS	219	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●	●	C001	
Up to 05/2005	CLS	219	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●	●		
Up to 05/2005	CLS	219	Body	CGW-Central gateway	●	●	●	●	○	○	○	●	C007 C006 C00F C010 C011 C012 C074 C013 C014 C015 C016 C076 C077 C078 C079 C017 C07A C07C C08B C0AA C0AB C0AC C005	F01B F01C F01D
Up to 05/2005	CLS	219	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	●	●		F01E F01F F020 F13A F022 F15D F023 F15E
Up to 05/2005	CLS	219	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
Up to 05/2005	CLS	219	Body	WSS-Weight sensing system	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Body	BCM-Battery control module	●	●	○	●	●	●	●	●		
Up to 05/2005	CLS	219	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
Up to 05/2005	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	○	●	●	C0AD C0AE C0AF C075 C0B0 C0B1 C0B2 C0B3 C0B4 C0B5 C0B6 C0B7 C0B8 C0B9 C0BA C0BB	
Up to 05/2005	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●	●	C070 C0AD C0BC C0B3 C0B5 C0BD C0BA C0B9 C0BE	
Up to 05/2005	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●	●	C0BF C0C0 C0C1 C0C2 C0C3 C0C4 C0C5 C0C6 C0C7 C0C8	
Up to 05/2005	CLS	219	Body	LCP-Lower control panel	●	●	●	●	●	○	●	●		
Up to 05/2005	CLS	219	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●		
Up to 05/2005	CLS	219	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C0CA C025 C0CB C092 C093 C0CC C0CD C091 C0CE C094 C0CF	F13C F15F F13B F160 F13E F161 F162 F163
Up to 05/2005	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001	
Up to 05/2005	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001	
Up to 05/2005	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
Up to 05/2005	CLS	219	Body	On board electrical system(voltage supply)	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●	●		
Up to 05/2005	CLS	219	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 05/2005	CLS	219	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E C09B C02C C09C C0D0 C0D1 C0D2 C0D3	F166 F028
Up to 05/2005	CLS	219	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	
Up to 05/2005	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	●	●	●	●	○	●	C0D4 C02C C0D5 C0D6	F167 F02C

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
Up to 05/2005	CLS	219	Information and communication	AUDIO	●	●	●	●	●	●	●	●	C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 05/2005	CLS	219	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●	●		
Up to 05/2005	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●	●		
Up to 05/2005	CLS	219	Information and communication	CDC-CD changer	●	●	○	●	●	●	○	●		F02E
Up to 05/2005	CLS	219	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●	●		
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner	●	●	○	●	●	●	●	●		
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●	●	C09B C0A9	
Up to 05/2005	CLS	219	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	GPS box	●	●	○	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○	●		
Up to 05/2005	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
Up to 05/2005	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
Up to 05/2005	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
Up to 05/2005	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
Up to 05/2005	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●	●		
Up to 05/2005	CLS	219	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●	●		
Up to 05/2005	CLS	219	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	CLS	219	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	CLS	219	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	CLS	219	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001	F169 F025
Up to 05/2005	CLS	219	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●	●	C001	
Up to 05/2005	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	●	●	●	●	●	●	●	●		
Up to 05/2005	CLS	219	Seats and doors	RWT-Rear-end door control module	●	●	●	●	●	○	●	●	C001	F16A F16B
Up to 05/2005	CLS	219	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C007 C046 C047 C06F	F02F F030 F025
Up to 05/2005	CLS	219	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●	●		
Up to 05/2005	CLS	219	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●	●		F152
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 06/2005 to 05/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●	●	C070 C04C C068 C069	F12C
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 06/2005 to 05/2006	CLS	219	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE F011
From 06/2005 to 05/2006	CLS	219	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
From 06/2005 to 05/2006	CLS	219	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function	
From 06/2005 to 05/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●	●	●	●		C069 C002 C049 C04B C04A	FOB8 FOB7 FOB9 FOA5 FOB9 FOB1 FOA7 FOA3 FOBA FOA1 FOBB FOBC FO0E FO0F F06D FOBD FOBE FOBF FOAA FOAB FOCO FOAD FOAE	
From 06/2005 to 05/2006	CLS	219	Drive	FSCU-Fuel pump	●	●	●	●	○	●	●		C068		
From 06/2005 to 05/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135	
From 06/2005 to 05/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135	
From 06/2005 to 05/2006	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 FO07 FO08 FO09 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE F011	
From 06/2005 to 05/2006	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	○				
From 06/2005 to 05/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	○				
From 06/2005 to 05/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154	
From 06/2005 to 05/2006	CLS	219	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○				
From 06/2005 to 05/2006	CLS	219	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019	
From 06/2005 to 05/2006	CLS	219	Chassis	AIRmatic	●	●	●	●	●	○	●			F06F F15A F15B	
From 06/2005 to 05/2006	CLS	219	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●				
From 06/2005 to 05/2006	CLS	219	Body	CGW-Central gateway	●	●	●	●	○	○	○	●	C007 C006 C00F C010 C011 C012 C074 C013 C014 C015 C016 C076 C077 C078 C079 C017 C07A C07C C08B COAA COAB COAC CO05	F01B F01C F01D	
From 06/2005 to 05/2006	CLS	219	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	●	●			F01E F01F F020 F13A F022 F15D F023 F15E
From 06/2005 to 05/2006	CLS	219	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A		
From 06/2005 to 05/2006	CLS	219	Body	WSS-Weight sensing system	●	●	●	●	●	●	○				
From 06/2005 to 05/2006	CLS	219	Body	BCM-Battery control module	●	●	○	●	●	●	●				
From 06/2005 to 05/2006	CLS	219	Body	System diagnosis (CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C		
From 06/2005 to 05/2006	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	○	●		COAD COAE COAF C075 COB0 COB1 COB2 COB3 COB4 COB5 COB6 COB7 COB8 COB9 COBA COBB		
From 06/2005 to 05/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●		C070 COAD COBC COB3 COB5 COBD COBA COB9 COBE		
From 06/2005 to 05/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●		COBF COC0 COC1 COC2 COC3 COC4 COC5 COC6 COC7 COC8		
From 06/2005 to 05/2006	CLS	219	Body	LCP-Lower control panel	●	●	●	●	●	○	●	●			
From 06/2005 to 05/2006	CLS	219	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●			
From 06/2005 to 05/2006	CLS	219	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	COCA C025 COCB C092 C093 COCC COCD C091 COCE C094 COCF	F13C F15F F13B F160 F13E F161 F162 F163	
From 06/2005 to 05/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001		
From 06/2005 to 05/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001		
From 06/2005 to 05/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 COA8	F157	
From 06/2005 to 05/2006	CLS	219	Body	On board electrical system(voltage supply)	●	●	●	●	●	●	○				
From 06/2005 to 05/2006	CLS	219	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●				
From 06/2005 to 05/2006	CLS	219	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●				
From 06/2005 to 05/2006	CLS	219	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E C09B C02C C09C C0D0 C0D1 C0D2 C0B3	F166 F028	
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F		
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	●	●	●	●	○	●	C0D4 C02C C0D5 C0D6	F167 F02C	
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025	
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025	
From 06/2005 to 05/2006	CLS	219	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025	
From 06/2005 to 05/2006	CLS	219	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●				

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 06/2005 to 05/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
From 06/2005 to 05/2006	CLS	219	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
From 06/2005 to 05/2006	CLS	219	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
From 06/2005 to 05/2006	CLS	219	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Information and communication	GPS box	●	●	○	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance (USA, Canada),Tele diagnosis (ECE)	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
From 06/2005 to 05/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
From 06/2005 to 05/2006	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
From 06/2005 to 05/2006	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 06/2005 to 05/2006	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 06/2005 to 05/2006	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	CLS	219	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001	F169 F025
From 06/2005 to 05/2006	CLS	219	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
From 06/2005 to 05/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	●	●	●	●	●	●	●			
From 06/2005 to 05/2006	CLS	219	Seats and doors	RWT-Rear-end door control module	●	●	●	●	●	○	●		C001	F16A F16B
From 06/2005 to 05/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C007 C046 C047 C06F	F02F F030 F025
From 06/2005 to 05/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
From 06/2005 to 05/2006	CLS	219	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
As of 06/2006	CLS	219	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 06/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
As of 06/2006	CLS	219	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 06/2006	CLS	219	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
As of 06/2006	CLS	219	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
As of 06/2006	CLS	219	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
As of 06/2006	CLS	219	Drive	TV-TV tuner	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●	●	●	●		C069 C002 C049 C04B C04A	F0B8 F007 F009 F0A5 F0B9 F0B1 F0A7 F0A3 F0BA F0A1 F0BB F0BC F00E F00F F06D F0BD F0BE F0BF F0AA F0AB F0CO F0AD F0AE
As of 06/2006	CLS	219	Drive	FSCU-Fuel pump	●	●	●	●	○	●	●		C068	
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 06/2006	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FO11
As of 06/2006	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	○			
As of 06/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	○			
As of 06/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
As of 06/2006	CLS	219	Chassis	ABR-Adaptive Brake	●	●	●	●	●	●	●	●		F019 FOEA F15C
As of 06/2006	CLS	219	Chassis	AIRmatic	●	●	●	●	●	○	●			F06F F15A F15B
As of 06/2006	CLS	219	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
As of 06/2006	CLS	219	Body	CGW-Central gateway	●	●	●	●	○	○	○	●	C007 C006 C00F C010 C011 C012 C074 C013 C014 C015 C016 C076 C077 C078 C079 C017 C07A C07C C08B C0AA C0AB C0AC C005	F01B F01C F01D
As of 06/2006	CLS	219	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	●	●		F01E F01F F020 F13A F022 F15D F023 F15E
As of 06/2006	CLS	219	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
As of 06/2006	CLS	219	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Body	System diagnosis (CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
As of 06/2006	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	○	●		C0AD C0AE C0AF C075 C0B0 C0B1 C0B2 C0B3 C0B4 C0B5 C0B6 C0B7 C0B8 C0B9 C0BA C0BB	
As of 06/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●		C070 C0AD C0BC C0B3 C0B5 C0BD C0BA C0B9 C0BE	
As of 06/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●		C0BF C0C0 C0C1 C0C2 C0C3 C0C4 C0C5 C0C6 C0C7 C0C8	
As of 06/2006	CLS	219	Body	LCP-Lower control panel	●	●	●	●	●	○	●	●		
As of 06/2006	CLS	219	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●		
As of 06/2006	CLS	219	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C0CA C025 C0CB C092 C093 C0CC C0CD C091 C0CE C094 C0CF	F13C F15F F13B F160 F13E F161 F162 F163
As of 06/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001	
As of 06/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C001	
As of 06/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	●	●	C04D C04E C0A5 C0A6 C0A7	
As of 06/2006	CLS	219	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
As of 06/2006	CLS	219	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E C09B C02C C09C C0D0 C0D1 C0D2 C0D3	F166 F028
As of 06/2006	CLS	219	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	
As of 06/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	●	●	●	●	○	●	C0D4 C02C C0D5 C0D6	F167 F02C
As of 06/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 06/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
As of 06/2006	CLS	219	Information and communication	AUDIO	●	●	●	●	●	●	●	●	C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 06/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 06/2006	CLS	219	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 06/2006	CLS	219	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 06/2006	CLS	219	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 06/2006	CLS	219	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	GPS box	●	●	○	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 06/2006	CLS	219	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 06/2006	CLS	219	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 06/2006	CLS	219	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 06/2006	CLS	219	Information and communication	SDAR-Satellite radio (Valid for USA)	●	●	●	●	●	●	●			
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 06/2006	CLS	219	Information and communication	CTEL-Cellular telephone (JAPAN)	●	●	○	●	●	○	●			
As of 06/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
As of 06/2006	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
As of 06/2006	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
As of 06/2006	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
As of 06/2006	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
As of 06/2006	CLS	219	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
As of 06/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	CLS	219	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	CLS	219	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●	●	C001	F169 F025
As of 06/2006	CLS	219	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
As of 06/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	●	●	●	●	●	●	●			
As of 06/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C007 C046 C047 C06F	F02F F030 F025
As of 06/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
As of 06/2006	CLS	219	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
As of 2011	CLS	218	Drive	SG-LML-VL - LED matrix of left front lamp unit	●	●	○	●	○	●	○			
As of 2011	CLS	218	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2011	CLS	218	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2011	CLS	218	Drive	FSUCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2011	CLS	218	Drive	FSUCU06 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2011	CLS	218	Drive	ESM [EWM] - Electronic selector module	●	●	○	●	●	●	●			
As of 2011	CLS	218	Drive	ME 9.7-Motor electronics 9.7	●	●	○	●	●	●	●			F17A F17B F17C F17D F17E F17F F180 F181 F182 F183 F184 F185 F186 F187 F188 F189
As of 2011	CLS	218	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	○	●	●	●	●			F17A F17B F17C F17D F18A F180 F181 F184 F185 F186 F187 F188 F189
As of 2011	CLS	218	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	○	●	●	●	●			F18B F17B F17D F17E F18C F18D F181 F18E F18F F183 F190 F191 F192 F193 F194 F195 F196
As of 2011	CLS	218	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2011	CLS	218	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D
As of 2011	CLS	218	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2011	CLS	218	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO'	●	●	●	●	●	●	●			F094 F095 F096 F097 F098 F099 F09A F040 F09B F09C F09D F09E
As of 2011	CLS	218	Drive	VGS - Transmission control for 7-speed transmissio	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2011	CLS	218	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2011	CLS	218	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2011	CLS	218	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2011	CLS	218	Drive	SCR-Selective Catalytic Reduction	●	●	○	●	●	●	●			F1B0 F1B1 F055 F1B2 F1B3 F1B4
As of 2011	CLS	218	Drive	SCR - Selective catalytic reduction	●	●	○	●	●	●	●			F1B5 F1B6 F1B7 F1B1 F1B0 F055
As of 2011	CLS	218	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607'	●	●	○	●	●	●	●			F048 F052 F04B F1B8 F040 F051 F1B9 F042 F1BA F1BB F1BC F04F F04D F1BD F1BE F09A F04A F1BF F056 F1C0 F059
As of 2011	CLS	218	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651'	●	●	○	●	●	●	●			F049 F048 F052 F04B F1C1 F040 F04A F051 F1B9 F042 F1BA F1C2 F1BB F1BC F09A F1BD F1BE F04D F1BF F1C0 F056 F1C3 F059
As of 2011	CLS	218	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	●	●	●			F048 F1C4 F1BE F04F F040 F09A F052 F1BD F1C1 F1C5 F04D F1BB F1C6 F051 F1BF F056 F1C0 F1C3 F059
As of 2011	CLS	218	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642'	●	●	○	●	●	●	●			F048 F1C7 F1C8 F1BD F1C9 F04F F1CA F040 F052 F09A F04D F1BE F1C4 F1C1 F055 F056 F058 F059 F057
As of 2011	CLS	218	Drive	CDI - Motor electronics CRI6EU5 for combustion engine OM651	●	●	○	●	●	●	●			F1CB F1CC F17B F1CD F1CE F1CF F1D0 F17C F1D1 F1D2 F1D3 F1D4 F1D5 F1D6 F1D7
As of 2011	CLS	218	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2011	CLS	218	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			FOF3 FOF4
As of 2011	CLS	218	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			
As of 2011	CLS	218	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			FOEF
As of 2011	CLS	218	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			FOEF FOFO FOF1 FOF2
As of 2011	CLS	218	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			F1D8 F1D9
As of 2011	CLS	218	Chassis	FWGW-Chassis gateway	●	●	○	●	●	●	○			
As of 2011	CLS	218	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2011	CLS	218	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2011	CLS	218	Body	CGW-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2011	CLS	218	Body	EZS-Electronic ignition lock	●	●	●	●	●	●	○			FOF6 F05C F05D F0F7 F0F8 F0F9 F0FE
As of 2011	CLS	218	Body	EZS-Electronic ignition lock	●	●	○	●	●	●	○			
As of 2011	CLS	218	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	SCCM-Steering column module	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2011	CLS	218	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2011	CLS	218	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2011	CLS	218	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2011	CLS	218	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2011	CLS	218	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2011	CLS	218	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	HKS-Tailgate control (N121/1)	●	●	○	●	●	●	●			F1DB F1DC
As of 2011	CLS	218	Body	MPK-Multifunction camera	●	●	○	●	●	●	○			
As of 2011	CLS	218	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	●			FOFD
As of 2011	CLS	218	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2011	CLS	218	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 2011	CLS	218	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2011	CLS	218	Body	OCP-Overhead control panel	●	●	○	●	●	●	●			F0FD
As of 2011	CLS	218	Body	Trailer recognition module	●	●	●	●	●	●	●			
As of 2011	CLS	218	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2011	CLS	218	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2011	CLS	218	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2011	CLS	218	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2011	CLS	218	Body	XALWA-L-Left xenon headlamp	●	●	○	●	●	●	○			
As of 2011	CLS	218	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	●			F071 F072 F073 F074
As of 2011	CLS	218	Body	XALWA-R-Right xenon headlamp	●	●	○	●	●	●	○			
As of 2011	CLS	218	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	●			F075 F076
As of 2011	CLS	218	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2011	CLS	218	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2011	CLS	218	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2011	CLS	218	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	AMG DRVU-AMG DRIVE UNIT	●	●	○	●	●	●	●			
As of 2011	CLS	218	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	○			
As of 2011	CLS	218	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	○	○			
As of 2011	CLS	218	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	ELC - Electronic level control	●	●	○	●	●	●	●			F1DD FOEF
As of 2011	CLS	218	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2011	CLS	218	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2011	CLS	218	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	NAVI20 - Navigation	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	ES-Electrical power steering	●	●	●	●	●	●	○			F1D8
As of 2011	CLS	218	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2011	CLS	218	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	●			
As of 2011	CLS	218	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	●			
As of 2011	CLS	218	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2011	CLS	218	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2011	CLS	218	Information and communication	AVE-H - DVD player	●	●	○	●	●	●	●			
As of 2011	CLS	218	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	CTEL - Mobile phone	●	●	○	●	●	○	○			
As of 2011	CLS	218	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	○			
As of 2011	CLS	218	Information and communication	DSI-DIRECT SELECT interface	●	●	○	●	●	●	○			
As of 2011	CLS	218	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	○	●			
As of 2011	CLS	218	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	●	○			
As of 2011	CLS	218	Seats and doors	AMKS-LF-Active multicontour seat	●	●	●	●	●	●	●			
As of 2011	CLS	218	Seats and doors	AMKS-RF-Active multicontour seat	●	●	●	●	●	●	●			
As of 2011	CLS	218	Seats and doors	ESA Driver - Electric seat adjustmet Driver	●	●	○	●	●	○	●			F106 F107 F108
As of 2011	CLS	218	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'	●	●	○	●	●	●	●			F106 F107 F108
As of 2011	CLS	218	Seats and doors	ESA-Electirc seat adjustment 'Front passenger'	●	●	●	●	●	●	●			F106 F107
As of 2011	CLS	218	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	●			F106 F107
As of 2011	CLS	218	Seats and doors	DCU-LF=Left front door	●	●	●	●	●	●	●			
As of 2011	CLS	218	Seats and doors	DCU-RF=Right front door	●	●	●	●	●	●	●			
As of 2011	CLS	218	Seats and doors	DCU-LR=Left rear door	●	●	○	●	●	●	●			
As of 2011	CLS	218	Seats and doors	DCU-RR=Right rear door	●	●	○	●	●	●	●			
As of 2011	CLS	218	Seats and doors	SIH-FOND=Rear passenger compartment seat heater	●	●	●	●	●	●	●			
As of 2011	CLS	218	Air conditioning	LRH=Steering wheel heater	●	●	●	●	●	●	○			
As of 2011	CLS	218	Air conditioning	AAC=Air conditioning	●	●	●	●	●	●	●			F109 F10A F10B
As of 2011	CLS	218	Air conditioning	STH - Stationary heater	●	●	●	●	●	●	●			
As of 2011	CLS	218	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2011	CLS	218	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			F069 F1DE
As of 2011	CLS	218	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2011	CLS	218	Driver assistance system	360 camera-360 camera	●	●	○	●	●	●	○			
As of 2011	CLS	218	Driver assistance system	IRS-HRA=Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2011	CLS	218	Driver assistance system	IRS-HLA=Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2011	CLS	218	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2011	CLS	218	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2011	CLS	218	Driver assistance system	NSA - Night View Assist	●	●	○	●	●	○	○			
As of 2011	CLS	218	Driver assistance system	NSA-Night View Assist	●	●	○	●	●	●	○			
As of 2011	CLS	218	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			F1DF F1E0 F1E1 F1E2
As of 2011	CLS	218	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2011	CLS	218	Driver assistance system	RFK-Backup camera	●	●	○	●	●	●	●			
As of 2011	CLS	218	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2011	CLS	218	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
Up to 06/2009	S-Class	221	Drive	ISM-Intelligent servo module	●	●	●	●	●	●	●	●	C0DB	F0C1 F0C2
Up to 06/2009	S-Class	221	Drive	ISM-Shift module	●	●	●	●	●	●	●		C06B	F0C1 F0C2
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
Up to 06/2009	S-Class	221	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
Up to 06/2009	S-Class	221	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	●	●	○		C069 C002 C049	
Up to 06/2009	S-Class	221	Drive	DTR-Distronic	●	●	●	●	●	●	○			F1E3
Up to 06/2009	S-Class	221	Drive	SGR-Radar sensors control unit	●	●	●	●	●	○	●			
Up to 06/2009	S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump AMG	●	●	●	●	○	●	●		C001	
Up to 06/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	○	●	○			
Up to 06/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	○			F011 FOA4 F008 F009 F00B F1E4 FOA2 F1E5 FOAB FOAE F1E6 F0C0 F0B6 F0B7
Up to 06/2009	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C048	F007 F009 F013 F0D6 F034 F015 F016 F014 F171 F03B F03A F173 F0D7 F174 F175 F176 F177
Up to 06/2009	S-Class	221	Chassis	ABR-Adaptive Brake	●	●	●	●	●	●	●			F019 FOEA FOEB F1E7
Up to 06/2009	S-Class	221	Chassis	AIRmatic	●	●	●	●	●	●	●			F06F F15A F1E8 F1E9 F15B F1EA F1EB F1EC F1ED F1EE F1EF F1F0 F1F1 F1F2
Up to 06/2009	S-Class	221	Chassis	ABC-ABC active body control	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Chassis	Electronic parking brake-Electric parking brake	●	●	●	●	●	●	●		C001	
Up to 06/2009	S-Class	221	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			F06F F070
Up to 06/2009	S-Class	221	Chassis	EHPS-Electrohydraulic Power Steering	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Body	CGW-Central gateway	●	●	●	●	●	●	○		C006 C001	F01B F01C F025
Up to 06/2009	S-Class	221	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○	●		F01E F139 F01F F020 F13A F023
Up to 06/2009	S-Class	221	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○	●		F01E F139 F01F F020 F13A F023
Up to 06/2009	S-Class	221	Body	KG-KEYLESS GO	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Body	KG-KEYLESS GO	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	●	●		C0DC C0DD CODE C0DF C0E0 C0E1 C0E2 C0E3 C0E4 C0E5 C0E6 C0E7	F025
Up to 06/2009	S-Class	221	Body	AB-Airbag	●	●	●	●	●	●	●		C001 C01D C096 C023 C020 C01F C0E8 C024 C062	
Up to 06/2009	S-Class	221	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
Up to 06/2009	S-Class	221	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Body	OCP-Overhead control panel	●	●	●	●	●	●	●		C070 C001 C092 C025 C0E9 C0EA C0EB C0EC C0CC C094 C0ED C0EE	
Up to 06/2009	S-Class	221	Body	UCP-Upper control panel	●	●	●	●	●	●	●		C001	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 06/2009	S-Class	221	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●		C001	F1F3
Up to 06/2009	S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●		COEF COF0 COF1 COF2 COC7 COC8 COF3	
Up to 06/2009	S-Class	221	Body	BNS-Vehicle power supply control module	●	●	●	●	●	○	●			
Up to 06/2009	S-Class	221	Body	AHE-Trailer recognition	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Body	PSD-Panoramic sliding roof(Interior CAN bus)	●	●	●	●	●	●	●		COF4 COF5	F1F4
Up to 06/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●		C001	
Up to 06/2009	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●		C001	
Up to 06/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●			F1F5
Up to 06/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●		C004 C065	F1F5 F1F6
Up to 06/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●			F1F5
Up to 06/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●		C004 C065	F1F5 F1F6
Up to 06/2009	S-Class	221	Body	System diagnosis (CAN)	●	●	●	●	●	○	○		C02B C007 C02C	
Up to 06/2009	S-Class	221	Body	COU [ZBE]-Central operating unit	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Information and communication	NSA-Night View Assist	●	●	●	●	●	○	●			F1F7 F1F8
Up to 06/2009	S-Class	221	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Information and communication	IC-Instrument cluster	●	●	●	●	●	●	●	●	C02D	F028 F0FF F166
Up to 06/2009	S-Class	221	Information and communication	ASSYST-Active Service System	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	ASSYST PLUS	●	●	●	●	●	●	○			F02C F1F9
Up to 06/2009	S-Class	221	Information and communication	PTS-Parktronic	●	●	●	●	●	●	●		C04D C04E	
Up to 06/2009	S-Class	221	Information and communication	RFK-Backup camera	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	COMAND	●	●	●	●	●	●	●		COF6 COF7 COF8 CO9F C030 COF9 C03E COFA COFB COFC COFD COFE COFF	
Up to 06/2009	S-Class	221	Information and communication	COMAND	●	●	●	●	●	●	●		C004 C051 C052 C100 C101 C053 C102 C103	
Up to 06/2009	S-Class	221	Information and communication	Tuner-Standard tuner	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	Tuner-Tuner sound	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	Tuner-Tuner sound	●	●	●	●	●	○	○			F02E F024
Up to 06/2009	S-Class	221	Information and communication	VCS-Voice control	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	DAB-Digital radio	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	ZAN-Central display	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
Up to 06/2009	S-Class	221	Information and communication	AVE-H - DVD player	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	Left rear screen	●	●	●	●	●	●	●			
Up to 06/2009	S-Class	221	Information and communication	Right rear screen	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
Up to 06/2009	S-Class	221	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
Up to 06/2009	S-Class	221	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C001	
Up to 06/2009	S-Class	221	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C001	
Up to 06/2009	S-Class	221	Seats and doors	MKL-HL-Rear left multicontour backrest	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Seats and doors	MKL-HR-Rear right multicontour backrest	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	●	●	●	C001	F1FA
Up to 06/2009	S-Class	221	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	●	●	●	C001	F1FA
Up to 06/2009	S-Class	221	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	●	●	●	C041	F1FA
Up to 06/2009	S-Class	221	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	●	●	●	C041	F1FA
Up to 06/2009	S-Class	221	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	●	●	●	C001	F1FB F1FC F14E
Up to 06/2009	S-Class	221	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	●	●	●	C001	F1FB F1FC F14E
Up to 06/2009	S-Class	221	Seats and doors	ESA-R-Electric seat adjustment rear	●	●	●	●	●	●	●	●	C001	F1FD
Up to 06/2009	S-Class	221	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●	●		
Up to 06/2009	S-Class	221	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●	●	C001	F1FE
Up to 06/2009	S-Class	221	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C007 C046 C104 C047 C105 C06F	F02F F030 F031 F032 F1FF
Up to 06/2009	S-Class	221	Air conditioning	STH-Stationary heater with remote control	●	●	●	●	●	●	●	●	C106 C107 C108 C109 C10A C10B C06F	F200
Up to 06/2009	S-Class	221	Air conditioning	KBE-H-Rear A/C operating unit	●	●	●	●	●	●	●	●		
As of 07/2009	S-Class	221	Drive	ISM-Shift module	●	●	●	●	●	●	●	●	C06B	F0C1 F0C2
As of 07/2009	S-Class	221	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 07/2009	S-Class	221	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 07/2009	S-Class	221	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●	●	C001	
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●	●	C001	
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	●	●	○	●	C069 C002 C049	
As of 07/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	●	●		F011 F0A4 F008 F009 F00B F1E4 F0A2 F1E5 F0AB F0AE F1E6 F0C0 F0B6 F0B7
As of 07/2009	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	○	●		F011 F0A4 F008 F009 F00B F1E4 F0A2 F1E5 F0AB F0AE F1E6 F0C0 F0B6 F0B7
As of 07/2009	S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		F0A4 F007 F008 F009 F0AF F082 F0A7 F0A9 F0AA F0AB F0AC F0AD F0AE F011
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump AMG	●	●	●	●	○	●	●	●	C001	
As of 07/2009	S-Class	221	Drive	FSCU-Fuel pump	●	●	●	●	○	●	○	●		
As of 07/2009	S-Class	221	Drive	ME-SF 17.7-Motor electronics 17.7	●	●	●	●	●	●	●	●	C069 C002 C049 C04B	F0A4 F008 F007 F0A5 F0B1 F0A7 F0A1 F0A9 F0AA F0AB F0AC F0B2 F0AE
As of 07/2009	S-Class	221	Drive	SG-EM - Electric motor control unit	●	●	●	●	●	●	●	●		
As of 07/2009	S-Class	221	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●	●	●	●	●	C004	F0A4 F0B0 F008 F007 F0A5 F0A6 F0B1 F0A7 F0A8 F0A3 F0A9 F0AB F0AC F0B2 F0AE F0B3 F0B4 F0B5 F0B6 F0B7
As of 07/2009	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	●	●	C003 C048	F007 F009 F013 F0D6 F034 F015 F016 F014 F171 F03B F03A F173 F0D7 F174 F175 F176 F177
As of 07/2009	S-Class	221	Drive	CDI 60LS-Common Rail Diesel Injection	●	●	●	●	●	●	●	●		F016 F033 F034 F013 F036 F038 F0DB F0DC F007 F008 F014 F0D7 F03A F03B F011 F0DD F0DE F0DF F0E0 F0E1

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 07/2009	S-Class	221	Drive	SCR-Selective Catalytic Reduction	●	●	●	●	●	●	●		C069 C049 C04B C04A	F0C3 F0C4 F0C5
As of 07/2009	S-Class	221	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C048 C049 C04A	F016 F011 F033 F034 F008 F03B F0D3 F0D4 F0D5 F0C9
As of 07/2009	S-Class	221	Chassis	DTR-Distronic	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F0EA F0EB F201 F202 F203 F204
As of 07/2009	S-Class	221	Chassis	ABR-Adaptive Brake	●	●	●	●	●	●	●			F019 F0EA F0EB F1E7
As of 07/2009	S-Class	221	Chassis	AIRmatic	●	●	●	●	●	●	●			F06F F15A F1E8 F1E9 F15B F1EA F1EB F1EC F1ED F1EE F1EF F1F0 F1F1 F1F2
As of 07/2009	S-Class	221	Chassis	ABC-ABC active body control	●	●	●	●	●	●	●	●		
As of 07/2009	S-Class	221	Chassis	Electronic parking brake-Electric parking brake	●	●	●	●	●	●	●		C001	
As of 07/2009	S-Class	221	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	●	●			FOEE
As of 07/2009	S-Class	221	Chassis	EHPS-Electrohydraulic Power Steering	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Chassis	RBS-Regenerative braking system	●	●	●	●	●	●	○			F019 F0EB F205 F206 F207 F208 F203
As of 07/2009	S-Class	221	Body	CGW-Central gateway	●	●	●	●	●	●	○		C006 C001	F01B F01C F025
As of 07/2009	S-Class	221	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○	●		F01E F139 F01F F020 F13A F023
As of 07/2009	S-Class	221	Body	KG-KEYLESS GO	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Body	KG-KEYLESS GO	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	●	●		C0DC C0DD C0DE C0DF C0E0 C0E1 C0E2 C0E3 C0E4 C0E5 C0E6 C0E7	F025
As of 07/2009	S-Class	221	Body	AB-Airbag	●	●	●	●	●	●	●		C001 C01D C096 C023 C020 C01F C0E8 C024 C062	
As of 07/2009	S-Class	221	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		C0D9 C0DA	F1DA F10D
As of 07/2009	S-Class	221	Body	SGR-Radar sensors control unit	●	●	●	●	○	●	○			
As of 07/2009	S-Class	221	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Body	OCP-Overhead control panel	●	●	●	●	●	●	●		C070 C001 C092 C025 C0E9 C0EA C0EB C0EC C0CC C094 C0ED C0EE	
As of 07/2009	S-Class	221	Body	UCP-Upper control panel	●	●	●	●	●	●	●		C001	
As of 07/2009	S-Class	221	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●		C001	F1F3
As of 07/2009	S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●		C0EF C0F0 C0F1 C0F2 C0C7 C0C8 C0F3	
As of 07/2009	S-Class	221	Body	Trailer recognition module	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Body	PSD-Panoramic sliding roof(Interior CAN bus)	●	●	●	●	●	●	●		C0F4 C0F5	F1F4
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●		C001	
As of 07/2009	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●		C001	F024
As of 07/2009	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●		C001	
As of 07/2009	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●		C001	F024
As of 07/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●		C004 C065	F1F5 F1F6
As of 07/2009	S-Class	221	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●		C004 C0A4	F1F5 F1F6
As of 07/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●		C004 C065	F1F5 F1F6
As of 07/2009	S-Class	221	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●		C004 C0A4	F1F5 F1F6
As of 07/2009	S-Class	221	Body	System diagnosis(CAN)	●	●	●	●	●	○	○		C02B C007 C02C	
As of 07/2009	S-Class	221	Body	COU [ZBE]-Central operating unit	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	●	●	●		
As of 07/2009	S-Class	221	Body	SG-BMS - Battery management system control unit	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Body	SG-DDW - DC/DC converter control unit	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Body	BNS-Vehicle power supply control module	●	●	●	●	●	○	●			
As of 07/2009	S-Class	221	Information and communication	NSA-Night View Assist	●	●	●	●	●	○	●			F1F7 F1F8
As of 07/2009	S-Class	221	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 07/2009	S-Class	221	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 07/2009	S-Class	221	Information and communication	IC-Instrument cluster	●	●	●	●	●	●	●	●	C02D	F028 F0FF F166
As of 07/2009	S-Class	221	Information and communication	ASSYST-Active Service System	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 07/2009	S-Class	221	Information and communication	ASSYST PLUS	●	●	●	●	●	●	○			F02C F1F9
As of 07/2009	S-Class	221	Information and communication	PTS-PARKTRONIC	●	●	●	●	●	●	●		C04D C04F C04E C06E	
As of 07/2009	S-Class	221	Information and communication	RFK-Backup camera	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	COMAND	●	●	●	●	●	●	●		COF6 COF7 COF8 CO9F C030 COF9 C03E COFA COFB COFC COFD COFE COFF	
As of 07/2009	S-Class	221	Information and communication	COMAND	●	●	●	●	●	●	●		C004 C051 C052 C100 C101 C053 C102 C103	
As of 07/2009	S-Class	221	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	Sound system (Bass amplifier)	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	Tuner-Standard tuner	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	Tuner-Tuner sound	●	●	●	●	●	○	○			F02E F024
As of 07/2009	S-Class	221	Information and communication	Tuner-Tuner sound	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	VCS-Voice control	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	TV-TV tuner (AGW)	●	●	○	●	○	●	○			
As of 07/2009	S-Class	221	Information and communication	SDAR-Satellite radio (Valid for USA)	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	DAB-Digital radio	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	ZAN-Central display	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	AVE-H-Rear audio video unit	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 07/2009	S-Class	221	Information and communication	AVE-H - DVD player	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	Left rear screen	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	Right rear screen	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 07/2009	S-Class	221	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
As of 07/2009	S-Class	221	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Seats and doors	MKL-HL-Rear left multicontour backrest	●	●	●	●	●	●	●	●		
As of 07/2009	S-Class	221	Seats and doors	MKL-HR-Rear right multicontour backrest	●	●	●	●	●	●	●	●		
As of 07/2009	S-Class	221	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	●	●	●	C001	F1FA
As of 07/2009	S-Class	221	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	●	●	●	C001	F1FA
As of 07/2009	S-Class	221	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	●	●	●	C041	F1FA
As of 07/2009	S-Class	221	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	●	●	●	C041	F1FA



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 07/2009	S-Class	221	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	●	●		C001	F1FB F1FC F14E
As of 07/2009	S-Class	221	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	●	●		C001	F1FB F1FC F14E
As of 07/2009	S-Class	221	Seats and doors	ESA-R-Electric seat adjustment rear	●	●	●	●	●	●	●		C001	F1FD
As of 07/2009	S-Class	221	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	F1FE
As of 07/2009	S-Class	221	Seats and doors	TSG-ML-Left center door control unit (interior Can bus)	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Seats and doors	TSG-MR-Right center door control unit (interior Can bus)	●	●	●	●	●	●	●			
As of 07/2009	S-Class	221	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C007 C046 C104 C047 C105 C06F	F02F F030 F031 F032 F1FF
As of 07/2009	S-Class	221	Air conditioning	STH-Stationary heater with remote control	●	●	●	●	●	●	●		C106 C107 C108 C109 C10A C10B C06F	F200
As of 07/2009	S-Class	221	Air conditioning	KBE-H-Rear A/C operating unit	●	●	●	●	●	●	●			
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	●	●	○	●	●	※	●			F077 F082 F10E F081 F10F F110 F111 F112 F113 F114 F08D F115 F116 F117 F118 F119 F11A F11B F001 F11C F11D F11E F11F F002 F089 F120
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 08/2002	S-Class	220	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
Up to 08/2002	S-Class	220	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●	●	※	●	●	C001 C10C C10D C069	FOA4 F20A F025 F009 FOA2
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●	●	※	●			FOA4 F20A F025 F009 FOA2
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
Up to 08/2002	S-Class	220	Drive	DTR-Distronic	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.7-Motor electronics 2.7	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
Up to 08/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002	F012 F0DA F0B3
Up to 08/2002	S-Class	220	Chassis	ESP-Electronic stability program	●	●	●	●	●	※	●	●		F019 F20B F20C
Up to 08/2002	S-Class	220	Chassis	AIRmatic	●	●	●	●	●	※	●	●		F15A F1E9 F15B F1EA F1EB F1EC F1ED F1EE F1EF F1F0 F1F1 F1F2
Up to 08/2002	S-Class	220	Chassis	ABC-ABC active body control	●	●	●	●	●	※	●	●		F06F F20D F20E F20F F210 F211
Up to 08/2002	S-Class	220	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	S-Class	220	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C007 C00F C011 C072 C10E C073 C074 C10F C110 C111 C112 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C086 C085	F01E F139 F020 F01F F212
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	F01E F139 F020 F01F F15D F212 F022 F023
Up to 08/2002	S-Class	220	Body	SAM-FL-Front left signal acquisition and actuation module	●	●	●	●	●	※	●	●	C11D C006 C11E C0C3 C11F C120	F1F3 F213
Up to 08/2002	S-Class	220	Body	SAM-FR-Front right signal acquisition and actuation module	●	●	●	●	●	※	●	●	C121 C122 C123 C124 C125	
Up to 08/2002	S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●	●	C0C8 C126 C127 C128	
Up to 08/2002	S-Class	220	Body	AHE-Trailer recognition	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	S-Class	220	Body	OCP-Overhead control panel	●	●	●	●	●	※	●	●	C129 C12A C12B	F214 F215 F216
Up to 08/2002	S-Class	220	Body	PSE-Pneumatic system equipment	●	●	●	●	●	※	●	●	C12C C12D C12E C12F C130 C131 C132 C114 C133 C134	
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	●	●	●	●	●	※	●	●		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2002	S-Class	220	Body	KG-KEYLESS GO	●	●	●	●	●	※	●	●		F217 F218
Up to 08/2002	S-Class	220	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	※	●	●		F025
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	S-Class	220	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
Up to 08/2002	S-Class	220	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○	○	C001	
Up to 08/2002	S-Class	220	Body	CGW-Central gateway	●	●	●	●	○	○	○	○	C005 C006 C007	F01B F01C F01D
Up to 08/2002	S-Class	220	Body	AB-Airbag	●	●	●	●	●	●	○	○	C059 C09A C01D C01C C08E C023 C097 C01F	
Up to 08/2002	S-Class	220	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	○	●		
Up to 08/2002	S-Class	220	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	○	●		
Up to 08/2002	S-Class	220	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●		
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●		
Up to 08/2002	S-Class	220	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	○		
Up to 08/2002	S-Class	220	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●	●		
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
Up to 08/2002	S-Class	220	Information and communication	TSTH-Radio remote control of stationary heater	●	●	●	●	●	※	●	●		
Up to 08/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	※	●	●	C135 C136 C0D2 C137 C138 C02C C09C C139 C13A C02F C09E C0D0 C13B C0A3	F219 F166
Up to 08/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C135 C136 C0D2 C137 C138 C02C C09C C139 C13A C02F C09E C0D0 C13B C0A3	F219 F166
Up to 08/2002	S-Class	220	Information and communication	COMAND	●	●	○	●	●	●	●	●		
Up to 08/2002	S-Class	220	Information and communication	AUDIO	●	●	●	●	●	●	●	●		
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	●	●	●	●	○	○	○	○		
Up to 08/2002	S-Class	220	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○	○		
Up to 08/2002	S-Class	220	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●	●		
Up to 08/2002	S-Class	220	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○	○		
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○	○		
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	●	●	●	●	●	●	●	●		
Up to 08/2002	S-Class	220	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○	○		
Up to 08/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●	●		
Up to 08/2002	S-Class	220	Information and communication	E-call [USA]-Emergency call system	●	●	●	●	○	○	○	○		
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Emergency call system	●	●	●	●	●	●	○	○		
Up to 08/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○	○		
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○	○		
Up to 08/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○	○		
Up to 08/2002	S-Class	220	Information and communication	DN-Dynamic navigation by means of CTEL	●	●	●	●	●	○	○	○		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
Up to 08/2002	S-Class	220	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
Up to 08/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●			
Up to 08/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 08/2002	S-Class	220	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
Up to 08/2002	S-Class	220	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
Up to 08/2002	S-Class	220	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
Up to 08/2002	S-Class	220	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	GPS box	●	●	○	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
Up to 08/2002	S-Class	220	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	※	●	●	C001 C13C	
Up to 08/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	※	●	●	C001 C13C	
Up to 08/2002	S-Class	220	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	S-Class	220	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear	●	●	●	●	●	※	●	●	C0C9 C04C	F21A F21B F21C F21D
Up to 08/2002	S-Class	220	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	※	●	●	C0C9 C13D C13E	F21E F21F F220 F221 F222 F223 F224
Up to 08/2002	S-Class	220	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	※	●	●	C0C9 C04C C13D C13E	F21E F21F F220 F221 F222 F223 F224
Up to 08/2002	S-Class	220	Seats and doors	OSB-R-Multicontour backrest rear	●	●	●	●	●	※	●			
Up to 08/2002	S-Class	220	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	●			
Up to 08/2002	S-Class	220	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	●			
Up to 08/2002	S-Class	220	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●			
Up to 08/2002	S-Class	220	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●			
Up to 08/2002	S-Class	220	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
Up to 08/2002	S-Class	220	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C11C C13F C124	F225 F226 F227 F228 F229 F22A F22B F22C F22D F22E F22F F230 F231 F232 F233 F234 F235 F236 F237
Up to 08/2002	S-Class	220	Air conditioning	REAR AC- Rear air conditioning	●	●	●	●	●	※	●			
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	○			
Up to 08/2002	S-Class	220	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	●			
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
As of 09/2002	S-Class	220	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
As of 09/2002	S-Class	220	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
As of 09/2002	S-Class	220	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
As of 09/2002	S-Class	220	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
As of 09/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
As of 09/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
As of 09/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
As of 09/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●			
As of 09/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 09/2002	S-Class	220	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 09/2002	S-Class	220	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 09/2002	S-Class	220	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 09/2002	S-Class	220	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	GPS box	●	●	○	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 09/2002	S-Class	220	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	※	●	●	C001 C13C	
As of 09/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	※	●	●	C001 C13C	
As of 09/2002	S-Class	220	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	※	●	●	C001	
As of 09/2002	S-Class	220	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	※	●	●	C001	
As of 09/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear	●	●	●	●	●	※	●	●	C0C9 C04C	F21A F21B F21C F21D
As of 09/2002	S-Class	220	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	※	●	●	C0C9 C13D C13E	F21E F21F F220 F221 F222 F223 F224
As of 09/2002	S-Class	220	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	※	●	●	C0C9 C04C C13D C13E	F21E F21F F220 F221 F222 F223 F224

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2002	S-Class	220	Seats and doors	OSB-R-Multicontour backrest rear	●	●	●	●	●	※	●			
As of 09/2002	S-Class	220	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	●			
As of 09/2002	S-Class	220	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	●			
As of 09/2002	S-Class	220	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●			
As of 09/2002	S-Class	220	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●			
As of 09/2002	S-Class	220	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
As of 09/2002	S-Class	220	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C11C C13F C124	F225 F226 F227 F228 F229 F22A F22B F22C F22D F22E F22F F230 F231 F232 F233 F234 F235 F236 F237
As of 09/2002	S-Class	220	Air conditioning	REAR AC- Rear air conditioning	●	●	●	●	●	※	●			
As of 09/2002	S-Class	220	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
As of 09/2002	S-Class	220	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			
From 1991 to 1998	S-Class	140	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●			FOA4 F155
From 1991 to 1998	S-Class	140	Drive	MEIRE-Motor electronics 1 RE	●	●	○	●	○	※	○			
From 1991 to 1998	S-Class	140	Drive	EFP, TPM, ISC-Electronic accelerator pedal, Cruise control, Idle speed control	●	●	○	●	○	※	○			
From 1991 to 1998	S-Class	140	Chassis	EGS, EAG-Electronic control for automatic transmission	●	●	○	●	○	※	○			
From 1991 to 1998	S-Class	140	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
From 1991 to 1998	S-Class	140	Chassis	BAS-Brake assist	●	●	○	●	●	※	●			
From 1991 to 1998	S-Class	140	Chassis	SPS-Speed-sensitive power steering	●	●	○	●	●	※	○			
From 1991 to 1998	S-Class	140	Body	RFL-Radio frequency locking/electric central locking	●	●	○	●	●	※	○			
From 1991 to 1998	S-Class	140	Body	PTS-Parktronic system	●	●	○	●	○	※	○			
From 1991 to 1998	S-Class	140	Body	PSE-Pneumatic system equipment	●	●	○	●	○	※	○			
From 1991 to 1998	S-Class	140	Body	AirBag	●	●	○	●	○	※	○			
From 1991 to 1998	S-Class	140	Body	KFB-Power windows, emergency opening, convenience closing, tilting/sliding roof	●	●	○	●	○	※	○			
From 1991 to 1998	S-Class	140	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
From 1991 to 1998	S-Class	140	Air conditioning	AAC-Automatic air conditioning	●	●	○	●	○	※	○			
As of 2006	CL	216	Drive	ISM-Intelligent servo module	●	●	●	●	●	●	●	●	C0DB	F0C1 F0C2
As of 2006	CL	216	Drive	ISM-Shift module	●	●	●	●	●	●	●		C06B	F0C1 F0C2
As of 2006	CL	216	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 2006	CL	216	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 2006	CL	216	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
As of 2006	CL	216	Drive	DTR-Distronic	●	●	●	●	●	●	○			F1E3
As of 2006	CL	216	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
As of 2006	CL	216	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
As of 2006	CL	216	Drive	FSCU-Fuel pump	●	●	●	●	●	●	○		C069 C002 C049	
As of 2006	CL	216	Drive	SGR-Radar sensors control unit	●	●	●	●	●	○	●			
As of 2006	CL	216	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	●			F011 FOA4 F008 F009 FO0B F1E4 FOA2 F1E5 FOAB FOAE F1E6 FOCC FOB6 FOB7
As of 2006	CL	216	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	○			F011 FOA4 F008 F009 FO0B F1E4 FOA2 F1E5 FOAB FOAE F1E6 FOCC FOB6 FOB7
As of 2006	CL	216	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
As of 2006	CL	216	Drive	FSCU-Fuel pump AMG	●	●	●	●	○	●	●		C001	
As of 2006	CL	216	Drive	FSCU-Fuel pump	●	●	●	●	○	●	○			
As of 2006	CL	216	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●	●	●	●		C004	FOA4 FOB0 F008 F007 FOA5 FOA6 FOB1 FOA7 FOA8 FOA3 FOA9 FOAB FOAC FOB2 FOAE FOB3 FOB4 FOB5 FOB6 FOB7
As of 2006	CL	216	Chassis	DTR-Distronic	●	●	●	●	●	●	○			
As of 2006	CL	216	Chassis	ABR-Adaptive Brake	●	●	●	●	●	●	●			F019 FOEA FOEB F1E7
As of 2006	CL	216	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 FOEA FOEB F201 F202 F203 F204
As of 2006	CL	216	Chassis	AIRmatic	●	●	●	●	●	●	●			F06F F15A F1E8 F1E9 F15B F1EA F1EB F1EC F1ED F1EE F1EF F1F0 F1F1 F1F2



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2006	CL	216	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	●			
As of 2006	CL	216	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●			
As of 2006	CL	216	Information and communication	TV-TV tuner(AGW)	●	●	○	●	○	●	○			
As of 2006	CL	216	Information and communication	DAB-Digital radio	●	●	●	●	●	●	○			
As of 2006	CL	216	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	○			
As of 2006	CL	216	Information and communication	ZAN-Central display	●	●	●	●	●	●	●			
As of 2006	CL	216	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 2006	CL	216	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 2006	CL	216	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 2006	CL	216	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●	●	●	○			
As of 2006	CL	216	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 2006	CL	216	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 2006	CL	216	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
As of 2006	CL	216	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C001	
As of 2006	CL	216	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C001	
As of 2006	CL	216	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
As of 2006	CL	216	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	●	●	●	C001	F1FA
As of 2006	CL	216	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	●	●	●	C001	F1FA
As of 2006	CL	216	Seats and doors	RCM-Rear control module	●	●	●	●	●	●	○			
As of 2006	CL	216	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	●	●		C001	F1FB F1FC F14E
As of 2006	CL	216	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	●	●		C001	F1FB F1FC F14E
As of 2006	CL	216	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●	●		
As of 2006	CL	216	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	F1FE
As of 2006	CL	216	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C007 C046 C104 C047 C105 C06F	F02F F030 F031 F032 F1FF
As of 2006	CL	216	Air conditioning	STH-Stationary heater with remote control	●	●	●	●	●	●	●		C106 C107 C108 C109 C10A C10B C06F	F200
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control	●	●	○	●	●	※	●			F077 F082 F10E F081 F10F F110 F111 F112 F113 F114 F08D F115 F116 F117 F118 F119 F11A F11B F001 F11C F11D F11E F11F F002 F089 F120
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 08/2002	CL	215	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
Up to 08/2002	CL	215	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●	●	※	●	●	C001 C10C C10D C069	FOA4 F20A F025 F009 FOA2
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●	●	※	●			FOA4 F20A F025 F009 FOA2
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2002	CL	215	Drive	ME-SFI 2.7-Motor electronics 2.7	●	●	●	●	●	●	○			
Up to 08/2002	CL	215	Chassis	ESP-Electronic stability program	●	●	●	●	●	※	●	●		F019 F20B F20C
Up to 08/2002	CL	215	Chassis	ABC-ABC active body control	●	●	●	●	●	※	●	●		F06F F20D F20E F20F F210 F211
Up to 08/2002	CL	215	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	CL	215	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C007 C00F C011 C072 C10E C073 C074 C10F C110 C111 C112 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C086 C085	F01E F139 F020 F01F F212
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	F01E F139 F020 F01F F15D F212 F022 F023
Up to 08/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	●	●	●	●	●	※	●	●	C11D C006 C11E C0C3 C11F C120	F1F3 F213
Up to 08/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	●	●	●	●	●	※	●	●	C121 C122 C123 C124 C125	
Up to 08/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●	●	C0C8 C126 C127 C128	
Up to 08/2002	CL	215	Body	AHE-Trailer recognition	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	CL	215	Body	OCP-Overhead control panel	●	●	●	●	●	※	●	●	C129 C12A C12B	F214 F215 F216
Up to 08/2002	CL	215	Body	PSE-Pneumatic system equipment	●	●	●	●	●	※	●	●	C12C C12D C12E C12F C130 C131 C132 C114 C133 C134	
Up to 08/2002	CL	215	Body	UCP-Upper control panel	●	●	●	●	●	※	●	●		
Up to 08/2002	CL	215	Body	KG-KEYLESS GO	●	●	●	●	●	※	●	●		F217 F218
Up to 08/2002	CL	215	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	※	●	●		F025
Up to 08/2002	CL	215	Body	HRA-Headlamp range adjustment	●	●	●	●	●	※	●	●	C001	
Up to 08/2002	CL	215	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●	●		
Up to 08/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
Up to 08/2002	CL	215	Information and communication	TSTH-Radio remote control of stationary heater	●	●	●	●	●	※	●	●		
Up to 08/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	※	●	●	C135 C136 C0D2 C137 C138 C02C C09C C139 C13A C02F C09E C0D0 C13B C0A3	F219 F166
Up to 08/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C135 C136 C0D2 C137 C138 C02C C09C C139 C13A C02F C09E C0D0 C13B C0A3	F219 F166
Up to 08/2002	CL	215	Information and communication	COMAND	●	●	○	●	●	●	●	●		
Up to 08/2002	CL	215	Information and communication	AUDIO	●	●	●	●	●	●	●	●		
Up to 08/2002	CL	215	Information and communication	CDC-CD changer	●	●	●	●	○	○	○	○		
Up to 08/2002	CL	215	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○	○		
Up to 08/2002	CL	215	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●	○		
Up to 08/2002	CL	215	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○	○		
Up to 08/2002	CL	215	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○	○		
Up to 08/2002	CL	215	Information and communication	TV-TV tuner	●	●	●	●	●	●	●	●		
Up to 08/2002	CL	215	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○	○		
Up to 08/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●	●		
Up to 08/2002	CL	215	Information and communication	E-call [USA]-Emergency call system	●	●	●	●	○	○	○	○		
Up to 08/2002	CL	215	Information and communication	TELE AID-Emergency call system	●	●	●	●	●	●	○	○		
Up to 08/2002	CL	215	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○	○		
Up to 08/2002	CL	215	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○	○		
Up to 08/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○	○		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2002	CL	215	Information and communication	DN-Dynamic navigation by means of CTEL	●	●	●	●	●	○	○			
Up to 08/2002	CL	215	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	※	●	●	C001 C13C	
Up to 08/2002	CL	215	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	※	●	●	C001 C13C	
Up to 08/2002	CL	215	Seats and doors	RCM-Rear control module	●	●	○	●	●	※	○			
Up to 08/2002	CL	215	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	○	●	●	※	●			
Up to 08/2002	CL	215	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	○	●	●	※	●			
Up to 08/2002	CL	215	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	○			
Up to 08/2002	CL	215	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	○			
Up to 08/2002	CL	215	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C11C C13F C124	F225 F226 F227 F228 F229 F22A F22B F22C F22D F22E F22F F230 F231 F232 F233 F234 F235 F236 F237
Up to 08/2002	CL	215	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	○			
Up to 08/2002	CL	215	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
Up to 08/2002	CL	215	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	●			
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 09/2002	CL	215	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
As of 09/2002	CL	215	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
As of 09/2002	CL	215	Drive	DTR-Distronic	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	●	●	●	●	●	※	●	●	C001 C10C C10D C069	FOA4 F20A F025 F009 FOA2
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 09/2002	CL	215	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●	●	●	●	●	C069 C140 C04B	F009 FOA2 F00C F00D F00E F00F F06D F238 F010 F011
As of 09/2002	CL	215	Chassis	ESP-Electronic stability program	●	●	●	●	●	※	●	●		F019 F20B F20C
As of 09/2002	CL	215	Chassis	ABC-ABC active body control	●	●	●	●	●	※	●	●		F06F F20D F20E F20F F210 F211
As of 09/2002	CL	215	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●	●	C001	
As of 09/2002	CL	215	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	
As of 09/2002	CL	215	Body	PSE-Pneumatic system equipment	●	●	●	●	●	※	●	●	C12C C12D C12E C12F C130 C131 C132 C114 C133 C134	
As of 09/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	●	●	●	●	●	※	●	●	C11D C006 C11E C0C3 C11F C120	F1F3 F213
As of 09/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	●	●	●	●	●	※	●	●	C121 C122 C123 C124 C125	
As of 09/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●	●	C0C8 C126 C127 C128	
As of 09/2002	CL	215	Body	AHE-Trailer recognition	●	●	●	●	●	※	●	●	C001	
As of 09/2002	CL	215	Body	KG-KEYLESS GO	●	●	●	●	●	※	●	●		F217 F218
As of 09/2002	CL	215	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	※	●			F025
As of 09/2002	CL	215	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
As of 09/2002	CL	215	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
As of 09/2002	CL	215	Body	CGW-Central gateway	●	●	●	●	○	○	○		C005 C006 C007	F01B F01C F01D
As of 09/2002	CL	215	Body	AB-Airbag	●	●	●	●	●	●	○		C059 C09A C01D C01C C08E C023 C097 C01F	
As of 09/2002	CL	215	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
As of 09/2002	CL	215	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
As of 09/2002	CL	215	Body	System diagnosis(CAN)	●	●	●	●	○	●	○			
As of 09/2002	CL	215	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●	●		
As of 09/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C135 C136 COD2 C137 C138 C02C C09C C139 C13A C02F C09E COD0 C13B C0A3	F219 F166
As of 09/2002	CL	215	Information and communication	COMAND	●	●	○	●	●	●	●			
As of 09/2002	CL	215	Information and communication	AUDIO	●	●	●	●	●	●	●			
As of 09/2002	CL	215	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
As of 09/2002	CL	215	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
As of 09/2002	CL	215	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
As of 09/2002	CL	215	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
As of 09/2002	CL	215	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
As of 09/2002	CL	215	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
As of 09/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
As of 09/2002	CL	215	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
As of 09/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
As of 09/2002	CL	215	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●			
As of 09/2002	CL	215	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 09/2002	CL	215	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 09/2002	CL	215	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 09/2002	CL	215	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 09/2002	CL	215	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
As of 09/2002	CL	215	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
As of 09/2002	CL	215	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 09/2002	CL	215	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 09/2002	CL	215	Information and communication	GPS box	●	●	○	●	●	●	○			
As of 09/2002	CL	215	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 09/2002	CL	215	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	※	●	●	C001 C13C	
As of 09/2002	CL	215	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	※	●	●	C001 C13C	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2002	CL	215	Seats and doors	RCM-Rear control module	●	●	○	●	●	※	○			
As of 09/2002	CL	215	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	○	●	●	※	●			
As of 09/2002	CL	215	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	○	●	●	※	●			
As of 09/2002	CL	215	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	○			
As of 09/2002	CL	215	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	○			
As of 09/2002	CL	215	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C11C C13F C124	F225 F226 F227 F228 F229 F22A F22B F22C F22D F22E F22F F230 F231 F232 F233 F234 F235 F236 F237
As of 09/2002	CL	215	Air conditioning	REAR AC- Rear air conditioning	●	●	●	●	●	※	●			
As of 09/2002	CL	215	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
As of 09/2002	CL	215	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			
Up to 08/2006	MayBach	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 08/2006	MayBach	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
Up to 08/2006	MayBach	240	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
Up to 08/2006	MayBach	240	Drive	SGR-Radar sensors control unit	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●	●	●	●		C069 C140 C04B	F009 F0A2 F00C F00D F00E F00F F06D F238 F010 F011
Up to 08/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	○	○			
Up to 08/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	●	●	●	●	●	○	○			
Up to 08/2006	MayBach	240	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
Up to 08/2006	MayBach	240	Chassis	AIRmatic	●	●	●	●	●	○	●			F06F F15A F15B
Up to 08/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●		C001	
Up to 08/2006	MayBach	240	Body	CGW-Central gateway	●	●	●	●	●	○	○		C005 C006 C007	F01B F01C F01D
Up to 08/2006	MayBach	240	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
Up to 08/2006	MayBach	240	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
Up to 08/2006	MayBach	240	Body	BNS-Vehicle power supply control module	●	●	●	●	●	○	○			
Up to 08/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
Up to 08/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	BCG-Remote control(Rear control field)	●	●	●	●	●	○	●			F025
Up to 08/2006	MayBach	240	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	CRN-Center roof node	●	●	○	●	●	○	●			
Up to 08/2006	MayBach	240	Body	PSE-Pneumatic system equipment	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
Up to 08/2006	MayBach	240	Body	System diagnosis(CAN)	●	●	●	●	○	●	○			
Up to 08/2006	MayBach	240	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
Up to 08/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 08/2006	MayBach	240	Information and communication	ICM-Instrument cluster	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	Telephone adapter for portable CTCL-Telecommunication for telematics services	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 08/2006	MayBach	240	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
Up to 08/2006	MayBach	240	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
Up to 08/2006	MayBach	240	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
Up to 08/2006	MayBach	240	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	AVC-Audio video controller	●	●	○	●	●	●	●			
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (REAR)	●	●	○	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	CDC-CD changer (REAR)	●	●	○	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	●	●	○	●	●	○	○			
Up to 08/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	●	●	○	●	●	○	○			
Up to 08/2006	MayBach	240	Information and communication	GPS box	●	●	○	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	●	●	○	●	●	●	●			
Up to 08/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	○	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●			
Up to 08/2006	MayBach	240	Seats and doors	PWC-Partition wall control module	●	●	●	●	●	○	○			
Up to 08/2006	MayBach	240	Seats and doors	LDCA-Electric left door closing assist	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Seats and doors	RDCA-Electric right door closing assist	●	●	●	●	●	●	○			
Up to 08/2006	MayBach	240	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
Up to 08/2006	MayBach	240	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	○	●			F025
Up to 08/2006	MayBach	240	Air conditioning	REAR AC-Rear air conditioning	●	●	●	●	●	○	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2006	MayBach	240	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
Up to 08/2006	MayBach	240	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	●	●			F025
As of 09/2006	MayBach	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 09/2006	MayBach	240	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 09/2006	MayBach	240	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
As of 09/2006	MayBach	240	Drive	SGR-Radar sensors control unit	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Drive	DTR-Distronic	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	●			F011 FOA4 F008 F009 F00B F1E4 FOA2 F1E5 FOAB FOAE F1E6 FOCC FOB6 FOB7
As of 09/2006	MayBach	240	Drive	FSCU-Fuel pump	●	●	●	●	○	●	●		C068	
As of 09/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	○	○			
As of 09/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	●	●	●	●	●	○	○			
As of 09/2006	MayBach	240	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
As of 09/2006	MayBach	240	Chassis	AIRmatic	●	●	●	●	●	○	●			F06F F15A F15B
As of 09/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●		C001	
As of 09/2006	MayBach	240	Body	CGW-Central gateway	●	●	●	●	●	○	○		C005 C006 C007	F01B F01C F01D
As of 09/2006	MayBach	240	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Body	AB-Airbag	●	●	●	●	●	●	●		C001 C01D C060 C096 C023 C099 C020 C01F C0E8 C142 C024 C062	
As of 09/2006	MayBach	240	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
As of 09/2006	MayBach	240	Body	BNS-Vehicle power supply control module	●	●	●	●	●	○	○			
As of 09/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
As of 09/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	BCG-Remote control (Rear control field)	●	●	●	●	●	○	●			F025
As of 09/2006	MayBach	240	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	CRN-Center roof node	●	●	○	●	●	○	●			
As of 09/2006	MayBach	240	Body	PSE-Pneumatic system equipment	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
As of 09/2006	MayBach	240	Body	System diagnosis (CAN)	●	●	●	●	○	●	○			
As of 09/2006	MayBach	240	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
As of 09/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 09/2006	MayBach	240	Information and communication	ICM-Instrument cluster	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 09/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	Telephone adapter for portable CTET-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 09/2006	MayBach	240	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 09/2006	MayBach	240	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/2006	MayBach	240	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 09/2006	MayBach	240	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	AVC-Audio video controller	●	●	○	●	●	●	●			
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (REAR)	●	●	○	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	CDC-CD changer (REAR)	●	●	○	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	●	●	○	●	●	○	○			
As of 09/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	●	●	○	●	●	○	○			
As of 09/2006	MayBach	240	Information and communication	GPS box	●	●	○	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	●	●	○	●	●	●	●			
As of 09/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	○	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Seats and doors	PWC-Partition wall control module	●	●	●	●	●	○	○			
As of 09/2006	MayBach	240	Seats and doors	LDCA-Electric left door closing assist	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Seats and doors	RDCA-Electric right door closing assist	●	●	●	●	●	●	○			
As of 09/2006	MayBach	240	Seats and doors	TLC-Trunk lid control	●	●	●	●	●	●	●		C001	
As of 09/2006	MayBach	240	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	○	●			F025
As of 09/2006	MayBach	240	Air conditioning	REAR AC-Rear air conditioning	●	●	●	●	●	○	●			
As of 09/2006	MayBach	240	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F152
As of 09/2006	MayBach	240	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	●	●			F025
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 08/2003	SL	230	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
Up to 08/2003	SL	230	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 08/2003	SL	230	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
Up to 08/2003	SL	230	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	○	○			
Up to 08/2003	SL	230	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
Up to 08/2003	SL	230	Chassis	ABC-ABC active body control	●	●	●	●	●	※	●	●		F06F F20D F20E F20F F210 F211
Up to 08/2003	SL	230	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●	●	C001	
Up to 08/2003	SL	230	Body	System diagnosis(CAN)	●	●	●	●	○	●	○			
Up to 08/2003	SL	230	Body	AB-Airbag	●	●	●	●	●	●	○		C059 C09A C01D C01C C08E C023 C097 C01F	
Up to 08/2003	SL	230	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
Up to 08/2003	SL	230	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	F01E F139 F020 F01F F15D F212 F022 F023
Up to 08/2003	SL	230	Body	OCP-Overhead control panel	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Body	LCP-Lower control panel	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Body	BNS-Vehicle power supply control module	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Body	RVC-Rollover bar/vario roof control module	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Body	PSE-Pneumatic system equipment	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Body	KG-KEYLESS GO	●	●	●	●	●	※	●	●		F217 F218
Up to 08/2003	SL	230	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
Up to 08/2003	SL	230	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
Up to 08/2003	SL	230	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
Up to 08/2003	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C09B C02C C09C C02F C0A3 C143 C09E C0D2 C144 C13B C145 C02E C0A0 C0A1 C0A2	
Up to 08/2003	SL	230	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
Up to 08/2003	SL	230	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
Up to 08/2003	SL	230	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
Up to 08/2003	SL	230	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
Up to 08/2003	SL	230	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
Up to 08/2003	SL	230	Information and communication	COMAND	●	●	○	●	●	●	●			
Up to 08/2003	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			
Up to 08/2003	SL	230	Information and communication	AUDIO	●	●	●	●	●	●	●			
Up to 08/2003	SL	230	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
Up to 08/2003	SL	230	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
Up to 08/2003	SL	230	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
Up to 08/2003	SL	230	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 08/2003	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
Up to 08/2003	SL	230	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
Up to 08/2003	SL	230	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	※	●			
Up to 08/2003	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C04C C047 C06F C146	F02F F030 F239
Up to 08/2003	SL	230	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	○			
Up to 08/2003	SL	230	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
From 09/2003 to 05/2006	SL	230	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 09/2003 to 05/2006	SL	230	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
From 09/2003 to 05/2006	SL	230	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●	●	●	●	●	C069 C140 C04B	F009 F0A2 F00C F00D F00E F00F F06D F238 F010 F011
From 09/2003 to 05/2006	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	●	●		F011 F0A4 F008 F009 F00B F1E4 F0A2 F1E5 F0AB F0AE F1E6 F0C0 F0B6 F0B7
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	●	●	●	●	●	※	●	●		F06F F20D F20E F20F F210 F211
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	●	●	●	●	●	●	●			F06F F23A F23B F20E F23C F20F F210 F211
From 09/2003 to 05/2006	SL	230	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●	●	C001	
From 09/2003 to 05/2006	SL	230	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Body	CGW-Central gateway	●	●	●	●	○	○	○		C005 C006 C007	F01B F01C F01D
From 09/2003 to 05/2006	SL	230	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	●	●	●	●	○	●	○			
From 09/2003 to 05/2006	SL	230	Body	AB-Airbag	●	●	●	●	●	●	○		C059 C09A C01D C01C C08E C023 C097 C01F	
From 09/2003 to 05/2006	SL	230	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
From 09/2003 to 05/2006	SL	230	Body	OCP-Overhead control panel	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Body	LCP-Lower control panel	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	※	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2003 to 05/2006	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Body	BNS-Vehicle power supply control module	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Body	PSE-Pneumatic system equipment	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Body	KG-KEYLESS GO	●	●	●	●	●	※	●	●		F217 F218
From 09/2003 to 05/2006	SL	230	Body	KG-KEYLESS GO	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
From 09/2003 to 05/2006	SL	230	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	●	●	○	●	○	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C09B C02C C09C C02F C0A3 C143 C09E C0D2 C144 C13B C145 C02E C0A0 C0A1 C0A2	
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
From 09/2003 to 05/2006	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
From 09/2003 to 05/2006	SL	230	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
From 09/2003 to 05/2006	SL	230	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance (USA, Canada),Tele diagnosis (ECE)	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	COMAND	●	●	○	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 09/2003 to 05/2006	SL	230	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 09/2003 to 05/2006	SL	230	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 09/2003 to 05/2006	SL	230	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●			
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●			
From 09/2003 to 05/2006	SL	230	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	※	●			
From 09/2003 to 05/2006	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C04C C047 C06F C146	F02F F030 F239
From 09/2003 to 05/2006	SL	230	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	○			
From 09/2003 to 05/2006	SL	230	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
From 06/2006 to 02/2008	SL	230	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 06/2006 to 02/2008	SL	230	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	●	●	●	●	●	※	○	●		F12E
From 06/2006 to 02/2008	SL	230	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FO11
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	●	●	●	●	●	●	●		C069 C140 C04B	F009 FOA2 F00C F00D F00E F00F F06D F238 F010 F011
From 06/2006 to 02/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	●			F011 FOA4 F008 F009 F00B F1E4 FOA2 F1E5 FOAB FOAE F1E6 F0C0 F0B6 F0B7
From 06/2006 to 02/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	○			F011 FOA4 F008 F009 F00B F1E4 FOA2 F1E5 FOAB FOAE F1E6 F0C0 F0B6 F0B7
From 06/2006 to 02/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
From 06/2006 to 02/2008	SL	230	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	●	●	●	●	●	※	●	●		F06F F20D F20E F20F F210 F211
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	●	●	●	●	●	●	●			F06F F23A F23B F20E F23C F20F F210 F211
From 06/2006 to 02/2008	SL	230	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●	●	C001	
From 06/2006 to 02/2008	SL	230	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Body	CGW-Central gateway	●	●	●	●	○	○	○		C005 C006 C007	F01B F01C F01D

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 06/2006 to 02/2008	SL	230	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	●	●	●	●	○	●	○			
From 06/2006 to 02/2008	SL	230	Body	AB-Airbag	●	●	●	●	●	●	○		C059 C09A C01D C01C C08E C023 C097 C01F	
From 06/2006 to 02/2008	SL	230	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
From 06/2006 to 02/2008	SL	230	Body	OCP-Overhead control panel	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Body	LCP-Lower control panel	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Body	BNS-Vehicle power supply control module	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Body	PSE-Pneumatic system equipment	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Body	KG-KEYLESS GO	●	●	●	●	●	※	●	●		F217 F218
From 06/2006 to 02/2008	SL	230	Body	KG-KEYLESS GO	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
From 06/2006 to 02/2008	SL	230	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	●	●	○	●	○	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C09B C02C C09C C02F C0A3 C143 C09E C0D2 C144 C13B C145 C02E C0A0 C0A1 C0A2	
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
From 06/2006 to 02/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	Telephone adapter for portable CTET-Telecommunication for telematics services	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
From 06/2006 to 02/2008	SL	230	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
From 06/2006 to 02/2008	SL	230	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 06/2006 to 02/2008	SL	230	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	COMAND	●	●	○	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 06/2006 to 02/2008	SL	230	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 06/2006 to 02/2008	SL	230	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●			
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●			
From 06/2006 to 02/2008	SL	230	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	※	●			
From 06/2006 to 02/2008	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C04C C047 C06F C146	F02F F030 F239
From 06/2006 to 02/2008	SL	230	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	○			
From 06/2006 to 02/2008	SL	230	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 03/2008	SL	230	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
As of 03/2008	SL	230	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
As of 03/2008	SL	230	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
As of 03/2008	SL	230	Drive	TV-TV tuner	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	●			F011 FOA4 F008 F009 FO0B F1E4 FOA2 F1E5 FOAB FOAE F1E6 F0C0 F0B6 F0B7
As of 03/2008	SL	230	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
As of 03/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	●	●	●	●	●	●	○			F011 FOA4 F008 F009 FO0B F1E4 FOA2 F1E5 FOAB FOAE F1E6 F0C0 F0B6 F0B7
As of 03/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2008	SL	230	Chassis	ABC-ABC active body control	●	●	●	●	●	●	●			F06F F23A F23B F20E F23C F20F F210 F211
As of 03/2008	SL	230	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
As of 03/2008	SL	230	Body	CGW-Central gateway	●	●	●	●	○	○	○		C005 C006 C007	F01B F01C F01D
As of 03/2008	SL	230	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	
As of 03/2008	SL	230	Body	System diagnosis(CAN)	●	●	●	●	○	●	○			
As of 03/2008	SL	230	Body	AB-Airbag	●	●	●	●	●	●	○		C059 C09A C01D C01C C08E C023 C097 C01F	
As of 03/2008	SL	230	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
As of 03/2008	SL	230	Body	OCP-Overhead control panel	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Body	LCP-Lower control panel	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Body	BNS-Vehicle power supply control module	●	●	●	●	●	※	○			
As of 03/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Body	PSE-Pneumatic system equipment	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Body	KG-KEYLESS GO	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●			
As of 03/2008	SL	230	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Body	System diagnosis(CAN)	●	●	○	●	○	●	○			
As of 03/2008	SL	230	Body	AMG DRVU-AMG DRIVE UNIT	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	PTS-Parktronic system	●	●	●	●	○	●	○			
As of 03/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
As of 03/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C09B C02C C09C C02F C0A3 C143 C09E C0D2 C144 C13B C145 C02E C0A0 C0A1 C0A2	
As of 03/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●			
As of 03/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 03/2008	SL	230	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 03/2008	SL	230	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 03/2008	SL	230	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 03/2008	SL	230	Information and communication	SOUND-Bose sound system	●	●	○	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
As of 03/2008	SL	230	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 03/2008	SL	230	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 03/2008	SL	230	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 03/2008	SL	230	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 03/2008	SL	230	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2008	SL	230	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 03/2008	SL	230	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
As of 03/2008	SL	230	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 03/2008	SL	230	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
As of 03/2008	SL	230	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
As of 03/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
As of 03/2008	SL	230	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
As of 03/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
As of 03/2008	SL	230	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	※	○			
As of 03/2008	SL	230	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	※	○			
As of 03/2008	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	●	●	●	●	●	※	●			
As of 03/2008	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	●	●	●	●	●	※	○			
As of 03/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	●	●	●	●	●	※	○			
As of 03/2008	SL	230	Seats and doors	AIRSCARF	●	●	●	●	●	●	○			
As of 03/2008	SL	230	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●	●	C04C C047 C06F C146	F02F F030 F239
As of 03/2008	SL	230	Air conditioning	STH-Stationary heater	●	●	●	●	●	※	○			
As of 03/2008	SL	230	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	※	●			
As of 09/99	SL	129	Drive	ETC-Electronic transmission control	●	●	○	●	○	※	●			F12E
As of 09/99	SL	129	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●			FOA4 F155
As of 09/99	SL	129	Drive	ME1-SFI-Motor electronics	●	●	○	●	○	※	○			
As of 09/99	SL	129	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
As of 09/99	SL	129	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
As of 09/99	SL	129	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			F03D
As of 09/99	SL	129	Chassis	BAS-Brake assist	●	●	○	●	●	※	●			
As of 09/99	SL	129	Body	AB-Airbag	●	●	○	●	○	※	○			
As of 09/99	SL	129	Body	HRA-Headlamp range adjustment	●	●	○	●	○	※	○			
As of 09/99	SL	129	Body	RFL-Radio frequency locking/electric central locking	●	●	○	●	●	※	○			
As of 09/99	SL	129	Body	APS-Auto pilot system	●	●	○	●	●	※	○			
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	●	○			
As of 09/99	SL	129	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○			
As of 09/99	SL	129	Information and communication	E-call [USA]-Emergency call system	●	●	●	●	○	○	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 09/99	SL	129	Information and communication	TELE AID-Emergency call system	●	●	●	●	●	●	○			
As of 09/99	SL	129	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
As of 09/99	SL	129	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
As of 09/99	SL	129	Information and communication	DN-Dynamic navigation by means of CTEL	●	●	●	●	●	○	○			
As of 09/99	SL	129	Information and communication	AUD10	●	●	●	●	●	●	●			
As of 09/99	SL	129	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
As of 09/99	SL	129	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
As of 09/99	SL	129	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
As of 09/99	SL	129	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
As of 09/99	SL	129	Air conditioning	AAC-Automatic air conditioning	●	●	○	●	○	※	○			
As of 09/99	SL	129	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
As of 2012	SL	231	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2012	SL	231	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2012	SL	231	Drive	ME-Motor electronics 'ME1778' for combustion engine 'M277'	●	●	○	●	●	●	○			
As of 2012	SL	231	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2012	SL	231	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D
As of 2012	SL	231	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2012	SL	231	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	SL	231	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	○			
As of 2012	SL	231	Chassis	ABC-ABC	●	●	○	●	●	●	○			
As of 2012	SL	231	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			F0EF
As of 2012	SL	231	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			F0EF F0F0 F0F1 F0F2
As of 2012	SL	231	Chassis	EPB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2012	SL	231	Chassis	FWGW-Chassis gateway	●	●	○	●	●	●	○			
As of 2012	SL	231	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2012	SL	231	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2012	SL	231	Body	CGW-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2012	SL	231	Body	EZS-Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	SL	231	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2012	SL	231	Body	MSC-MAGIC SKY CONTROL	●	●	○	●	●	●	○			
As of 2012	SL	231	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2012	SL	231	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2012	SL	231	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2012	SL	231	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	SL	231	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	SL	231	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2012	SL	231	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	SL	231	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	SL	231	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2012	SL	231	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2012	SL	231	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	Freeze	●			
As of 2012	SL	231	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2012	SL	231	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2012	SL	231	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	○	●	●	●	●			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	SL	231	Body	VDS-Vario roof control	●	●	○	●	●	●	○			
As of 2012	SL	231	Body	AIRSCARF-AIRSCARF system	●	●	○	●	●	●	●			
As of 2012	SL	231	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2012	SL	231	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2012	SL	231	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2012	SL	231	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	AMG DRVU-AMG DRIVE UNIT	●	●	○	●	●	●	●			
As of 2012	SL	231	Information and communication	AMG PM-AMG Performance Media	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	SOUND - Sound system(N40/3)	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	○	○			
As of 2012	SL	231	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2012	SL	231	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2012	SL	231	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	ES-Electrical power steering	●	●	●	●	●	●	○			F1D8
As of 2012	SL	231	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	SL	231	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2012	SL	231	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2012	SL	231	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	●			
As of 2012	SL	231	Information and communication	DSI-DIRECT SELECT interface	●	●	○	●	●	●	○			
As of 2012	SL	231	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	○	●			
As of 2012	SL	231	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	●	○			
As of 2012	SL	231	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function	●	●	○	●	●	●	○			
As of 2012	SL	231	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	○			
As of 2012	SL	231	Seats and doors	DCU-LF-Left front door	●	●	○	●	●	●	○			
As of 2012	SL	231	Seats and doors	DCU-RF-Right front door	●	●	○	●	●	●	○			
As of 2012	SL	231	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2012	SL	231	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2012	SL	231	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2012	SL	231	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	SL	231	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	SL	231	Driver assistance system	NSA-Night View Assist	●	●	○	●	●	●	○			
As of 2012	SL	231	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
From 2006 to 2009	SLR	199	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 2006 to 2009	SLR	199	Drive	ESM-Electronic selector module	●	●	●	●	●	※	●			F209
From 2006 to 2009	SLR	199	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 2006 to 2009	SLR	199	Chassis	SBC-Sensotronic Brake Control	●	●	●	●	●	○	○			
From 2006 to 2009	SLR	199	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019
From 2006 to 2009	SLR	199	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	※	●	●	C001	
From 2006 to 2009	SLR	199	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
From 2006 to 2009	SLR	199	Body	EZS-Electronic ignition switch	●	●	●	●	●	※	○	●	C119 C11A C00A C11B C007 C071 C00F C011 C072 C10E C073 C074 C10F C110 C111 C075 C015 C113 C076 C077 C114 C115 C017 C116 C117 C08B C07A C07B C118 C07C C080 C081 C014 C11C C085	F01E F139 F020 F01F F15D F212 F022 F023
From 2006 to 2009	SLR	199	Body	OCP-Overhead control panel	●	●	●	●	●	※	●			
From 2006 to 2009	SLR	199	Body	LCP-Lower control panel	●	●	●	●	●	※	●			
From 2006 to 2009	SLR	199	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	※	●			
From 2006 to 2009	SLR	199	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	●	●	●	●	●	※	●			
From 2006 to 2009	SLR	199	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	※	●			
From 2006 to 2009	SLR	199	Body	BNS-Vehicle power supply control module	●	●	●	●	●	※	○			
From 2006 to 2009	SLR	199	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	○	●	●	C001	F026
From 2006 to 2009	SLR	199	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	○	○		C001	
From 2006 to 2009	SLR	199	Body	RS-Roadster soft top	●	●	●	●	●	●	○			
From 2006 to 2009	SLR	199	Body	CGW-Central gateway	●	●	●	●	○	○	○		C005 C006 C007	F01B F01C F01D
From 2006 to 2009	SLR	199	Body	AB-Airbag	●	●	●	●	●	●	○		C059 C09A C01D C01C C08E C023 C097 C01F	
From 2006 to 2009	SLR	199	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
From 2006 to 2009	SLR	199	Body	ACL [ZLB]-Air brake (spoiler) and central locking control unit	●	●	●	●	●	●	●			
From 2006 to 2009	SLR	199	Body	BKGS-Brake cooling and gearshift	●	●	●	●	●	●	○			
From 2006 to 2009	SLR	199	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
From 2006 to 2009	SLR	199	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	※	●	●		
From 2006 to 2009	SLR	199	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●	●	C09B C02C C09C C02F C0A3 C143 C09E C0D2 C144 C13B C145 C02E C0A0 C0A1 C0A2	
From 2006 to 2009	SLR	199	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 2006 to 2009	SLR	199	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 2006 to 2009	SLR	199	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
From 2006 to 2009	SLR	199	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 2006 to 2009	SLR	199	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 2006 to 2009	SLR	199	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
From 2006 to 2009	SLR	199	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
From 2006 to 2009	SLR	199	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
From 2006 to 2009	SLR	199	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 2006 to 2009	SLR	199	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	※	○			
From 2006 to 2009	SLR	199	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	※	○			
From 2006 to 2009	SLR	199	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	※	●		C04C C047 C06F C146	F02F F030 F239
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 05/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
Up to 05/2005	SLK	171	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FOA0 F008
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F009 F007 F09F F12D FO0B FOA0 F12F F130 F008
Up to 05/2005	SLK	171	Drive	TV-TV tuner	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE F011
Up to 05/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 05/2005	SLK	171	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 FOEB FOEA F138
Up to 05/2005	SLK	171	Body	CGW-Central gateway	●	●	●	●	●	○	○		C005 C006 C007	F01B F01C F01D
Up to 05/2005	SLK	171	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	●	●		F01E F01F F020 F13A F022 F15D F023 F15E
Up to 05/2005	SLK	171	Body	System diagnosis (CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
Up to 05/2005	SLK	171	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
Up to 05/2005	SLK	171	Body	VR-Vario roof	●	●	●	●	●	○	●			
Up to 05/2005	SLK	171	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
Up to 05/2005	SLK	171	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C025 C147	
Up to 05/2005	SLK	171	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
Up to 05/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
Up to 05/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
Up to 05/2005	SLK	171	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
Up to 05/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
Up to 05/2005	SLK	171	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F166 F028
Up to 05/2005	SLK	171	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○			
Up to 05/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
Up to 05/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
Up to 05/2005	SLK	171	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
Up to 05/2005	SLK	171	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
Up to 05/2005	SLK	171	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
Up to 05/2005	SLK	171	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
Up to 05/2005	SLK	171	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
Up to 05/2005	SLK	171	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 05/2005	SLK	171	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
Up to 05/2005	SLK	171	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
Up to 05/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
Up to 05/2005	SLK	171	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
Up to 05/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
Up to 05/2005	SLK	171	Information and communication	GPS box	●	●	○	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
Up to 05/2005	SLK	171	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	○	●	●	C001	
Up to 05/2005	SLK	171	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	○	●	●	C001	
Up to 05/2005	SLK	171	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
Up to 05/2005	SLK	171	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
Up to 05/2005	SLK	171	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
Up to 05/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●	●	C007 C046 C047 C06F	F02F F030 F032 F23D
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 06/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission	●	●	●	●	●	●	●		C070 C04C C068 C069	F12C
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 06/2005	SLK	171	Drive	ESM-Electronic selector module	●	●	●	●	●	○	●	●	C001	F001
As of 06/2005	SLK	171	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	F0A4 F009 F007 F09F F12D F0A0 F008
As of 06/2005	SLK	171	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C069 C002 C049 C04B	F0A4 F009 F007 F09F F12D F00B F0A0 F12F F130 F008
As of 06/2005	SLK	171	Drive	TV-TV tuner	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
As of 06/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
As of 06/2005	SLK	171	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F0EB F0EA F138
As of 06/2005	SLK	171	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			F06F F070
As of 06/2005	SLK	171	Body	CGW-Central gateway	●	●	●	●	●	○	○		C005 C006 C007	F01B F01C F01D
As of 06/2005	SLK	171	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	●	●		F01E F01F F020 F13A F022 F15D F023 F15E
As of 06/2005	SLK	171	Body	System diagnosis(CAN)	●	●	●	●	○	●	○	●	C02B C007 C02C	
As of 06/2005	SLK	171	Body	AB-Airbag	●	●	●	●	●	●	○	●	C01C C01D C08E C023 C095 C096 C097 C01F C098 C099 C024 C062 C059 C09A	
As of 06/2005	SLK	171	Body	WSS-Weight sensing system	●	●	●	●	●	○	○			
As of 06/2005	SLK	171	Body	VR-Vario roof	●	●	●	●	●	○	●			
As of 06/2005	SLK	171	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
As of 06/2005	SLK	171	Body	OCP-Overhead control panel	●	●	●	●	●	○	●	●	C025 C147	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 06/2005	SLK	171	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
As of 06/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
As of 06/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	●	●	●	●	●	●	●			
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	●	●	C04D C04E C0A5 C0A6 C0A7	
As of 06/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
As of 06/2005	SLK	171	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F166 F028
As of 06/2005	SLK	171	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○			
As of 06/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 06/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
As of 06/2005	SLK	171	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 06/2005	SLK	171	Information and communication	NAVI-Navigation system	●	●	○	●	●	●	●			
As of 06/2005	SLK	171	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 06/2005	SLK	171	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 06/2005	SLK	171	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 06/2005	SLK	171	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 06/2005	SLK	171	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 06/2005	SLK	171	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 06/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
As of 06/2005	SLK	171	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 06/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
As of 06/2005	SLK	171	Information and communication	GPS box	●	●	○	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
As of 06/2005	SLK	171	Seats and doors	DCM-L-Door control module left	●	●	●	●	●	○	●	●	C001	
As of 06/2005	SLK	171	Seats and doors	DCM-R-Door control module right	●	●	●	●	●	○	●	●	C001	
As of 06/2005	SLK	171	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
As of 06/2005	SLK	171	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 06/2005	SLK	171	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
As of 06/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	●	●	●	●	●	○	●	●	C007 C046 C047 C06F	F02F F030 F032 F23D
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	○	●	●	※	●			F077 F082 F10E F081 F10F F110 F111 F112 F113 F114 F08D F115 F116 F117 F118 F119 F11A F11B F001 F11C F11D F11E F11F F002 F089 F120
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F082 F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C001 C002 C069	FOA4 F007 F09F F009 F12D
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F137
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F0EB FOEA F138
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Chassis	BAS-Brake assist	●	●	○	●	●	●	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	○	※	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Body	RFL-Radio frequency locking/electric central locking	●	●	○	●	●	※	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Body	PSE-Pneumatic system equipment	●	●	○	●	●	※	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Body	CCM-Multifunction control module	●	●	○	●	●	※	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Body	VR-Vario roof	●	●	○	●	●	※	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Body	ATA-Anti-theft alarm system	●	●	○	●	○	error	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Body	HRA-Headlamp range adjustment	●	●	●	●	●	※	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Emergency call system	●	●	○	●	●	●	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	E-call [USA]-Emergency call system	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Air conditioning	TAC-Automatic temperature control	●	●	○	●	●	※	●			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	●	●	○	●	○	※	○			
From 1998 to 2004	SLK	170(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	○	●	○	※	●			F12E
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●			FOA4 F155
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Chassis	ABS-Antilock brake system	●	●	○	●	●	※	○			
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Chassis	ASR-Acceleration Slip Regulation	●	●	○	●	●	※	○			
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Chassis	BAS-Brake assist	●	●	○	●	●	※	●			
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	○	※	○			
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Body	RFL-Radio frequency locking/electric central locking	●	●	○	●	●	※	○			
From 1998 to 2004	SLK	170(38-pin diagnostic socket)	Body	PSE-Pneumatic system equipment	●	●	○	●	●	※	○			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Body	CCM-Multifunction control module	●	●	○	●	●	※	○			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Body	VR-Vario roof	●	●	○	●	●	※	●			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Body	ATA-Anti-theft alarm system	●	●	○	●	○	error	○			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Air conditioning	TAC-Automatic temperature control	●	●	○	●	●	※	●			
From 1998 to 2004	SLK	170 (38-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	●	●	○	●	○	※	○			
As of 2010	SLK	172	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2010	SLK	172	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2010	SLK	172	Drive	FSCU06 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2010	SLK	172	Drive	ESM[EWM] - Electronic selector module	●	●	○	●	●	●	●			
As of 2010	SLK	172	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2010	SLK	172	Drive	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'	●	●	○	●	●	●	○			
As of 2010	SLK	172	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D
As of 2010	SLK	172	Drive	ME - Motor electronics 'S1M271DE20' for combustion engine 'M271EVO'	●	●	●	●	●	●	●			F094 F095 F096 F097 F098 F099 F09A F040 F09B F09C F09D F09E

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2010	SLK	172	Drive	VGS - Transmission control for 7-speed transmissio	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2010	SLK	172	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2010	SLK	172	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2010	SLK	172	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F23E F0F4 F23F F240 F241
As of 2010	SLK	172	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			FOEF
As of 2010	SLK	172	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			FOEF FOFO FOF1 FOE2
As of 2010	SLK	172	Chassis	EHPS - Electorhydraulic power sreeting	●	●	○	●	●	●	○			
As of 2010	SLK	172	Chassis	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2010	SLK	172	Chassis	EPB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2010	SLK	172	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2010	SLK	172	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2010	SLK	172	Body	CGW-Central gateway	●	●	○	●	●	●	○			FOF5
As of 2010	SLK	172	Body	EZS-Electronic ignition lock	●	●	○	●	●	●	○			FOF6 F05C F05D F0F7 F0F8 F0F9 FOFE
As of 2010	SLK	172	Body	EZS-Electronic ignition lock	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2010	SLK	172	Body	SCCM-Steering column module	●	●	○	●	●	●	●			
As of 2010	SLK	172	Body	MSC-MAGIC SKY CONTROL	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2010	SLK	172	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2010	SLK	172	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2010	SLK	172	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			FOEF
As of 2010	SLK	172	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2010	SLK	172	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2010	SLK	172	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2010	SLK	172	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2010	SLK	172	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2010	SLK	172	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2010	SLK	172	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2010	SLK	172	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2010	SLK	172	Body	VDS-Vario roof control	●	●	○	●	●	●	○			
As of 2010	SLK	172	Body	AIRSCARF-AIRSCARF system	●	●	●	●	●	●	●			
As of 2010	SLK	172	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2010	SLK	172	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2010	SLK	172	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2010	SLK	172	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2010	SLK	172	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2010	SLK	172	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2010	SLK	172	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	NAVI20 - Navigation	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2010	SLK	172	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2010	SLK	172	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2010	SLK	172	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	●			
As of 2010	SLK	172	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'	●	●	○	●	●	●	●			F106 F107 F108
As of 2010	SLK	172	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	●			F106 F107
As of 2010	SLK	172	Seats and doors	DCU-LF-Left front door	●	●	●	●	●	●	●			
As of 2010	SLK	172	Seats and doors	DCU-RF-Right front door	●	●	●	●	●	●	●			
As of 2010	SLK	172	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2010	SLK	172	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2010	SLK	172	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2010	SLK	172	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	SLK	172	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	SLK	172	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2010	SLK	172	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2010	SLK	172	Driver assistance system	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 2008	GLK	X 204	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 2008	GLK	X 204	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
As of 2008	GLK	X 204	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
As of 2008	GLK	X 204	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	●	●	●	●	●		C004	FOA4 FOB0 F008 F007 FOA5 FOA6 FOB1 FOA7 FOA8 FOA3 FOA9 FOAB FOAC FOB2 FOAE FOB3 FOB4 FOB5 FOB6 FOB7
As of 2008	GLK	X 204	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2008	GLK	X 204	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	●	●	●	●	●		C069 C002 C049 C04B C04A	FOB8 F007 F009 FOA5 FOB9 FOB1 FOA7 FOA3 FOBA FOA1 FOBB FOBC FO0E FO0F F06D FOBD FOBE FOBF FOAA FOAB FOCA FOAD FOAE

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	GLK	X 204	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
As of 2008	GLK	X 204	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
As of 2008	GLK	X 204	Drive	FSCU-Fuel pump	●	●	●	●	●	●	○		C069 C002 C049	
As of 2008	GLK	X 204	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	○			
As of 2008	GLK	X 204	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	○			
As of 2008	GLK	X 204	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO'	●	●	●	●	●	●	●			F094 F095 F096 F097 F098 F099 F09A F040 F09B F09C F09D F09E
As of 2008	GLK	X 204	Drive	ME-SFI-Motor electronics	●	●	●	●	●	●	●		C002 C049 C04B	F007 F008 F09F F009 F0A0 F0A1 F00C F00D F00E F00F F06D F010 F0A2 F0A3
As of 2008	GLK	X 204	Drive	ESM[EWM] - Electronic selector module	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Drive	ISM-Shift module	●	●	●	●	●	●	●		C06B	F0C1 F0C2
As of 2008	GLK	X 204	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Drive	SCR-Selective Catalytic Reduction	●	●	●	●	●	●	●		C069 C049 C04B C04A	F0C3 F0C4 F0C5
As of 2008	GLK	X 204	Drive	FSCU-Fuel pump	●	●	●	●	○	●	○			
As of 2008	GLK	X 204	Drive	CDID-Common Rail Diesel Injection	●	●	●	●	●	●	●		C048 C049 C04A	F0CE F0CF F0D0 F0D1 F0D2
As of 2008	GLK	X 204	Drive	CDI 3-Common Rail Diesel Injection3	●	●	●	●	●	●	●		C048 C049 C04A	F016 F011 F033 F034 F008 F03B F0D3 F0D4 F0D5 F0C9
As of 2008	GLK	X 204	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●		C001	F0D6 F016 F033 F007 F034 F008 F0D7 F013 F036 F0D8 F014 F03A F03B F0D9 F0DA F0B3 F0B4
As of 2008	GLK	X 204	Drive	CDI 60LS-Common Rail Diesel Injection	●	●	●	●	●	●	●			F016 F033 F034 F013 F036 F038 F0DB F0DC F007 F008 F014 F0D7 F03A F03B F011 F0DD F0DE F0DF F0E0 F0E1
As of 2008	GLK	X 204	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 F0E2 F0DC F0E3 F0E4 F036 F0E5 F0DB F0E6 F0E7 F0E8 F038 F0C5 F008 F014 F0D7 F03A F0E9 F03B F016 F033 F034 F035
As of 2008	GLK	X 204	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 F036 F0DB F0E8 F038 F008 F014 F0D7 F03A F03B F016 F033 F034
As of 2008	GLK	X 204	Drive	CDID-Common Rail Diesel Injection	●	●	●	●	●	●	●		C04A C06C	F015 F0C6 F0C7 F016 F013 F007 F0C8 F008 F0C9 F0CA F0CB F0CC F0CD
As of 2008	GLK	X 204	Drive	SG-SOGE-AGA - Sound generator for exhaust system	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2008	GLK	X 204	Drive	FSCU01 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Drive	FSCU04 - Left fuel pump	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Drive	FSCU06 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Drive	FSCU04 - Right fuel pump	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Drive	ME 9.7-Motor electronics 9.7	●	●	○	●	●	●	●			F17A F17B F17C F17D F17E F17F F180 F181 F182 F183 F184 F185 F186 F187 F188 F189
As of 2008	GLK	X 204	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	○	●	●	●	●			F17A F17B F17C F17D F18A F180 F181 F184 F185 F186 F187 F188 F189
As of 2008	GLK	X 204	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	○	●	●	●	●			F18B F17B F17D F17E F18C F18D F181 F18E F18F F183 F190 F191 F192 F193 F194 F195 F196
As of 2008	GLK	X 204	Drive	ME-SFI-Motor electronics	●	●	○	●	●	●	●			F094 F095 F096 F197 F098 F099 F09A F040 F242 F052 F243 F09D F09C F09E
As of 2008	GLK	X 204	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2008	GLK	X 204	Drive	ETC[EGS] - Transmission control for 5-speed transmisssion	●	●	○	●	●	●	●			F244 F245 F1A0 F246 F247 F19A F1A1
As of 2008	GLK	X 204	Drive	VGS - Transmission control for 7-speed transmisssion	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2008	GLK	X 204	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2008	GLK	X 204	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Drive	SCR-Selective Catalytic Reduction	●	●	○	●	●	●	●			F1B0 F1B1 F055 F1B2 F1B3 F1B4
As of 2008	GLK	X 204	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F248 F249 F24A F1D5 F1CC F17B F24B F17C F24C F24D F24E F24F F250
As of 2008	GLK	X 204	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607'	●	●	○	●	●	●	●			F048 F052 F04B F1B8 F040 F051 F1B9 F042 F1BA F1BB F1BC F04F F04D F1BD F1BE F09A F04A F1BF F056 F1C0 F059

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	GLK	X 204	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	●	error	●			F251 F1D5 F1D6 F17B F1D7 F17C F1D2 F1CC F1CD F252 F1D1 F1D3 F1D4 F253 F254 F255 F256
As of 2008	GLK	X 204	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	●	●	●			F048 F1C4 F1BE F04F F040 F09A F052 F1BD F1C1 F1C5 F04D F1BB F1C6 F051 F1BF F056 F1C0 F1C3 F059
As of 2008	GLK	X 204	Drive	CDI - Motor electronics CRI6EU5 for combustion engine OM651	●	●	○	●	●	●	●			F1CB F1CC F17B F1CD F1CE F1CF F1D0 F17C F1D1 F1D2 F1D3 F1D4 F1D5 F1D6 F1D7
As of 2008	GLK	X 204	Drive	CDID-Common Rail Diesel Injection	●	●	○	●	●	●	●			F049 F040 F04A F04B F050
As of 2008	GLK	X 204	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2008	GLK	X 204	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F0EA F0EB F0EC F0ED
As of 2008	GLK	X 204	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			F06F F070
As of 2008	GLK	X 204	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	●	●			F0EE
As of 2008	GLK	X 204	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			F0EF F0F0 F0F1 F0F2
As of 2008	GLK	X 204	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Chassis	DTR-Distronic	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Chassis	EHPS-Electrohydraulic Power Steering	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F0F3 F0F4
As of 2008	GLK	X 204	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			F0EF
As of 2008	GLK	X 204	Chassis	ESP - Electronic stability program	●	●	○	●	●	●	●			F257 F23E F0F4 F23F F240
As of 2008	GLK	X 204	Chassis	ESP-Regenerative braking system	●	●	○	●	●	●	●			F258 F259 F23E F0F4 F25A F25B F25C
As of 2008	GLK	X 204	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F23E F0F4 F23F F240 F241
As of 2008	GLK	X 204	Chassis	TPM - Tire pressure monitor	●	●	○	●	●	○	●			F069
As of 2008	GLK	X 204	Chassis	EHPS - Electorhydraulic power sreeting	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			F1D8 F1D9
As of 2008	GLK	X 204	Body	CGW-Central gateway	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2008	GLK	X 204	Body	CGW-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2008	GLK	X 204	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	KG-KEYLESS GO	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	Trailer recognition module	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	AB-Airbag	●	●	●	●	●	●	○		C06D C062	F0FB F0FC
As of 2008	GLK	X 204	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	OCP-Overhead control panel	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	●			F0FD
As of 2008	GLK	X 204	Body	PSD-Control mdule 'Panoramic sliding roof'	●	●	○	●	●	●	●			F0FD
As of 2008	GLK	X 204	Body	Dr-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	AHE-Trailer recognition	●	●	●	●	●	●	●	●		
As of 2008	GLK	X 204	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	Multifunction control unit-Multifunction control unit	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	SCM [MRM]-Steering column module	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	SCCM-Steering column module	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	GLK	X 204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	EZS-Electronic ignition lock	●	●	●	●	●	●	○			F0F6 F05C F05D F0F7 F0F8 F0F9 F0FE
As of 2008	GLK	X 204	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Body	SGR-Radar sensors control unit	●	●	●	●	○	●	○			
As of 2008	GLK	X 204	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			F0F6 F05C F05D F0F7 F0F8 F0F9 F0FA
As of 2008	GLK	X 204	Body	OCP-Overhead control panel	●	●	○	●	●	●	●			F0FD
As of 2008	GLK	X 204	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2008	GLK	X 204	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		C0D9 C0DA	F1DA F10D
As of 2008	GLK	X 204	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2008	GLK	X 204	Body	SRS - Supplemental restraint system	●	●	○	●	●	●	○			F25D F25E
As of 2008	GLK	X 204	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	Multifunction control unit - Multifunction control unit	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	HKS-Tailgate control (N121/1)	●	●	○	●	●	●	●			F1DB F1DC
As of 2008	GLK	X 204	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Body	AHE-Trailer recognition - Trailer recognition control (N28/1)	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	XALWA-L-Xenon headlamp, left	●	●	○	●	●	●	●			F071
As of 2008	GLK	X 204	Body	XALWA-L-Xenon headlamp, left	●	●	○	●	●	error	●			F071 F25F
As of 2008	GLK	X 204	Body	XALWA-R-Xenon headlamp, right	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Body	XALWA-R-Xenon headlamp, right	●	●	○	●	●	error	●			F25F
As of 2008	GLK	X 204	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	●	●		C02D C02E	F028 F0FF F100
As of 2008	GLK	X 204	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2008	GLK	X 204	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	PTS-Parktronic	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	PTS-PARKTRONIC	●	●	●	●	●	●	●		C04D C04F C04E C06E	
As of 2008	GLK	X 204	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	RFK-Backup camera	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	GLK	X 204	Information and communication	COU [ZBE]-Central operating unit	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	ZAN-Central display	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	DAB-Digital radio	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 2008	GLK	X 204	Information and communication	AVE-H - DVD player	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	Left rear screen	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	Right rear screen	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	AMG PM-AMG Performance Media	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	AMG DRVU-AMG DRIVE UNIT	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	Drive-side SAM-Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2008	GLK	X 204	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	360camera-360camera	●	●	○	●	●	●	●			F101 F102 F103 F104 F105
As of 2008	GLK	X 204	Information and communication	TV-TV tuner (AGW)	●	●	○	●	○	●	○			
As of 2008	GLK	X 204	Information and communication	NAVI20 - Navigation	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2008	GLK	X 204	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	PTS - PARKTRONIC	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	GLK	X 204	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	ES-Electrical power steering	●	●	●	●	●	●	○			F1D8
As of 2008	GLK	X 204	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2008	GLK	X 204	Information and communication	AVE-H - DVD player	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Information and communication	TV - TV tuner	●	●	○	●	●	○	○			
As of 2008	GLK	X 204	Information and communication	CTEL - Mobile phone	●	●	○	●	●	○	○			
As of 2008	GLK	X 204	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	DCU-LF-Left front door	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	DCU-RF-Right front door	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	DCU-LR-Left rear door	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	DCU-RR-Right rear door	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	HKS-Tailgate control (N121/1)	●	●	○	●	●	●	●		C001	
As of 2008	GLK	X 204	Seats and doors	ESA Driver - Electric seat adjustmet Driver	●	●	○	●	●	○	●			F106 F107 F108
As of 2008	GLK	X 204	Seats and doors	ESA 'Driver'-Electric seat adjustment 'Driver'	●	●	○	●	●	●	●			F106 F107 F108
As of 2008	GLK	X 204	Seats and doors	ESA passenger	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Seats and doors	ESA-Electirc seat adjustment 'Front passenger'	●	●	●	●	●	●	●			F106 F107
As of 2008	GLK	X 204	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	●			F106 F107
As of 2008	GLK	X 204	Seats and doors	DCU-LF - Left front door	●	●	○	●	●	error	●			F260
As of 2008	GLK	X 204	Seats and doors	DCU-RF - Right front door	●	●	○	●	●	error	●			F260
As of 2008	GLK	X 204	Seats and doors	DCU-LR - Left rear door	●	●	○	●	●	error	●			F260
As of 2008	GLK	X 204	Seats and doors	DCU-RR - Right rear door	●	●	○	●	●	error	●			F260
As of 2008	GLK	X 204	Air conditioning	STH - Stationary heater	●	●	●	●	●	●	●			
As of 2008	GLK	X 204	Air conditioning	AAC-Air conditioning	●	●	●	●	●	●	●		C007 C046 C047 C06F	F02F F030 F031 F032
As of 2008	GLK	X 204	Air conditioning	AAC-Air conditioning	●	●	●	●	●	●	●			F109 F10A F10B
As of 2008	GLK	X 204	Air conditioning	EKMK-Electric refrigerant compressor	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	LIN Bus	LCP-Lower control panel	●	●	○	●	○	●	○			
As of 2008	GLK	X 204	LIN Bus	GTO-Garage door opener	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	LIN Bus	AMLAB-L 1-Actuation module 1, LED exterior lighting, left front	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	LIN Bus	AMLAB-R 1-Actuation module 1, LED exterior lighting, right front	●	●	○	●	●	●	○			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2008	GLK	X 204	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2008	GLK	X 204	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Driver assistance system	RFK-Backup camera	●	●	○	●	●	●	●			
As of 2008	GLK	X 204	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			F069 F1DE
As of 2008	GLK	X 204	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2008	GLK	X 204	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			F1DF F1E0 F1E1 F1E2
From 2006 to 2011	M-Class	164	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 2006 to 2011	M-Class	164	Drive	VG - Transfer case	●	●	●	●	○	●	●			F068
From 2006 to 2011	M-Class	164	Drive	HAQ-Interwheel differential lock at rear axle	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Drive	ISM-Intelligent servo module	●	●	●	●	●	●	●	●	C0DB	FOC1 FOC2
From 2006 to 2011	M-Class	164	Drive	ISM-Shift module	●	●	●	●	●	●	●		C06B	FOC1 FOC2
From 2006 to 2011	M-Class	164	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
From 2006 to 2011	M-Class	164	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
From 2006 to 2011	M-Class	164	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
From 2006 to 2011	M-Class	164	Drive	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Drive	TV-TV tuner	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 2006 to 2011	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
From 2006 to 2011	M-Class	164	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FOA11
From 2006 to 2011	M-Class	164	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	●		C001	F156
From 2006 to 2011	M-Class	164	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	●		C001	F156
From 2006 to 2011	M-Class	164	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
From 2006 to 2011	M-Class	164	Drive	CDI 6BIN5-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F0E2 F0DC F0E3 F0E4 F036 F0DB F0E6 F0E7 F0E8 F038 F0C5 F008 F014 F0D7 F03A F0E9 F03B F007 F016 F034 F035 F033
From 2006 to 2011	M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 F0E2 F0DC F0E3 F0E4 F036 F0E5 F0DB F0E6 F0E7 F0E8 F038 F0C5 F008 F014 F0D7 F03A F0E9 F03B F016 F033 F034 F035
From 2006 to 2011	M-Class	164	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 F036 F0DB F0E8 F038 F008 F014 F0D7 F03A F03B F016 F033 F034
From 2006 to 2011	M-Class	164	Drive	SCR-Selective Catalytic Reduction	●	●	●	●	●	●	●		C069 C049 C04B C04A	FOC3 FOC4 FOC5
From 2006 to 2011	M-Class	164	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C048	F007 F009 F013 F0D6 F034 F015 F016 F014 F171 F03B F03A F173 F0D7 F174 F175 F176 F177
From 2006 to 2011	M-Class	164	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Drive	ME-SF 17.7-Motor electronics 17.7	●	●	●	●	●	●	●		C069 C002 C049 C04B	FOA4 F008 F007 FOA5 F0B1 FOA7 FOA1 FOA9 FOAA FOAB FOAC F0B2 FOAE
From 2006 to 2011	M-Class	164	Drive	FSCU-Fuel pump	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Drive	HSG-Hybrid control unit	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Drive	CDI 60LS-Common Rail Diesel Injection	●	●	●	●	●	●	●			F016 F033 F034 F013 F036 F038 F0DB F0DC F007 F008 F014 F0D7 F03A F03B F011 F0DD F0DE F0DF F0E0 F0E1

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 2006 to 2011	M-Class	164	Chassis	DTR-Distronic	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●		C148 C077 C149	F019 FOEA FOEB
From 2006 to 2011	M-Class	164	Chassis	Suspension	●	●	●	●	●	○	●	●		F06F F15A F1E8 F15B F1EA F1EB F1EC F1ED F1EE F1EF F1F0 F1F1 F1F2
From 2006 to 2011	M-Class	164	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	●	●		C14A	FOEE
From 2006 to 2011	M-Class	164	Chassis	EHPS-Electrohydraulic Power Steering	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Chassis	RBS-Regenerative braking system	●	●	●	●	●	●	○			F019 FOEB F261 F206 F0B4
From 2006 to 2011	M-Class	164	Body	CGW-Central gateway	●	●	○	●	○	○	○	●	C005 C006 C007	F01B F01C F01D
From 2006 to 2011	M-Class	164	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C00A C00B C14B	F01E F139 F01F F020 F13A
From 2006 to 2011	M-Class	164	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○	●	C007 C00A C00B C14B	F01E F139 F01F F020 F13A
From 2006 to 2011	M-Class	164	Body	KG-KEYLESS GO	●	●	●	●	●	●	●		C001	
From 2006 to 2011	M-Class	164	Body	KG-KEYLESS GO	●	●	●	●	●	●	○		C001	
From 2006 to 2011	M-Class	164	Body	AB-Airbag	●	●	●	●	●	●	●		C001 C01D C060 C096 C023 C099 C020 C01F C0E8 C142 C024 C062	
From 2006 to 2011	M-Class	164	Body	OCP-Overhead control panel	●	●	●	●	●	●	●	●	C001 C14C C025 C14D C14E	F262 F263 F264 F265
From 2006 to 2011	M-Class	164	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●		
From 2006 to 2011	M-Class	164	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●	●		
From 2006 to 2011	M-Class	164	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	●	●	●	C14F C150 C151 C152 C153 C154 C155	
From 2006 to 2011	M-Class	164	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●		C156 C157 C0C8 C158 C159 C15A C0C7 C15B C15C C15D C15E C145	
From 2006 to 2011	M-Class	164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C059	
From 2006 to 2011	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	○		C001	F024
From 2006 to 2011	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C059	
From 2006 to 2011	M-Class	164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	○		C001	F024
From 2006 to 2011	M-Class	164	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
From 2006 to 2011	M-Class	164	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●	●	C065	F026 F164 F165
From 2006 to 2011	M-Class	164	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●	●	C004 C065	F164 F165
From 2006 to 2011	M-Class	164	Body	System diagnosis (CAN)	●	●	○	●	○	●	○	●	C02B C007 C02C	
From 2006 to 2011	M-Class	164	Body	SG-DDW - DC/DC converter control unit	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Body	SG-BMS - Battery management system control unit	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
From 2006 to 2011	M-Class	164	Information and communication	CM-Compass module	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F028 F166
From 2006 to 2011	M-Class	164	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	F266
From 2006 to 2011	M-Class	164	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○	●	C15F C02C C160 C0D5 C0D6	F02A
From 2006 to 2011	M-Class	164	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	○		C04C C161 C04D C0A5 C162	
From 2006 to 2011	M-Class	164	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	●	●	C04D C04E C0A5 C0A6 C0A7	
From 2006 to 2011	M-Class	164	Information and communication	RFK-Backup camera	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
From 2006 to 2011	M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
From 2006 to 2011	M-Class	164	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 2006 to 2011	M-Class	164	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 2006 to 2011	M-Class	164	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
From 2006 to 2011	M-Class	164	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●		C09B C0A9	
From 2006 to 2011	M-Class	164	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
From 2006 to 2011	M-Class	164	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	AVE-H-Rear audio video unit	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
From 2006 to 2011	M-Class	164	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
From 2006 to 2011	M-Class	164	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
From 2006 to 2011	M-Class	164	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
From 2006 to 2011	M-Class	164	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
From 2006 to 2011	M-Class	164	Information and communication	AVE-H - DVD player	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	Left rear screen	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	Right rear screen	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
From 2006 to 2011	M-Class	164	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001 C041 C043	
From 2006 to 2011	M-Class	164	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001 C041 C043	
From 2006 to 2011	M-Class	164	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	●	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
From 2006 to 2011	M-Class	164	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	●	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
From 2006 to 2011	M-Class	164	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 2006 to 2011	M-Class	164	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 2006 to 2011	M-Class	164	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
From 2006 to 2011	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	●	●	●	●	●	○	●		C001	F267
From 2006 to 2011	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	●	●	●	●	●	●	●		C163 C164	F268
From 2006 to 2011	M-Class	164	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
From 2006 to 2011	M-Class	164	Seats and doors	ERA-Electric fold-down backrest system (3rd seat row)	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 2006 to 2011	M-Class	164	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C165 C046 C104 C166 C06F	F030 F02F F031 F032
From 2006 to 2011	M-Class	164	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
From 2006 to 2011	M-Class	164	Air conditioning	STH-Stationary heater with remote control	●	●	●	●	●	●	●		C106 C167 C06F C108 C168 C169	F200
From 2006 to 2011	M-Class	164	Air conditioning	EKMK-Electric refrigerant compressor	●	●	●	●	●	○	○			
From 1998 to 2005	M-Class	163	Drive	ETC-Electronic transmission control	●	●	○	●	○	※	●			F12E
From 1998 to 2005	M-Class	163	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 1998 to 2005	M-Class	163	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
From 1998 to 2005	M-Class	163	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●			F0A4 F155
From 1998 to 2005	M-Class	163	Drive	VG - Transfer case	●	●	○	●	●	※	○			
From 1998 to 2005	M-Class	163	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 1998 to 2005	M-Class	163	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 1998 to 2005	M-Class	163	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
From 1998 to 2005	M-Class	163	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002	F012 F0DA F0B3
From 1998 to 2005	M-Class	163	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●			F019 F0EB F0EA F138
From 1998 to 2005	M-Class	163	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
From 1998 to 2005	M-Class	163	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			F03D
From 1998 to 2005	M-Class	163	Chassis	ESP-Electronic stability program	●	●	○	●	●	※	●			
From 1998 to 2005	M-Class	163	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
From 1998 to 2005	M-Class	163	Chassis	ETS-Electronic traction system	●	●	○	●	●	※	●			
From 1998 to 2005	M-Class	163	Chassis	BAS-Brake assist	●	●	○	●	●	※	●			
From 1998 to 2005	M-Class	163	Chassis	VP-Vacuum pump brake booster	●	●	●	●	●	●	●			
From 1998 to 2005	M-Class	163	Body	AB-Airbag	●	●	○	●	○	※	●			
From 1998 to 2005	M-Class	163	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
From 1998 to 2005	M-Class	163	Body	EAM-Extended activity module	●	●	○	●	●	※	●			
From 1998 to 2005	M-Class	163	Body	AAM-All Activity Module	●	●	○	●	●	※	●			F269 F0A4 F26A F26B
From 1998 to 2005	M-Class	163	Body	AAM-All Activity Module	●	●	○	●	●	※	●			F26C F26A F26D F26E F26F
From 1998 to 2005	M-Class	163	Body	DAS-Drive authorization system	●	●	●	●	●	※	○			F270 F271 F272 F273
From 1998 to 2005	M-Class	163	Body	HRA-Headlamp range adjustment	●	●	●	●	●	○	●			F026
From 1998 to 2005	M-Class	163	Body	LCP-Lower operating panel with power window function	●	●	●	●	●	※	●			
From 1998 to 2005	M-Class	163	Body	SEM-Security Module(Up to model year 1999)	●	●	○	●	○	※	●			
From 1998 to 2005	M-Class	163	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
From 1998 to 2005	M-Class	163	Information and communication	PTS-Parktronic system	●	●	●	●	●	※	●			
From 1998 to 2005	M-Class	163	Information and communication	COMAND	●	●	○	●	●	●	●			
From 1998 to 2005	M-Class	163	Information and communication	MCS-Modular control system	●	●	○	●	●	●	●			
From 1998 to 2005	M-Class	163	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 1998 to 2005	M-Class	163	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 1998 to 2005	M-Class	163	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 1998 to 2005	M-Class	163	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 1998 to 2005	M-Class	163	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 1998 to 2005	M-Class	163	Information and communication	SOUND- Sound system	●	●	○	●	●	●	○			
From 1998 to 2005	M-Class	163	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
From 1998 to 2005	M-Class	163	Information and communication	MCS navigation-Navigation in MCS	●	●	○	●	●	●	○			
From 1998 to 2005	M-Class	163	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 1998 to 2005	M-Class	163	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
From 1998 to 2005	M-Class	163	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
From 1998 to 2005	M-Class	163	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C04C C001 C06F	F02F F030
As of 2012	M-Class	166	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2012	M-Class	166	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Drive	VG - Transfer case	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2012	M-Class	166	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D
As of 2012	M-Class	166	Drive	VGS - Transmission control for 7-speed transmissio	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2012	M-Class	166	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2012	M-Class	166	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2012	M-Class	166	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Drive	SCR-Selective Catalytic Reduction	●	●	○	●	●	●	●			F1B0 F1B1 F055 F1B2 F1B3 F1B4
As of 2012	M-Class	166	Drive	SCR - Selective catalytic reduction	●	●	○	●	●	●	●			F1B5 F1B6 F1B7 F1B1 F1B0 F055
As of 2012	M-Class	166	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Drive	SG-EM - Power electronics	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651'	●	●	○	●	●	●	●			F049 F048 F052 F04B F1C1 F040 F04A F051 F1B9 F042 F1BA F1C2 F1BB F1BC F09A F1BD F1BE F04D F1BF F1C0 F056 F1C3 F059
As of 2012	M-Class	166	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	●	●	●			F048 F1C4 F1BE F04F F040 F09A F052 F1BD F1C1 F1C5 F04D F1BB F1C6 F051 F1BF F056 F1C0 F1C3 F059
As of 2012	M-Class	166	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642'	●	●	○	●	●	●	●			F048 F1C7 F1C8 F1BD F1C9 F04F F1CA F040 F052 F09A F04D F1BE F1C4 F1C1 F055 F056 F058 F059 F057
As of 2012	M-Class	166	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2012	M-Class	166	Chassis	ESP-Regenerative braking system	●	●	○	●	●	●	●			F258 F259 F23E F0F4 F25A F25B F25C
As of 2012	M-Class	166	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F258 F274 F275 F276
As of 2012	M-Class	166	Chassis	AIRMATIC - AIRMATIC	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			F1D8 F1D9
As of 2012	M-Class	166	Chassis	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Chassis	EPB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2012	M-Class	166	Chassis	FWGW-Chassis gateway	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Chassis	Roll control-Roll control	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	EZS-Electronic ignition switch	●	●	○	●	●	●	○			F05C F05D F05E F05F F060 F061 F062 F063
As of 2012	M-Class	166	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2012	M-Class	166	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2012	M-Class	166	Body	ATA-ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	SRS-Supplemental restraint system	●	●	○	●	●	●	●			F064 F065
As of 2012	M-Class	166	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Body	HKS-Tailgate control (N121/1)	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	MPK-Multifunction camera	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	SD-Control module 'Sliding roof'	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	M-Class	166	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	Trailer recognition module-Trailer recognition	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	Rear-Rear control unit	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	●			F071 F072 F073 F074
As of 2012	M-Class	166	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	●			F075 F076
As of 2012	M-Class	166	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2012	M-Class	166	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2012	M-Class	166	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	SOUND - Sound system (N40/3)	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	○	○			
As of 2012	M-Class	166	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2012	M-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2012	M-Class	166	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	M-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2012	M-Class	166	Information and communication	AVE-H - DVD player	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	○	●			
As of 2012	M-Class	166	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	MKS-FS-Multicontour seat 'Driver'	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	MKS-BFS-Multicontour seat 'Front passenger'	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	DCU-LF-Left front door	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	DCU-RF-Right front door	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	DCU-LR-Left rear door	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Seats and doors	DCU-RR-Right rear door	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Air conditioning	STH-Stationary heater	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Air conditioning	HBF-Rear control panel	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2012	M-Class	166	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2012	M-Class	166	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Driver assistance system	360camera-360camera	●	●	○	●	●	●	●			F277 F278 F279
As of 2012	M-Class	166	Driver assistance system	360 camera-360 camera	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	NSA - Night View Assist	●	●	○	●	●	○	○			
As of 2012	M-Class	166	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012	M-Class	166	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2012	M-Class	166	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	VG - Transfer case	●	●	●	●	●	○	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002	F012 F0DA F0B3
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	●	●	●	●	●	※	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	※	●	●		F019 F20B F20C
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●		C09B C02C C09C C09D C02F C09E C09F C0A0 C0A1 C0A2	F13F F100 F140 F08C
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND	●	●	○	●	●	●	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●		C001	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●		C001	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●		C001	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●		C001	
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F142 F145
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F151 F152
Up to 03/2004	G-Class	463(16-pin diagnostic socket)	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	●	●			F025
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	VG - Transfer case	●	●	●	●	●	○	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	CDI-V-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002	F012 F0DA F0B3
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	●	●	●	●	●	※	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	※	●	●		F019 F20B F20C
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●		C09B C02C C09C C09D C02F C09E C09F C0A0 C0A1 C0A2	F13F F100 F140 F08C

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND	●	●	○	●	●	●	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●		C001	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●		C001	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●		C001	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●		C001	
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F142 F145
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F151 F152
From 04/2004 to 08/2006	G-Class	463(16-pin diagnostic socket)	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	VG - Transfer case	●	●	●	●	●	○	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	●	●	●	●	●	※	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	※	●	●		F019 F20B F20C
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	ALWR-Headlamp range adjustment	●	●	●	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●		C09B C02C C09C C09D C02F C09E C09F C0A0 C0A1 C0A2	F13F F100 F140 F08C
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463 (16-pin diagnostic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	●	●	●	●	●	●	●			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND	●	●	○	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	●	●	●	●	○	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	●	○	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	●	●	●	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [Japan]-Telematic system	●	●	●	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	E-call [USA]-Telematic system	●	●	●	●	●	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic system	●	●	●	●	●	○	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	●	●	●	●	○	○	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance (USA, Canada), Tele diagnosis (ECE)	●	●	●	●	●	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	●	●	●	●	●	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●		C001	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●		C001	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●		C001	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●		C001	
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F142 F145
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F151 F152
From 09/2006 to 02/2007	G-Class	463(16-pin diagnostic socket)	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	VG - Transfer case	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●		C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	TV-TV tuner	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 F0E2 F0DC F0E3 F0E4 F036 F0E5 F0DB F0E6 F0E7 F0E8 F038 F0C5 F008 F014 F0D7 F03A F0E9 F03B F016 F033 F034 F035

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Drive	SCR-Selective Catalytic Reduction	●	●	●	●	●	●	●		C069 C049 C04B C04A	F0C3 F0C4 F0C5
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	●	●	●	●	●	※	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	※	●	●		F019 F20B F20C
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			F06F F070
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Chassis	Traction systems ABS	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C071 C00F C011 C072 C073 C074 C075 C015 C088 C089 C076 C077 C078 C079 C017 C08A C07C C016 C08B C07D C012 C00B C08C C080 C081 C082 C08D C083 C084 C085 C086 C087	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	UCP-Upper control panel	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	OCP-Overhead control panel	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	ALWR-Headlamp range adjustment	●	●	●	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	MSS-Special vehicle multifunction control module	●	●	●	●	●	○	●			F025
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Body	AHE-Trailer recognition	●	●	●	●	●	○	●	●		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	○	●		COA3	F141
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner(AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●		C001	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●		C001	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RL-Door control module rear left	●	●	●	●	●	○	●		C001	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	DCM-RR-Door control module rear right	●	●	●	●	●	○	●		C001	
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●			F142 F143 F144 F145 F146
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	○	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F142 F145
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	●	●	●	●	●	○	●			F14E F142 F143 F144 F145 F146



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	○	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●		C001	F02F F030
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	●	●	●	●	●	●	●			F151 F152
As of 03/2007	G-Class	463(16-pin diagnostic socket)	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	○	●	○	※	●			F12E
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Drive	ME2-SFI-Motor electronics 2	●	●	○	●	●	※	●			F0A4 F155
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 F0A4 F009 F131 F0A0 F00B F0A2 F132 F133 F134 F135
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Drive	HFM-SFI-Hot film engine management	●	●	○	●	●	※	○			
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Chassis	ABS-Antilock brake system	●	●	○	●	●	※	○			
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	○	※	○			
As of 03/2007	G-Class	463(38-pin diagnostic socket)	Body	APS-Auto pilot system	●	●	○	●	●	※	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 03/2007	G-Class	463 (38-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	○	※	●			
As of 03/2007	G-Class	463 (38-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	●	●	●	●	○			
As of 03/2007	G-Class	463 (38-pin diagnostic socket)	Information and communication	AUDIO	●	●	●	●	●	●	●			
As of 03/2007	G-Class	463 (38-pin diagnostic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	●	●	●	●	○	○	○			
As of 03/2007	G-Class	463 (38-pin diagnostic socket)	Information and communication	VCS-Voice control system	●	●	●	●	○	○	○			
As of 03/2007	G-Class	463 (38-pin diagnostic socket)	Information and communication	CDC-CD changer	●	●	●	●	○	○	○			
As of 03/2007	G-Class	463 (38-pin diagnostic socket)	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
As of 1990	G-Class	461 (16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F08D F078 F121 F122 F123 F124 F125 F126 F127 F128 F129 F081 F082 F083 F12A F12B F087 F088 F086 F002 F089 F005 F006
As of 1990	G-Class	461 (16-pin diagnostic socket)	Drive	ESM-Electronic selector module	●	●	○	●	●	※	●			
As of 1990	G-Class	461 (16-pin diagnostic socket)	Drive	VG - Transfer case	●	●	●	●	●	○	●			
As of 1990	G-Class	461 (16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C048 C002 C049	F136 F0DA F0D9
As of 1990	G-Class	461 (16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	●	●		F077 F078 F079 F07A F07B F07C F07D F07E F07F F080 F081 F082 F083 F084 F085 F086 F087 F088 F086 F002 F089 F06F F005 F006
As of 1990	G-Class	461 (16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●			F016 F015 F153 F27A F27B

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 1990	G-Class	461(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	●	●	●	●	●	※	●			
As of 1990	G-Class	461(16-pin diagnostic socket)	Chassis	Traction systems ABS	●	●	●	●	●	●	○			
As of 1990	G-Class	461(16-pin diagnostic socket)	Body	AB-Airbag	●	●	○	●	●	※	○	●	C057 C058 C059 C05A C05B C05C C05D C021 C05E C05F C060 C061 C024 C062	
As of 1990	G-Class	461(16-pin diagnostic socket)	Body	CGW-Central gateway	●	●	●	●	●	●	○		C001	F025
As of 1990	G-Class	461(16-pin diagnostic socket)	Information and communication	WSP immobilizer	●	●	●	●	●	※	○			
As of 1990	G-Class	461(16-pin diagnostic socket)	Information and communication	IC-Instrument cluster	●	●	●	●	●	※	●			
As of 1990	G-Class	461(16-pin diagnostic socket)	Information and communication	AUDIO	●	●	○	●	○	●	○			
As of 1990	G-Class	461(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	●	●	○	●	●	※	●			F03E
From 2006 to 2011	GL-Class	X 164	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
From 2006 to 2011	GL-Class	X 164	Drive	VG - Transfer case	●	●	●	●	○	●	●			F068
From 2006 to 2011	GL-Class	X 164	Drive	HAQ-Interwheel differential lock at rear axle	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Drive	ISM-Intelligent servo module	●	●	●	●	●	●	●	●	C0DB	F0C1 F0C2
From 2006 to 2011	GL-Class	X 164	Drive	ISM-Shift module	●	●	●	●	●	●	●		C06B	F0C1 F0C2
From 2006 to 2011	GL-Class	X 164	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	F0A4 F007 F008 F009 F0A5 F0A6 F082 F0A7 F0A8 F0A1 F0A9 F0AA F0AB F0AC F0AD F0AE F011
From 2006 to 2011	GL-Class	X 164	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●		C001	
From 2006 to 2011	GL-Class	X 164	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
From 2006 to 2011	GL-Class	X 164	Drive	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Drive	TV-TV tuner	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
From 2006 to 2011	GL-Class	X 164	Drive	CDI 5-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C048	F007 F009 F013 F0D6 F034 F015 F016 F014 F171 F03B F03A F173 F0D7 F174 F175 F176 F177
From 2006 to 2011	GL-Class	X 164	Chassis	DTR-Distronic	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●		C148 C077 C149	F019 F0EA F0EB
From 2006 to 2011	GL-Class	X 164	Chassis	EHPS-Electrohydraulic Power Steering	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Chassis	Suspension	●	●	●	●	●	○	●	●		F06F F15A F1E8 F15B F1EA F1EB F1EC F1ED F1EE F1EF F1F0 F1F1 F1F2

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 2006 to 2011	GL-Class	X 164	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	●	●		C14A	FOEE
From 2006 to 2011	GL-Class	X 164	Body	CGW-Central gateway	●	●	○	●	○	○	○	●	C005 C006 C007	F01B F01C F01D
From 2006 to 2011	GL-Class	X 164	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C00A C00B C14B	F01E F139 F01F F020 F13A
From 2006 to 2011	GL-Class	X 164	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○	●	C007 C00A C00B C14B	F01E F139 F01F F020 F13A
From 2006 to 2011	GL-Class	X 164	Body	KG-KEYLESS GO	●	●	●	●	●	●	●		C001	
From 2006 to 2011	GL-Class	X 164	Body	KG-KEYLESS GO	●	●	●	●	●	●	○		C001	
From 2006 to 2011	GL-Class	X 164	Body	AB-Airbag	●	●	●	●	●	●	●		C001 C01D C060 C096 C023 C099 C020 C01F C0E8 C142 C024 C062	
From 2006 to 2011	GL-Class	X 164	Body	OCP-Overhead control panel	●	●	●	●	●	●	●	●	C001 C14C C025 C14D C14E	F262 F263 F264 F265
From 2006 to 2011	GL-Class	X 164	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●		
From 2006 to 2011	GL-Class	X 164	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●	●		
From 2006 to 2011	GL-Class	X 164	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	●	●	●	C14F C150 C151 C152 C153 C154 C155	
From 2006 to 2011	GL-Class	X 164	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●		C156 C157 C0C8 C158 C159 C15A C0C7 C15B C15C C15D C15E C145	
From 2006 to 2011	GL-Class	X 164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C059	
From 2006 to 2011	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	○		C001	F024
From 2006 to 2011	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C059	
From 2006 to 2011	GL-Class	X 164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	○		C001	F024
From 2006 to 2011	GL-Class	X 164	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
From 2006 to 2011	GL-Class	X 164	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●	●		
From 2006 to 2011	GL-Class	X 164	Body	XALWA-L-Xenon headlamp, left	●	●	●	●	●	●	●	●	C065	F026 F164 F165
From 2006 to 2011	GL-Class	X 164	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●	●		
From 2006 to 2011	GL-Class	X 164	Body	XALWA-R-Xenon headlamp, right	●	●	●	●	●	●	●	●	C004 C065	F164 F165
From 2006 to 2011	GL-Class	X 164	Body	System diagnosis(CAN)	●	●	○	●	○	●	○	●	C02B C007 C02C	
From 2006 to 2011	GL-Class	X 164	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
From 2006 to 2011	GL-Class	X 164	Information and communication	CM-Compass module	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F028 F166
From 2006 to 2011	GL-Class	X 164	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	F266
From 2006 to 2011	GL-Class	X 164	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○	●	C15F C02C C160 C0D5 C0D6	F02A
From 2006 to 2011	GL-Class	X 164	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	○		C04C C161 C04D C0A5 C162	
From 2006 to 2011	GL-Class	X 164	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	●	●	C04D C04E C0A5 C0A6 C0A7	
From 2006 to 2011	GL-Class	X 164	Information and communication	RFK-Backup camera	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
From 2006 to 2011	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C036 C037 C038	F025
From 2006 to 2011	GL-Class	X 164	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
From 2006 to 2011	GL-Class	X 164	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
From 2006 to 2011	GL-Class	X 164	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
From 2006 to 2011	GL-Class	X 164	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
From 2006 to 2011	GL-Class	X 164	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	AVE-H-Rear audio video unit	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
From 2006 to 2011	GL-Class	X 164	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	CTEL-Cellular telephone(JAPAN)	●	●	○	●	●	○	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	AVE-H - DVD player	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	Left rear screen	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	Right rear screen	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
From 2006 to 2011	GL-Class	X 164	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001 C041 C043	
From 2006 to 2011	GL-Class	X 164	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001 C041 C043	
From 2006 to 2011	GL-Class	X 164	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	●	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D
From 2006 to 2011	GL-Class	X 164	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	●	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
From 2006 to 2011	GL-Class	X 164	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 2006 to 2011	GL-Class	X 164	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
From 2006 to 2011	GL-Class	X 164	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Seats and doors	ERA-Electric fold-down backrest system (3rd seat row)	●	●	●	●	●	●	●			
From 2006 to 2011	GL-Class	X 164	Seats and doors	REDC-Rear-end door closing control module	●	●	●	●	●	○	●		C001	F267
From 2006 to 2011	GL-Class	X 164	Seats and doors	REDC-Rear-end door closing control module	●	●	●	●	●	●	●		C163 C164	F268
From 2006 to 2011	GL-Class	X 164	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
From 2006 to 2011	GL-Class	X 164	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C165 C046 C104 C166 C06F	F030 F02F F031 F032
From 2006 to 2011	GL-Class	X 164	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
From 2006 to 2011	GL-Class	X 164	Air conditioning	STH-Stationary heater with remote control	●	●	●	●	●	●	●		C106 C167 C06F C108 C168 C169	F200
As of 2012	GL-Class	166	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2012	GL-Class	166	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Drive	VG - Transfer case	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	GL-Class	166	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2012	GL-Class	166	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D
As of 2012	GL-Class	166	Drive	VGS - Transmission control for 7-speed transmissio	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2012	GL-Class	166	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 FIAB F1A0 FIAC FIAD F1AE F1A3 F1A4 F1A5 F1AF
As of 2012	GL-Class	166	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2012	GL-Class	166	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Drive	SCR-Selective Catalytic Reduction	●	●	○	●	●	●	●			F1B0 F1B1 F055 F1B2 F1B3 F1B4
As of 2012	GL-Class	166	Drive	SCR - Selective catalytic reduction	●	●	○	●	●	●	●			F1B5 F1B6 F1B7 F1B1 F1B0 F055
As of 2012	GL-Class	166	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Drive	SG-EM - Power electronics	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651'	●	●	○	●	●	●	●			F049 F048 F052 F04B F1C1 F040 F04A F051 F1B9 F042 F1BA F1C2 F1BB F1BC F09A F1BD F1BE F04D F1BF F1C0 F056 F1C3 F059
As of 2012	GL-Class	166	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	●	●	●			F048 F1C4 F1BE F04F F040 F09A F052 F1BD F1C1 F1C5 F04D F1BB F1C6 F051 F1BF F056 F1C0 F1C3 F059
As of 2012	GL-Class	166	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642'	●	●	○	●	●	●	●			F048 F1C7 F1C8 F1BD F1C9 F04F F1CA F040 F052 F09A F04D F1BE F1C4 F1C1 F055 F056 F058 F059 F057
As of 2012	GL-Class	166	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2012	GL-Class	166	Chassis	ESP-Regenerative braking system	●	●	○	●	●	●	●			F258 F259 F23E F0F4 F25A F25B F25C
As of 2012	GL-Class	166	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F258 F274 F275 F276
As of 2012	GL-Class	166	Chassis	AIRMATIC - AIRMATIC	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			F1D8 F1D9
As of 2012	GL-Class	166	Chassis	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Chassis	EPB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2012	GL-Class	166	Chassis	FWGW-Chassis gateway	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Chassis	Roll control-Roll control	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	EZS-Electronic ignition switch	●	●	○	●	●	●	○			F05C F05D F05E F05F F060 F061 F062 F063
As of 2012	GL-Class	166	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2012	GL-Class	166	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2012	GL-Class	166	Body	ATA-ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	SRS-Supplemental restraint system	●	●	○	●	●	●	●			F064 F065
As of 2012	GL-Class	166	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Body	HKS-Tailgate control (N121/1)	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	MPK-Multifunction camera	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	SD-Control module 'Sliding roof '	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	Trailer recognition module-Trailer recognition	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	GL-Class	166	Body	Rear-Rear control unit	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	●			F071 F072 F073 F074
As of 2012	GL-Class	166	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	●			F075 F076
As of 2012	GL-Class	166	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2012	GL-Class	166	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2012	GL-Class	166	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	SOUND - Sound system(N40/3)	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	○	○			
As of 2012	GL-Class	166	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2012	GL-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	MPK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2012	GL-Class	166	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2012	GL-Class	166	Information and communication	AVE-H - DVD player	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	GL-Class	166	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	○	●			
As of 2012	GL-Class	166	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	MKS-FS-Multicontour seat 'Driver'	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	MKS-BFS-Multicontour seat 'Front passenger'	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	ESA 'Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	DCU-LF-Left front door	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	DCU-RF-Right front door	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	DCU-LR-Left rear door	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Seats and doors	DCU-RR-Right rear door	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Air conditioning	STH-Stationary heater	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Air conditioning	HBF-Rear control panel	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2012	GL-Class	166	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2012	GL-Class	166	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Driver assistance system	360camera-360camera	●	●	○	●	●	●	●			F277 F278 F279
As of 2012	GL-Class	166	Driver assistance system	360 camera-360 camera	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	NSA - Night View Assist	●	●	○	●	●	○	○			
As of 2012	GL-Class	166	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012	GL-Class	166	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2012	GL-Class	166	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
As of 1996	R-Class	251	Drive	ISM-Intelligent servo module	●	●	●	●	●	●	●	●	C0DB	FOC1 FOC2
As of 1996	R-Class	251	Drive	ISM-Shift module	●	●	●	●	●	●	●	●	C06B	FOC1 FOC2
As of 1996	R-Class	251	Drive	ETC-Electronic transmission control	●	●	●	●	●	●	○	●	C068	F08A F08B F08C F089 F08D F08E F08F F090 F091 F092 F093
As of 1996	R-Class	251	Drive	ME 9.7-Motor electronics 9.7	●	●	●	●	●	●	●	●	C069 C002 C06A C04A	FOA4 F007 F008 F009 FOA5 FOA6 F082 FOA7 FOA8 FOA1 FOA9 FOAA FOAB FOAC FOAD FOAE FO11
As of 1996	R-Class	251	Drive	FSCU-Fuel pump	●	●	●	●	●	●	●	●	C001	
As of 1996	R-Class	251	Drive	DTR-Distronic	●	●	●	●	●	●	○	●		
As of 1996	R-Class	251	Drive	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Drive	IRS-HLA - Outer left rear intelligent radar sensor system	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Drive	TV-TV tuner	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 1996	R-Class	251	Drive	ME-SFI 2.8-Motor electronics 2.8	●	●	●	●	●	●	●	●	C069 C068 C002 C049	F011 FOA4 F009 F131 FOA0 F00B FOA2 F132 F133 F134 F135
As of 1996	R-Class	251	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	●	●	●	●	●	●		FOA4 F007 F008 F009 FOAF F082 FOA7 FOA9 FOAA FOAB FOAC FOAD FOAE FO11



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 1996	R-Class	251	Drive	FSCU Left-Control unit 'Left fuel pump'	●	●	●	●	○	●	●		C001	F156
As of 1996	R-Class	251	Drive	FSCU Right-Control unit 'Right fuel pump'	●	●	●	●	○	●	●		C001	F156
As of 1996	R-Class	251	Drive	CDI 4-Common Rail Diesel Injection	●	●	●	●	●	●	●		C003 C001 C004 C048	F007 F015 F016 F153 F013 F014 F03A F03B F0D7 F0DA F017 F154
As of 1996	R-Class	251	Drive	CDI 6BIN5-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F0E2 F0DC F0E3 F0E4 F036 F0DB F0E6 F0E7 F0E8 F038 F0C5 F008 F014 F0D7 F03A F0E9 F03B F007 F016 F034 F035 F033
As of 1996	R-Class	251	Drive	CDI 6-Common Rail Diesel Injection	●	●	●	●	●	●	●			F011 F013 F007 F0E2 F0DC F0E3 F0E4 F036 F0E5 F0DB F0E6 F0E7 F0E8 F038 F0C5 F008 F014 F0D7 F03A F0E9 F03B F016 F033 F034 F035
As of 1996	R-Class	251	Drive	CDI 60LS-Common Rail Diesel Injection	●	●	●	●	●	●	●			F016 F033 F034 F013 F036 F038 F0DB F0DC F007 F008 F014 F0D7 F03A F03B F011 F0DD F0DE F0DF F0E0 F0E1
As of 1996	R-Class	251	Drive	SCR-Selective Catalytic Reduction	●	●	●	●	●	●	●		C069 C049 C04B C04A	F0C3 F0C4 F0C5
As of 1996	R-Class	251	Chassis	DTR-Distronic	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Chassis	ESP-Electronic stability program	●	●	●	●	●	●	●		C148 C077 C149	F019 F0EA F0EB
As of 1996	R-Class	251	Chassis	Suspension	●	●	●	●	●	○	●	●		F06F F15A F1E8 F15B F1EA F1EB F1EC F1ED F1EE F1EF F1F0 F1F1 F1F2
As of 1996	R-Class	251	Chassis	Suspension	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Chassis	TPC-Tire pressure monitor	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Chassis	TPM - Tire pressure monitor	●	●	●	●	●	●	●		C14A	F0EE
As of 1996	R-Class	251	Chassis	EHPS-Electrohydraulic Power Steering	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Body	CGW-Central gateway	●	●	○	●	○	○	○	●	C005 C006 C007	F01B F01C F01D
As of 1996	R-Class	251	Body	EZS-Electronic ignition switch	●	●	●	●	●	○	○		C007 C00A C00B C14B	F01E F139 F01F F020 F13A
As of 1996	R-Class	251	Body	EZS-Electronic ignition switch	●	●	●	●	●	●	○	●	C007 C00A C00B C14B	F01E F139 F01F F020 F13A
As of 1996	R-Class	251	Body	KG-KEYLESS GO	●	●	●	●	●	●	●		C001	
As of 1996	R-Class	251	Body	KG-KEYLESS GO	●	●	●	●	●	●	○		C001	
As of 1996	R-Class	251	Body	AB-Airbag	●	●	●	●	●	●	●		C001 C01D C060 C096 C023 C099 C020 C01F C0E8 C142 C024 C062	
As of 1996	R-Class	251	Body	OCP-Overhead control panel	●	●	●	●	●	●	●	●	C001 C14C C025 C14D C14E	F262 F263 F264 F265
As of 1996	R-Class	251	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Body	UCP-Upper control panel	●	●	●	●	●	○	●	●		
As of 1996	R-Class	251	Body	HBF (Rear control panel)-Rear control field	●	●	●	●	●	○	●	●		
As of 1996	R-Class	251	Body	SAM-F-Signal acquisition and actuation module front	●	●	●	●	●	●	●	●	C14F C150 C151 C152 C153 C154 C155	
As of 1996	R-Class	251	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	○	●		C156 C157 C0C8 C158 C159 C15A C0C7 C15B C15C C15D C15E C145	
As of 1996	R-Class	251	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C059	
As of 1996	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	○		C001	F024
As of 1996	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●	●	C059	
As of 1996	R-Class	251	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	○		C001	F024
As of 1996	R-Class	251	Body	HRA-Automatic headlamp range adjustment and headlamp control	●	●	●	●	●	○	●	●	C001 C0A8	F157
As of 1996	R-Class	251	Body	HRA-FL-Front left headlamp range control	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Body	HRA-FR-Front right headlamp range control	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Body	System diagnosis (CAN)	●	●	○	●	○	●	○	●	C02B C007 C02C	
As of 1996	R-Class	251	Information and communication	SCM [MRM]-Steering column module	●	●	●	●	●	●	●	●		
As of 1996	R-Class	251	Information and communication	CM-Compass module	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	IC-Instrument cluster	●	●	●	●	●	○	●	●	C02D C02E	F028 F166
As of 1996	R-Class	251	Information and communication	ASSYST-Active Service System	●	●	○	●	●	○	○	●	C02F	F266
As of 1996	R-Class	251	Information and communication	ASSYST PLUS-PLUS Active Service System	●	●	○	●	●	●	○	●	C15F C02C C160 C0D5 C0D6	F02A
As of 1996	R-Class	251	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	○		C04C C161 C04D C0A5 C162	

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 1996	R-Class	251	Information and communication	PTS-Parktronic system	●	●	●	●	●	○	●	●	C04D C04E C0A5 C0A6 C0A7	
As of 1996	R-Class	251	Information and communication	RFK-Backup camera	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●	●	C030 C031 C032 C033 C034 C035 C036	F025
As of 1996	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	●	●	●	●	●	●	●		C030 C031 C032 C033 C036 C037 C038	F025
As of 1996	R-Class	251	Information and communication	CDC-CD changer	●	●	○	●	●	●	○			F02E
As of 1996	R-Class	251	Information and communication	VCS-Voice control system	●	●	○	●	○	●	●			
As of 1996	R-Class	251	Information and communication	AUDIO	●	●	●	●	●	●	●		C032 C039 C03A C03B C03C C03D C03E C036 C037 C03F C040	F025
As of 1996	R-Class	251	Information and communication	COMAND or AUDIO	●	●	○	●	●	●	●			
As of 1996	R-Class	251	Information and communication	TV-TV tuner	●	●	○	●	●	●	●			
As of 1996	R-Class	251	Information and communication	TV-TV tuner (AGW)	●	●	●	●	●	●	●		C09B C0A9	
As of 1996	R-Class	251	Information and communication	SDAR-Satellite radio	●	●	○	●	●	●	○			
As of 1996	R-Class	251	Information and communication	SOUND- Sound system	●	●	○	●	●	●	●			F02E
As of 1996	R-Class	251	Information and communication	CTEL-Mobile phone adapter with universal interface	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	NAVI-Navigation system	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Information and communication	AVE-H-Rear audio video unit	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Information and communication	CTEL-Cellular telephone	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	●		C004 C051 C052 C053 C054 C055 C056	F03C
As of 1996	R-Class	251	Information and communication	Sound system (Main amplifier)	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Information and communication	UCI-Media interface	●	●	●	●	○	●	○			
As of 1996	R-Class	251	Information and communication	DAB-Digital radio	●	●	○	●	●	○	○			
As of 1996	R-Class	251	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Information and communication	TV-TV tuner	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	TV-TV tuner	●	●	●	●	○	●	○			
As of 1996	R-Class	251	Information and communication	CTEL-Cellular telephone (JAPAN)	●	●	○	●	●	○	●			
As of 1996	R-Class	251	Information and communication	AVE-H - DVD player	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	Left rear screen	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Information and communication	Right rear screen	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Information and communication	TELE AID-Control unit	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	TELE AID-Telematic services Emergency call	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance (USA, Canada),Tele diagnosis (ECE)	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	●	●	●	●	●	●	○			
As of 1996	R-Class	251	Seats and doors	DCM-FL-Door control module front left	●	●	●	●	●	○	●	●	C001 C041 C043	
As of 1996	R-Class	251	Seats and doors	DCM-FR-Door control module front right	●	●	●	●	●	○	●	●	C001 C041 C043	
As of 1996	R-Class	251	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	●	●	●	●	●	●	●	●	C001	F14E F14F F147 F142 F143 F144 F145 F146 F150 F149 F14A F14B F14C F14D

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 1996	R-Class	251	Seats and doors	ESA passenger-Electric seat adjustment passenger	●	●	●	●	●	●	●	●	C001	F147 F142 F143 F144 F145 F146 F148 F149 F14A F14B F14C F14D
As of 1996	R-Class	251	Seats and doors	DS-LF-Left front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
As of 1996	R-Class	251	Seats and doors	DS-RF-Right front dynamic seat	●	●	●	●	●	●	●	●	C0D7	F168
As of 1996	R-Class	251	Seats and doors	DSP-Pneumatic pump for dynamic seat	●	●	●	●	●	●	●			
As of 1996	R-Class	251	Seats and doors	REDC-Rear-end door closing control module	●	●	●	●	●	○	●		C001	F267
As of 1996	R-Class	251	Seats and doors	REDC-Rear-end door closing control module	●	●	●	●	●	●	●		C163 C164	F268
As of 1996	R-Class	251	Seats and doors	HS-Seat heater	●	●	●	●	●	○	●			
As of 1996	R-Class	251	Air conditioning	AAC-Automatic air conditioning	●	●	●	●	●	●	●	●	C165 C046 C104 C166 C06F	F030 F02F F031 F032
As of 1996	R-Class	251	Air conditioning	STH-Stationary heater with remote control	●	●	●	●	●	●	●		C106 C167 C06F C108 C168 C169	F200
As of 1996	R-Class	251	Air conditioning	HSW-Heated steering wheel	●	●	●	●	●	○	●			
As of 2010	E-Class	212	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2010	E-Class	212	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Drive	FSCU06 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Drive	ME - Motro electronics CNGCM246 for combustion engine 379CNG	●	●	○	●	●	●	error	○		
As of 2010	E-Class	212	Drive	ESM[EWM] - Electronic selector module	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Drive	ME 9.7-Motor electronics 9.7	●	●	○	●	●	●	●			F17A F17B F17C F17D F17E F17F F180 F181 F182 F183 F184 F185 F186 F187 F188 F189
As of 2010	E-Class	212	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	●	●	○	●	●	●	●			F17A F17B F17C F17D F18A F180 F181 F184 F185 F186 F187 F188 F189
As of 2010	E-Class	212	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	○	●	●	●	●			F18B F17B F17D F17E F18C F18D F181 F18E F18F F183 F190 F191 F192 F193 F194 F195 F196
As of 2010	E-Class	212	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO'	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2010	E-Class	212	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D
As of 2010	E-Class	212	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2010	E-Class	212	Drive	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO'	●	●	●	●	●	●	●			F094 F095 F096 F097 F098 F099 F09A F040 F09B F09C F09D F09E
As of 2010	E-Class	212	Drive	ETC[EGS] - Transmission control for 5-speed transimssion	●	●	○	●	●	●	●			F244 F245 F1A0 F246 F247 F19A F1A1
As of 2010	E-Class	212	Drive	VGS - Transmission control for 7-speed transimssion	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2010	E-Class	212	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2010	E-Class	212	Drive	VGS - Transmission control for 9-speed transimssion	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2010	E-Class	212	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Drive	SCR-Selective Catalytic Reduction	●	●	○	●	●	●	●			F1B0 F1B1 F055 F1B2 F1B3 F1B4
As of 2010	E-Class	212	Drive	SCR - Selective catalytic reduction	●	●	○	●	●	●	●			F1B5 F1B6 F1B7 F1B1 F1B0 F055
As of 2010	E-Class	212	Drive	SG-EM-Power electronics	●	●	○	●	●	●	●			F27C F27D F27E
As of 2010	E-Class	212	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607'	●	●	○	●	●	●	●			F048 F052 F04B F1B8 F040 F051 F1B9 F042 F1BA F1BB F1BC F04F F04D F1BD F1BE F09A F04A F1BF F056 F1C0 F059
As of 2010	E-Class	212	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651'	●	●	○	●	●	●	●			F049 F048 F052 F04B F1C1 F040 F04A F051 F1B9 F042 F1BA F1C2 F1BB F1BC F09A F1BD F1BE F04D F1BF F1C0 F056 F1C3 F059
As of 2010	E-Class	212	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	●	●	●			F048 F1C4 F1BE F04F F040 F09A F052 F1BD F1C1 F1C5 F04D F1BB F1C6 F051 F1BF F056 F1C0 F1C3 F059
As of 2010	E-Class	212	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642'	●	●	○	●	●	●	●			F048 F1C7 F1C8 F1BD F1C9 F04F F1CA F040 F052 F09A F04D F1BE F1C4 F1C1 F055 F056 F058 F059 F057
As of 2010	E-Class	212	Drive	CDI-Motor electronics	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Drive	CDI - Motor electronics CRI6EU5 for combustion engine OM651	●	●	○	●	●	●	●			F1CB F1CC F17B F1CD F1CE F1CF F1D0 F17C F1D1 F1D2 F1D3 F1D4 F1D5 F1D6 F1D7

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2010	E-Class	212	Drive	CDID-Common Rail Diesel Injection	●	●	○	●	●	●	●			F049 F040 F04A F04B F050
As of 2010	E-Class	212	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2010	E-Class	212	Chassis	ESP-Regenerative braking system	●	●	○	●	●	●	●			F258 F259 F23E F0F4 F25A F25B F25C
As of 2010	E-Class	212	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F0F3 F0F4
As of 2010	E-Class	212	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			FOEF
As of 2010	E-Class	212	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			FOEF F0F0 F0F1 F0F2
As of 2010	E-Class	212	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			F1D8 F1D9
As of 2010	E-Class	212	Chassis	FWGW-Chassis gateway	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2010	E-Class	212	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2010	E-Class	212	Body	CGW-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2010	E-Class	212	Body	EZS-Electronic ignition lock	●	●	●	●	●	●	○			F0F6 F05C F05D F0F7 F0F8 F0F9 F0FE
As of 2010	E-Class	212	Body	EZS-Electronic ignition lock	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	SCCM-Steering column module	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2010	E-Class	212	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2010	E-Class	212	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2010	E-Class	212	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2010	E-Class	212	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	HKS-Tailgate control (N121/1)	●	●	○	●	●	●	●			F1DB F1DC
As of 2010	E-Class	212	Body	MPK-Multifunction camera	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	●			F0FD
As of 2010	E-Class	212	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 2010	E-Class	212	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Body	OCP-Overhead control panel	●	●	○	●	●	●	●			F0FD
As of 2010	E-Class	212	Body	Trailer recognition module	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	XALWA-L-Left xenon headlamp	●	●	●	●	●	●	●			F071 F27F F25F
As of 2010	E-Class	212	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	●			F071 F072 F073 F074
As of 2010	E-Class	212	Body	XALWA-R-Right xenon headlamp	●	●	●	●	●	●	●			F25F
As of 2010	E-Class	212	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	●			F075 F076
As of 2010	E-Class	212	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Body	BMS-Battery management system	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Body	BMS - Battery management system	●	●	○	●	●	●	●			F280 F27C
As of 2010	E-Class	212	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2010	E-Class	212	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2010	E-Class	212	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	AMG DRVU-AMG DRIVE UNIT	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	○			
As of 2010	E-Class	212	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	○	○			
As of 2010	E-Class	212	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	ELC - Electronic level control	●	●	○	●	●	●	●			F1DD FOEF
As of 2010	E-Class	212	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2010	E-Class	212	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2010	E-Class	212	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	NAVI20 - Navigation	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	ES-Electrical power steering	●	●	●	●	●	●	○			F1D8
As of 2010	E-Class	212	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2010	E-Class	212	Information and communication	AVE-H - DVD player	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Information and communication	CTEL - Mobile phone	●	●	○	●	●	○	○			
As of 2010	E-Class	212	Information and communication	PTS-PARKTRONIC	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2010	E-Class	212	Information and communication	DSI-DIRECT SELECT interface	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	○	●			
As of 2010	E-Class	212	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Seats and doors	AMKS-LF-Active multicontour seat	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Seats and doors	AMKS-RF-Active multicontour seat	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Seats and doors	ESA Driver - Electric seat adjustmet Driver	●	●	○	●	●	○	●			F106 F107 F108
As of 2010	E-Class	212	Seats and doors	ESA 'Driver' -Electric seat adjustment 'Driver'	●	●	○	●	●	●	●			F106 F107 F108
As of 2010	E-Class	212	Seats and doors	ESA-Electirc seat adjustment 'Front passenger'	●	●	●	●	●	●	●			F106 F107
As of 2010	E-Class	212	Seats and doors	ESA'Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	●			F106 F107
As of 2010	E-Class	212	Seats and doors	DCU-LF-Left front door	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Seats and doors	DCU-RF-Right front door	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Seats and doors	DCU-LR-Left rear door	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Seats and doors	DCU-RR-Right rear door	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Seats and doors	SIH-FOND-Rear passenger compartment seat heater	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Air conditioning	LRH-Steering wheel heater	●	●	●	●	●	●	○			
As of 2010	E-Class	212	Air conditioning	AAC-Air conditioniong	●	●	○	●	●	●	●			F109 F10A F10B
As of 2010	E-Class	212	Air conditioning	STH - Stationary heater	●	●	●	●	●	●	●			
As of 2010	E-Class	212	Air conditioning	EKMK-Electric refrigerant compressor	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2010	E-Class	212	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			F069 F1DE
As of 2010	E-Class	212	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Driver assistance system	360camera-360camera	●	●	○	●	●	●	●			F277 F278 F279
As of 2010	E-Class	212	Driver assistance system	360 camera-360 camera	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Driver assistance system	NSA - Night View Assist	●	●	○	●	●	○	○			
As of 2010	E-Class	212	Driver assistance system	NSA-Night View Assist	●	●	○	●	●	●	○			
As of 2010	E-Class	212	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			F1DF F1E0 F1E1 F1E2
As of 2010	E-Class	212	Driver assistance system	RFK-Backup camera	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2010	E-Class	212	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2009	E-Class	207	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Drive	ESM[EW] - Electronic selector module	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Drive	ME 9.7-Motor electronics 9.7	●	●	○	●	●	●	●			F17A F17B F17C F17D F17E F17F F180 F181 F182 F183 F184 F185 F186 F187 F188 F189
As of 2009	E-Class	207	Drive	MED 9.7-Motor electronics for direct injection 9.7	●	●	○	●	●	●	●			F18B F17B F17D F17E F18C F18D F181 F18E F18F F183 F190 F191 F192 F193 F194 F195 F196
As of 2009	E-Class	207	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2009	E-Class	207	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2009	E-Class	207	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2009	E-Class	207	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO'	●	●	●	●	●	●	●			F094 F095 F096 F097 F098 F099 F09A F040 F09B F09C F09D F09E
As of 2009	E-Class	207	Drive	ETC[EGS] - Transmission control for 5-speed transmissio	●	●	○	●	●	●	●			F244 F245 F1A0 F246 F247 F19A F1A1
As of 2009	E-Class	207	Drive	VGS - Transmission control for 7-speed transmissio	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2009	E-Class	207	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2009	E-Class	207	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2009	E-Class	207	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Drive	SCR-Selective Catalytic Reduction	●	●	○	●	●	●	●			F1B0 F1B1 F055 F1B2 F1B3 F1B4
As of 2009	E-Class	207	Drive	SCR - Selective catalytic reduction	●	●	○	●	●	●	●			F1B5 F1B6 F1B7 F1B1 F1B0 F055
As of 2009	E-Class	207	Drive	CDI-Motor electronics 'CR42' for combustion engine 'OM607'	●	●	○	●	●	●	●			F048 F052 F04B F1B8 F040 F051 F1B9 F042 F1BA F1BB F1BC F04F F04D F1BD F1BE F09A F04A F1BF F056 F1C0 F059
As of 2009	E-Class	207	Drive	CDI-Motor electronics 'CR43' for combustion engine 'OM651'	●	●	○	●	●	●	●			F049 F048 F052 F04B F1C1 F040 F04A F051 F1B9 F042 F1BA F1C2 F1BB F1BC F09A F1BD F1BE F04D F1BF F1C0 F056 F1C3 F059
As of 2009	E-Class	207	Drive	CDI-Common Rail Diesel Injection	●	●	○	●	●	●	●			F048 F1C4 F1BE F04F F040 F09A F052 F1BD F1C1 F1C5 F04D F1BB F1C6 F051 F1BF F056 F1C0 F1C3 F059
As of 2009	E-Class	207	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642'	●	●	○	●	●	●	●			F048 F1C7 F1C8 F1BD F1C9 F04F F1CA F040 F052 F09A F04D F1BE F1C4 F1C1 F055 F056 F058 F059 F057
As of 2009	E-Class	207	Drive	CDI - Motor electronics CRI6EU5 for combustion engine OM651	●	●	○	●	●	●	●			F1CB F1CC F17B F1CD F1CE F1CF F1D0 F17C F1D1 F1D2 F1D3 F1D4 F1D5 F1D6 F1D7
As of 2009	E-Class	207	Drive	CDID-Common Rail Diesel Injection	●	●	○	●	●	●	●			F049 F040 F04A F04B F050
As of 2009	E-Class	207	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2009	E-Class	207	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F0F3 F0F4
As of 2009	E-Class	207	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Chassis	ADS-Adaptive damping system	●	●	○	●	●	●	●			F0EF
As of 2009	E-Class	207	Chassis	ADS-Adaptive damping system	●	●	●	●	●	●	●			F0EF F0F0 F0F1 F0F2
As of 2009	E-Class	207	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			F1D8 F1D9
As of 2009	E-Class	207	Chassis	FWGW-Chassis gateway	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2009	E-Class	207	Body	CGW[ZGW]-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2009	E-Class	207	Body	CGW-Central gateway	●	●	○	●	●	●	○			F0F5
As of 2009	E-Class	207	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			F0F6 F05C F05D F0F7 F0F8 F0F9 F0FA
As of 2009	E-Class	207	Body	EZS-Electronic ignition lock	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	SCCM-Steering column module	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2009	E-Class	207	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2009	E-Class	207	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2009	E-Class	207	Body	SRS-Supplemental restraint system	●	●	●	●	●	●	○			
As of 2009	E-Class	207	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	KG - KEYLESS GO	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	HKS-Tailgate control (N121/1)	●	●	○	●	●	●	●			F1DB F1DC
As of 2009	E-Class	207	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Body	PSD-Control mudule 'Panoramic sliding roof'	●	●	○	●	●	●	●			F0FD

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2009	E-Class	207	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Body	WSS-Weight sensing system	●	●	●	●	●	●	○			
As of 2009	E-Class	207	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Body	Trailer recognition module	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Body	REAR SAM-Rear signal acquisition and actuation module	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Body	AIRSCARF-AIRSCARF system	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Body	XALWA-L-Left xenon headlamp	●	●	●	●	●	●	●			F071 F27F F25F
As of 2009	E-Class	207	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	●			F071 F072 F073 F074
As of 2009	E-Class	207	Body	XALWA-R-Right xenon headlamp	●	●	●	●	●	●	●			F25F
As of 2009	E-Class	207	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	●			F075 F076
As of 2009	E-Class	207	Body	BMS-Battery management system	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2009	E-Class	207	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2009	E-Class	207	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	AMG DRVU-AMG DRIVE UNIT	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	COMAND or AUDIO	●	●	●	●	●	●	○			
As of 2009	E-Class	207	Information and communication	360camera-360camera	●	●	○	●	●	●	●			F101 F102 F103 F104 F105
As of 2009	E-Class	207	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	○	○			
As of 2009	E-Class	207	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	TV-TV tuner	●	●	○	●	●	○	○			
As of 2009	E-Class	207	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2009	E-Class	207	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	NAVI20 - Navigation	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	ES-Electrical power steering	●	●	●	●	●	●	○			F1D8
As of 2009	E-Class	207	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2009	E-Class	207	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	SG-FOND-Rear control unit	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2009	E-Class	207	Information and communication	AVE-H - DVD player	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Information and communication	ICI-InCar Internet	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Information and communication	CTEL - Mobile phone	●	●	○	●	●	○	○			
As of 2009	E-Class	207	Information and communication	PTS-PARKTRONIC	●	●	●	●	●	●	●		C04D C04F C04E C06E	
As of 2009	E-Class	207	Information and communication	DSI-DIRECT SELECT interface	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Seats and doors	ESA Driver - Electric seat adjustmet Driver	●	●	○	●	●	○	●			F106 F107 F108
As of 2009	E-Class	207	Seats and doors	ESA 'Driver' -Electric seat adjustment 'Driver'	●	●	○	●	●	●	●			F106 F107 F108
As of 2009	E-Class	207	Seats and doors	ESA-Electirc seat adjustment 'Front passenger'	●	●	●	●	●	●	●			F106 F107
As of 2009	E-Class	207	Seats and doors	ESA' Front passenger' -Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	●			F106 F107
As of 2009	E-Class	207	Seats and doors	DCU-LF-Left front door	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Seats and doors	DCU-RF-Right front door	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Seats and doors	SIH-FOND-Rear passenger compartment seat heater	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Air conditioning	AAC-Air conditioniing	●	●	○	●	●	●	●			F109 F10A F10B
As of 2009	E-Class	207	Air conditioning	STH - Stationary heater	●	●	●	●	●	●	●			
As of 2009	E-Class	207	Air conditioning	EKMK-Electric refrigerant compressor	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2009	E-Class	207	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			F069 F1DE
As of 2009	E-Class	207	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Driver assistance system	360 camera-360 camera	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Driver assistance system	NSA-Night View Assist	●	●	○	●	●	●	○			
As of 2009	E-Class	207	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			F1DF F1E0 F1E1 F1E2
As of 2009	E-Class	207	Driver assistance system	RFK-Backup camera	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2009	E-Class	207	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Drive	mbrace-mbrace	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	M-Class	292	Drive	ISM-Shift module	●	●	○	●	●	●	●			F178 F052 F179
As of 2012	M-Class	292	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Drive	VG - Transfer case	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19D
As of 2012	M-Class	292	Drive	MED 17.7-Motor electronics for direct injection 17.7	●	●	○	●	●	●	●			F094 F095 F197 F098 F048 F03F F052 F040 F198 F199 F19A F19B F19C F19E F19D
As of 2012	M-Class	292	Drive	VGS - Transmission control for 7-speed transmissio	●	●	○	●	●	●	●			F19F F1A0 F1A1 F1A2 F1A3 F1A4 F1A5 F1A6 F1A7 F1A8 F052 F1A9
As of 2012	M-Class	292	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2012	M-Class	292	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2012	M-Class	292	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Drive	SCR - Selective catalytic reduction	●	●	○	●	●	●	●			F1B5 F1B6 F1B7 F1B1 F1B0 F055
As of 2012	M-Class	292	Drive	CDI-Motor electronics 'CDI61' for combustion engine 'OM642'	●	●	○	●	●	●	●			F048 F1C7 F1C8 F1BD F1C9 F04F F1CA F040 F052 F09A F04D F1BE F1C4 F1C1 F055 F056 F058 F059 F057
As of 2012	M-Class	292	Chassis	ESP-Regenerative braking system	●	●	○	●	●	●	●			F258 F259 F23E F0F4 F25A F25B F25C
As of 2012	M-Class	292	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	●			F258 F274 F275 F276
As of 2012	M-Class	292	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			F1D8 F1D9
As of 2012	M-Class	292	Chassis	EPB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2012	M-Class	292	Chassis	FWGW-Chassis gateway	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Chassis	Roll control-Roll control	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	EZS-Electronic ignition switch	●	●	○	●	●	●	○			F05C F05D F05E F05F F060 F061 F062 F063
As of 2012	M-Class	292	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Body	SGR-Radar sensors control unit	●	●	●	●	●	●	●		COD9 CODA	F1DA F10D
As of 2012	M-Class	292	Body	SGR-Radar sensors control unit	●	●	○	●	●	●	●			F1DA F10D
As of 2012	M-Class	292	Body	ATA-ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	SRS-Supplemental restraint system	●	●	○	●	●	●	●			F064 F065
As of 2012	M-Class	292	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	SD-Control module 'Sliding roof '	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	PSD-Control module 'Panoramic sliding roof '	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	Rear-Rear control unit	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	●			F071 F072 F073 F074
As of 2012	M-Class	292	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	●			F075 F076
As of 2012	M-Class	292	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2012	M-Class	292	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2012	M-Class	292	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	TPAD - Touchpad	●	●	○	●	○	●	○			
As of 2012	M-Class	292	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	M-Class	292	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	MPK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2012	M-Class	292	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2012	M-Class	292	Information and communication	AVE-H - DVD player	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Seats and doors	PPAMKS - Pneumatic pump for active multicontour seat	●	●	○	●	●	○	●			
As of 2012	M-Class	292	Seats and doors	MKS-FS-Multicontour seat 'Driver'	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Seats and doors	MKS-BFS-Multicontour seat 'Front passenger'	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Seats and doors	DCU-LF-Left front door	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Seats and doors	DCU-RF-Right front door	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Seats and doors	DCU-LR-Left rear door	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Seats and doors	DCU-RR-Right rear door	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Air conditioning	STH-Stationary heater	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Air conditioning	HBF-Rear control panel	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Driver assistance system	SGR-Radar sensors control unit	●	●	○	●	●	●	○			F10C F0F7 F10D
As of 2012	M-Class	292	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2012	M-Class	292	Driver assistance system	360 camera-360 camera	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Driver assistance system	NSA-Night View Assist	●	●	○	●	●	●	○			
As of 2012	M-Class	292	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2012	M-Class	292	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Drive	ME - Motor electronics ME1778 for combustion engine M277	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Drive	ME - Motor electronics MED177 for combustion engine M276	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	S-Class/CL/Maybach	222	Drive	ME - Motor electronics MED177 for combustion engine M276 Turbocharger	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2012	S-Class/CL/Maybach	222	Drive	FSCU08 - Control unit Fuel pump	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Drive	PTCU - Control unit powertrain	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Drive	SG-EM - Power electronics	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Drive	SG-EM-Power electronics	●	●	○	●	●	●	●			F27C F27D F27E
As of 2012	S-Class/CL/Maybach	222	Drive	CDI - Motor electronics CR43 for combustion engine OM651	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Drive	CDI - Motor electronics CR61 for combustion engine OM642	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Chassis	EFB - Electric parking brake	●	●	○	●	●	●	●			F05A
As of 2012	S-Class/CL/Maybach	222	Chassis	ES - Electric power steering	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Chassis	ES - Electric power steering	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Chassis	ESP - Electric stability program	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	ATA - ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	Multifunction control unit - Multifunction control unit	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	AGS - Active bell buckle	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	PSD - Control module Panoramic sliding roof	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	MSC - MAGIC SKY CONTROL	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	S-Class/CL/Maybach	222	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Body	RevETR-LF - Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	SRS - Supplemental restraint system	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Body	RevETR-RF - Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	SOGESTAR2 - Sound generator for electric vehicle	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	DC/DC - DC/DC converter	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	SCM - Steering column module	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	Fire extinguishing system and emergency fresh air system (FLANFS) - Fire extinguishing system and emergency fresh air system	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	mbrace - mbrace	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	TPAD - Touchpad	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	D-FOL - Display in left rear passenger compartment	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	D-FOR - Display in right rear passenger compartment	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Information and communication	IC - Instrument cluster	●	●	○	●	●	●	●			F066 F281 F282
As of 2012	S-Class/CL/Maybach	222	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	S- Class/CL/M aybach	222	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Information and communication	AVE-H - Controller unit Rear entertainment system	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Information and communication	DAB - Digital radio Tuner unit	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	DCU-LF - Left front door	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	DCU-RF - Right front door	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	DCU-LR - Left rear door	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	DCU-RR - Right rear door	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	ESA Driver - Electric seat adjustmet Driver with memory function	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	Left rear ESE - Left rear electrical seat adjustment	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	ESA Front passenger - Electric seat adjustment Front passenger with memory function	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	Right rear ESE - Right rear electrical seat adjustment	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	MKS-LF - Left front multicontour seat	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	MKS-RF - Right front multicontour seat	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	MKS-LR - Left rear multicontour seat	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	HKS - Trunk lid control	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	MKS-RR - Right rear multicontour seat	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Seats and doors	PPAMKS - Pneumatic pump for multicontour seat	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Air conditioning	AAC - Ari conditioning	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Air conditioning	STH - Stationary heater	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Air conditioning	SCR - Selective catalytic reduction	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Driver assistance system	KAB - Control unit Camera cover	●	●	○	●	●	●	○			
As of 2012	S- Class/CL/M aybach	222	Driver assistance system	NSA - Night View Assist	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	360 camera - 360 camera	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	MFK - Multifunction camera(mono)	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	SG-AWF - Control unit COLLISION PREVENTION ASSIST	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	MFK - Multifunction camera(stereo)	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	SGR - Radar sensors control unit	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	222	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Drive	ME - Motor electronics ME1778 for combustion engine M277	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	217	Drive	ME - Motor electronics MED177 for combustion engine M276	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	217	Drive	ME - Motor electronics MED177 for combustion engine M276 Turbocharger	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	217	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2012	S-Class/CL/Maybach	217	Drive	VGS - Transmission control for 9-speed transimssion	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2012	S-Class/CL/Maybach	217	Drive	FSCU08 - Control unit Fuel pump	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Drive	PTCU - Control unit powertrain	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Drive	SG-EM-Power electronics	●	●	○	●	●	●	●			F27C F27D F27E
As of 2012	S-Class/CL/Maybach	217	Chassis	EPB - Electric parking brake	●	●	○	●	●	●	●			F05A
As of 2012	S-Class/CL/Maybach	217	Chassis	ES - Electric power steering	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Chassis	ES - Electric power steering	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Chassis	ESP - Electric stability program	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	217	Body	SG-FOND - Rear control unit	●	●	○	●	○	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	S-Class/CL/M aybach	217	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	ATA - ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	PSD - Control module Panoramic sliding roof	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	MSC - MAGIC SKY CONTROL	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/M aybach	217	Body	RevETR-LF - Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	SRS - Supplemental restraint system	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/M aybach	217	Body	RevETR-RF - Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	SG-LG - Charger	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	DC/DC - DC/DC converter	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	SCM - Steering column module	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Information and communication	TPAD - Touchpad	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/M aybach	217	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	●	○			



Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	S-Class/CL/Maybach	217	Information and communication	IC - Instrument cluster	●	●	○	●	●	●	●			F066 F281 F282
As of 2012	S-Class/CL/Maybach	217	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	DCU-LF - Left front door	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	DCU-RF - Right front door	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	ESA Driver - Electric seat adjustmet Driver	●	●	○	●	○	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	ESA Front passenger - Electric seat adjustment Front passenger	●	●	○	●	○	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	MKS-LF - Left front multicontour seat	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	MKS-RF - Right front multicontour seat	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	HKS - Trunk lid control	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Seats and doors	PPAMKS - Pneumatic pump for multicontour seat	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Air conditioning	AAC - Ari conditioning	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Air conditioning	SCR - Selective catalytic reduction	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	KAB - Control unit Camera cover	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	NSA - Night View Assist	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	360 camera - 360 camera	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	MFK - Multifunction camera(mono)	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	SG-AWF - Control unit COLLISION PREVENTION ASSIST	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	MFK - Multifunction camera(stereo)	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	SGR - Radar sensors control unit	●	●	○	●	●	●	○			
As of 2012	S-Class/CL/Maybach	217	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Drive	ME - Motor electronics MED177 for combustion engine M276	●	●	○	●	●	●	●			
As of 2012	C-Class	205	Drive	ME - Motor electronics ME1778 for combustion engine M277	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Drive	ME - Motor electronics MED177 for combustion engine M276 Turbocharger	●	●	○	●	●	●	●			
As of 2012	C-Class	205	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2012	C-Class	205	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2012	C-Class	205	Drive	FSCU08 - Control unit Fuel pump	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Drive	PTCU - Control unit powertrain	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Drive	SG-EM-Power electronics	●	●	○	●	●	●	●			F27C F27D F27E
As of 2012	C-Class	205	Drive	CDI - Motor electronics CDI41R for combustion engine OM626	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Drive	CDI - Motor electronics CR43 for combustion engine OM651	●	●	○	●	●	●	●			
As of 2012	C-Class	205	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Chassis	EFB - Electric parking brake	●	●	○	●	●	●	●			F05A
As of 2012	C-Class	205	Chassis	ES - Electric power steering	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Chassis	ES - Electric power steering	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Chassis	ESP - Electric stability program	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Chassis	ESP - Electric stability program	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Body	SG-FOND - Rear control unit	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	ATA - ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	Multifunction control unit - Multifunction control unit	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	SD - Control module Silding roof	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Body	PSD - Control module Panoramic sliding roof	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012	C-Class	205	Body	RevETR-LF - Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	SRS - Supplemental restraint system	●	●	○	●	●	●	●			
As of 2012	C-Class	205	Body	RevETR-RF - Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	SOGESTAR2 - Sound generator for electric vehicle	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	SG-SW-L - Left headlamp	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	SG-SW-R - Right headlamp	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	SG-LG - Charger	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	SCM - Steering column module	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	mbrace - mbrace	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012	C-Class	205	Information and communication	TPAD - Touchpad	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Information and communication	IC - Instrument cluster	●	●	○	●	●	●	●			F066 F281 F282
As of 2012	C-Class	205	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Information and communication	DAB - Digital radio Tuner unit	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Seats and doors	DCU-LF - Left front door	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Seats and doors	DCU-RF - Right front door	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Seats and doors	DCU-LR - Left rear door	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Seats and doors	DCU-RR - Right rear door	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Seats and doors	ESA Driver - Electric seat adjustmnet Driver with memory function	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Seats and doors	ESA Front passenger - Electric seat adjustment Front passenger with memory function	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Seats and doors	HKS - Trunk lid control	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Air conditioning	AAC - Ari conditioning	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Air conditioning	SCR - Selective catalytic reduction	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	KAB - Control unit Camera cover	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	IRS-HRA - Outer right rear intelligent radar sensor system	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Driver assistance system	IRS-HLA - Outer left rear intelligent radar sensor system	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	360 camera-360 camera	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			
As of 2012	C-Class	205	Driver assistance system	MFK - Multifunction camera(mono)	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	SG-AWF - Control unit COLLISION PREVENTION ASSIST	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	MFK - Multifunction camera(stereo)	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	DTR - DISTRONIC	●	●	○	●	○	●	○			
As of 2012	C-Class	205	Driver assistance system	SGR - Radar sensors control unit	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	○			
As of 2012	C-Class	205	Driver assistance system	360 camera - 360 camera	●	●	○	●	○	●	○			
As of 2012		156	Drive	mbrace-mbrace	●	●	○	●	●	●	○			
As of 2012		156	Drive	FSCU05 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012		156	Drive	VG - All-wheel drive	●	●	○	●	○	●	○			
As of 2012		156	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	●	●	●			F03F F040 F041 F042 F043 F044 F045 F046 F047 F048
As of 2012		156	Drive	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012		156	Drive	DKG-Electronic transmission control for double-plate clutch transmission	●	●	○	●	●	●	○			
As of 2012		156	Drive	FSCU07 - Control unit Fuel pump	●	●	○	●	●	●	●			
As of 2012		156	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2012		156	Drive	PTCU-Common powertrain controller	●	●	○	●	●	●	○			
As of 2012		156	Drive	CDI - Motor electronics CDID3 for combustion engine OM651	●	●	○	●	●	●	●			F049 F048 F040 F04A F04B F04C F04D F04E F04F F050 F051 F03F F052 F053 F042 F054 F055 F056 F057 F058 F059
As of 2012		156	Drive	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'	●	●	○	●	●	●	○			
As of 2012		156	Chassis	ESP-Electronic stability program	●	●	○	●	●	●	○			
As of 2012		156	Chassis	ES-Electrical power steering	●	●	○	●	●	●	○			
As of 2012		156	Chassis	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012		156	Chassis	EFB-Electronic parking brake	●	●	○	●	●	●	●			F05A F05B
As of 2012		156	Body	EZS-Electronic ignition switch	●	●	○	●	●	●	○			F05C F05D F05E F05F F060 F061 F062 F063
As of 2012		156	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012		156	Body	SCM-Steering column module	●	●	○	●	●	●	●			
As of 2012		156	Body	ATA-ATA(EDW)/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012		156	Body	SRS-Supplemental restraint system	●	●	○	●	●	●	●			F064 F065
As of 2012		156	Body	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012		156	Body	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012		156	Body	Multifunction control unit-Multifunction control unit	●	●	○	●	●	●	●			
As of 2012		156	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012		156	Body	HKS - Tailgate control	●	●	○	●	○	●	○			
As of 2012		156	Body	MFK-Multifunction camera	●	●	○	●	●	●	○			
As of 2012		156	Body	PSD-Control module 'Panoramic sliding roof'	●	●	○	●	●	●	○			
As of 2012		156	Body	RevETR-LF-Left front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2012		156	Body	RevETR-RF-Right front reversible emergency tensioning retractor	●	●	●	●	●	●	●			
As of 2012		156	Body	Trailer recognition module-Trailer recognition	●	●	○	●	●	●	●			
As of 2012		156	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			
As of 2012		156	Body	SAM-Signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012		156	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012		156	Body	SG-SW-Control unit 'Headlamp'	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			F066 F067
As of 2012		156	Information and communication	IC-Instrument cluster	●	●	○	●	●	●	●			
As of 2012		156	Information and communication	ICM-Instrument cluster with maintenance interval display	●	●	○	●	●	●	●		C063 C064	F066 F067
As of 2012		156	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	NAV-Navigation module	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	Audio-Audio or COMAND	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	SOUND - Sound system (N40/3)	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	Sound system (Main amplifier)	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	TV-TV tuner	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	MFK-Multifunction camera	●	●	●	●	●	●	○			F068
As of 2012		156	Information and communication	DAB-Digital Audio Broadcasting	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	DAB - Digital Audio Broadcasting	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012		156	Information and communication	Drive Kit Plus - Drive kit for iPhone	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	SDAR-Satellite radio(Valid for USA)	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	MIF - Media interface	●	●	○	●	●	●	○			
As of 2012		156	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	●	●	●			
As of 2012		156	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	●	○	○			
As of 2012		156	Information and communication	DSI-DIRECT SELECT interface	●	●	○	●	●	●	○			
As of 2012		156	Seats and doors	ESA 'Driver'-Electrical seat adjustment 'Driver' with memory function	●	●	○	●	●	●	○			
As of 2012		156	Seats and doors	ESA' Front passenger'-Electric seat adjustment 'Front passenger' with memory function	●	●	○	●	●	●	○			
As of 2012		156	Seats and doors	DCU-LF-Left front door	●	●	○	●	●	●	○			
As of 2012		156	Seats and doors	DCU-RF-Right front door	●	●	○	●	●	●	○			
As of 2012		156	Air conditioning	AAC-Air conditioning	●	●	○	●	●	●	○			
As of 2012		156	Air conditioning	STH-Stationary heater	●	●	○	●	●	●	○			
As of 2012		156	Driver assistance system	TPM-Tire pressure monitor	●	●	○	●	●	●	●			F069
As of 2012		156	Driver assistance system	SG-AWF-Control unit 'COLLISION PREVENTION ASSIST'	●	●	○	●	●	●	●			
As of 2012		156	Driver assistance system	IRS-HRA-Outer right rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012		156	Driver assistance system	IRS-HLA-Outer left rear intelligent radar sensor system	●	●	○	●	●	●	○			
As of 2012		156	Driver assistance system	DTR-DISTRONIC	●	●	○	●	●	●	○			
As of 2012		156	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012		156	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	●			
As of 2012		156	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	●			
As of 2012		156	Driver assistance system	KAB-Control unit 'Camera cover'	●	●	○	●	●	●	○			
As of 2012		253	Drive	ME - Motor electronics MED177 for combustion engine M276	●	●	○	●	●	●	●			
As of 2012		253	Drive	ME-Motor electronics 'MED40' for combustion engine 'M270'	●	●	○	●	○	●	○			
As of 2012		253	Drive	VGS - Fully integrated transmission control	●	●	○	●	●	●	●			F1AA F1A2 F052 F1A9 F1AB F1A0 F1AC F1AD F1AE F1A3 F1A4 F1A5 F1AF
As of 2012		253	Drive	VGS - Transmission control for 9-speed transmissio	●	●	○	●	●	●	●			F1AB F1AF F1A1
As of 2012		253	Drive	FSCU08 - Control unit Fuel pump	●	●	○	●	●	●	○			
As of 2012		253	Drive	PTCU - Control unit powertrain	●	●	○	●	●	●	○			
As of 2012		253	Drive	SG-EM - Power electronics	●	●	○	●	●	●	○			
As of 2012		253	Drive	CDI - Motor electronics CR43 for combustion engine OM651	●	●	○	●	●	●	●			
As of 2012		253	Drive	CDI - Motor electronics CR61 for combustion engine OM642	●	●	○	●	●	●	●			
As of 2012		253	Chassis	ES - Electric power steering	●	●	○	●	○	●	○			
As of 2012		253	Chassis	ES - Electric power steering	●	●	○	●	○	●	○			
As of 2012		253	Chassis	ESP - Electric stability program	●	●	○	●	○	●	○			
As of 2012		253	Body	EZS - Electronic ignition lock	●	●	○	●	●	●	○			
As of 2012		253	Body	Driver-side SAM - Front signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012		253	Body	Rear SAM - Rear signal acquisition and actuation module	●	●	○	●	●	●	○			
As of 2012		253	Body	ATA - ATA[EDW]/tow-away protection/interior protection	●	●	○	●	●	●	○			
As of 2012		253	Body	Trailer recognition module - Trailer recognition	●	●	○	●	●	●	○			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012		253	Body	Multifunction control unit - Multifunction control unit	●	●	○	●	●	●	○			
As of 2012		253	Body	SD - Control module Silding roof	●	●	○	●	○	●	○			
As of 2012		253	Body	PSD - Control module Panoramic sliding roof	●	●	○	●	●	●	○			
As of 2012		253	Body	KG-KEYLESS GO	●	●	○	●	●	●	●			
As of 2012		253	Body	RevETR-LF - Left front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012		253	Body	SRS - Supplemental restraint system	●	●	○	●	●	●	●			
As of 2012		253	Body	RevETR-RF - Right front reversible emergency tensioning retractor	●	●	○	●	●	●	○			
As of 2012		253	Body	SOGESTAR2 - Sound generator for electric vehicle	●	●	○	●	●	●	○			
As of 2012		253	Body	SG-LG - Charger	●	●	○	●	●	●	○			
As of 2012		253	Body	DC/DC - DC/DC converter	●	●	○	●	●	●	○			
As of 2012		253	Body	SCM - Steering column module	●	●	○	●	●	●	○			
As of 2012		253	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012		253	Body	BMS - Battery management system	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	KOMO - Communication module Telematics services	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	mbrace - mbrace	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	TPAD - Touchpad	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	Audio - Audio or COMAND	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	COU[ZBE] - Audio/COMAND operating unit	●	●	○	●	○	●	○			
As of 2012		253	Information and communication	ZAN - Audio/COMAND display	●	●	○	●	○	●	○			
As of 2012		253	Information and communication	IC - Instrument cluster	●	●	○	●	●	●	●			F066 F281 F282
As of 2012		253	Information and communication	Head-up display - Head-up display	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	TB5 - TV tuner Tuner unit	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	SOUND - Sound system	●	●	○	●	●	●	○			
As of 2012		253	Information and communication	DAB - Digital radio Tuner unit	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	DCU-LF - Left front door	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	DCU-RF - Right front door	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	DCU-LR - Left rear door	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	DCU-RR - Right rear door	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	ESA Driver - Electric seat adjustmnet Driver with memory function	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	ESA Front passenger - Electric seat adjustment Front passenger with memory function	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	HKS - Trunk lid control	●	●	○	●	●	●	○			
As of 2012		253	Seats and doors	PPAMKS - Pneumatic pump for multicontour seat	●	●	○	●	●	●	○			
As of 2012		253	Air conditioning	AAC - Ari conditioning	●	●	○	●	●	●	○			
As of 2012		253	Air conditioning	SCR - Selective catalytic reduction	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	KAB - Control unit Camera cover	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	IRS-HRA - Outer right rear intelligent radar sensor system	●	●	○	●	○	●	○			
As of 2012		253	Driver assistance system	IRS-HLA - Outer left rear intelligent radar sensor system	●	●	○	●	○	●	○			
As of 2012		253	Driver assistance system	RFK - Backup camera	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	360 camera-360 camera	●	●	○	●	○	●	○			
As of 2012		253	Driver assistance system	TPM - Tire pressure monitor	●	●	○	●	●	●	●			

Model year	Model	Model Series	Control Unit Groups	System Name	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Initial Startup	Coding	Special Function
As of 2012		253	Driver assistance system	MPK - Multifunction camera(mono)	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	SG-AWF - Control unit COLLISION PREVENTION ASSIST	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	MPK - Multifunction camera(stereo)	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	DTR - DISTRONIC	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	DTR - DISTRONIC	●	●	○	●	○	●	○			
As of 2012		253	Driver assistance system	SGR - Radar sensors control unit	●	●	○	●	●	●	○			
As of 2012		253	Driver assistance system	PARK - Parking system	●	●	○	●	●	●	○			

# Specil\_Function

Index	Specil Function Name	Index	Specil Function Name
F001	Operational check	F002	Switch off solenoid valve for torque converter lockup clutch.
F003	Actual values of flush counter	F004	Actual values: Oil level check
F005	Oil color and oil smell	F006	Abrasion in transmission oil
F007	Learning of the throttle valve stop	F008	Activate fuel pump.
F009	Teach in of drive authorization system	F00A	Performing sensor rotor adaptation
F00B	Resetting of mixture adaptation	F00C	Ignition
F00D	Fuel quantity	F00E	Idling specified speed with selector lever in position P or N
F00F	Idling specified speed with gear engaged	F010	Electric suction fan for engine or air conditioning
F011	Variant coding	F012	Extension of run-on time
F013	Adjustment of injector injection quantities	F014	Reset quantity mean value adaptation data.
F015	Replace component Diesel particulate filter.	F016	Regeneration of diesel particulate filter when driving
F017	Diesel particulate filter Used Program	F018	Standstill test
F019	Road test	F01A	Tire pressure loss warner
F01B	Vehicle data	F01C	Modification year or model year
F01D	All codes	F01E	Disable key or key track.
F01F	Once again authorize key or key track.	F020	Program replacement keys.
F021	Activate control module N73 (EIS [EVS] control unit).	F022	Activate control module N26/5 (Electric steering lock control module).
F023	Writing of the VIN	F024	Carry out control unit reset.
F025	Read coding and change if necessary.	F026	Zero position adjustment
F027	Set reading of main odometer.	F028	Setting days since initial registration
F029	ASSYST settings	F02A	Control module reset
F02B	Special equipment	F02C	Internal ASSYST PLUS data
F02D	Configuration of oil grade selection	F02E	Restart of optical ring
F02F	Normalizing of positioning motors	F030	Check of adjustment range of positioning motors
F031	Teach-in of actuator motors after actuator motor replacement	F032	Breaking-in procedure after replacement of refrigerant compressor
F033	Teach-in process after replacement of component Diesel particulate filter	F034	Teaching in the diesel particulate filter after replacing the engine control unit
F035	Teach-in of diesel particulate filter after replacement of engine control unit without transfer of values	F036	Teach-in process after replacement of component B28/8 (Pressure differential sensor (DPF))
F037	Teach-in process after replacement of component G3/1 (O2 sensor downstream TWC)	F038	Teach-in process after replacement of component Y74 (Pressure control valve)
F039	Teach-in process after replacement of component Y100/2 (Boost pressure regulator)	F03A	Reset values for HFM drift compensation.
F03B	Resetting air filter learned values after air filter replacement	F03C	Changing the language version(LINGUATRONIC)
F03D	Program brake assist	F03E	CO2 setting
F03F	Activation of fuel pump	F040	Teach in of throttle valve stop
F041	Teach-in of positions for camshafts	F042	B79/2 (Transmission neutral position sensor)
F043	Control unit ' ' is defective.	F044	Status of teach-in processes
F045	Display of SCN	F046	Display of CVN
F047	Display of model check number	F048	Injector injection quantity adjustment
F049	Regeneration of the diesel particulate filter while driving	F04A	Teach-in of intake port shutoff
F04B	Teach-in of diesel particulate filter after replacement of control unit 'N3/9 (CDI control unit)'	F04C	Reset of lambda values
F04D	Resetting of contamination level of air filter	F04E	Teach in component 'Y77/1 (Boost pressure positioner)'
F04F	Quick teach-in of values of zero quantity calibration	F050	Teach-in process after replacement of component 'Diesel particulate filter'
F051	Oxidation catalytic converter	F052	Teach-in of drive authorization system
F053	Bleeding of high-pressure fuel circuit	F054	Resetting of learned values of component 'B6/1 (Camshaft Hall sensor)'



Index	Specil Function Name	Index	Specil Function Name
F055	Teach-in process after replacement of component 'SCR catalytic converter'	F056	Reset learned values of components 'NOx sensor upstream of SCR catalytic converter' and 'NOx sensor downstream of SCR catalytic converter'.
F057	Teach-in process after replacement of component 'B16/15 (Temperature sensor upstream of SCR catalytic converter)'	F058	Teach-in process after replacement of component 'Y129 (AdBlue metering valve)'
F059	Reset learned values for AdBlue metering.	F05A	Calibration of control unit 'N128 (Electric parking brake control unit)'
F05B	Move to the assembly position	F05C	Disabling of key or key track
F05D	Re-enabling of key or key track	F05E	Display of locking data record
F05F	Offline locking of key or key track	F060	Programming and teach-in of spare key
F061	Programming and teach-in of additional key	F062	Vehicle registration for ordering a programmed key
F063	Personalization and activation of control unit 'ESL [ELV]'	F064	Unlocking of control unit
F065	Locking of control unit	F066	Transfer of manufacturer default settings
F067	Customer-specific settings	F068	Calibration
F069	Write identification numbers of tire pressure sensors.	F06A	Program CNG compressed natural gas Mode
F06B	Resetting of mixture adaptation(CNG compressed natural gas)	F06C	Idle speed set value
F06D	CO setting for vehicles without TWC	F06E	CO setting for vehicles without TWC(Natural gas)
F06F	Initial startup with automatic takeover of settings of previous control unit	F070	Initial startup with manual settings input for new control unit,For example: The previous control unit can no longer be read.
F071	Zero position adjustment	F072	Adjustment of headlamps via diagnosis
F073	Resetting of operating hours counters of component 'E1 (Left front lamp unit)'	F074	Resetting the operating hours counter of component 'E1m4 (Left front lamp unit fan motor 1)'
F075	Resetting of operating hours counters of component 'E2 (Right front lamp unit)'	F076	Resetting the operating hours counter of component 'E2m4 (Right front lamp unit fan motor 1)'
F077	Definition	F078	Important information on adaptation limit values
F079	Adaptation values of shift :1-2:	F07A	Adaptation values of shift :2-3:
F07B	Adaptation values of shift :3-4:	F07C	Adaptation values of shift :4-5:
F07D	Adaptation values of shift :5-4:	F07E	Adaptation values of shift :4-3:
F07F	Adaptation values of shift :3-2:	F080	Adaptation values of shift :2-1:
F081	Display all adaptation data.	F082	Resetting of adaptation data
F083	Performing adaptation	F084	Adaptation via coolant temperature
F085	Adaptation via torque ranges	F086	Help
F087	Warranty or goodwill processing	F088	Actual values: Oil level check
F089	Switch off the incline recognition for dynamometer mode.	F08A	Detach the transport protection of control module ETC, personalize or activate the control module.
F08B	Learning process: Y3/8sl (Selection range sensor (VGS))	F08C	Learning to the drive authorization system
F08D	Assignment of hydraulic shift elements	F08E	Resetting of adaptation data(Torque converter lockup clutch)
F08F	Adaptation of torque converter lockup clutch	F090	Performing adaptation(Wet start-off clutch (NAK))
F091	Upshifts	F092	Downshifts
F093	Reverse gear	F094	Correction programming of ignition
F095	Correction programming of fuel quantity	F096	Correction programming of electric fan for combustion engine or air conditioning
F097	Correction programming of specified idle speed	F098	Correction programming of specified idle speed with gear range engaged
F099	Default initialization	F09A	Activate fuel pump.
F09B	M59 (Intake manifold swirl flap actuator motor)	F09C	Reset of mixture adaptation values
F09D	Acceleration of sensor rotor adaptation	F09E	Perform teach-in process for control unit 'ME'.
F09F	Learning of the recirculated air flap stop	FOA0	Resetting of sensor adaptation
FOA1	Sensor rotor adaptation	FOA2	Default initialization
FOA3	Quick test of mixture adaptation	FOA4	Correction programming
FOA5	Teach-in process after engine replacement	FOA6	Teach in ethanol portion in fuel.
FOA7	Resetting the cold-start adaptation values	FOA8	Resetting the reading of the counter for ethanol teach-in processes
FOA9	Readiness-Codes	FOAA	Test values of emissions test
FOAB	Measures for initiating the fault path tests	FOAC	Notes on emissions inspection (OBD I/M check)

Index	Specil Function Name	Index	Specil Function Name
FOAD	Readiness for exhaust emissions inspection (AU)	FOAE	Notes on readiness
FOAF	Teach-in of camshaft positions	FOBO	Coding according to plant data
FOB1	Resetting of adaptation data	FOB2	Readiness for exhaust emissions inspection (AU)
FOB3	SCN(Software Calibration Number)	FOB4	CVN(Calibration verification number)
FOB5	Type approval number	FOB6	Lambda control, upstream TWC
FOB7	Lambda control, downstream TWC	FOB8	Fuel pump
FOB9	Teach-in process for component M16/45 (EGR [ARF] actuator motors)	FOBA	Initiation of self-adjustment
FOBB	Correction programming of ignition	FOBC	Correction programming of fuel quantity
FOBD	Correction programming of the CO setting(For vehicles with no catalytic converter)	FOBE	Desensibilize shutoff threshold of smooth engine running.
FOBF	Readiness-Codes	FOCO	Notes on Emissions inspection ( OBD I/M Check )
FOC1	Perform calibration.	FOC2	Detach the transport protection of control module ISM, personalize or activate the control module.
FOC3	Refill AdBlue.	FOC4	Erasing adaptation values after replacement of AdBlue fluid
FOC5	Teach-in process after replacement of component Y129 (AdBlue?metering valve)	FOC6	Reprogram diesel particulate filter in control unit N3/9 (CDI control unit).
FOC7	Regeneration of diesel particulate filter	FOC8	Teach in component Y94 (Quantity control valve).
FOC9	Resetting the lambda values	FOCA	Rapid teach-in of zero quantity calibration values for calibration point 230 bar
FOCB	Rapid teach-in of zero quantity calibration values for calibration point 600 bar	FOCC	Drive authorization(Personalizing)
FOCD	Drive authorization(Activating)	FOCE	Carry out the following procedure in order to include a new system in the list:
FOCF	Test terminal 15 connection from and .	FODO	System pressure in brake circuit 2
FOD1	H4/4 (Right rear door speaker group)	FOD2	Test fuel pump, replace if necessary.
FOD3	Teach in component M16/6 (Throttle valve actuator).	FOD4	Teach in component M55 (Inlet port shutoff motor).
FOD5	Teach in component Y77/1 (Charge pressure positioner).	FOD6	Purge control Diesel particulate filter
FOD7	Rapid teach-in of zero quantity calibration values	FOD8	Teach-in process after replacement of component Y74 (Pressure control valve)
FOD9	Variant coding according to factory data	FODA	Drive authorization
FODB	Teach-in process after replacement of component G3/2 (O2 sensor upstream of KAT)	FODC	Teach-in process after replacement of component Diesel oxidation catalytic converter
FODD	Teach-in process after replacement of component SCR-Catalytic converter	FODE	Teach-in process after replacement of component B16/15 (Temperature sensor upstream of SCR catalytic converter)
FODF	Teach-in process after replacement of component N37/7b1 (NOx sensor downstream of diesel particulate filter)	FOE0	Teach-in process after replacement of component N37/8b1 (NOx sensor downstream of SCR catalytic converter)
FOE1	Teach-in process after replacement of component Y129 (AdBlue?metering valve)	FOE2	Teach-in of SCR exhaust aftertreatment system after replacement of engine control unit without transfer of values
FOE3	Teach-in process after replacement of component SCR-Catalytic converter	FOE4	Teach-in process after replacement of component B16/15 (Temperature sensor upstream of SCR catalytic converter)
FOE5	Teach-in process after replacement of component B28/16 (DPF differential pressure sensor for OBD)	FOE6	Teach-in process after replacement of component NOx sensor upstream of SCR catalytic converter
FOE7	Teach-in process after replacement of component NOx sensor downstream of SCR catalytic converter	FOE8	Teach-in process after replacement of component Y27/9 (Exhaust gas recirculation actuator)
FOE9	Resetting AdBlue quality factor	FOEA	Tire pressure loss warner(Activating)
FOEB	Erase zero point offset error of component N49 (Steering angle sensor).	FOEC	Calibration of control unit N30/4 (Electronic Stability Program control unit)-Calibration of intake valves
FOED	Calibration of control unit N30/4 (Electronic Stability Program control unit)-Calibration of separation valves	FOEE	Write wheel electronics identification number.
FOEF	Level calibration	FOFO	The key is not initialized or not present in the center console.
FOF1	Now insert the unprogrammed key into the center console./Communication with the control processor has been ended.	FOF2	Communication with the control processor has been ended.
FOF3	Teach in component 'B24/15 (Yaw rate sensor for lateral and longitudinal acceleration)'. .	FOF4	Activate function 'Tire pressure loss warning'.
FOF5	Vehicle data	FOF6	Disabling of key or key track with workshop key
FOF7	Writing of vehicle identification number	FOF8	Teach-in of a spare key
FOF9	Activation of control unit 'N73 (Electronic ignition lock control unit)'	FOFA	Activation of control unit 'N26/5 (Electric steering lock control unit)'

Index	Specil Function Name	Index	Specil Function Name
F0FB	Control unit UNLOCK	F0FC	Control unit LOCK
F0FD	Teach-in process of anti-pinch protection	F0FE	Activation of control unit 'N26/5 (Electric steering lock control unit)' U940 (Valid without DIRECT SELECT)
F0FF	Resetting menu settings to manufacturer default settings	F100	Increase main odometer reading.
F101	Calibration of 360?camera at front end	F102	Calibration of 360?camera at rear end
F103	Calibration of 360?camera in left outside mirror	F104	Calibration of 360?camera in right outside mirror
F105	Calibration of multiple 360?cameras	F106	Normalization
F107	Normalization and adaptation	F108	Separate normalization of steering column
F109	Normalization of actuator motors	F10A	Teach-in of actuator motors
F10B	Breaking-in of refrigerant compressor	F10C	Reset of reading of frequency counter 'Crash event'
F10D	Initializing of control module	F10E	Read coding.
F10F	Adaptation data of power upshifts	F110	Adaptation data deceleration upshifts
F111	Adaptation data power downshifts	F112	Adaptation data deceleration downshifts
F113	Adaptation data filling pressure and filling time	F114	Adaptation stop values
F115	Notes on combinations of adaptation data	F116	Acceleration upshift from gear 1 to 2
F117	Acceleration upshift from gear 2 to 3	F118	Acceleration upshift from gear 3 to 4
F119	Acceleration upshift from gear 4 to 5	F11A	Decelerate downshifts from 5 to 4
F11B	Decelerate downshifts from 4 to 3	F11C	Additional information regarding oil level check
F11D	Actual values: Oil level check	F11E	Electric emergency running
F11F	Mechanical-hydraulic emergency running	F120	Reset Distronic option.
F121	Important information on the combination possibilities for adapation end stop values	F122	Adaptation values of shift 1-2:
F123	Adaptation values of shift 2-3:	F124	Adaptation values of shift 3-4:
F125	Adaptation values of shift 4-5:	F126	Adaptation values of shift 5-4:
F127	Adaptation values of shift 4-3:	F128	Adaptation values of shift 3-2:
F129	Adaptation values of shift 2-1:	F12A	Performing adaptation on vehicles with torque converter lockup clutch engagement as of gear 1
F12B	Performing adaptation on vehicles with torque converter lockup clutch engagement as of gear 3	F12C	Settings
F12D	Acceleration of sensor rotor adaptation	F12E	Control unit adaptations
F12F	Teaching in of swirl flap stop	F130	Exhaust gas recirculation valve teach-in
F131	Check sensor adaptation.	F132	Secondary air injection
F133	Diagnosis of O2 sensors	F134	Exhaust gas recirculation diagnosis
F135	Selfadaptation of mixture formation	F136	Extension of run-on time DAS 3
F137	Erase zero point offset error of component N49 (Steering angle sensor).	F138	Erase zero point offset error of component B24/15 (Rotary speed and lateral acceleration sensor).
F139	Disable key or key track with the workshop key.	F13A	Activate control module N73 (EIS [EZS] control unit).
F13B	Windshield adaptation	F13C	Adaptation of the light sensor amplification factor
F13D	Adaptation:Windshield Green glass	F13E	Normalization of the tilting/sliding roof's obstruction sensor
F13F	Trip computer settings	F140	Set main odometer back.
F141	Instrument cluster settings	F142	Normalizing of forward/back adjustment
F143	Normalizing of height adjustment at front	F144	Normalizing of height adjustment at rear
F145	Normalizing of head restraint adjustment	F146	Normalizing of backrest adjustment
F147	Adjust parameter for backrest adjustment.	F148	Parameterization of function for moving front passenger seat out of way when folding down rear seat
F149	Readjust adjustment parameters.	F14A	Setting parameters for collision avoidance With this routine, the parameters for the compensating movement for collisions between the backrest and the rear panel can be changed.

Index	Specil Function Name	Index	Specil Function Name
F14B	Resetting the parameters for collision avoidance to the default value The standard parameters for the control unit will be restored.	F14C	Deactivate collision avoidance. If the collision avoidance feature is the subject of a customer complaint because the seat cannot be moved to a desired position, the collision avoidance feature can be deactivated.
F14D	The collision avoidance feature prevents the seat from colliding with surrounding elements (such as the headliner or rear wall) during seat adjustment by limiting the range of adjustment or triggering evasive motion.	F14E	Parameterize easy entry/exit.
F14F	Increase fore/aft adjustment range to rear.	F150	Parameterization of function for moving driver seat out of way when folding down rear seat
F151	C02 setting (cold setting of combustion air blower)	F152	Learning component A8/3 (STH radio remote control transmitter)
F153	Diesel particulate filter Purge control	F154	Diesel particulate filter New Initializing
F155	Self-adaptation	F156	Assignment of control modules to plug connections
F157	Zero position adjustment of axle or level sensors	F158	CNG compressed natural gas Mode
F159	Resetting of mixture adaptation CNG compressed natural gas	F15A	Initial startup with manual settings input for new control unit/Level calibration
F15B	Pneumatic test of component A9/1 (AIRmatic compressor unit)	F15C	PML speed-sensitive power steering
F15D	Key assignment or key track assignment to a memory block number	F15E	Telematic service 'Remote door unlocking' (TELE AID)
F15F	Parameterization and windshield adaptation	F160	Adaptation:Windshield Green glass-Only for customer complaints concerning the lights' switch-on thresholds!
F161	Panoramic sliding roof	F162	Sliding/tilting roof
F163	Automatic interior mirror dimming	F164	Tourist mode(Symmetrical light distribution)
F165	EP: Reset operating hours counter.	F166	Setting main odometer forward and back
F167	Current brake lining thickness	F168	Air cushion calibration
F169	Short stroke parameter	F16A	Delay of rear wiper startup after wiper/wash function is turned on
F16B	Duration of wipe cycle	F16C	Voltage threshold for vehicle power supply emergency mode
F16D	Intermediate position Rear-end door	F16E	Initializing Diesel particulate filter
F16F	Prevention of diesel particulate filter regeneration	F170	Replace component NOx storage catalytic converter.
F171	Replace component Y74 (Pressure control valve).	F172	Replace component M16/6 (Throttle valve actuator).
F174	Replacement of component Diesel particulate filter on left	F175	Replacement of component Diesel particulate filter on right
F176	Replacement of an exhaust-relevant component on the left bank	F177	Replacement of an exhaust-relevant component on the right bank
F178	Calibrate control unit 'A80 (Intelligent servo module for DIRECT SELECT)'. If all the requirements are met, the calibration can be started by pressing button ''.	F179	Variant coding reset
F17A	If all the requirements are met, the calibration can be started by pressing button ''.	F17B	ALWAYS ACTIVE
F17C	X21 (Engine cab-chassis electrical connector)	F17D	Teach in of drive authorization system
F17E	Teach-in process after engine replacement	F17F	The test has been aborted.
F180	The soft top compartment lid does not move.	F181	Resetting the cold-start adaptation values
F182	Resetting the reading of the counter for ethanol teach-in processes	F183	Short circuit at component ''
F184	CAN signal '' from control unit '' is implausible.	F185	Power supply for flashing lights in trunk lid or liftgate
F186	Measures for initiating the fault path tests	F187	CAN signal '' from control unit '' or CAN signal '' from control unit '' is implausible.
F188	Readiness for exhaust emissions inspection (AU)	F189	Notes on readiness
F18A	Teach-in of camshaft positions	F18B	Overview
F18C	Teach-in process for component M16/45 (EGR [ARF] actuator motors)	F18D	The hydraulic cylinders of the soft top compartment lid may be leaky.
F18E	Quick test of mixture adaptation	F18F	Initiation of self-adjustment
F190	Check whether the correct oxygen sensor is installed.	F191	Control voltage of fuel injector, cylinder
F192	The precondition at the input is met when the waiting time after clutch opening has expired or the rpm of the transmission input shaft is lower than parameter value 'P' and parameter 'N' has been set to ''.	F193	Electric charge of fuel injectors
F194	Electric charge of fuel injector, cylinder	F195	F4f126 (Fuse 126) (Suppression of function '')

Index	Specil Function Name	Index	Specil Function Name
F196	Conversion factor 'Intake manifold pressure to filling capacity'	F197	Correction programming of specified idle speed in selector lever position 'P' or 'N'
F198	Teach-in of exhaust gas recirculation actuators	F199	Teaching in the ethanol proportion in the fuel
F19A	Resetting of adaptation values	F19B	Resetting reading of frequency counter for ethanol teach-in processes
F19C	Teach-in process after replacement of the combustion engine	F19D	Enabling of engine start after crash event
F19E	Teach-in of used fuel injectors	F19F	Correction programming of electrohydraulic actuator part number
F1A0	Assignment of hydraulic shift elements	F1A1	Adaptation procedure for torque converter lockup clutch
F1A2	Adaptation of wet start-up clutch (NAK)	F1A3	Upshifts
F1A4	Downshifts	F1A5	Acceleration downshifts
F1A6	Shift	F1A7	Reverse gear
F1A8	Torque converter	F1A9	Teach-in of selection range sensor
F1AA	Adaptation of component 'Torque converter lockup clutch'	F1AB	Teach-in of position sensor of park pawl
F1AC	Adaptation values of shift operations	F1AD	Resetting the service life data of the torque converter
F1AE	Resetting of service life data of automatic transmission	F1AF	Standstill adaptation
F1B0	Teach-in process after replacement of component 'AdBlue metering valve'	F1B1	Resetting of adaptation values-Factor for long-term adaptation of SCR exhaust aftertreatment system
F1B2	Resetting the adaptation values of the NOx sensors	F1B3	Cancellation of limitation of engine starts
F1B4	Cancellation of limitation of remaining distance	F1B5	Resetting the calculated fill level of the AdBlue tank
F1B6	Resetting adaptation values of component 'A103/2ml (AdBlue delivery pump)'	F1B7	Calibration of component 'A103/1b5 (AdBlue fill level sensor)'
F1B8	Perform teach-in process for component 'Diesel particulate filter'.	F1B9	B28/8 (Differential pressure sensor (DPF))
F1BA	G3/2 (Oxygen sensor upstream of catalytic converter)	F1BB	Y74 (Pressure regulating valve)
F1BC	Y94 (Quantity control valve)	F1BD	Reset values of HFM drift compensation.
F1BE	Reset values of quantity mean value adaptation.	F1BF	B16/15 (Temperature sensor upstream of SCR catalytic converter)
F1C0	Y129 (AdBlue metering valve)	F1C1	Replace component 'Diesel particulate filter'.
F1C2	M16/46 (Low-pressure exhaust gas recirculation actuator motor)	F1C3	SCR catalytic converter
F1C4	Teach in used diesel particulate filter.	F1C5	G3/2 (Oxygen sensor upstream of catalytic converter)
F1C6	B28/8 (DPF differential pressure sensor)	F1C7	Teach-in process after replacement of component 'Y74 (Pressure regulating valve)'
F1C8	Teach-in process after replacement of component 'B28/8 (DPF differential pressure sensor)'	F1C9	Teach-in process after replacement of component 'G3/2 (Oxygen sensor upstream of catalytic converter)'
F1CA	Teach-in process after replacement of component 'Oxidation catalytic converter'	F1CB	Readout of service memory
F1CC	Deactivate alarm triggered by panic alarm system after .	F1CD	Teach-in process after replacement of component B28/8 (Pressure differential sensor (DPF))
F1CE	Teach-in process after replacement of component G3/2 (O2 sensor upstream of KAT)	F1CF	Teach-in process after replacement of component Y27/9 (Exhaust gas recirculation actuator)
F1D0	Teach-in process after replacement of component Y74 (Pressure control valve)	F1D1	Reset quantity mean value adaptation data.
F1D2	Rapid teach-in of zero quantity calibration values	F1D3	Reset values for HFM drift compensation.
F1D4	Resetting air filter learned values after air filter replacement	F1D5	Regeneration of diesel particulate filter when driving
F1D6	Teach-in process after replacement of component Diesel particulate filter	F1D7	Teaching in the diesel particulate filter after replacing the engine control unit
F1D8	Reset of coding	F1D9	Teach-in of limit stop of steering
F1DA	Reset frequency counter 'Emergency stop'.	F1DB	N121/1 (Liftgate control control unit)
F1DC	N121 (Trunk lid control control unit)	F1DD	Reset of compressor operating time
F1DE	Write tire pressure specified values.	F1DF	Calibration of reversing camera
F1E0	Calibration of backup camera in passenger-side outside mirror	F1E1	Calibration of steering angle sensor
F1E2	Resetting of calibration settings	F1E3	Replacement of control module N80 (Steering column module)
F1E4	Reset lambda adaptation	F1E5	Readiness for exhaust emissions inspection (AU)
F1E6	Readiness-Codes	F1E7	Calibration of control unit ABR

Index	Specil Function Name	Index	Specil Function Name
F1E8	Reset compressor operating time	F1E9	Level calibration
F1EA	Pneumatic test of component A9/1y1 (AIRmatic pressure release valve)	F1EB	Pneumatic test of component Y36/6y1 (Left front level control valve)
F1EC	Pneumatic test of component Y36/6y2 (Right front level control valve)	F1ED	Pneumatic test of component Y36/6y3 (Left rear level control valve)
F1EE	Pneumatic test of component Y36/6y4 (Right rear level control valve)	F1EF	Pneumatic test of component Y36/6y5 (AIRmatic central reservoir charge valve)
F1F0	Leakage test between compressor and valve block	F1F1	Leakage test between valve block and suspension struts
F1F2	Leakage test between valve block and central reservoir	F1F3	Steering column module
F1F4	Teach-in process for anti-pinch protection function of panoramic sliding sunroof/Roller sun blind	F1F5	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or vice versa.
F1F6	Resetting operating hours counter	F1F7	Perform self-test 'B84/2 (Night View Assist camera)'.
F1F8	Calibration Reset	F1F9	Average mileage per day
F1FA	Initialization of power closing	F1FB	Normalization of all seat adjustment motors
F1FC	Adapt obstruction protection.	F1FD	Normalizing Rear left and right
F1FE	Denormalization and normalization of trunk lid control	F1FF	Teach-in of rotary potentiometers for the air outlets
F200	Learning component A8/3 (STH radio remote control transmitter)	F201	Calibration of control unit N47-5 (ESP control unit)
F202	Complete or correct VIN.	F203	Denormalization due to VIN deletion
F204	Interrupt driving test.	F205	Calibration of control unit RBS
F206	Calibration of component B37/1 (Pedal angle sensor)	F207	Erase zero point offset error of component B24/15 (Micromechanical yaw rate sensor AY pickup).
F208	Calibration of component Vacuum pump brake booster	F209	Detach the transport protection of control module N15/5 (Electronic selector lever module control unit), personalize or activate the control module.
F20A	Read coding and transfer to the new control unit.	F20B	Learning process
F20C	Resetting of variant locking	F20D	Calibration of the plunger travel sensors
F20E	Load adjustment	F20F	Raise and lower the suspension struts at low speed
F210	Raise and lower the suspension struts at medium speed	F211	Raise and lower the suspension struts at high speed
F212	Activate electronic ignition switch.	F213	Rain sensor
F214	Setting of limit position of excess force limiter	F215	Coding of the close-via-tilt function
F216	Coding of sliding/tilting roof function of 'automatic operation'	F217	Assign transmitter card to key track.
F218	Assign Keyless Go key to key track.	F219	Set time.
F21A	Normalization of fore/aft adjustment of left seat	F21B	Normalization of inclination adjustment of left seat cushion
F21C	Normalization of fore/aft adjustment of right seat	F21D	Normalization of inclination adjustment of right seat cushion
F21E	Reduce the longitudinal travel with the retaining clip installed on the fore/aft adjustment rail.	F21F	Forward/back adjustment
F220	Height at front	F221	Height at rear
F222	Seat cushion depth	F223	Backrest
F224	Head restraint	F225	Change of adjusted temperature
F226	Blower	F227	Evaporator temperature
F228	Ventilation of heat exchangers	F229	Test of left heating capacity
F22A	Test of right heating capacity	F22B	Refrigerant circuit test
F22C	Defroster button	F22D	Pushbutton for rear window defroster
F22E	Rest button	F22F	ON/OFF button
F230	Right air distribution	F231	EC button
F232	Right temperature button	F233	Blower button
F234	Left temperature button	F235	REC pushbutton
F236	Left air distribution	F237	Activated charcoal filter button

Index	Specil Function Name	Index	Specil Function Name
F238	Dwell time	F239	Teaching-in of rotary potentiometer for center nozzle and side outlets
F23A	Reset of calibrations	F23B	Calibration of plunger travel
F23C	Calibration of component B24/12 (ABC lateral acceleration sensor)	F23D	Keyboard test
F23E	Reset offset value of signal 'Steering angle'.	F23F	Calibration of intake valves
F240	Calibration of separation valves	F241	Calibrate control unit 'N30/4 (Electronic Stability Program control unit)'.
F242	Teach-in of stop for boost pressure control flap	F243	Resetting of values for sensor rotor adaptation
F244	Definition	F245	Information on the adaptation limit values
F246	Display of all adaptation data	F247	Adaptation of the gearshifts
F248	NORMALIZED AT TOP AND BOTTOM	F249	Reprogram diesel particulate filter in control unit N3/9 (CDI control unit).
F24A	Regeneration of diesel particulate filter	F24B	Teach in component Y94 (Quantity control valve).
F24C	Resetting the lambda values	F24D	Rapid teach-in of zero quantity calibration values for calibration point 230 bar
F24E	Rapid teach-in of zero quantity calibration values for calibration point 600 bar	F24F	Control unit '' reads in the signal '' of component '' and makes the value available on the chassis CAN bus. (R12/32 (Driver thorax-pelvis sidebag squib))
F250	Control unit '' reads in the signal '' of component '' and makes the value available on the chassis CAN bus. (R12/33 (Front passenger thorax-pelvis sidebag squib))	F251	The climate control reacts more to setting ''.
F252	Teach-in process after replacement of component Y74 (Pressure control valve)	F253	UPPER NEUTRAL POSITION
F254	Control unit '' reads in the signal '' of component '' and makes the value available on the chassis CAN bus.	F255	F2f1/2 (Electrical fuse 2) (Button 'AIRSCARF' has a malfunction.)
F256	CVN(Calibration verification number)	F257	Road test
F258	Special functions	F259	Special function
F25A	Calibrate separation and intake valves in component 'A7/3 (Traction system hydraulic unit)'.	F25B	Teach in component 'B37/1 (Pedal angle sensor)'.
F25C	Resetting the operating hours counter of component 'M56 (Vacuum pump)'	F25D	The engine speed of the engine control system is not available on the CAN bus. At least two of the measured actual values are OK.
F25E	The engine speed of the engine control system is not available on the CAN bus. Overall procedure (overview):	F25F	Reset of operating hours counter
F260	Normalization of power window	F261	Calibration of control unit RBS
F262	Teach-in process for obstruction sensor of tilting/sliding roof	F263	Normalization of tilting/sliding roof
F264	Normalization of panoramic sliding roof	F265	Teach-in process for anti-pinch protection function of panoramic sliding sunroof
F266	Re-initialization of AdBlue range	F267	Intermediate position Rear-end door
F268	Denormalization and normalization of rear-end door closing.	F269	Transmitter key / Transponder key
F26A	Test of remote control key	F26B	Test of immobilizer
F26C	Learn radio code of a new transmitter key.	F26D	Correction programming of AC compressor
F26E	Erase crash memory.	F26F	Perform windscreen adaptation for rain sensor.
F270	Revocably deactivate key.	F271	Reactivate key.
F272	Irrevocably deactivate key.	F273	Learn replacement key.
F274	Reactivate tire pressure loss warning.	F275	Calibration of component 'A7/3 (Traction system hydraulic unit)'
F276	Calibration of component 'B24/15 (Yaw rate sensor for lateral and longitudinal acceleration)'	F277	Transfer of calibration values
F278	Calibration of component 'N148 (360?camera control unit)'	F279	Special measures
F27A	Teach in used diesel particulate filter.	F27B	Teach in new diesel particulate filter.
F27C	Perform voltage adjustment.	F27D	Reset of 'L20 (Electric machine rotor position sensor)'
F27E	The contact of the ground strap is faulty.	F27F	Tourist mode
F280	Unlock high-voltage component lock.	F281	Oil grade factor
F282	Synchronization of maintenance data		

# Coding Special\_Function

Index	Specil Function Name	Index	Specil Function Name
C001	Coding	C002	Read coding and change if necessary.
C003	Control unit replacement	C004	Display of coding data
C005	Chassis number	C006	Steering variant
C007	Seat belt buckle switch(FRONT)	C008	Seat belt reminder warning for front passenger
C009	Seat mat type 'Passenger'	C00A	Passenger airbag
C00B	Emergency tensioning retractor(FRONT)	C00C	Side airbags
C00D	Control unit is released.	C00E	Vehicle data
C00F	Modification year or model year	C010	All codes
C011	Central gateway functionality	C012	Vehicle speed signal threshold for automatic locking
C013	Turn signal confirmation for opening and closing via transmitter key	C014	Telematic service 'Remote door unlocking' (TELE AID)
C015	Fuel cell or electric drive	C016	Modification year or model year Interior CAN bus
C017	Modification year or model year Engine CAN bus	C018	Series and engine version
C019	National version	C01A	Driving lights
C01B	Transmission	C01C	Telecommunications
C01D	Climate control	C01E	Washer system
C01F	Headlamp cleaning system	C020	Parktronic
C021	Convenience systems	C022	Wipers
C023	Trailer	C024	Special vehicles
C025	Parameterization and windshield adaptation	C026	ATA basic function
C027	ATA alarm signal siren	C028	Basic setting(N10 (SAM control unit))
C029	Rear foglight(National version)	C02A	Light sensor
C02B	Programming of vehicle equipment	C02C	Special equipment
C02D	Current menu setting	C02E	Customer-specific settings
C02F	Engine type	C030	Specified configuration of MOST components
C031	Apply actual configuration of the MOST components as the specified configuration.	C032	Radio parameters
C033	Additional settings	C034	Fan setting
C035	Station memory	C036	Restart of optical ring
C037	Installation state	C038	Operating principle Fan
C039	Navigation	C03A	Navigation parameters
C03B	TV parameters(Shut off criteria)	C03C	TV/DVD deactivation(Valid for Hongkong)
C03D	Rear screen	C03E	DVD country code
C03F	Fan(EXTERNAL)	C040	Fan(INTERNAL)
C041	Read coding and change if necessary. (Only for special protection vehicles)	C042	Read coding and change if necessary. (Customer settings)
C043	Power window parameters	C044	Fault monitoring at output E6/5 (Left exterior mirror turn signal lamp):Deactivating
C045	Fault monitoring at output E6/6 (Right exterior mirror turn signal lamp):Deactivating	C046	This setting should only be changed if requested by customer.
C047	Workshop coding	C048	Variant coding according to factory data
C049	SCN(Software Calibration Number)	C04A	Type approval number
C04B	CVN(Calibration verification number)	C04C	Read coding and transfer to the new control unit.
C04D	License plate bracket	C04E	Warning signal-Configuration
C04F	Trailer coupling	C050	ROELight Configuration



Index	Specil Function Name	Index	Specil Function Name
C051	Information on redocumentation of equipment codes for SCN coding	C052	Information on coding
C053	Language settings	C054	Navigation data
C055	AUX input	C056	Video AUX jack
C057	Display coded vehicle data.	C058	Disposal detonation
C059	Vehicle equipment	C05A	Settings
C05B	Coding for weight-optimized running boards	C05C	Side airbag deactivation [USA]
C05D	Special protection	C05E	Seat fittings
C05F	Seat belt buckles	C060	Emergency tensioning retractor
C061	Check parameterization.	C062	Control unit LOCK
C063	VCD_Implizite_Variantenkodierung	C064	Clean inside and outside of windshield area in front of camera.
C065	Diagnosis to plant specifications:Read coding and change if necessary.	C066	Zero position adjustment
C067	Diagnosis to plant specifications	C068	Read coding.
C069	SCN( Software Calibration Number) CVN( Calibration verification number)	C06A	Reset parameter Variant coding.
C06B	Learning processes	C06C	Control unit UNLOCK
C06D	Steering version	C06E	Internal resistance of battery at engine start
C06F	Menu item '' is found in main menu '' (menu item '').	C070	Vehicle model
C071	Side airbags[FRONT PASSENGER]	C072	Set status CAN bus
C073	Headlamp range adjustment	C074	Automatic driving lights on
C075	COMAND or AUDIO	C076	Wiper system
C077	Rear window screen	C078	Distronic
C079	ATA interior motion sensor	C07A	ATA towing sensor
C07B	Trailer recognition	C07C	Trailer lighting
C07D	Special vehicle multifunction control module (SVMCM)	C07E	Lane recognition
C07F	Sound system	C080	Key assignment or key track assignment to a memory block number
C081	Automatic closing of front windows	C082	Automatic closing of rear windows
C083	Standard setting: Climate control	C084	Pollutant-dependent switchover to recirculated air
C085	Temperature correction (only valid for temperature increase)	C086	Manual recirculated air control
C087	Sun sensor	C088	Temperature correction
C089	Seat adjustment	C08A	Windscreen heater
C08B	Trailer recognition/Trailer lighting	C08C	Keyless Go
C08D	Version: Interior CAN bus	C08E	Setting of basic ventilation
C08F	Interior rearview mirror	C090	Sliding/tilting roof
C091	Panoramic sliding roof	C092	Roller sun blind
C093	Closing of tilting/sliding roof when it rains	C094	Kneebags
C095	Buckle emergency tensioning retractor	C096	Automatic child seat recognition(ACSR [AKSE])/Seat occupied recognition
C097	Rear seat belts	C098	Window airbags
C099	Test of seat mat components	C09A	National variant coding
C09B	Codings specific for instrument cluster	C09C	Configuration of menu items in multifunction display
C09D	Fuel tank version	C09E	Factory settings
C09F	Configuration for key 1	COA0	Configuration for key 2
COA1	Configuration for key 3	COA2	Trip computer settings
COA3	Coding according to plant data:Read coding and change if necessary.	COA4	Vehicle version

Index	Specil Function Name	Index	Specil Function Name
COA5	Rear warning elements	COA6	PTS switch
COA7	Zero position adjustment of axle or level sensors	COA8	PAL/NTSC
COA9	'Driver' automatic seat adjustment with memory	COAA	Stationary heater
COAB	Convenience closing	COAC	Reset coding.
COAD	Engine version	COAE	Equipment
COAF	Footwell lighting	COB0	Oil cooler relay
COB1	Gear display	COB2	Curve illumination
COB3	Headlamp cleaning system	COB4	Turning lamps
COB5	'Refrigerant' pressure sensor	COB6	Status of terminal via CAN bus
COB7	Signal Terminal 61	COB8	Coding of model series
COB9	Coding Modification year	COBA	Model designation(Only with code 336)
COBB	Radiator blind	COBC	Side lamp Version
COBD	Front seat heater	COBE	Battery sensor
COBF	Battery sensor LIN bus	COC0	Rear head restraint lowering
COC1	Deactivate ATA function.	COC2	National version of ATA function
COC3	Volume control Warning buzzer(USA)	COC4	Spotlight Trunk lid
COC5	Diesel particulate filter	COC6	Equipment version
COC7	Flashing stop lamp	COC8	Variant coding
COC9	Automatic interior mirror dimming	COCA	Adaptation:Windshield Green glass-Only for customer complaints concerning the lights' switch-on thresholds!
COCB	Tilting/sliding roof memory feature	COCC	Automatic closing function
COCD	Anti-throbbing position	COCE	PRE-SAFE
COCF	Key-dependent storage	COD0	Oil level indicator
COD1	Standard variant coding	COD2	Setting of trip computer constants
COD3	Brake data	COD4	Configuration of oil grade selection
COD5	Service work sequence	COD6	Program vehicle parameters.
COD7	Menu item 'Read coding and transfer to the new control unit.' is found in main menu 'Rear-end door closing control module' (menu item 'Initial startup').	COD8	E1/1e2 (Left low beam)
COD9	Delete coding.	CODA	NECK-PRO head restraint
CODB	Set control module to base function.	CODC	Read the coding of control module .
CODD	Higher-priority alarm options	CODE	Silent alarm
CODF	Full alarm	COE0	Radio help call
COE1	Odometer	COE2	Additional equipment
COE3	Options	COE4	Advanced options
COE5	Run-on times	COE6	Undervoltage value
COE7	Interior lamp-Actuation	COE8	Interior emergency illumination
COE9	Convenience function Rear side blind Rear window screen	COEA	Convenience function Sliding/tilting roof
COEB	Close-via-tilt function	COEC	Anti-pinch protection
COED	ATA Volume control: Warning buzzer(USA) (The coding is set according to the customer's request.)	COEE	ATA National variant coding

Index	Specil Function Name	Index	Specil Function Name
COEF	ATA Volume control: Warning buzzer(USA)	COF0	Cigarette lighter
COF1	Rear foglight	COF2	Closing the panoramic sliding sunroof during rain
COF3	Automatic opening and closing of panoramic sliding sunroof	COF4	Actual configuration of MOST and telematics CAN bus control units
COF5	Specified configuration of MOST and telematics CAN bus control units	COF6	Menu settings
COF7	Specified configuration of Telematics CAN bus control units	COF8	TV DVD Shut off criteria
COF9	Activate or deactivate navigation functionality.	COFA	Menu settings(Only development data)
COFB	Adopt the actual configuration of the MOST and telematics CAN bus control units as the specified configuration.	COFC	Automatically adjust vehicle-specific and special equipment-specific codings.
COFD	Display of all COMAND codings	COFE	SPLITVIEW(USA Canada)
COFF	Activation Video AUX jack(Only for special protection vehicles)	C100	Mercedes-Benz Contact
C101	Service call(Development data)	C102	Workshop coding1
C103	Engine model coding	C104	CO2 setting of combustion air blower
C105	Vehicle power supply emergency operation	C106	Undervoltage shutoff threshold
C107	Flashing of LED in switch N72/1s30 (STH/HB [ZUH]/residual heat button) due to undervoltage	C108	Settings: Ventilation time, Settings: Heating time
C109	Auxiliary heating	C10A	Special vehicle special protection(B6/B7):Read coding and change if necessary.
C10B	Special vehicle special protection(B4):Read coding and change if necessary.	C10C	AIRmatic/ABC active body control
C10D	Rear air conditioning	C10E	Stationary heater or Telestart
C10F	Cellular telephone	C110	Engine cooling
C111	Automatic dimming mirror	C112	Power locking
C113	ATA interior motion / towing sensor	C114	Voice control system
C115	Multifunction steering wheel	C116	Tire pressure monitor
C117	CGW N93 (Central gateway control unit)	C118	Adaptation of electronic ignition switch to vehicle model/Turn signal confirmation for opening and closing via transmitter key
C119	Adaptation of electronic ignition switch to vehicle model	C11A	Suction fan control
C11B	Initializing:Steering column module	C11C	Alarm siren:Reset coding.
C11D	Rain sensor	C11E	Steering column module
C11F	Activated/Deactivated	C120	Signal
C121	Positions	C122	Temperature
C123	Cycles	C124	Rear screen
C125	Electric rear window curtain	C126	Miscellaneous
C127	Setting of limit position of excess force limiter	C128	Coding of the close-via-tilt function
C129	Coding of sliding/tilting roof function of 'automatic operation'	C12A	Factory settings Trunk lid remote closing
C12B	Trunk lid remote release	C12C	Trunk lid remote closing
C12D	Trunk interior button	C12E	Head restraint adjustment
C12F	Multicontour backrests	C130	Central locking
C131	Childproof locks	C132	Emergency opening
C133	Presafe	C134	Adaptation of the light sensor amplification factor
C135	Display coding	C136	Key-dependent configurations
C137	National variant coding for vehicles without special protection'GUARD'	C138	National variant coding for vehicles with special protection'GUARD'

Index	Specil Function Name	Index	Specil Function Name
C139	RDK tire presssure control	C13A	Bus system-Telematic
C13B	ASSYST settings	C13C	Duration of actuation:Mirror housing adjustment
C13D	Readjust adjustment parameters.	C13E	Activate or deactivate easy entry/exit.
C13F	MAXCOOL	C140	SCN( Software Calibration Number)
C141	Control unit adaptations	C142	Pyrofuse
C143	Fuel tank characteristic curve	C144	Setting main odometer forward and back
C145	Easy Entry	C146	Installation of control unit in vehicles prior to model refinement 2008
C147	Windshield adaptation	C148	Speed-sensitive power steering
C149	ESP-Trailer stabilization	C14A	Check coding of national version.
C14B	Relocking/Vehicle speed threshold for automatic locking	C14C	Parameterization
C14D	Read coding and change if necessary. (Sliding/tilting roof)	C14E	Read coding and change if necessary. (Panoramic sliding roof)
C14F	Daytime running lamps Japan variant	C150	Rear power windows
C151	Basic setting	C152	Standard Drive/ Full hybrid drive
C153	Front windscreen wipers/ Washer nozzle heater/ Seat heater/ Power window PRE-SAFE/ Foglights/ Turning lamps	C154	Modification year
C155	Equipment Special equipment code Acoustic lock feedback	C156	Easy Entry/ Rear seat belt buckle switch( Code U01)
C157	Rear-end door lock	C158	EDW anti-theft alarm
C159	Light	C15A	Trailer coupling/ Spare wheel carrier
C15B	Model series	C15C	LED' Trailer lighting'
C15D	Relays Seat adjustment	C15E	Ambiance lighting( Code 877)
C15F	Control module reset	C160	Internal ASSYST PLUS data
C161	Volume	C162	Pushbutton
C163	Assignment of control unit to model series	C164	Special equipment 'Spare wheel carrier'
C165	All coding settings	C166	Workshop coding2
C167	Coding of control module A6 (Stationary heater)	C168	Flashing of LED in switch due to undervoltageN72/1s30 (STH switch)
C169	Settings: Ventilation time, Settings: Heating time		